

Annexure I				
S.No.	SPN	MANUFACTURER	PART NO.	DESCRIPTION
1	1.01.0001.1.01.5	CU	8265	WASHER,PLAIN
2	1.01.0002.1.01.6	CU	43828	CLAMP,HOSE
3	1.01.0003.1.01.7	CU	44680	LEVER,THROTTLE
4	1.01.0004.1.01.8	CU	63495	HOSE,PLAIN
5	1.01.0005.1.01.9	CU	65434	SPACER,MOUNTING
6	1.01.0006.1.01.1	CU	68139	ELBOW, MALE ADAPTER
7	1.01.0007.1.01.2	CU	68174	KEY,SQUARE
8	1.01.0008.1.01.3	CU	68645	ELBOW,MALE ADAPTER
9	1.01.0009.1.01.4	CU	69558	DOWEL,PIN
10	1.01.0010.1.01.5	CU	69901	PLUG,PIPE
11	1.01.0011.1.01.6	CU	69936	NUT,HEAVY HEXAGON
12	1.01.0012.1.01.7	CU	70183	RING,RETAINING
13	1.01.0013.1.01.8	CU	70437	BUSHING
14	1.01.0014.1.01.9	CU	70550	DOWEL,PIN
15	1.01.0015.1.01.1	CU	70690	DRIVER,GOVERNOR PLUNGER
16	1.01.0016.1.01.2	CU	70699	RING,RETAINING
17	1.01.0017.1.01.3	CU	70700	SPRING,COMPRESSION
18	1.01.0018.1.01.4	CU	70713	RETAINER,SPRING
19	1.01.0019.1.01.5	CU	FP3904166	SLEEVE
20	1.01.0020.1.01.6	CU	70717	SHIM,FUEL PUMP GOVERNOR
21	1.01.0021.1.01.7	CU	70720	GEAR,TACHOMETER DRIVE
22	1.01.0022.1.01.8	CU	70732	GASKET,TACHOMETER
23	1.01.0023.1.01.9	CU	70811	SHIM
24	1.01.0024.1.01.1	CU	70820	PLUNGER,GOVERNOR SPRING
25	1.01.0025.1.01.2	CU	70897	NUT,LOCK
26	1.01.0026.1.01.3	CU	100192	SHAFT,FUEL PUMP DRIVE
27	1.01.0027.1.01.4	CU	100215	SHAFT,FUEL PUMP DRIVE
28	1.01.0028.1.01.5	CU	100765	COVER,FUEL CONTROL
29	1.01.0029.1.01.6	CU	101918	HUB,JAW COUPLING
30	1.01.0030.1.01.7	CU	102030	SEAL,O RING
31	1.01.0031.1.01.8	CU	104087	SHAFT,TACHOMETER DRIVE
32	1.01.0032.1.01.9	CU	106339	SEAL,OIL
33	1.01.0033.1.01.1	CU	107261	WEIGHT,GOVERNOR
34	1.01.0034.1.01.2	CU	107981	CAP,FILLER
35	1.01.0035.1.01.3	CU	108186	LOCKWIRE,TPT ROLLER PIN
36	1.01.0036.1.01.4	CU	108187	LOCKWIRE,TPT ROLLER PIN
37	1.01.0037.1.01.5	CU	109319	LOCKPLATE
38	1.01.0038.1.01.6	CU	109333	PLUNGER,PRS REGULATOR
39	1.01.0039.1.01.7	CU	109915	SCREW,SLOTTED SET
40	1.01.0040.1.01.8	CU	115508	NUT,LOCK
41	1.01.0041.1.01.9	CU	116391	BUSHING
42	1.01.0042.1.01.1	CU	116935	CONNECTOR,MALE
43	1.01.0043.1.01.2	CU	116936	ELBOW,MALE ADAPTER
44	1.01.0044.1.01.3	CU	118939	PIN,ROLL
45	1.01.0045.1.01.4	CU	119984	CONNECTOR,MALE
46	1.01.0046.1.01.5	CU	120437	ELBOW, MALE ADAPTER
47	1.01.0047.1.01.6	CU	121229	ELBOW,MALE ADAPTER
48	1.01.0048.1.01.7	CU	123078	GASKET,WATER PUMP
49	1.01.0049.1.01.8	CU	123128	GEAR,ACCESSORY DRIVE
50	1.01.0050.1.01.9	CU	123558	GUIDE,VALVE CROSSHEAD
51	1.01.0051.1.01.1	CU	125485	GEAR,ACCESSORY DRIVE
52	1.01.0052.1.01.2	CU	125741	CLAMP,T BOLT
53	1.01.0053.1.01.3	CU	126333	SEAL,O RING
54	1.01.0054.1.01.4	CU	127554	COLLET,VALVE
55	1.01.0055.1.01.5	CU	127930	INSERT,VALVE
56	1.01.0056.1.01.6	CU	129859	ELBOW, MALE UNION
57	1.01.0057.1.01.7	CU	130083	BEARING,THRUST
58	1.01.0058.1.01.8	CU	130394	CONNECTION,WATER BYPASS
59	1.01.0059.1.01.9	CU	132770	BUSHING
60	1.01.0060.1.01.1	CU	134809	BELT,V
61	1.01.0061.1.01.2	CU	135675	THERMOSTAT
62	1.01.0062.1.01.3	CU	135957	VALVE,INTAKE
63	1.01.0063.1.01.4	CU	140314	CLAMP,T BOLT
64	1.01.0064.1.01.5	CU	140315	CLAMP,T BOLT
65	1.01.0065.1.01.6	CU	140330	BUSHING
66	1.01.0066.1.01.7	CU	140332	CLAMP,T BOLT
67	1.01.0067.1.01.8	CU	140558	SHAFT,ACCESSORY DRIVE
68	1.01.0068.1.01.9	CU	145623	SEAL,O RING
69	1.01.0069.1.01.1	CU	145701	VALVE,EXHAUST
70	1.01.0070.1.01.2	CU	146437	WEIGHT,GOVERNOR
71	1.01.0071.1.01.3	CU	146483	SCREEN,FILTER
72	1.01.0072.1.01.4	CU	146856	BOLT,CONNECTING ROD
73	1.01.0073.1.01.5	CU	147100	CONNECTION,FUEL CROSSOVER
74	1.01.0074.1.01.6	CU	147389	SCREW,CROSSHEAD ADJUSTING

75	1.01.0075.1.01.7	CU	147610	BUSHING
76	1.01.0076.1.01.8	CU	149503	BARREL,GOVERNOR
77	1.01.0077.1.01.9	CU	153526	SEAT,BYPASS VALVE
78	1.01.0078.1.01.1	CU	154087	SEAL,RECTANGULAR RING
79	1.01.0079.1.01.2	CU	154088	SEAL,RECTANGULAR RING
80	1.01.0080.1.01.3	CU	163022	SHIELD,HEAT
81	1.01.0081.1.01.4	CU	165006	SCREW,HEXAGON HEAD CAP
82	1.01.0082.1.01.5	CU	166009	SPRING,COMPRESSION
83	1.01.0083.1.01.6	CU	167157	BALL,CHECK
84	1.01.0084.1.01.7	CU	168306	SCREW,SLOTTED SET
85	1.01.0085.1.01.8	CU	170296	GUIDE,VALVE SPRING
86	1.01.0086.1.01.9	CU	172034	GUIDE,VALVE SPRING
87	1.01.0087.1.01.1	CU	173086	GASKET,INJECTOR
88	1.01.0088.1.01.2	CU	173176	SPRING,COMPRESSION
89	1.01.0089.1.01.3	CU	173718	LEVER,THROTTLE
90	1.01.0090.1.01.4	CU	174299	RETAINER,SCREEN
91	1.01.0091.1.01.5	CU	175755	RING,RETAINING
92	1.01.0092.1.01.6	CU	175830	PLUG,EXPANSION
93	1.01.0093.1.01.7	CU	175864	SHAFT,FUEL PUMP
94	1.01.0094.1.01.8	CU	177417	SHAFT,LUB OIL PUMP DRIVE
95	1.01.0095.1.01.9	CU	177419	SHAFT,LUB OIL PUMP
96	1.01.0096.1.01.1	CU	178456	BELT,V
97	1.01.0097.1.01.2	CU	180753	TUBE,WATER TRANSFER
98	1.01.0098.1.01.3	CU	180862	SLINGER,OIL
99	1.01.0099.1.01.4	CU	185138	RETAINER,INJECTOR CUP
100	1.01.0100.1.01.5	CU	185139	ADAPTER,INJECTOR
101	1.01.0101.1.01.6	CU	186780	SEAL,THERMOSTAT
102	1.01.0102.1.01.7	CU	186917	CLAMP,V BAND
103	1.01.0103.1.01.8	CU	187368	ADAPTER,PLAIN
104	1.01.0104.1.01.9	CU	187420	BUSH
105	1.01.0105.1.01.1	CU	188040	BEARING,THRUST
106	1.01.0106.1.01.2	CU	193552	DAMPER,VIBRATION
107	1.01.0107.1.01.3	CU	193736	SEAL,O RING
108	1.01.0108.1.01.4	CU	195952	SEAL,O RING
109	1.01.0109.1.01.5	CU	198843	BRACE,AIR COMPRESSOR
110	1.01.0110.1.01.6	CU	199510	BUSHING
111	1.01.0111.1.01.7	CU	199843	PLUNGER,PRS REGULATOR
112	1.01.0112.1.01.8	CU	200307	SEAL,OIL
113	1.01.0113.1.01.9	CU	200354	INSERT,VALVE
114	1.01.0114.1.01.1	CU	200600	BEARING,CONNECTING ROD
115	1.01.0115.1.01.2	CU	200601	BEARING,CONNECTING ROD
116	1.01.0116.1.01.3	CU	200602	BEARING,CONNECTING ROD
117	1.01.0117.1.01.4	CU	200819	ORIFICE,FUL FLOW LIMITING
118	1.01.0118.1.01.5	CU	202897	DIAPHRAGM,FUL PUMP DAMPER
119	1.01.0119.1.01.6	CU	203131	NUT,HEAVY HEXAGON
120	1.01.0120.1.01.7	CU	203426	PIN,ROLL
121	1.01.0121.1.01.8	CU	203850	UNION,MALE
122	1.01.0122.1.01.9	CU	204193	SHAFT,LUB OIL PUMP DRIVE
123	1.01.0123.1.01.1	CU	205052	SHAFT,IDLER
124	1.01.0124.1.01.2	CU	205065	SHAFT,LUB OIL PUMP
125	1.01.0125.1.01.3	CU	205080	PLUNGER,PRS REGULATOR
126	1.01.0126.1.01.4	CU	205091	COLLET,VALVE
127	1.01.0127.1.01.5	CU	205112	BEARING,THRUST
128	1.01.0128.1.01.6	CU	205126	WASHER,PLAIN
129	1.01.0129.1.01.7	CU	205156	BUSHING
130	1.01.0130.1.01.8	CU	205227	PLUG,EXPANSION
131	1.01.0131.1.01.9	CU	205243	IMPELLER,WATER PUMP
132	1.01.0132.1.01.1	CU	205439	RING,RETAINING
133	1.01.0133.1.01.2	CU	205464	SPRING,COMPRESSION
134	1.01.0134.1.01.3	CU	205841	BEARING,CONNECTING ROD
135	1.01.0135.1.01.4	CU	206224	PLUG,EXPANSION
136	1.01.0136.1.01.5	CU	206948	SEAL,OIL
137	1.01.0137.1.01.6	CU	207226	BUSHING
138	1.01.0138.1.01.7	CU	207233	TUBE,WATER TRANSFER
139	1.01.0139.1.01.8	CU	207251	GEAR,WATER PUMP
140	1.01.0140.1.01.9	CU	207344	BUSHING
141	1.01.0141.1.01.1	CU	207378	TUBE,WATER TRANSFER
142	1.01.0142.1.01.2	CU	209806	SHAFT,WATER PUMP
143	1.01.0143.1.01.3	CU	209971	TUBE,COMPRESSOR AIR INLET
144	1.01.0144.1.01.4	CU	210570	TUBE,CPR WATER OUTLET
145	1.01.0145.1.01.5	CU	211315	SEAL,O RING
146	1.01.0146.1.01.6	CU	211633	SHAFT,GOVERNOR
147	1.01.0147.1.01.7	CU	211636	GEAR,GOVERNOR
148	1.01.0148.1.01.8	CU	211662	BEARING,THRUST
149	1.01.0149.1.01.9	CU	211999	SPRING,VALVE
150	1.01.0150.1.01.1	CU	212601	SHAFT,FUEL PUMP DRIVE
151	1.01.0151.1.01.2	CU	212610	GEAR,TACHOMETER DRIVE

152	1.01.0152.1.01.3	CU	213559	SOCKET,CAM FOLLOWER
153	1.01.0153.1.01.4	CU	214836	CORE,AFTERCOOLER
154	1.01.0154.1.01.5	CU	214951	BEARING,CONNECTING ROD
155	1.01.0155.1.01.6	CU	216484	DIPSTICK, BLANK
156	1.01.0156.1.01.7	CU	217302	HOSE,PLAIN
157	1.01.0157.1.01.8	CU	217638	BELT,V RIBBED
158	1.01.0158.1.01.9	CU	218153	BUSHING
159	1.01.0159.1.01.1	CU	250843	RING,RETAINING
160	1.01.0160.1.01.2	CU	251152	SPRING,COMPRESSION
161	1.01.0161.1.01.3	CU	255180	BREATHER,CRANKCASE
162	1.01.0162.1.01.4	CU	500109	GAUGE,PRESSURE
163	1.01.0163.1.01.5	CU	500184	CABLE,FLEXIBLE DRIVE
164	1.01.0164.1.01.6	CU	501151	HOURLMETER
165	1.01.0165.1.01.7	CU	501253	PULLEY,ALTERNATOR
166	1.01.0166.1.01.8	CU	502041	DIPSTICK
167	1.01.0167.1.01.9	CU	504760	STUD
168	1.01.0168.1.01.1	CU	504867	BELT,V
169	1.01.0169.1.01.2	CU	2865287	ASSEMBLY,OIL PAN
170	1.01.0170.1.01.3	CU	2865519	SWITCH,MAGNETIC
171	1.01.0171.1.01.4	CU	2880039	GASKET EXH OUT CONNECTION
172	1.01.0172.1.01.5	CU	2885050	GASKET,FUEL PUMP
173	1.01.0173.1.01.6	CU	2897691	SWITCH,PRESSURE
174	1.01.0174.1.01.7	CU	3000060	TUBE,CPR WATER INLET
175	1.01.0175.1.01.8	CU	3000174	HUB,SPLINE COUPLING
176	1.01.0176.1.01.9	CU	3001405	LOCKPLATE
177	1.01.0177.1.01.1	CU	3002834	BUSHING
178	1.01.0178.1.01.2	CU	3002956	TUBE,WATER TRANSFER
179	1.01.0179.1.01.3	CU	3005132	DRIVE, ACCESSORY
180	1.01.0180.1.01.4	CU	3005407	MANIFOLD,AIR INTAKE
181	1.01.0181.1.01.5	CU	3005752	WEIGHT CARRIER
182	1.01.0182.1.01.6	CU	3006696	CLAMP,INJECTOR
183	1.01.0183.1.01.7	CU	3006699	ROLLER,TAPPET
184	1.01.0184.1.01.8	CU	3006745	RING,RETAINING
185	1.01.0185.1.01.9	CU	3008062	HOUSING,FLYWHEEL
186	1.01.0186.1.01.1	CU	3009213	LOCKPLATE
187	1.01.0187.1.01.2	CU	3010146	SPRING,COMPRESSION
188	1.01.0188.1.01.3	CU	3010510	SEAL,O RING
189	1.01.0189.1.01.4	CU	3010615	COOLER,OIL
190	1.01.0190.1.01.5	CU	3011951	BUSHING
191	1.01.0191.1.01.6	CU	3012531	SHAFT,IDLER
192	1.01.0192.1.01.7	CU	3012532	SHAFT,LUB OIL PUMP DRIVE
193	1.01.0193.1.01.8	CU	3013266	SCREW,CONNECTING ROD CAP
194	1.01.0194.1.01.9	CU	3013330	PIN,CAM FOLLOWER ROLLER
195	1.01.0195.1.01.1	CU	3013331	PIN,CAM FOLLOWER ROLLER
196	1.01.0196.1.01.2	CU	3014092	COVER,GEAR
197	1.01.0197.1.01.3	CU	3014778	GASKET,LUB OIL PUMP COVER
198	1.01.0198.1.01.4	CU	3015527	PULLEY,WATER PUMP
199	1.01.0199.1.01.5	CU	3015585	SCREW,TWELVE POINT CAP
200	1.01.0200.1.01.6	CU	3015665	SHAFT,TACHOMETER DRIVE
201	1.01.0201.1.01.7	CU	3016142	HOSE,PLAIN
202	1.01.0202.1.01.8	CU	3016477	ELBOW,PLAIN UNION
203	1.01.0203.1.01.9	CU	3016826	ROLLER,CAM FOLLOWER
204	1.01.0204.1.01.1	CU	3017511	ROLLER,TAPPET
205	1.01.0205.1.01.2	CU	3017759	INSERT,VALVE
206	1.01.0206.1.01.3	CU	3017961	ROD,PUSH
207	1.01.0207.1.01.4	CU	3018889	CONNECTOR,FEMALE
208	1.01.0208.1.01.5	CU	3023079	CORE COOLER
209	1.01.0209.1.01.6	CU	3023891	ROD,ENGINE CONNECTING
210	1.01.0210.1.01.7	CU	3025100	WASHER,PLAIN
211	1.01.0211.1.01.8	CU	3025887	SHAFT,WATER PUMP
212	1.01.0212.1.01.9	CU	3026556	BEARING,THRUST
213	1.01.0213.1.01.1	CU	3026557	BEARING,THRUST
214	1.01.0214.1.01.2	CU	3026832	HOSE,FLEXIBLE
215	1.01.0215.1.01.3	CU	3028075	BUSHING
216	1.01.0216.1.01.4	CU	3028269	BUSHING
217	1.01.0217.1.01.5	CU	3028291	SEAL,O RING
218	1.01.0218.1.01.6	CU	3028293	CROSSHEAD,VALVE
219	1.01.0219.1.01.7	CU	3028946	DISC,VALVE
220	1.01.0220.1.01.8	CU	3030514	HOSE,ELBOW
221	1.01.0221.1.01.9	CU	3030772	HOSE,ELBOW
222	1.01.0222.1.01.1	CU	3030774	ELBOW HOSE
223	1.01.0223.1.01.2	CU	3030790	HOSE,HUMP
224	1.01.0224.1.01.3	CU	3033411	TEE,MALE UNION
225	1.01.0225.1.01.4	CU	3033740	VALVE,CHECK
226	1.01.0226.1.01.5	CU	3033742	PLUG,THREADED
227	1.01.0227.1.01.6	CU	3034222	PUMP,GEAR FUEL
228	1.01.0228.1.01.7	CU	3034243	PUMP,GEAR FUEL

229	1.01.0229.1.01.8	CU	3035110	VALVE EXHAUST
230	1.01.0230.1.01.9	CU	3035331	SEAL,GROMMET
231	1.01.0231.1.01.1	CU	3036933	ROLLER,CAM FOLLOWER
232	1.01.0232.1.01.2	CU	3036966	RETAINER,VALVE SPRING
233	1.01.0233.1.01.3	CU	3037732	TUBE,FUEL SUPPLY
234	1.01.0234.1.01.4	CU	3037733	TUBE,FUEL SUPPLY
235	1.01.0235.1.01.5	CU	3038218	GUIDE & SPRING
236	1.01.0236.1.01.6	CU	3039532	TEE,MALE ADAPTER
237	1.01.0237.1.01.7	CU	3040377	BELT,V
238	1.01.0238.1.01.8	CU	3042827	SHAFT,WATER PUMP
239	1.01.0239.1.01.9	CU	3043650	INSERT,PISTON
240	1.01.0240.1.01.1	CU	3043909	BUSHING
241	1.01.0241.1.01.2	CU	3045047	PLUG,INJECTOR ORIFICE
242	1.01.0242.1.01.3	CU	3045986	SEAL,O RING
243	1.01.0243.1.01.4	CU	3046200	SPIDER,JAW COUPLING
244	1.01.0244.1.01.5	CU	3046418	ROD,PUSH
245	1.01.0245.1.01.6	CU	3046419	ROD,PUSH
246	1.01.0246.1.01.7	CU	3046431	ROD,PUSH
247	1.01.0247.1.01.8	CU	3046432	ROD,PUSH
248	1.01.0248.1.01.9	CU	3048912	TUBE,FUEL DRAIN
249	1.01.0249.1.01.1	CU	3048916	TUBE,FUEL DRAIN
250	1.01.0250.1.01.2	CU	3050163	CONNECTION,WATER BYPASS
251	1.01.0251.1.01.3	CU	3052218	RETAINER,INJECTOR SPRING
252	1.01.0252.1.01.4	CU	3054258	INJECTOR
253	1.01.0253.1.01.5	CU	3054999	SCREEN,FILTER
254	1.01.0254.1.01.6	CU	3056356	HARNESS,WIRING
255	1.01.0255.1.01.7	CU	3057139	ROD,PUSH
256	1.01.0256.1.01.8	CU	3058653	SEAL,O RING
257	1.01.0257.1.01.9	CU	3062415	SPRING,COMPRESSION
258	1.01.0258.1.01.1	CU	3072817	GASKET,FUEL PUMP
259	1.01.0259.1.01.2	CU	3081040	DAMPER,VIBRATION
260	1.01.0260.1.01.3	CU	3081053	HOSE,PLAIN
261	1.01.0261.1.01.4	CU	3081212	SPRING,VALVE
262	1.01.0262.1.01.5	CU	3081248	ROLLER,CAM FOLLOWER
263	1.01.0263.1.01.6	CU	3081283	BLOCK,CYLINDER
264	1.01.0264.1.01.7	CU	3086191	INSERT,VALVE
265	1.01.0265.1.01.8	CU	3086192	INSERT,VALVE
266	1.01.0266.1.01.9	CU	3086436	VALVE,EXHAUST
267	1.01.0267.1.01.1	CU	3096077	GASKET,FUEL PUMP
268	1.01.0268.1.01.2	CU	3166554	ELEMENT,LUB OIL FILTER
269	1.01.0269.1.01.3	CU	3167063	CONTROL,GOVERNOR
270	1.01.0270.1.01.4	CU	3167224	INHIBITOR,CORROSION
271	1.01.0271.1.01.5	CU	3167836	HOSE,FLEXIBLE
272	1.01.0272.1.01.6	CU	3201311	GUIDE,VALVE STEM
273	1.01.0273.1.01.7	CU	3225253	TUBE,FUEL BYPASS
274	1.01.0274.1.01.8	CU	3225660	CAP,DUST
275	1.01.0275.1.01.9	CU	3227327	TUBE,LUB OIL TRANSFER
276	1.01.0276.1.01.1	CU	3229083	CONNECTION,FUEL BLOCK
277	1.01.0277.1.01.2	CU	3229284	BRACKET FAN
278	1.01.0278.1.01.3	CU	3230038	MOTOR,HYDRAULIC
279	1.01.0279.1.01.4	CU	3231404	PICKUP,MAGNETIC
280	1.01.0280.1.01.5	CU	3231787	SEPARATOR,FUEL WATER
281	1.01.0281.1.01.6	CU	3232013	TUBE,TUR OIL DRAIN
282	1.01.0282.1.01.7	CU	3232556	BUSHING
283	1.01.0283.1.01.8	CU	3233140	TUBE,OIL GAUGE
284	1.01.0284.1.01.9	CU	3234408	PLUG,EXPANSION
285	1.01.0285.1.01.1	CU	3235591	NUT,HEXAGON FLANGE
286	1.01.0286.1.01.2	CU	3235704	HOSE,PLAIN
287	1.01.0287.1.01.3	CU	3236199	TUBE,FUEL TRANSFER
288	1.01.0288.1.01.4	CU	3236201	TUBE,FUEL SUPPLY
289	1.01.0289.1.01.5	CU	3236202	TUBE,FUEL TRANSFER
290	1.01.0290.1.01.6	CU	3236450	GEAR,LUBRICATING OIL PUMP
291	1.01.0291.1.01.7	CU	3236452	GEAR,LUB OIL PUMPING
292	1.01.0292.1.01.8	CU	3236454	GEAR,LUBRICATING OIL PUMP
293	1.01.0293.1.01.9	CU	3240551	VALVE,SOLENOID
294	1.01.0294.1.01.1	CU	3240573	VALVE,SOLENOID
295	1.01.0295.1.01.2	CU	3241306	NOZZLE,PISTON COOLING
296	1.01.0296.1.01.3	CU	3241328	LINER,CYLINDER
297	1.01.0297.1.01.4	CU	3241630	HEAD,CYLINDER
298	1.01.0298.1.01.5	CU	3241793	PUMP,FUEL
299	1.01.0299.1.01.6	CU	3245718	RING SET PISTON (SERVICE)
300	1.01.0300.1.01.7	CU	3264349	PUMP,WATER AND IDLER
301	1.01.0301.1.01.8	CU	3310169	ELEMENT,LUB OIL FILTER
302	1.01.0302.1.01.9	CU	3392696	COVER,HAND HOLE
303	1.01.0303.1.01.1	CU	3406702	SLEEVE,INJECTOR
304	1.01.0304.1.01.2	CU	3414063	CONNECTION,OIL SUCTION
305	1.01.0305.1.01.3	CU	3521033	SHAFT & WHEEL

306	1.01.0306.1.01.4	CU	3521918	IMPELLER,TUR COMPRESSOR
307	1.01.0307.1.01.5	CU	3545647	KIT,TURBO REPAIR HC5A
308	1.01.0308.1.01.6	CU	3609826	SEAL,WATER PUMP
309	1.01.0309.1.01.7	CU	3629006	SPRING,VALVE
310	1.01.0310.1.01.8	CU	3634007	SEAL,WATER PUMP
311	1.01.0311.1.01.9	CU	3803853	TURBOCHARGER
312	1.01.0312.1.01.1	CU	3804414	KIT,ENGINE PISTON
313	1.01.0313.1.01.2	CU	3818271	HOSE,PLAIN
314	1.01.0314.1.01.3	CU	3872252	CONNECTOR,PIPE
315	1.01.0315.1.01.4	CU	3872258	CONNECTOR,PIPE
316	1.01.0316.1.01.5	CU	3872278	CONNECTOR,PIPE
317	1.01.0317.1.01.6	CU	3872294	CONNECTOR,PIPE
318	1.01.0318.1.01.7	CU	3872299	CONNECTOR,PIPE
319	1.01.0319.1.01.8	CU	3872813	INDICATOR,RESTRICTION
320	1.01.0320.1.01.9	CU	3872815	INSERT,VALVE
321	1.01.0321.1.01.1	CU	3872844	CONNECTION,WATER BYPASS
322	1.01.0322.1.01.2	CU	3872845	TUBE,WATER BYPASS
323	1.01.0323.1.01.3	CU	3873355	CONNECTION,WATER OUTLET
324	1.01.0324.1.01.4	CU	3873542	BREATHER,CRANKCASE
325	1.01.0325.1.01.5	CU	3874152	VALVE,CHECK
326	1.01.0326.1.01.6	CU	3874153	VALVE,CHECK
327	1.01.0327.1.01.7	CU	3874400	TUBE,WATER OUTLET
328	1.01.0328.1.01.8	CU	3874401	TUBE,WATER OUTLET
329	1.01.0329.1.01.9	CU	3874427	TEE,MALE BRANCH PIPE
330	1.01.0330.1.01.1	CU	3875875	ACTUATOR
331	1.01.0331.1.01.2	CU	3878470	PUMP, HYDRAULIC
332	1.01.0332.1.01.3	CU	3878472	COMPRESSOR,AIR
333	1.01.0333.1.01.4	CU	3879074	ELEMENT,AIR CLEANER
334	1.01.0334.1.01.5	CU	3879075	ELEMENT,AIR CLEANER
335	1.01.0335.1.01.6	CU	3880282	SHAFT,ACCESSORY DRIVE
336	1.01.0336.1.01.7	CU	3880416	TUBE,FUEL SUPPLY
337	1.01.0337.1.01.8	CU	3880497	SHAFT,ACCESSORY DRIVE
338	1.01.0338.1.01.9	CU	3880524	KIT REPAIR 2CYL AIR COMPR
339	1.01.0339.1.01.1	CU	3880812	NOZZLE,PISTON COOLING
340	1.01.0340.1.01.2	CU	3881230	PULLEY,ACCESSORY DRIVE
341	1.01.0341.1.01.3	CU	3881680	GEAR,LUBRICATING OIL PUMP
342	1.01.0342.1.01.4	CU	3884126	PLUNGER,PRS REGULATOR
343	1.01.0343.1.01.5	CU	3931904	SEALANT LIQUIDE GASKET
344	1.01.0344.1.01.6	CU	4009247	PIN,CAM FOLLOWER ROLLER
345	1.01.0345.1.01.7	CU	4009248	PIN,CAM FOLLOWER ROLLER
346	1.01.0346.1.01.8	CU	4024946	UPPER ENGINE GASKET SET
347	1.01.0347.1.01.9	CU	4055279	ELEMENT,AIR CLEANER
348	1.01.0348.1.01.1	CU	4055280	ELEMENT,AIR CLEANER
349	1.01.0349.1.01.2	CU	4071443	PIN,TAPPET ROLLER
350	1.01.0350.1.01.3	CU	4071444	PIN,TAPPET ROLLER
351	1.01.0351.1.01.4	CU	4072619	IMPELLER,WATER PUMP
352	1.01.0352.1.01.5	CU	4072621	PUMP,WATER
353	1.01.0353.1.01.6	CU	4073133	CAMSHAFT
354	1.01.0354.1.01.7	CU	4073134	CAMSHAFT
355	1.01.0355.1.01.8	CU	4073137	BEARING,THRUST
356	1.01.0356.1.01.9	CU	4084693	FILTER,FUEL
357	1.01.0357.1.01.1	CU	4095009	PIN,PISTON
358	1.01.0358.1.01.2	CU	4327021	SWITCH,TEMPERATURE
359	1.01.0359.1.01.3	CU	4345448	GUIDE,VALVE SPRING
360	1.01.0360.1.01.4	CU	4352578	KIT,UPPER ENGINE GASKET
361	1.01.0361.1.01.5	CU	4371769	KIT,LINER
362	1.01.0362.1.01.6	CU	4376512	KIT,LOWER ENGINE GASKET
363	1.01.0363.1.01.7	CU	4912321	GASKET,CYLINDER HEAD
364	1.01.0364.1.01.8	CU	4952020	GEAR,ACCESSORY DRIVE
365	1.01.0365.1.01.9	CU	4971772	GAUGE,TEMPERATURE
366	1.01.0366.1.01.1	CU	4979720	PUMP, LUB OIL
367	1.01.0367.1.01.2	CU	4987064	DAMPER,VIBRATION
368	1.01.0368.1.01.3	CU	5277629	KIT,UNLOADER VALVE
369	1.01.0369.1.01.4	CU	500108 M	GAUGE,TEMPERATURE
370	1.01.0370.1.01.5	CU	9235 1	BEARING,THRUST
371	1.01.0371.1.01.6	CU	9300 1	KEY,SQUARE
372	1.01.0372.1.01.7	CU	AK 4032 SS	HOSE,FLEXIBLE
373	1.01.0373.1.01.8	CU	AK 4045 SS	HOSE,FLEXIBLE
374	1.01.0374.1.01.9	CU	AK 4060 MS	HOSE,FLEXIBLE
375	1.01.0375.1.01.1	CU	AK 5014 SS	HOSE,FLEXIBLE
376	1.01.0376.1.01.2	CU	AK 5015 SS	HOSE,FLEXIBLE
377	1.01.0377.1.01.3	CU	AK 5090 SS	HOSE,FLEXIBLE
378	1.01.0378.1.01.4	CU	AK 6020 SS	HOSE,FLEXIBLE
379	1.01.0379.1.01.5	CU	AK 6045 SS	HOSE,FLEXIBLE
380	1.01.0380.1.01.6	CU	AK 6065 SS	HOSE,FLEXIBLE
381	1.01.0381.1.01.7	CU	AK16011 6MS	HOSE,FLEXIBLE
382	1.01.0382.1.01.8	CU	AK16015 6MS	HOSE,FLEXIBLE

383	1.01.0383.1.01.9	CU	AK16018 6MS	HOSE,FLEXIBLE
384	1.01.0384.1.01.1	CU	AK16022 6MC	HOSE,FLEXIBLE
385	1.01.0385.1.01.2	CU	AK16027 NF	HOSE,FLEXIBLE
386	1.01.0386.1.01.3	CU	AR40130	PLUNGER GOVERNOR
387	1.01.0387.1.01.4	CU	AR96295	SHELL, ASSEMBLY
388	1.01.0388.1.01.5	CU	AX1008862	LABOUR CHARGES OF OVERHAULING
389	1.01.0389.1.01.6	CU	BM28848	DRIVE TACHOMETER
390	1.01.0390.1.01.7	CU	BM33880	SHAFT, FUEL PUMP DRIVE
391	1.01.0391.1.01.8	CU	BM68540	COVER,HAND HOLE
392	1.01.0392.1.01.9	CU	BM74081	SHAFT,THROTTLE
393	1.01.0393.1.01.1	CU	BM76340	DAMPER,FUEL PUMP
394	1.01.0394.1.01.2	CU	BM78930	SHAFT,THROTTLE
395	1.01.0395.1.01.3	CU	JE-AX1003115	TRANSPORTAION CHARGES
396	1.01.0396.1.01.4	CU	KIT2865146	KIT,PISTON RINGS
397	1.01.0397.1.01.5	CU	KIT2865301	KIT,BARREL PLUNGER & CUP
398	1.01.0398.1.01.6	CU	KIT3238194	KIT PISTON, RING SET V-28
399	1.01.0399.1.01.7	CU	KIT3238195	KIT INJ BARREL PLUNGER
400	1.01.0400.1.01.8	CU	KIT3238204	ELEMENT LUB OIL FILTER
401	1.01.0401.1.01.9	CU	KIT3238493	KIT FUEL FILTER AND RING
402	1.01.0402.1.01.1	CU	KIT3238535	KIT PISTON ENGINE
403	1.01.0403.1.01.2	CU	KIT3239991	SET MAIN BEARING (010)
404	1.01.0404.1.01.3	CU	KIT3240239	GASKET SET
405	1.01.0405.1.01.4	CU	KIT3247965	GASKET SET VTA-1710
406	1.01.0406.1.01.5	CU	KIT3803471	SET PISTON RING
407	1.01.0407.1.01.6	CU	KIT3879488	KIT SUPER BYP.FILTER ELEM
408	1.01.0408.1.01.7	CU	KIT3880784	KIT INJECTOR REPAIR-KT
409	1.01.0409.1.01.8	CU	KIT3881132	CRANKSHAFT
410	1.01.0410.1.01.9	CU	KITAR 4220	SET, MAIN BEAR. STD.
411	1.01.0411.1.01.1	CU	KITAR 4221	SET, MAIN BEAR. STD.
412	1.01.0412.1.01.2	CU	KITAR 4222	SET, MAIN BEAR. STD.
413	1.01.0413.1.01.3	CU	KITAR12271	SHELL,MAIN BEARING .010
414	1.01.0414.1.01.4	CU	KITAR95138	GASKET SET
415	1.01.0415.1.01.5	CU	KITBM68356	GASKET GOVERNOR SET
416	1.01.0416.1.01.6	CU	S 212	NUT,REGULAR HEXAGON
417	1.01.0417.1.01.7	CU	S 221	NUT,HEAVY HEXAGON
418	1.01.0418.1.01.8	CU	S 251	NUT,REGULAR HEXAGON JAM
419	1.01.0419.1.01.9	CU	S 670	WASHER,PLAIN
420	1.01.0420.1.01.1	CU	S 679	WASHER,PLAIN
421	1.01.0421.1.01.2	CU	S 911 B	PLUG,PIPE
422	1.01.0422.1.01.3	CU	S 962 E	DRAINCOCK
423	1.01.0423.1.01.4	CU	S 988	ELBOW,PLAIN STREET PIPE
424	1.01.0424.1.01.5	CU	S 1039	ELBOW,FEMALE UNION
425	1.01.0425.1.01.6	CU	S 1040	ELBOW,PLAIN ADAPTER
426	1.01.0426.1.01.7	CU	S 1059	COUPLING,PLAIN PIPE
427	1.01.0427.1.01.8	CU	S 16002	BEARING,BALL
428	1.01.0428.1.01.9	CU	S 16069	BEARING,BALL
429	1.01.0429.1.01.1	CU	4020347	Isolator Vibration
430	1.01.0430.1.01.2	CU	3229945	GASKET EX OUT CONNECTION
431	1.01.0431.1.01.3	CU	AK 10070 SS	HOSE FLEXIBLE
432	1.01.0432.1.01.4	CU	3077198	GASKET ROCKER LEVER COVER
433	1.01.0433.1.01.5	CU	501385	CABLE FLEXABLE DRIVE
434	1.01.0434.1.01.6	CU	3020943	GASKET EXHAUST MOHIFOLD
435	1.01.0435.1.01.7	CU	3066497	SCREW HEX FLANG HEAD CAP
436	1.01.0436.1.01.8	CU	3872268	CONNECTOR PIPE
437	1.01.0437.1.01.9	CU	3049187	GASKET RKR LEVER HOUSING
438	1.01.0438.1.01.1	CU	3872284	CONNECTOR PIPE
439	1.01.0439.1.01.2	CU	AK-10072 SS	HOSE FLEXABLE
440	1.01.0440.1.01.3	CU	3035310	WASHER PLAIN
441	1.01.0441.1.01.4	CU	3076522	GASKET WATER PUMP
442	1.01.0442.1.01.5	CU	125742	CLAMP BOLT
443	1.01.0443.1.01.6	CU	3820664	HOSE PLAIN
444	1.01.0444.1.01.7	CU	3046286	SPACER MOUNTING
445	1.01.0445.1.01.8	CU	3004316	OIL SEAL
446	1.01.0446.1.01.9	CU	67532	LOCK NUT
447	1.01.0447.1.01.1	CU	3628902	WASHER PLAIN
448	1.01.0448.1.01.2	CU	AK-10032 SS	HOSE
449	1.01.0449.1.01.3	CU	AK-880 SS	HOSE
450	1.01.0450.1.01.4	CU	3030768	HOES HUMP
451	1.01.0451.1.01.5	CU	30307 R	HOSE ELBOW
452	1.01.0452.1.01.6	CU	3058356	HORNESS WIRING
453	1.01.0453.1.01.7	CU	3167127	SHAFT FAN DRIVE
454	1.01.0454.1.01.8	CU	66912-1A	SCREW HEX HEAD CAP
455	1.01.0455.1.01.9	CU	205354	SCREW TWALVE POINT CAP
456	1.01.0456.1.01.1	CU	4055075	SWITCH PRESSURE
457	1.01.0457.1.01.2	CU	3095026	SCREW HEX FLANGE HEAD CAP
458	1.01.0458.1.01.3	CU	4926975	SENCER TEMPRATURE

459	1.01.0459.1.01.4	CU	4071829	GAUGE TEMPRATURE
460	1.01.0460.1.01.5	CU	3801689	TURBOCHARGER HC5A
461	1.01.0461.1.01.6	CU	3411335	THERMOSTAT
462	1.01.0462.1.01.7	CU	3051371	PUMP WATER IDLER
463	1.01.0463.1.01.8	CU	3880663	PISTONS TING SET /KTA-1150
464	1.01.0464.1.01.9	CU	4026171	GASKAT FUEL PUMP
465	1.01.0465.1.01.1	CU	4912939	MOTOR SHORTING
466	1.01.0466.1.01.2	CU	3881509	HEAD CYLINDER
467	1.01.0467.1.01.3	CU	3879458	FUEL PUMP
468	1.01.0468.1.01.4	CU	3239790	INJECTOR ASSY
469	1.01.0469.1.01.5	CU	AR-3016676	INJECTOR LESS LINK
470	1.01.0470.1.01.6	CU	3880781	KIT BARELL & PLUNGER
471	1.01.0471.1.01.7	CU	3240746	COMPRESSOR AIR
472	1.01.0472.1.01.8	CU	3239097	PUMP WATER
473	1.01.0473.1.01.9	CU	127950	GASKET CONNECTION
474	1.01.0474.1.01.1	CU	3166497	PUMP WATER
475	1.01.0475.1.01.2	CU	147278	SUPPORT FAN
476	1.01.0476.1.01.3	CU	3246943	FAN HUB
477	1.01.0477.1.01.4	CU	3232548	FAN ENGINE
478	1.01.0478.1.01.5	CU	4344837	Pump Fuel
479	1.01.0479.1.01.6	CU	6304465	Alternator
480	1.01.0480.1.01.7	CU	3238514	B CHECK KIT
481	1.01.0481.1.01.8	CU	3238358	KIT AIR CLEANER ELEMENT
482	1.01.0482.1.01.9	CU	4021119	RADIATOR
483	1.01.0483.1.01.1	CU	3238528	B CHECK KIT
484	1.01.0484.1.01.2	CU	AR7944	AIR COMPRESSOR
485	1.01.0485.1.01.3	CU	3873512	RADIATOR
486	1.01.0486.1.01.4	CU	3879481KC445	PUMP FUEL W.CAL CODE
487	1.01.0487.1.01.5	CU	3240743	AIR COMPRESSOR
488	1.01.0488.1.01.6	CU	3103972/6322723	PUMP , WATER & IDLER
489	1.01.0489.1.01.7	CU	3240744	AIR COMPRESSOR
490	1.01.0490.1.01.8	CU	3879533KC894	PUMP FUEL W.CAL CODE
491	1.01.0491.1.01.9	CU	5301090	AIR COMPRESSOR
492	1.01.0492.1.01.1	CU	5254004	PUMP FUEL INJECTION
493	1.01.0493.1.01.2	CU	3973114	PUMP , WATER & IDLER
494	1.01.0494.1.01.3	CU	3329289	FUEL WATER FS1000
495	1.01.0495.1.01.4	CU	AX1006742/ FS19763.G	FUEL FILTER
496	1.01.0496.1.01.5	CU	4331005/2882674	LUB OIL FILTER
497	1.01.0497.1.01.6	CU	3238627	B CHECK KIT
498	1.01.0498.1.01.7	CU	3238665	KIT AIR CLEANER ELEMENT
499	1.01.0499.1.01.8	CU	3411760	INJECTOR
500	1.01.0500.1.01.9	CU	3284454	PUMP,FUEL
501	1.01.0501.1.01.1	CU	A062Y519	RADIATOR
502	1.01.0502.1.01.2	CU	4344509	TLA FUEL FILTER
503	1.01.0503.1.01.3	CU	3095556KG19	PT PUMP
504	1.01.0504.1.01.4	CU	4911769	PT PUMP
505	1.01.0505.1.01.5	CU	3093637	PUMP FUEL INJECTION
506	1.01.0506.1.01.6	CU	3093696	HARNESS WIRING (Main Engine Harness wiring)
507	1.01.0507.1.01.7	CU	4067815	HARNESS,WIRING (Engine Accessory-Alternator Harness wiring)
508	1.01.0508.1.01.8	CU	5260634	PUMP,FUEL TRANSFER (FUEL LIFT)
509	1.01.0509.1.01.9	CU	5594395	SENSOR,FUEL PRESSURE
510	1.01.0510.1.01.1	CU	4076493/2897331	SENSOR, AMBIENT AIR PRESSURE
511	1.01.0511.1.01.2	CU	3408472/3865349/ 4327239	SENSOR,SPEED (MAGNETIC PICKUP UNIT)
512	1.01.0512.1.01.3	CU	3408560	SENSOR OIL PRESSURE
513	1.01.0513.1.01.4	CU	3408556	COOLANT PRESSURE SENSOR/INTAKE MANIFOLD PRESSURE SENSOR
514	1.01.0514.1.01.5	CU	4954905/3096153	COOLANT TEMPERATURE SENSOR/FUEL TEMPERATURE SENSOR/LUBE OIL TEMPERATURE SENSOR
515	1.01.0515.1.01.6	CU	4088832	INTAKE MANIFOLD TEMPERATURE SENSOR
516	1.01.0516.1.01.7	CU	0193-0486, A055K311	SENSOR COOLANT LEVEL
517	1.01.0517.1.01.8	CU	3400698	ALTERNATOR
518	1.01.0518.1.01.9	CU	3093176	ALTERNATOR Belt
519	1.01.0519.1.01.1	CU	5413006/3003343	BELT V RIBBED (RADIATOR FAN BELT)
520	1.01.0520.1.01.2	CU	4081237	Motor starting(self starter)
521	1.01.0521.1.01.3	CU	3003697	BLANKET TURBOCHARGER HEAT
522	1.01.0522.1.01.4	CU	3594190	TURBOCHARGER
523	1.01.0523.1.01.5	CU	3035766	ENGINE HOURMETER
524	1.01.0524.1.01.6	CU	3031734	TACHOMETER
525	1.01.0525.1.01.7	CU	3658780	FUEL RELAY

526	1.01.0526.1.01.8	CU	3021420	SOLENOID FUEL SHUT OFF VALVE
527	1.01.0527.1.01.9	CU	3050692	SWITCH,MAGNETIC
528	1.01.0528.1.01.1	CU	3094043	CLAMP V BAND
529	1.01.0529.1.01.2	CU	201989	CLAMP-V BAND 5.00
530	1.01.0530.1.01.3	CU	131536 / 3093594	WATER PUMP
531	1.01.0531.1.01.4	CU	2871203	Module Electronic control
532	1.01.0532.1.01.5	CU	3238132	KIT Air cleaner NTA 855 BC
533	1.01.0533.1.01.6	CU	3878141	Radiator(KTA 115 0)
534	1.02.0001.1.01.6	PL	3900025224	ELBOW
535	1.02.0002.1.01.7	PL	130X6MM.90LG	CONNECTING PIECE
536	1.02.0003.1.01.8	PL	ABA104-138/12	HOSE CLIP
537	1.02.0004.1.01.9	PL	ABA130-165/12	HOSE CLIP
538	1.02.0005.1.01.1	PL	ID 130-300LG	GUSETTED TUBE
539	1.02.0006.1.01.2	PL	ROHR130X2ST37BK.DIN2393	PRECISION STEEL TUBE WELDED 250MM LENGTH
540	1.02.0007.1.01.3	DE	0 001 368 012	SELF STARTER
541	1.02.0008.1.01.4	DE	0 001 417 055	SELF STARTER
542	1.02.0009.1.01.5	DE	0 001 417 058 /	SELF STARTER
543	1.02.0010.1.01.6	DE	0 120 339 537	ALTERNATOR
544	1.02.0011.1.01.7	DE	0 120 469 643	ALTERNATOR
545	1.02.0012.1.01.8	Shifted to Annexure II		
546	1.02.0013.1.01.9	DE	0 120 689 511 / 0 120 689 543	ALTERNATOR
547	1.02.0014.1.01.1	DE	0 290 800 052	SUPPRESSION CAPACITOR
548	1.02.0015.1.01.2	DE	0 330 001 016	SOLENOID COIL / SWITCH
549	1.02.0016.1.01.3	DE	0 330 004 004	SWITCH
550	1.02.0017.1.01.4	DE	0 331 101 005	CONTROL RELAY
551	1.02.0018.1.01.5	DE	0 331 101 006	CONTROL RELAY
552	1.02.0019.1.01.6	DE	0 331 402 206	SOLENOID
553	1.02.0020.1.01.7	DE	0 331 450 001	SOLENOID
554	1.02.0021.1.01.8	DE	0 331 450 002	SOLENOID
555	1.02.0022.1.01.9	DE	0 401 840 754	FUEL PUMP
556	1.02.0023.1.01.1	DE	0 401 870 070	FUEL PUMP
557	1.02.0024.1.01.2	DE	0 432 131 880	INJECTORS
558	1.02.0025.1.01.3	DE	0 432 291 520	INJECTORS
559	1.02.0026.1.01.4	DE	0 432 291 699	INJECTORS
560	1.02.0027.1.01.5	DE	0 433 171 066	NOZZLE
561	1.02.0028.1.01.6	DE	0 433 271 685	NOZZLE
562	1.02.0029.1.01.7	DE	0 433 271 819	NOZZLE
563	1.02.0030.1.01.8	DE	0 440 008 008 / 0 440 008 995	FEED PUMP
564	1.02.0031.1.01.9	DE	0 440 008 009 / 0 440 008 076	FEED PUMP
565	1.02.0032.1.01.1	DE	0 451 105 067	FILTER
566	1.02.0033.1.01.2	DE	0 460 426 073	FUEL PUMP
567	1.02.0034.1.01.3	DE	0148-01-001	DUMMY
568	1.02.0035.1.01.4	DE	0148-01-003	PARALLEL PIN
569	1.02.0036.1.01.5	DE	0148-01-004	DOWEL PIN
570	1.02.0037.1.01.6	DE	0148-01-005	ALLEN BOLT
571	1.02.0038.1.01.7	DE	0148-01-006	COVER
572	1.02.0039.1.01.8	DE	0148-01-008	SCREW PLUG
573	1.02.0040.1.01.9	DE	0148-01-009	CORE HOLE PLUG
574	1.02.0041.1.01.1	DE	0148-01-010	PLUG
575	1.02.0042.1.01.2	DE	0148-01-013	CAM THRUST PLATE
576	1.02.0043.1.01.3	DE	0148-01-015	BUSH
577	1.02.0044.1.01.4	DE	0148-01-016	BUSH
578	1.02.0045.1.01.5	DE	0148-01-017	SCREW PLUG
579	1.02.0046.1.01.6	DE	0148-01-018	SEALING RING
580	1.02.0047.1.01.7	DE	0148-01-019	CAP NUT
581	1.02.0048.1.01.8	DE	0148-01-020	ADJUSTING SCREW
582	1.02.0049.1.01.9	DE	0148-01-021	SPRING
583	1.02.0050.1.01.1	DE	0148-01-02149331	L. HOSE
584	1.02.0051.1.01.2	DE	0148-01-022	PRESSURE RELIEF VALVE
585	1.02.0052.1.01.3	DE	0148-01-025	SCREW PLUG
586	1.02.0053.1.01.4	DE	0148-01-027	SCREW PLUG
587	1.02.0054.1.01.5	DE	0148-01-028	MAIN BEARING
588	1.02.0055.1.01.6	DE	0148-01-028/1	MAIN BEARING (1U/S)
589	1.02.0056.1.01.7	DE	0148-01-028/2	MAIN BEARING (2U/S)
590	1.02.0057.1.01.8	DE	0148-01-028/3	MAIN BEARING (3U/S)
591	1.02.0058.1.01.9	DE	0148-01-028/4	MAIN BEARING (4U/S)
592	1.02.0059.1.01.1	DE	0148-01-028/5	MAIN BEARING (5 U/S)
593	1.02.0060.1.01.2	DE	0148-01-029	THRUST WASHER
594	1.02.0061.1.01.3	DE	0148-01-031	HEX BOLT
595	1.02.0062.1.01.4	DE	0148-01-034	OIL PIPE
596	1.02.0063.1.01.5	DE	0148-01-035	ALLEN BOLT
597	1.02.0064.1.01.6	DE	0148-01-036	O-SEAL
598	1.02.0065.1.01.7	DE	0148-01-037	COVER

599	1.02.0066.1.01.8	DE	0148-01-040	GASKET
600	1.02.0067.1.01.9	DE	0148-01-043	ROT. SHAFT LIP SEAL
601	1.02.0068.1.01.1	DE	0148-01-044	PACKING COMPOUND
602	1.02.0069.1.01.2	DE	0148-01-045	TAPPET BRIDGE PIPE
603	1.02.0070.1.01.3	DE	0148-01-046	TAPPET BRIDGE
604	1.02.0071.1.01.4	DE	0148-01-047	SLEEVE
605	1.02.0072.1.01.5	DE	0148-01-048	RUBBER RING
606	1.02.0073.1.01.6	DE	0148-01-050	OVER PRESSURE VALVE
607	1.02.0074.1.01.7	DE	0148-01-052	NOZZLE
608	1.02.0075.1.01.8	DE	0148-01-058	SPACER FOR SCREEN PLATE
609	1.02.0076.1.01.9	DE	0148-01-079	SOLUTION
610	1.02.0077.1.01.1	DE	0148-01-121	DIPSTICK
611	1.02.0078.1.01.2	DE	0148-01-128	CLAMP FOR TUBE
612	1.02.0079.1.01.3	DE	0148-01-132	ADAPTER
613	1.02.0080.1.01.4	DE	0148-01-134	TUBE
614	1.02.0081.1.01.5	DE	0148-01-135	BRACKET FOR ABOVE
615	1.02.0082.1.01.6	DE	0148-01-161	BOLT
616	1.02.0083.1.01.7	DE	0148-01-162	PIPE
617	1.02.0084.1.01.8	DE	0148-01-163	WASHER
618	1.02.0085.1.01.9	DE	0148-01-164	NUT
619	1.02.0086.1.01.1	DE	0148-01-165	HOSE CLIP
620	1.02.0087.1.01.2	DE	0148-01-166	RUBBER SLEEVE
621	1.02.0088.1.01.3	DE	0148-01-167	VACUUM HOSE
622	1.02.0089.1.01.4	DE	0148-01-168	SOCKET/ADAPTER
623	1.02.0090.1.01.5	DE	0148-01-169	SEALING RING
624	1.02.0091.1.01.6	DE	0148-01-170	HOSE CLIP
625	1.02.0092.1.01.7	DE	0148-01-171	RUBBER HOSE
626	1.02.0093.1.01.8	DE	0148-01-172	VALVE MECHAN CAS
627	1.02.0094.1.01.9	DE	0148-01-173	BREATHING ASSY.
628	1.02.0095.1.01.1	DE	0148-01-175	O SEAL
629	1.02.0096.1.01.2	DE	0148-01-177	CHEESE HEAD SCREW
630	1.02.0097.1.01.3	DE	0148-01-179	CHEESE HEAD SCREW
631	1.02.0098.1.01.4	DE	0148-01-183	VALVE INSERT
632	1.02.0099.1.01.5	DE	0148-01-192	OIL SEPARATOR
633	1.02.0100.1.01.6	DE	0148-01-193	HOSE CLIP
634	1.02.0101.1.01.7	DE	0148-01-194	PIPE ELBOW
635	1.02.0102.1.01.8	DE	0148-01-196	PLAIN WASHER
636	1.02.0103.1.01.9	DE	0148-01-197	OIL SEAL
637	1.02.0104.1.01.1	DE	0148-01-198	RUBBER SLEEVE
638	1.02.0105.1.01.2	DE	0148-01-200	PIPE ELBOW
639	1.02.0106.1.01.3	DE	0148-01-201	RUBBER SLEEVE
640	1.02.0107.1.01.4	DE	0148-01-202	BREATHING HOUSING
641	1.02.0108.1.01.5	DE	0148-01-203	HOSE CLIP
642	1.02.0109.1.01.6	DE	0148-01-204	OIL SEAL
643	1.02.0110.1.01.7	DE	0148-01-205	DIAPHRAGM FOR BREATHING
644	1.02.0111.1.01.8	DE	0148-01-2297	HALF STOP RING
645	1.02.0112.1.01.9	DE	0148-01-241	CAP
646	1.02.0113.1.01.1	DE	0148-01-245	CLAMP
647	1.02.0114.1.01.2	DE	0148-01-248	HOSE CLIP
648	1.02.0115.1.01.3	DE	0148-01-266	HEXAGON BOLT
649	1.02.0116.1.01.4	DE	0148-01-267	OIL FILLER
650	1.02.0117.1.01.5	DE	0148-01-269	BRACKET
651	1.02.0118.1.01.6	DE	0148-01-270	RUBBER SLEEVE
652	1.02.0119.1.01.7	DE	0148-01-271	PLAIN WASHER
653	1.02.0120.1.01.8	DE	0148-01-272	OIL FILLER
654	1.02.0121.1.01.9	DE	0148-01-356	RUBBER HOSE
655	1.02.0122.1.01.1	DE	0148-01-360	RUBBER SLEEVE
656	1.02.0123.1.01.2	DE	0148-01-361	CARRIER ASSEMBLY
657	1.02.0124.1.01.3	DE	0148-01-368	ROT. SHAFT LIP SEAL
658	1.02.0125.1.01.4	DE	0148-01-376	O' SEAL
659	1.02.0126.1.01.5	DE	0148-01-377	GASKET
660	1.02.0127.1.01.6	DE	0148-01-379	WASHER
661	1.02.0128.1.01.7	DE	0148-01-380	LUB OIL TUBE
662	1.02.0129.1.01.8	DE	0148-01-441	PACKING COMPOUND
663	1.02.0130.1.01.9	DE	0148-01-481	HOSE CLIP
664	1.02.0131.1.01.1	DE	0148-01-482	RUBBER SLEEVE
665	1.02.0132.1.01.2	DE	0148-01-483	BREATHING LINE
666	1.02.0133.1.01.3	DE	0148-01-487	HEXAGON BOLT
667	1.02.0134.1.01.4	DE	0148-01-488	PLAIN WASHER
668	1.02.0135.1.01.5	DE	0148-01-489	PIPE CLAMP
669	1.02.0136.1.01.6	DE	0148-01-490	HEXAGON NUT
670	1.02.0137.1.01.7	DE	0148-01-499	RUBBER GROMMET
671	1.02.0138.1.01.8	DE	0148-01-526	ELBOW
672	1.02.0139.1.01.9	DE	0148-02-002	OIL PAN GASKET
673	1.02.0140.1.01.1	DE	0148-02-003	BOLT
674	1.02.0141.1.01.2	DE	0148-02-004	WASHER
675	1.02.0142.1.01.3	DE	0148-02-017	SOLUTION

676	1.02.0143.1.01.4	DE	0148-02-046	BOLT
677	1.02.0144.1.01.5	DE	0148-02-047	SPRING WASHER
678	1.02.0145.1.01.6	DE	0148-02-048	WASHER
679	1.02.0146.1.01.7	DE	0148-02-050	HEXAGON BOLT
680	1.02.0147.1.01.8	DE	0148-02-054	BOLT
681	1.02.0148.1.01.9	DE	0148-04-001	CYLINDER
682	1.02.0149.1.01.1	DE	0148-04-002	SPACER RING
683	1.02.0150.1.01.2	DE	0148-04-003	SPACER RING
684	1.02.0151.1.01.3	DE	0148-04-004	SPACER RING
685	1.02.0152.1.01.4	DE	0148-04-005	O SEAL
686	1.02.0153.1.01.5	DE	0148-04-006	SPACER RING
687	1.02.0154.1.01.6	DE	0148-05-003	CHEESE HEAD SCREW
688	1.02.0155.1.01.7	DE	0148-05-041	CHEESE HEAD SCREW
689	1.02.0156.1.01.8	DE	0148-05-042	BELT PULLEY
690	1.02.0157.1.01.9	DE	0148-05-043	TORS. VIBRATE DAMPER
691	1.02.0158.1.01.1	DE	0148-05-048	BALL BEARING
692	1.02.0159.1.01.2	DE	0148-05-050	GEAR RIM
693	1.02.0160.1.01.3	DE	0148-05-051	FLY WHEEL BOLT
694	1.02.0161.1.01.4	DE	0148-05-063	HEXAGON BOLT
695	1.02.0162.1.01.5	DE	0148-05-064	BEARING FLANGE
696	1.02.0163.1.01.6	DE	0148-06-001	CONNECTING ROD
697	1.02.0164.1.01.7	DE	0148-06-002	BIG END BUSH
698	1.02.0165.1.01.8	DE	0148-06-003	BIG END BEARING
699	1.02.0166.1.01.9	DE	0148-06-003/1	BIG END BEARING (1U/S)
700	1.02.0167.1.01.1	DE	0148-06-003/2	BIG END BEARING (2U/S)
701	1.02.0168.1.01.2	DE	0148-06-003/3	BIG END BEARING (3U/S)
702	1.02.0169.1.01.3	DE	0148-06-003/4	BIG END BEARING (4U/S)
703	1.02.0170.1.01.4	DE	0148-06-003/5	CON ROD BEARING (5 U/S)
704	1.02.0171.1.01.5	DE	0148-06-004	CENTERING PIECE
705	1.02.0172.1.01.6	DE	0148-06-005	BIG END BOLT
706	1.02.0173.1.01.7	DE	0148-07-001	PISTON
707	1.02.0174.1.01.8	DE	0148-07-004	SET OF PISTON RING
708	1.02.0175.1.01.9	DE	0148-08-001	INLET VALVE
709	1.02.0176.1.01.1	DE	0148-08-002	VALVE SEAT INSERT
710	1.02.0177.1.01.2	DE	0148-08-003	EXHAUST VALVE
711	1.02.0178.1.01.3	DE	0148-08-004	VALVE SEAT INSERT
712	1.02.0179.1.01.4	DE	0148-08-005	PLAIN WASHER
713	1.02.0180.1.01.5	DE	0148-08-006	CYLINDER HEAD BOLT
714	1.02.0181.1.01.6	DE	0148-08-007	STUD
715	1.02.0182.1.01.7	DE	0148-08-008	STUD
716	1.02.0183.1.01.8	DE	0148-08-010	CYLINDER HEAD
717	1.02.0184.1.01.9	DE	0148-08-011	VALVE GUIDE
718	1.02.0185.1.01.1	DE	0148-08-012	VALVE GUIDE
719	1.02.0186.1.01.2	DE	0148-08-013	SQ. WASHER FOR BOLT
720	1.02.0187.1.01.3	DE	0148-08-014	STUD
721	1.02.0188.1.01.4	DE	0148-08-015	GASKET
722	1.02.0189.1.01.5	DE	0148-08-017	HEXAGON BOLT
723	1.02.0190.1.01.6	DE	0148-08-018	SEALING CONE
724	1.02.0191.1.01.7	DE	0148-08-019	O SEAL
725	1.02.0192.1.01.8	DE	0148-08-022	O SEAL
726	1.02.0193.1.01.9	DE	0148-08-023	LUB OIL RETURN LINE
727	1.02.0194.1.01.1	DE	0148-08-025	PLAIN WASHER
728	1.02.0195.1.01.2	DE	0148-08-027	HEXAGON BOLT
729	1.02.0196.1.01.3	DE	0148-08-028	SEALING SECTION
730	1.02.0197.1.01.4	DE	0148-08-029	TAPER COLLET PIECE
731	1.02.0198.1.01.5	DE	0148-08-030	VALVE CUP
732	1.02.0199.1.01.6	DE	0148-08-031	SHIM
733	1.02.0200.1.01.7	DE	0148-08-032	SHIM
734	1.02.0201.1.01.8	DE	0148-08-033	VALVE ROTATOR
735	1.02.0202.1.01.9	DE	0148-08-034	SHIM
736	1.02.0203.1.01.1	DE	0148-08-035	SHIM
737	1.02.0204.1.01.2	DE	0148-08-036	SHIM
738	1.02.0205.1.01.3	DE	0148-08-037	SHIM
739	1.02.0206.1.01.4	DE	0148-08-038	SPRING SEAL
740	1.02.0207.1.01.5	DE	0148-08-040	VALVE SPRING
741	1.02.0208.1.01.6	DE	0148-08-041	VALVE MECHAN. COVER
742	1.02.0209.1.01.7	DE	0148-08-043	GASKET
743	1.02.0210.1.01.8	DE	0148-08-044	BOLT
744	1.02.0211.1.01.9	DE	0148-08-047	VALVE SEAL
745	1.02.0212.1.01.1	DE	0148-10-001	CAMSHAFT
746	1.02.0213.1.01.2	DE	0148-10-002	CAM BOLT
747	1.02.0214.1.01.3	DE	0148-10-003	TOOTHED GEAR
748	1.02.0215.1.01.4	DE	0148-10-004	WASHER
749	1.02.0216.1.01.5	DE	0148-10-005	CAM SHAFT BOLT
750	1.02.0217.1.01.6	DE	0148-11-001	VALVE TAPPET
751	1.02.0218.1.01.7	DE	0148-11-002	O SEAL
752	1.02.0219.1.01.8	DE	0148-11-003	PUSH TUBE SLEEVE

753	1.02.0220.1.01.9	DE	0148-11-004	PUSH ROD
754	1.02.0221.1.01.1	DE	0148-11-005	O SEAL
755	1.02.0222.1.01.2	DE	0148-11-006	ROCKER ARM BRACKET
756	1.02.0223.1.01.3	DE	0148-11-007	ROCKER ARM
757	1.02.0224.1.01.4	DE	0148-11-008	R.A.SCREW
758	1.02.0225.1.01.5	DE	0148-11-009	ROCKER ADJUSTMENT NUT
759	1.02.0226.1.01.6	DE	0148-11-010	HEXAGON BOLT
760	1.02.0227.1.01.7	DE	0148-14-007	OIL PRESS PUMP
761	1.02.0228.1.01.8	DE	0148-15-006	SCREW PLUG
762	1.02.0229.1.01.9	DE	0148-15-008	ADAPTER
763	1.02.0230.1.01.1	DE	0148-15-012	SCREW FITTING
764	1.02.0231.1.01.2	DE	0148-15-019	PLATE
765	1.02.0232.1.01.3	DE	0148-15-020	BOLT
766	1.02.0233.1.01.4	DE	0148-15-021	SPIN ON FILTER
767	1.02.0234.1.01.5	DE	0148-15-022	LOCK WASHER
768	1.02.0235.1.01.6	DE	0148-15-023	HOSE CLIP
769	1.02.0236.1.01.7	DE	0148-15-161	OIL COOLER
770	1.02.0237.1.01.8	DE	0148-15-162	RUBBER STRIP
771	1.02.0238.1.01.9	DE	0148-15-164	COVER PLATE
772	1.02.0239.1.01.1	DE	0148-15-165	HEXAGON BOLT
773	1.02.0240.1.01.2	DE	0148-15-166	COVER PLATE
774	1.02.0241.1.01.3	DE	0148-15-168	O SEAL
775	1.02.0242.1.01.4	DE	0148-15-169	BOLT
776	1.02.0243.1.01.5	DE	0148-15-179	SPRING WASHER
777	1.02.0244.1.01.6	DE	0148-15-180	PLAIN WASHER
778	1.02.0245.1.01.7	DE	0148-15-194	WASHER
779	1.02.0246.1.01.8	DE	0148-15-208	CLAMPING SECTION
780	1.02.0247.1.01.9	DE	0148-15-209	CLAMPING SECTION
781	1.02.0248.1.01.1	DE	0148-15-243	OIL COOLER
782	1.02.0249.1.01.2	DE	0148-16-002	ANGLED RETAINER
783	1.02.0250.1.01.3	DE	0148-16-003	SEALING RING
784	1.02.0251.1.01.4	DE	0148-16-004	UNION FOR LUB OIL LINE
785	1.02.0252.1.01.5	DE	0148-16-009	GASKET
786	1.02.0253.1.01.6	DE	0148-16-010	PIPE LINE
787	1.02.0254.1.01.7	DE	0148-16-011	CLIP
788	1.02.0255.1.01.8	DE	0148-16-012	HEXAGON BOLT
789	1.02.0256.1.01.9	DE	0148-16-013	PIPE CLAMP
790	1.02.0257.1.01.1	DE	0148-16-014	HEXAGON BOLT
791	1.02.0258.1.01.2	DE	0148-16-015	SPRING WASHER
792	1.02.0259.1.01.3	DE	0148-16-017	BRACKET
793	1.02.0260.1.01.4	DE	0148-16-018	BRACKET
794	1.02.0261.1.01.5	DE	0148-16-020	PIPE LINE
795	1.02.0262.1.01.6	DE	0148-16-022	HEXAGON BOLT
796	1.02.0263.1.01.7	DE	0148-16-023	ADAPTER
797	1.02.0264.1.01.8	DE	0148-16-024	PIPE LINE
798	1.02.0265.1.01.9	DE	0148-16-028	GASKET
799	1.02.0266.1.01.1	DE	0148-16-029	HEXAGON BOLT
800	1.02.0267.1.01.2	DE	0148-16-030	PIPELINE
801	1.02.0268.1.01.3	DE	0148-16-031	CLIP
802	1.02.0269.1.01.4	DE	0148-16-032	RUBBER SLEEVE
803	1.02.0270.1.01.5	DE	0148-16-035	O SEAL
804	1.02.0271.1.01.6	DE	0148-16-036	PIPELINE
805	1.02.0272.1.01.7	DE	0148-16-041	HEXAGON BOLT
806	1.02.0273.1.01.8	DE	0148-16-042	FLANGE
807	1.02.0274.1.01.9	DE	0148-17-001	O SEAL
808	1.02.0275.1.01.1	DE	0148-17-002	FIP LUB OIL DRAIN PIPE
809	1.02.0276.1.01.2	DE	0148-17-003	CLAMP FOR ABOVE
810	1.02.0277.1.01.3	DE	0148-17-004	CONNECTING PIECE
811	1.02.0278.1.01.4	DE	0148-17-005	CLAMP FOR ABOVE
812	1.02.0279.1.01.5	DE	0148-17-014	PLAIN WASHER
813	1.02.0280.1.01.6	DE	0148-17-017	FUEL INJECTION PUMP
814	1.02.0281.1.01.7	DE	0148-17-032	FUEL SUPPLY PUMP
815	1.02.0282.1.01.8	DE	0148-17-046	SUPPLY PUMP
816	1.02.0283.1.01.9	DE	0148-17-061	SEALING RING
817	1.02.0284.1.01.1	DE	0148-17-0726	DELIVERY VALVE
818	1.02.0285.1.01.2	DE	0148-17-083	BANJO
819	1.02.0286.1.01.3	DE	0148-17-084	SEALING RING
820	1.02.0287.1.01.4	DE	0148-17-085	PIPE
821	1.02.0288.1.01.5	DE	0148-17-091	HEXAGON BOLT
822	1.02.0289.1.01.6	DE	0148-17-093	FUEL PUMP BOLT
823	1.02.0290.1.01.7	DE	0148-17-094	SPRING WASHER
824	1.02.0291.1.01.8	DE	0148-17-097	FUEL PUMP BOLT
825	1.02.0292.1.01.9	DE	0148-17-098	BOLT
826	1.02.0293.1.01.1	DE	0148-17-099	WASHER
827	1.02.0294.1.01.2	DE	0148-17-100	COUPLING PLATE
828	1.02.0295.1.01.3	DE	0148-17-101	PLAIN WASHER
829	1.02.0296.1.01.4	DE	0148-17-107	CHEASE HEAD SCREW

830	1.02.0297.1.01.5	DE	0148-17-110	FIP COUPLING ASSY
831	1.02.0298.1.01.6	DE	0148-17-8821	PUMPING ELEMENT
832	1.02.0299.1.01.7	DE	0148-18-001	AUTO TIMER ASSY.
833	1.02.0300.1.01.8	DE	0148-18-020	ROT SHAFT LIP SEAL
834	1.02.0301.1.01.9	DE	0148-18-021	BUSH
835	1.02.0302.1.01.1	DE	0148-18-022	BEARING RACE
836	1.02.0303.1.01.2	DE	0148-18-023	OIL SEAL
837	1.02.0304.1.01.3	DE	0148-18-024	O SEAL
838	1.02.0305.1.01.4	DE	0148-18-027	GEAR
839	1.02.0306.1.01.5	DE	0148-18-029	GEAR
840	1.02.0307.1.01.6	DE	0148-19-001	THRUST PAD
841	1.02.0308.1.01.7	DE	0148-19-003	HEXAGON NUT
842	1.02.0309.1.01.8	DE	0148-19-004	SEALING RING
843	1.02.0310.1.01.9	DE	0148-19-005	NOZZLE
844	1.02.0311.1.01.1	DE	0148-19-006	NOZZLE HOLDER
845	1.02.0312.1.01.2	DE	0148-19-007	O SEAL
846	1.02.0313.1.01.3	DE	0148-20-006	COPPER WASHER
847	1.02.0314.1.01.4	DE	0148-20-007	GASKET
848	1.02.0315.1.01.5	DE	0148-20-008	STAINER ELEMENT
849	1.02.0316.1.01.6	DE	0148-20-009	FUEL PRE FILTER
850	1.02.0317.1.01.7	DE	0148-20-015	SEALING RING
851	1.02.0318.1.01.8	DE	0148-20-026	FILTER ELEMENT
852	1.02.0319.1.01.9	DE	0148-20-027	FELT ELEMENT
853	1.02.0320.1.01.1	DE	0148-20-028	FUEL FILTER BODY
854	1.02.0321.1.01.2	DE	0148-20-083	HEXAGON BOLT
855	1.02.0322.1.01.3	DE	0148-20-084	DISC PLATE
856	1.02.0323.1.01.4	DE	0148-20-085	PIPE CLIP
857	1.02.0324.1.01.5	DE	0148-20-088	BANJO FITTING
858	1.02.0325.1.01.6	DE	0148-20-091	PIPE
859	1.02.0326.1.01.7	DE	0148-20-094	RETAINER
860	1.02.0327.1.01.8	DE	0148-20-095	RETAINER
861	1.02.0328.1.01.9	DE	0148-20-112	FUEL PIPE
862	1.02.0329.1.01.1	DE	0148-20-113	FUEL PIPE
863	1.02.0330.1.01.2	DE	0148-20-114	FUEL PIPE
864	1.02.0331.1.01.3	DE	0148-20-115	FUEL PIPE
865	1.02.0332.1.01.4	DE	0148-20-115A	PIPE LINE
866	1.02.0333.1.01.5	DE	0148-20-116	FUEL PIPE
867	1.02.0334.1.01.6	DE	0148-20-116A	PIPE LINE
868	1.02.0335.1.01.7	DE	0148-20-117	FUEL PIPE
869	1.02.0336.1.01.8	DE	0148-20-118	FUEL PIPE
870	1.02.0337.1.01.9	DE	0148-20-119	RETAINER
871	1.02.0338.1.01.1	DE	0148-20-137	ADAPTER
872	1.02.0339.1.01.2	DE	0148-21-012	PIPE CLIP
873	1.02.0340.1.01.3	DE	0148-21-013	PIPE CLIP
874	1.02.0341.1.01.4	DE	0148-21-014	BRACKET RUBBER
875	1.02.0342.1.01.5	DE	0148-21-015	PIPE CLIP
876	1.02.0343.1.01.6	DE	0148-21-029	PIPE CLIP
877	1.02.0344.1.01.7	DE	0148-21-030	HIGH PRESSURE PIPE
878	1.02.0345.1.01.8	DE	0148-21-031	HIGH PRESSURE PIPE
879	1.02.0346.1.01.9	DE	0148-21-032	HIGH PRESSURE PIPE
880	1.02.0347.1.01.1	DE	0148-21-033	HIGH PRESSURE PIPE
881	1.02.0348.1.01.2	DE	0148-21-034	HIGH PRESSURE PIPE
882	1.02.0349.1.01.3	DE	0148-21-035	HIGH PRESSURE PIPE
883	1.02.0350.1.01.4	DE	0148-21-036	HIGH PRESSURE PIPE
884	1.02.0351.1.01.5	DE	0148-21-037	HIGH PRESSURE PIPE
885	1.02.0352.1.01.6	DE	0148-21-038	HIGH PRESSURE PIPE
886	1.02.0353.1.01.7	DE	0148-21-039	HIGH PRESSURE PIPE
887	1.02.0354.1.01.8	DE	0148-21-040	HIGH PRESSURE PIPE
888	1.02.0355.1.01.9	DE	0148-21-041	HIGH PRESSURE PIPE
889	1.02.0356.1.01.1	DE	0148-21-053	PIPE LINE
890	1.02.0357.1.01.2	DE	0148-21-057	INJ. RETURN PIPE
891	1.02.0358.1.01.3	DE	0148-21-058	BANJO BOLT
892	1.02.0359.1.01.4	DE	0148-21-059	SEALING RING
893	1.02.0360.1.01.5	DE	0148-21-066	ADAPTER
894	1.02.0361.1.01.6	DE	0148-21-067	RUBBER GROMMET
895	1.02.0362.1.01.7	DE	0148-21-068	RETAINER
896	1.02.0363.1.01.8	DE	0148-21-072	BANJO BOLT
897	1.02.0364.1.01.9	DE	0148-21-073	RETURN PIPE
898	1.02.0365.1.01.1	DE	0148-21-077	RETURN PIPE
899	1.02.0366.1.01.2	DE	0148-21-079	RETURN PIPE
900	1.02.0367.1.01.3	DE	0148-21-080	BANJO FITTING
901	1.02.0368.1.01.4	DE	0148-22-001	O SEAL
902	1.02.0369.1.01.5	DE	0148-22-002	O SEAL
903	1.02.0370.1.01.6	DE	0148-22-005	BATH AIR CLEANER
904	1.02.0371.1.01.7	DE	0148-22-010	PAPER CARTRIDGE
905	1.02.0372.1.01.8	DE	0148-22-011	SAFETY CARTRIDGE
906	1.02.0373.1.01.9	DE	0148-22-012	SEALING NUT

907	1.02.0374.1.01.1	DE	0148-22-015	DUST EJECTOR
908	1.02.0375.1.01.2	DE	0148-22-043	PIPE
909	1.02.0376.1.01.3	DE	0148-22-046	PIPE CLAMP
910	1.02.0377.1.01.4	DE	0148-22-051	PIPE LINE
911	1.02.0378.1.01.5	DE	0148-22-056	PIPE CLAMP
912	1.02.0379.1.01.6	DE	0148-22-059	BRACKET
913	1.02.0380.1.01.7	DE	0148-22-075	SOCKET/ADAPTER
914	1.02.0381.1.01.8	DE	0148-22-081	HOSE CLIP
915	1.02.0382.1.01.9	DE	0148-22-082	RUBBER SLEEVE
916	1.02.0383.1.01.1	DE	0148-22-085	EXHAUST GASKET
917	1.02.0384.1.01.2	DE	0148-22-107	HOSE CLIP
918	1.02.0385.1.01.3	DE	0148-22-108	RUBBER SLEEVE
919	1.02.0386.1.01.4	DE	0148-22-109	SCREW PLUG
920	1.02.0387.1.01.5	DE	0148-22-111	ELBOW CONNECTOR
921	1.02.0388.1.01.6	DE	0148-22-201	HEXAGON NUT
922	1.02.0389.1.01.7	DE	0148-22-202	WASHER
923	1.02.0390.1.01.8	DE	0148-22-205	SCREW PLUG
924	1.02.0391.1.01.9	DE	0148-22-206	HOSE CLIP
925	1.02.0392.1.01.1	DE	0148-22-207	RUBBERSLEEVE
926	1.02.0393.1.01.2	DE	0148-22-214	PROFILE WASHER
927	1.02.0394.1.01.3	DE	0148-22-241	INLET MANIFOLD
928	1.02.0395.1.01.4	DE	0148-22-243	PLAIN WASHER
929	1.02.0396.1.01.5	DE	0148-26-001	HOSE STRAP
930	1.02.0397.1.01.6	DE	0148-26-002	PIPELINE
931	1.02.0398.1.01.7	DE	0148-26-003	PIPE LINE
932	1.02.0399.1.01.8	DE	0148-26-004	PIPELINE
933	1.02.0400.1.01.9	DE	0148-26-005	PIPE LINE
934	1.02.0401.1.01.1	DE	0148-26-021	SOCKET/ADAPTER
935	1.02.0402.1.01.2	DE	0148-26-023	SOCKET/ADAPTER
936	1.02.0403.1.01.3	DE	0148-26-024	FLAME GLOW PLUG
937	1.02.0404.1.01.4	DE	0148-26-026	HEXAGON BOLT
938	1.02.0405.1.01.5	DE	0148-26-027	SPRING WASHER
939	1.02.0406.1.01.6	DE	0148-26-028	BRACKET
940	1.02.0407.1.01.7	DE	0148-26-029	SOLENOID VALVE
941	1.02.0408.1.01.8	DE	0148-26-030	HEXAGON BOLT
942	1.02.0409.1.01.9	DE	0148-26-031	SPRING WASHER
943	1.02.0410.1.01.1	DE	0148-26-039	PIPELINE
944	1.02.0411.1.01.2	DE	0148-29-034	BALL JOINT
945	1.02.0412.1.01.3	DE	0148-29-041	FIP SPRING TOP
946	1.02.0413.1.01.4	DE	0148-29-049	TOW BAR
947	1.02.0414.1.01.5	DE	0148-29-079	HOSE
948	1.02.0415.1.01.6	DE	0148-29-082	BEARING
949	1.02.0416.1.01.7	DE	0148-29-089	CONTROL LEVER
950	1.02.0417.1.01.8	DE	0148-29-092	SHAFT
951	1.02.0418.1.01.9	DE	0148-29-161	HEXAGON NUT
952	1.02.0419.1.01.1	DE	0148-29-162	PLAIN WASHER
953	1.02.0420.1.01.2	DE	0148-29-163	BALL JOINT
954	1.02.0421.1.01.3	DE	0148-29-164	BELLOWS
955	1.02.0422.1.01.4	DE	0148-29-165	TOW BAR
956	1.02.0423.1.01.5	DE	0148-29-173	CONTROL LEVER
957	1.02.0424.1.01.6	DE	0148-29-174	SPRING
958	1.02.0425.1.01.7	DE	0148-29-175	PLATE FOR SPRING
959	1.02.0426.1.01.8	DE	0148-29-189	BALL JOINT
960	1.02.0427.1.01.9	DE	0148-33-000	SPECIAL GASKET
961	1.02.0428.1.01.1	DE	0148-33-026	CYLINDER
962	1.02.0429.1.01.2	DE	0148-33-073	PIPELINE
963	1.02.0430.1.01.3	DE	0148-33-101	RETURN PIPE
964	1.02.0431.1.01.4	DE	0148-33-123	UNION
965	1.02.0432.1.01.5	DE	0148-33-127	ALLEN BOLT 10X45
966	1.02.0433.1.01.6	DE	0148-33-129	O – SEAL
967	1.02.0434.1.01.7	DE	0148-33-130	CHEESE HEAD SCREW
968	1.02.0435.1.01.8	DE	0148-33-131	TOURQUE LIMITER
969	1.02.0436.1.01.9	DE	0148-33-133	WHEEL NUT
970	1.02.0437.1.01.1	DE	0148-33-135	AIR COMPRESSOR
971	1.02.0438.1.01.2	DE	0148-33-137	PRESSURE REGULATOR
972	1.02.0439.1.01.3	DE	0148-33-138	RELIEF VALVE
973	1.02.0440.1.01.4	DE	0148-33-139	VALVE
974	1.02.0441.1.01.5	DE	0148-33-1507	SNAP RING
975	1.02.0442.1.01.6	DE	0148-33-161	BANJO BOLT
976	1.02.0443.1.01.7	DE	0148-33-162	SEALING RING
977	1.02.0444.1.01.8	DE	0148-33-163	PIPELINE
978	1.02.0445.1.01.9	DE	0148-33-164	ADAPTER
979	1.02.0446.1.01.1	DE	0148-33-165	SEALING RING
980	1.02.0447.1.01.2	DE	0148-33-166	SEALING RING
981	1.02.0448.1.01.3	DE	0148-33-167	SOCKET
982	1.02.0449.1.01.4	DE	0148-33-168	PIPELINE
983	1.02.0450.1.01.5	DE	0148-33-169	PIPELINE

984	1.02.0451.1.01.6	DE	0148-33-181	PIPELINE
985	1.02.0452.1.01.7	DE	0148-33-182	SEALING RING
986	1.02.0453.1.01.8	DE	0148-33-183	NUT
987	1.02.0454.1.01.9	DE	0148-33-184	ELBOW
988	1.02.0455.1.01.1	DE	0148-33-185	HOSE CLIPS
989	1.02.0456.1.01.2	DE	0148-33-186	VACUUM HOSE
990	1.02.0457.1.01.3	DE	0148-33-187	VACUUM HOSE
991	1.02.0458.1.01.4	DE	0148-33-188	SOCKET/ADAPTER
992	1.02.0459.1.01.5	DE	0148-33-189	ELBOW
993	1.02.0460.1.01.6	DE	0148-33-3381	STUD
994	1.02.0461.1.01.7	DE	0148-33-7147	LAMINA
995	1.02.0462.1.01.8	DE	0148-33-7554	CYLINDER ROLLER BEARING
996	1.02.0463.1.01.9	DE	0148-33-8473	GASKET
997	1.02.0464.1.01.1	DE	0148-33-8474	LEAF SPRING
998	1.02.0465.1.01.2	DE	0148-33-8475	GASKET
999	1.02.0466.1.01.3	DE	0148-33-8477	GASKET
1000	1.02.0467.1.01.4	DE	0148-33-9590	GASKET
1001	1.02.0468.1.01.5	DE	0148-33-9710	VALVE
1002	1.02.0469.1.01.6	DE	0148-33-9896	SCRAPER RING
1003	1.02.0470.1.01.7	DE	0148-33-9904	PISTON
1004	1.02.0471.1.01.8	DE	0148-33-9905	OIL RING
1005	1.02.0472.1.01.9	DE	0148-39-001	EXHAUST THERMOSTAT
1006	1.02.0473.1.01.1	DE	0148-39-002	LUB OIL PIPE FOR BLOWER
1007	1.02.0474.1.01.2	DE	0148-39-003	LUB OIL PIPE FOR BLOWER
1008	1.02.0475.1.01.3	DE	0148-39-004	LUB OIL PIPE
1009	1.02.0476.1.01.4	DE	0148-39-005	LUB OIL PIPE
1010	1.02.0477.1.01.5	DE	0148-39-007	UNION FOR LUB OIL PIPE
1011	1.02.0478.1.01.6	DE	0148-39-009	RUBBER HOSE
1012	1.02.0479.1.01.7	DE	0148-39-013	BEND FOR LUB OIL PIPE
1013	1.02.0480.1.01.8	DE	0148-39-014	UNION FOR LUB OIL PIPE
1014	1.02.0481.1.01.9	DE	0148-39-015	WASHER
1015	1.02.0482.1.01.1	DE	0148-39-033	METAL PIPE
1016	1.02.0483.1.01.2	DE	0148-39-034	WASHER
1017	1.02.0484.1.01.3	DE	0148-39-035	UNION
1018	1.02.0485.1.01.4	DE	0148-39-038	RUBBER HOSE
1019	1.02.0486.1.01.5	DE	0148-39-093	HEXAGON NUT
1020	1.02.0487.1.01.6	DE	0148-39-095	THRUST PAD
1021	1.02.0488.1.01.7	DE	0148-39-096	CLAMPING STRAP
1022	1.02.0489.1.01.8	DE	0148-39-097	HEXAGON BOLT
1023	1.02.0490.1.01.9	DE	0148-39-098	SPRING WASHER
1024	1.02.0491.1.01.1	DE	0148-39-099	DOMED WASHER
1025	1.02.0492.1.01.2	DE	0148-39-100	O – SEAL
1026	1.02.0493.1.01.3	DE	0148-39-101	RETURN PIPE
1027	1.02.0494.1.01.4	DE	0148-39-107	SOCKET/ADAPTER
1028	1.02.0495.1.01.5	DE	0148-39-109	HEXAGON BOLT
1029	1.02.0496.1.01.6	DE	0148-39-110	SPRING WASHER
1030	1.02.0497.1.01.7	DE	0148-39-111	PLAIN WASHER
1031	1.02.0498.1.01.8	DE	0148-39-112	COVER
1032	1.02.0499.1.01.9	DE	0148-39-113	O – SEAL
1033	1.02.0500.1.01.1	DE	0148-39-114	RING
1034	1.02.0501.1.01.2	DE	0148-39-115	BOLT
1035	1.02.0502.1.01.3	DE	0148-39-116	BOWL
1036	1.02.0503.1.01.4	DE	0148-39-117	SPACER
1037	1.02.0504.1.01.5	DE	0148-39-118	THRUST WASHER
1038	1.02.0505.1.01.6	DE	0148-39-119	BLOWER FAN COUPLING O SEAL
1039	1.02.0506.1.01.7	DE	0148-39-120	CLUTCH/ COUPLING
1040	1.02.0507.1.01.8	DE	0148-39-121	WASHER
1041	1.02.0508.1.01.9	DE	0148-39-122	CIRCLIP
1042	1.02.0509.1.01.1	DE	0148-39-123	BALL BEARING
1043	1.02.0510.1.01.2	DE	0148-39-125	ROT SHAFT LIP SEAL
1044	1.02.0511.1.01.3	DE	0148-39-126	SPACER RING
1045	1.02.0512.1.01.4	DE	0148-39-127	O SEAL
1046	1.02.0513.1.01.5	DE	0148-39-128	FAN ASSEMBLY
1047	1.02.0514.1.01.6	DE	0148-39-129	LOCK WASHER
1048	1.02.0515.1.01.7	DE	0148-39-130	SLOTTED ROUND NUT
1049	1.02.0516.1.01.8	DE	0148-39-131	ROT SHAFT LIP SEAL
1050	1.02.0517.1.01.9	DE	0148-39-132	DRIVER/ACTUATOR
1051	1.02.0518.1.01.1	DE	0148-39-134	SPRING WASHER
1052	1.02.0519.1.01.2	DE	0148-39-135	COOLING BLOWER
1053	1.02.0520.1.01.3	DE	0148-39-161	HEXAGON BOLT
1054	1.02.0521.1.01.4	DE	0148-39-162	WASHER
1055	1.02.0522.1.01.5	DE	0148-39-165	BRACKET
1056	1.02.0523.1.01.6	DE	0148-39-166	CHEESE HEAD SCREW
1057	1.02.0524.1.01.7	DE	0148-39-169	BEARING BUSH
1058	1.02.0525.1.01.8	DE	0148-39-170	COUPLING PIECE
1059	1.02.0526.1.01.9	DE	0148-39-171	ROT SHAFT LIP SEAL
1060	1.02.0527.1.01.1	DE	0148-39-174	BEARING

1061	1.02.0528.1.01.2	DE	0148-39-176	BUSH
1062	1.02.0529.1.01.3	DE	0148-39-178	SEALING RING
1063	1.02.0530.1.01.4	DE	0148-39-184	HOUSING/CASE
1064	1.02.0531.1.01.5	DE	0148-39-185	TRANSMISSION BOLT
1065	1.02.0532.1.01.6	DE	0148-39-191	SPRING WASHER
1066	1.02.0533.1.01.7	DE	0148-39-196	HEXAGON NUT
1067	1.02.0534.1.01.8	DE	0148-39-197	INTERMEDIATE SHAFT
1068	1.02.0535.1.01.9	DE	0148-39-198	RUBBER STOP
1069	1.02.0536.1.01.1	DE	0148-39-199	BOLT
1070	1.02.0537.1.01.2	DE	0148-39-200	DRIVE SHAFT
1071	1.02.0538.1.01.3	DE	0148-39-201	ROT SHAFT LIP SEAL
1072	1.02.0539.1.01.4	DE	0148-39-202	CIRCLIP
1073	1.02.0540.1.01.5	DE	0148-39-203	BALL BEARING
1074	1.02.0541.1.01.6	DE	0148-39-204	SPACER SLEEVE
1075	1.02.0542.1.01.7	DE	0148-39-205	CYL ROLLER BEARING
1076	1.02.0543.1.01.8	DE	0148-39-206	BL DRIVE GEAR
1077	1.02.0544.1.01.9	DE	0148-39-208	THRUST WASHER
1078	1.02.0545.1.01.1	DE	0148-39-209	BEARING BUSH
1079	1.02.0546.1.01.2	DE	0148-39-210	DRIVER/ACTUATOR
1080	1.02.0547.1.01.3	DE	0148-39-213	HEXAGON BOLT
1081	1.02.0548.1.01.4	DE	0148-39-214	O RING
1082	1.02.0549.1.01.5	DE	0148-39-217	O RING
1083	1.02.0550.1.01.6	DE	0148-39-218	COUPLING DISC
1084	1.02.0551.1.01.7	DE	0148-39-241	BLOWER OIL SUPPLY PIPE
1085	1.02.0552.1.01.8	DE	0148-39-242	BLOWER OIL SUPPLY PIPE
1086	1.02.0553.1.01.9	DE	0148-39-243	BLOWER OIL SUPPLY PIPE
1087	1.02.0554.1.01.1	DE	0148-39-256	RUBBER SLEEVE
1088	1.02.0555.1.01.2	DE	0148-39-287	PIPE
1089	1.02.0556.1.01.3	DE	0148-39-293	SOCKET/ADAPTER
1090	1.02.0557.1.01.4	DE	0148-39-295	SOLENOID VALVE
1091	1.02.0558.1.01.5	DE	0148-40-002	BOLT 6X25
1092	1.02.0559.1.01.6	DE	0148-40-004	PLATE
1093	1.02.0560.1.01.7	DE	0148-40-011	COVER
1094	1.02.0561.1.01.8	DE	0148-40-013	COVER
1095	1.02.0562.1.01.9	DE	0148-40-014	HEXAGON BOLT
1096	1.02.0563.1.01.1	DE	0148-40-017	RUBBER SECTION
1097	1.02.0564.1.01.2	DE	0148-40-018	COVER
1098	1.02.0565.1.01.3	DE	0148-40-019	SEALING SECTION
1099	1.02.0566.1.01.4	DE	0148-40-020	COVER
1100	1.02.0567.1.01.5	DE	0148-40-023	PLAIN WASHER
1101	1.02.0568.1.01.6	DE	0148-40-024	SEALING SECTION
1102	1.02.0569.1.01.7	DE	0148-40-025	RUBBER SECTION
1103	1.02.0570.1.01.8	DE	0148-40-029	SIDE BUFFER
1104	1.02.0571.1.01.9	DE	0148-40-032	LOCK
1105	1.02.0572.1.01.1	DE	0148-40-033	PLATE
1106	1.02.0573.1.01.2	DE	0148-40-034	COVER
1107	1.02.0574.1.01.3	DE	0148-40-035	HEXAGON BOLT
1108	1.02.0575.1.01.4	DE	0148-40-036	SEALING SECTION
1109	1.02.0576.1.01.5	DE	0148-40-037	PLUG
1110	1.02.0577.1.01.6	DE	0148-40-038	COVER
1111	1.02.0578.1.01.7	DE	0148-40-040	PLUG
1112	1.02.0579.1.01.8	DE	0148-40-043	RUBBER PIECE
1113	1.02.0580.1.01.9	DE	0148-40-047	PLUG
1114	1.02.0581.1.01.1	DE	0148-40-057	SEALING SECTION
1115	1.02.0582.1.01.2	DE	0148-40-089	HEXAGON NUT
1116	1.02.0583.1.01.3	DE	0148-40-090	RUBBER BUSH
1117	1.02.0584.1.01.4	DE	0148-40-125	WASHER
1118	1.02.0585.1.01.5	DE	0148-40-127	NUT
1119	1.02.0586.1.01.6	DE	0148-40-130	BRACKET
1120	1.02.0587.1.01.7	DE	0148-40-131	BRACKET
1121	1.02.0588.1.01.8	DE	0148-40-134	CONNECTING SHEET
1122	1.02.0589.1.01.9	DE	0148-40-139	RUBBER STOP
1123	1.02.0590.1.01.1	DE	0148-40-143	FRONT PLATE
1124	1.02.0591.1.01.2	DE	0148-40-145	CLAMPING SECTION
1125	1.02.0592.1.01.3	DE	0148-40-148	BRACKET
1126	1.02.0593.1.01.4	DE	0148-40-149	BOLT
1127	1.02.0594.1.01.5	DE	0148-40-156	SEALING SECTION
1128	1.02.0595.1.01.6	DE	0148-40-162	PLAIN WASHER
1129	1.02.0596.1.01.7	DE	0148-40-179	BRACKET AVM'S
1130	1.02.0597.1.01.8	DE	0148-40-181	CASE/BOX
1131	1.02.0598.1.01.9	DE	0148-40-183	CASE/BOX
1132	1.02.0599.1.01.1	DE	0148-40-188	COOL, AIR COWLING
1133	1.02.0600.1.01.2	DE	0148-40-189	RUBBER SEAL
1134	1.02.0601.1.01.3	DE	0148-40-190	HEXAGON BOLT
1135	1.02.0602.1.01.4	DE	0148-40-191	COVER
1136	1.02.0603.1.01.5	DE	0148-40-195	RAIL/BAR
1137	1.02.0604.1.01.6	DE	0148-40-196	FRAME

1138	1.02.0605.1.01.7	DE	0148-40-197	RAIL/BAR
1139	1.02.0606.1.01.8	DE	0148-40-198	SEALING STRIP
1140	1.02.0607.1.01.9	DE	0148-40-199	SECTIONAL RUBBER
1141	1.02.0608.1.01.1	DE	0148-41-013	COOLING AIR BAFFLE
1142	1.02.0609.1.01.2	DE	0148-41-014	STUD
1143	1.02.0610.1.01.3	DE	0148-41-015	EXHAUST GASKET
1144	1.02.0611.1.01.4	DE	0148-41-016	LOCKING COLLAR
1145	1.02.0612.1.01.5	DE	0148-41-018	HEXAGON NUT
1146	1.02.0613.1.01.6	DE	0148-41-019	EXHAUST MANIFOLD
1147	1.02.0614.1.01.7	DE	0148-41-081	NUT
1148	1.02.0615.1.01.8	DE	0148-41-082	STUD
1149	1.02.0616.1.01.9	DE	0148-41-083	EXHAUST MANIFOLD
1150	1.02.0617.1.01.1	DE	0148-41-084	RECTANGULAR RING
1151	1.02.0618.1.01.2	DE	0148-41-086	GASKET
1152	1.02.0619.1.01.3	DE	0148-41-088	NUT
1153	1.02.0620.1.01.4	DE	0148-41-089	PACKING COMPOUND
1154	1.02.0621.1.01.5	DE	0148-41-090	EXHAUST MANIFOLD
1155	1.02.0622.1.01.6	DE	0148-41-121	GASKET
1156	1.02.0623.1.01.7	DE	0148-41-122	SEALING RING
1157	1.02.0624.1.01.8	DE	0148-41-153	CORRUGATED TUBE
1158	1.02.0625.1.01.9	DE	0148-41-154	SQUARE FANGE
1159	1.02.0626.1.01.1	DE	0148-41-155	SEGMENT INNER RING
1160	1.02.0627.1.01.2	DE	0148-43-000	REPAIR KIT
1161	1.02.0628.1.01.3	DE	0148-43-001	BOLT
1162	1.02.0629.1.01.4	DE	0148-43-003	TURBOCHARGER
1163	1.02.0630.1.01.5	DE	0148-43-004	GASKET
1164	1.02.0631.1.01.6	DE	0148-43-006	TURBOCHARGER
1165	1.02.0632.1.01.7	DE	0148-43-007	BRACKET
1166	1.02.0633.1.01.8	DE	0148-43-008	STUD
1167	1.02.0634.1.01.9	DE	0148-43-011	NUT
1168	1.02.0635.1.01.1	DE	0148-43-013	HEXAGON BOLT
1169	1.02.0636.1.01.2	DE	0148-43-014	HEXAGON NUT
1170	1.02.0637.1.01.3	DE	0148-43-015	PLAIN WASHER
1171	1.02.0638.1.01.4	DE	0148-43-016	CLAMP
1172	1.02.0639.1.01.5	DE	0148-43-017	COVER
1173	1.02.0640.1.01.6	DE	0148-43-018	CLAMP
1174	1.02.0641.1.01.7	DE	0148-43-020	COVER
1175	1.02.0642.1.01.8	DE	0148-43-5628	RUBBER SLEEVE
1176	1.02.0643.1.01.9	DE	0148-43-8856	TURBO SUPPLY PIPE
1177	1.02.0644.1.01.1	DE	0148-43-8912	TURBO SUPPLY PIPE
1178	1.02.0645.1.01.2	DE	0148-44-060	CLAMPING STRAP
1179	1.02.0646.1.01.3	DE	0148-44-066	SET OF V BELTS
1180	1.02.0647.1.01.4	DE	0148-44-126	PLUG
1181	1.02.0648.1.01.5	DE	0148-44-129	HEXAGON BOLT
1182	1.02.0649.1.01.6	DE	0148-44-241	STARTER
1183	1.02.0650.1.01.7	DE	0148-44-244	STUD
1184	1.02.0651.1.01.8	DE	0148-46-001	MOUNTING FOOT
1185	1.02.0652.1.01.9	DE	0148-46-002	WASHER
1186	1.02.0653.1.01.1	DE	0148-46-005	MOUNTING FOOT
1187	1.02.0654.1.01.2	DE	0148-46-006	HEXAGON BOLT
1188	1.02.0655.1.01.3	DE	0148-48-017	OIL PRESSURE SWITCH
1189	1.02.0656.1.01.4	DE	0148-48-029	BRACKET
1190	1.02.0657.1.01.5	DE	0148-48-034	CONNECTOR
1191	1.02.0658.1.01.6	DE	0148-48-081	WIRING SET INTERNAL
1192	1.02.0659.1.01.7	DE	0148-48-083	WIRING SET
1193	1.02.0660.1.01.8	DE	0148-51-001	HEXAGON BOLT
1194	1.02.0661.1.01.9	DE	0148-51-002	SPRING WASHER
1195	1.02.0662.1.01.1	DE	0148-51-007	BUSH
1196	1.02.0663.1.01.2	DE	0148-51-010	FLANGE
1197	1.02.0664.1.01.3	DE	0148-51-011	DRIVING TAG
1198	1.02.0665.1.01.4	DE	0148-51-012	SEAL RING
1199	1.02.0666.1.01.5	DE	0148-51-013	SEAL RING
1200	1.02.0667.1.01.6	DE	0148-51-019	LUB OIL SENSOR
1201	1.02.0668.1.01.7	DE	0148-51-020	THERMOSTAT
1202	1.02.0669.1.01.8	DE	0148-51-021	TEMPER TRANSMITTER CYL. HEAD
1203	1.02.0670.1.01.9	DE	0148-51-028	TEMPER TRANSMITTER LUB OIL
1204	1.02.0671.1.01.1	DE	0148-51-053	TACHO GENERATOR
1205	1.02.0672.1.01.2	DE	0148-52-002	CONNECTING HOUSING
1206	1.02.0673.1.01.3	DE	0148-52-003	BELL HOUSING BOLT
1207	1.02.0674.1.01.4	DE	0148-52-004	BELL HOUSING BOLT
1208	1.02.0675.1.01.5	DE	0148-52-005	GASKET
1209	1.02.0676.1.01.6	DE	0148-52-006	PLATE
1210	1.02.0677.1.01.7	DE	0148-52-007	CHEESE HEAD SCREW
1211	1.02.0678.1.01.8	DE	0148-52-121	CLUTCH PLATE
1212	1.02.0679.1.01.9	DE	0148-52-122	THRUST PLATE
1213	1.02.0680.1.01.1	DE	0148-52-125	DISENGAGER
1214	1.02.0681.1.01.2	DE	0148-52-126	CLUTCH LEVER

1215	1.02.0682.1.01.3	DE	0148-52-127	BALL SEAT
1216	1.02.0683.1.01.4	DE	0148-52-128	BALL STUD
1217	1.02.0684.1.01.5	DE	0148-52-129	CONNECTING PLATE
1218	1.02.0685.1.01.6	DE	0148-52-132	ROT. SHAFT LIP SEAL
1219	1.02.0686.1.01.7	DE	0148-52-133	BALL BEARING
1220	1.02.0687.1.01.8	DE	0148-52-134	BELL HOUSING
1221	1.02.0688.1.01.9	DE	0148-52-136	HEXAGON BOLT
1222	1.02.0689.1.01.1	DE	0148-52-137	DRIVE SHAFT
1223	1.02.0690.1.01.2	DE	0148-52-139	POWER CYLINDER
1224	1.02.0691.1.01.3	DE	0148-52-141	HEXAGON BOLT
1225	1.02.0692.1.01.4	DE	0148-52-2480	HEXAGON BOLT
1226	1.02.0693.1.01.5	DE	0148-52-4843	O – SEAL
1227	1.02.0694.1.01.6	DE	0148-52-6312	BUSH
1228	1.02.0695.1.01.7	DE	0148-52-6345	COVER
1229	1.02.0696.1.01.8	DE	0148-52-6431	ROT. SHAFT LIP SEAL
1230	1.02.0697.1.01.9	DE	0148-52-6433	ROT. SHAFT LIP SEAL
1231	1.02.0698.1.01.1	DE	0148-56-001	BALL PIN
1232	1.02.0699.1.01.2	DE	0148-56-002	SEALING RING
1233	1.02.0700.1.01.3	DE	0148-56-003	YOKE
1234	1.02.0701.1.01.4	DE	0148-56-004	LINK
1235	1.02.0702.1.01.5	DE	0148-56-005	STOPING LEVER
1236	1.02.0703.1.01.6	DE	0148-56-006	BUSH
1237	1.02.0704.1.01.7	DE	0148-56-007	BUSH
1238	1.02.0705.1.01.8	DE	0148-56-008	WASHER
1239	1.02.0706.1.01.9	DE	0148-56-009	BOLT
1240	1.02.0707.1.01.1	DE	0148-56-010	BALL SEAT
1241	1.02.0708.1.01.2	DE	0148-56-011	BOLT
1242	1.02.0709.1.01.3	DE	0148-56-012	PLAIN WASHER
1243	1.02.0710.1.01.4	DE	0148-56-013	BALL JOINT
1244	1.02.0711.1.01.5	DE	0148-56-014	CHEESE HEAD SCREW
1245	1.02.0712.1.01.6	DE	0148-56-015	PLAIN WASHER
1246	1.02.0713.1.01.7	DE	0148-56-016	CLAMPING RING
1247	1.02.0714.1.01.8	DE	0148-56-017	BOLT
1248	1.02.0715.1.01.9	DE	0148-56-018	SPACER
1249	1.02.0716.1.01.1	DE	0148-56-019	BRACKET
1250	1.02.0717.1.01.2	DE	0148-56-020	WASHER
1251	1.02.0718.1.01.3	DE	0148-56-022	NUT
1252	1.02.0719.1.01.4	DE	0148-56-023	BRACKET
1253	1.02.0720.1.01.5	DE	0148-56-024	WASHER
1254	1.02.0721.1.01.6	DE	0148-56-025	BELLOW
1255	1.02.0722.1.01.7	DE	0148-56-026	WASHER
1256	1.02.0723.1.01.8	DE	0148-56-027	SOLENOID
1257	1.02.0724.1.01.9	DE	0148-56-028	HOSE CLIP
1258	1.02.0725.1.01.1	DE	0148-56-030	SOCKET
1259	1.02.0726.1.01.2	DE	0148-56-031	SOLENOID SPRING
1260	1.02.0727.1.01.3	DE	0148-56-032	NUT
1261	1.02.0728.1.01.4	DE	0148-56-033	BELLOWS
1262	1.02.0729.1.01.5	DE	0148-58-001	HOSE CLIP
1263	1.02.0730.1.01.6	DE	0148-58-002	RUBBER SLEEVE
1264	1.02.0731.1.01.7	DE	0148-58-005	RUBBER STOP
1265	1.02.0732.1.01.8	DE	0148-58-008	GASKET
1266	1.02.0733.1.01.9	DE	0148-58-016	RUBBER SLEEVE
1267	1.02.0734.1.01.1	DE	0148-58-017	HOSE CLIP
1268	1.02.0735.1.01.2	DE	0148-61-028	SEALING SECTION
1269	1.02.0736.1.01.3		Shifted to Annexure II	
1270	1.02.0737.1.01.4	DE	0148-81-010	EXPANSION TANK
1271	1.02.0738.1.01.5	DE	0148-90-001	GASKET SET
1272	1.02.0739.1.01.6	DE	0165-01-013	Bearing Bush
1273	1.02.0740.1.01.7	DE	0165-01-014	Bearing Bush
1274	1.02.0741.1.01.8	DE	0165-01-016	Nozzle
1275	1.02.0742.1.01.9	DE	0165-01-017	Relief Valve
1276	1.02.0743.1.01.1	DE	0165-01-029	Rot. Shaft Lip Seal
1277	1.02.0744.1.01.2	DE	0165-01-030	Gasket
1278	1.02.0745.1.01.3	DE	0165-01-046	Dipstick
1279	1.02.0746.1.01.4	DE	0165-01-051	Oil Separator
1280	1.02.0747.1.01.5	DE	0165-01-052	O-Seal
1281	1.02.0748.1.01.6	DE	0165-01-053	Hose Clip
1282	1.02.0749.1.01.7	DE	0165-01-054	Rubber Sleeve
1283	1.02.0750.1.01.8	DE	0165-01-055	Breather Pipe
1284	1.02.0751.1.01.9	DE	0165-01-093	Rot. Shaft Lip Seal
1285	1.02.0752.1.01.1	DE	0165-01-101	Gasket
1286	1.02.0753.1.01.2	DE	0165-01-127	Sealing Ring
1287	1.02.0754.1.01.3	DE	0165-01-130	Packing Compound
1288	1.02.0755.1.01.4	DE	0165-01-161	Cylinder Liner
1289	1.02.0756.1.01.5	DE	0165-01-162	Oil Seal
1290	1.02.0757.1.01.6	DE	0165-02-001	Gasket
1291	1.02.0758.1.01.7	DE	0165-02-003	Screw Plug

1292	1.02.0759.1.01.8	DE	0165-02-004	Sealing Ring
1293	1.02.0760.1.01.9	DE	0165-05-004	Main Bearing (Std)
1294	1.02.0761.1.01.1	DE	0165-05-004/1	Main Bearing (1st U/S)
1295	1.02.0762.1.01.2	DE	0165-05-004/2	Main Bearing (2nd U/S)
1296	1.02.0763.1.01.3	DE	0165-05-004/3	Main Bearing (3rd U/S)
1297	1.02.0764.1.01.4	DE	0165-05-004/4	Main Bearing (4th U/S)
1298	1.02.0765.1.01.5	DE	0165-05-005	Thrust Washer
1299	1.02.0766.1.01.6	DE	0165-05-006	Big End Bearing (Std)
1300	1.02.0767.1.01.7	DE	0165-05-006/1	Big End Bearing (1st U/S)
1301	1.02.0768.1.01.8	DE	0165-05-006/2	Big End Bearing (2nd U/S)
1302	1.02.0769.1.01.9	DE	0165-05-006/3	Big End Bearing (3rd U/S)
1303	1.02.0770.1.01.1	DE	0165-05-047	Gear Rim
1304	1.02.0771.1.01.2	DE	0165-05-056	Ball Bearing
1305	1.02.0772.1.01.3	DE	0165-06-001	Connecting Rod
1306	1.02.0773.1.01.4	DE	0165-06-002	Big End Bolt
1307	1.02.0774.1.01.5	DE	0165-06-003	Big End Bush
1308	1.02.0775.1.01.6	DE	0165-07-001	Piston
1309	1.02.0776.1.01.7	DE	0165-07-007	Set of Piston Rings
1310	1.02.0777.1.01.8	DE	0165-08-001	Valve Collet
1311	1.02.0778.1.01.9	DE	0165-08-003	Valve Spring
1312	1.02.0779.1.01.1	DE	0165-08-004	Valve Stem Seal
1313	1.02.0780.1.01.2	DE	0165-08-005	Valve Guide
1314	1.02.0781.1.01.3	DE	0165-08-009	Inlet Valve Seat
1315	1.02.0782.1.01.4	DE	0165-08-010	Exhaust Valve Seat
1316	1.02.0783.1.01.5	DE	0165-08-011	Inlet Valve
1317	1.02.0784.1.01.6	DE	0165-08-012	Exhaust Valve
1318	1.02.0785.1.01.7	DE	0165-08-013	Cylinder Head
1319	1.02.0786.1.01.8	DE	0165-08-014	Safety/Lock. Agent
1320	1.02.0787.1.01.9	DE	0165-08-016	Cylinder Head Gasket (1Notch)
1321	1.02.0788.1.01.1	DE	0165-08-017	Cylinder Head Gasket (2Notch)
1322	1.02.0789.1.01.2	DE	0165-08-018	Cylinder Head Gasket (3Notch)
1323	1.02.0790.1.01.3	DE	0165-08-019	Cheese Head Screw
1324	1.02.0791.1.01.4	DE	0165-08-022	Valve Mechan. Cover
1325	1.02.0792.1.01.5	DE	0165-08-023	Gasket
1326	1.02.0793.1.01.6	DE	0165-08-024	Filler Cap
1327	1.02.0794.1.01.7	DE	0165-08-026	Profile Washer
1328	1.02.0795.1.01.8	DE	0165-08-028	Gasket
1329	1.02.0796.1.01.9	DE	0165-10-001	One-Piece Camshaft
1330	1.02.0797.1.01.1	DE	0165-10-002	Idler Gear
1331	1.02.0798.1.01.2	DE	0165-10-003	Toothed Gear
1332	1.02.0799.1.01.3	DE	0165-10-004	Parallel Pin
1333	1.02.0800.1.01.4	DE	0165-11-005	Hexagon Nut
1334	1.02.0801.1.01.5	DE	0165-11-006	Adjusting Screw
1335	1.02.0802.1.01.6	DE	0165-11-009	Push Rod
1336	1.02.0803.1.01.7	DE	0165-11-010	Valve Tappet
1337	1.02.0804.1.01.8	DE	0165-14-004	Oil Pressure Pump
1338	1.02.0805.1.01.9	DE	0165-15-001	Spin-On Oil Filter
1339	1.02.0806.1.01.1	DE	0165-15-041	Gasket
1340	1.02.0807.1.01.2	DE	0165-15-049	Lubricant Oil Cooler
1341	1.02.0808.1.01.3	DE	0165-16-043	Gasket
1342	1.02.0809.1.01.4	DE	0165-16-054	Gasket
1343	1.02.0810.1.01.5	DE	0165-16-073	Rubber Hose
1344	1.02.0811.1.01.6	DE	0165-16-074	Spring Band Clamp
1345	1.02.0812.1.01.7	DE	0165-17-001	Fuel Injection Pump
1346	1.02.0813.1.01.8	DE	0165-17-002	Supply Pump
1347	1.02.0814.1.01.9	DE	0165-17-012	Supply Pump
1348	1.02.0815.1.01.1	DE	0165-19-002	Nozzle
1349	1.02.0816.1.01.2	DE	0165-19-003	Sealing Ring
1350	1.02.0817.1.01.3	DE	0165-19-004	Fuel Injector
1351	1.02.0818.1.01.4	DE	0165-19-006	Union Screw
1352	1.02.0819.1.01.5	DE	0165-20-010	Spin-On Fuel Filter
1353	1.02.0820.1.01.6	DE	0165-20-017	Filter Cartridge
1354	1.02.0821.1.01.7	DE	0165-21-001	High Pressure Pipe
1355	1.02.0822.1.01.8	DE	0165-21-002	High Pressure Pipe
1356	1.02.0823.1.01.9	DE	0165-21-003	High Pressure Pipe
1357	1.02.0824.1.01.1	DE	0165-21-004	High Pressure Pipe
1358	1.02.0825.1.01.2	DE	0165-21-005	High Pressure Pipe
1359	1.02.0826.1.01.3	DE	0165-21-006	High Pressure Pipe
1360	1.02.0827.1.01.4	DE	0165-22-046	Gasket
1361	1.02.0828.1.01.5	DE	0165-22-054	Hose Clip
1362	1.02.0829.1.01.6	DE	0165-22-055	Rubber Sleeve
1363	1.02.0830.1.01.7	DE	0165-22-059	Stud
1364	1.02.0831.1.01.8	DE	0165-22-060	Plain Washer
1365	1.02.0832.1.01.9	DE	0165-22-061	Hexagon Nut
1366	1.02.0833.1.01.1	DE	0165-22-081	Hose Clip
1367	1.02.0834.1.01.2	DE	0165-22-082	Rubber Dust Exclud
1368	1.02.0835.1.01.3	DE	0165-22-084	O-Seal

1369	1.02.0836.1.01.4	DE	0165-22-085	Plug
1370	1.02.0837.1.01.5	DE	0165-22-090	Intake Elbow
1371	1.02.0838.1.01.6	DE	0165-22-091	Hose Clip
1372	1.02.0839.1.01.7	DE	0165-22-092	Rubber Sleeve
1373	1.02.0840.1.01.8	Shifted to Annexure II		
1374	1.02.0841.1.01.9	Shifted to Annexure II		
1375	1.02.0842.1.01.1	DE	0165-27-016	Control Unit
1376	1.02.0843.1.01.2	DE	0165-29-007	Tension Spring
1377	1.02.0844.1.01.3	DE	0165-33-001	Air Compressor
1378	1.02.0845.1.01.4	DE	0165-33-003	Toothed Gear
1379	1.02.0846.1.01.5	DE	0165-33-004	O-Seal
1380	1.02.0847.1.01.6	DE	0165-36-001	Cooling System
1381	1.02.0848.1.01.7	DE	0165-36-002	Rubber Mounting
1382	1.02.0849.1.01.8	DE	0165-36-003	Filler Cap
1383	1.02.0850.1.01.9	DE	0165-36-014	Rubber Sleeve
1384	1.02.0851.1.01.1	DE	0165-36-019	Rubber Dust Exclud
1385	1.02.0852.1.01.2	DE	0165-37-001	Gasket
1386	1.02.0853.1.01.3	DE	0165-37-002	O-Seal
1387	1.02.0854.1.01.4	DE	0165-37-003	O-Seal
1388	1.02.0855.1.01.5	DE	0165-37-006	Gasket
1389	1.02.0856.1.01.6	DE	0165-37-025	Repair Kit
1390	1.02.0857.1.01.7	DE	0165-38-009	Gasket
1391	1.02.0858.1.01.8	DE	0165-38-010	Sealing Ring
1392	1.02.0859.1.01.9	DE	0165-38-011	Thermostat
1393	1.02.0860.1.01.1	DE	0165-38-019	Rubber Sleeve
1394	1.02.0861.1.01.2	DE	0165-38-034	Thermostat
1395	1.02.0862.1.01.3	DE	0165-39-003	Suction Fan
1396	1.02.0863.1.01.4	DE	0165-39-043	Rot. Shaft Lip Seal
1397	1.02.0864.1.01.5	DE	0165-41-001	Exhaust Manifold
1398	1.02.0865.1.01.6	DE	0165-41-002	Gasket
1399	1.02.0866.1.01.7	DE	0165-41-003	Hexagon Bolt
1400	1.02.0867.1.01.8	DE	0165-41-006	Hexagon Nut
1401	1.02.0868.1.01.9	DE	0165-41-007	Plain Washer
1402	1.02.0869.1.01.1	DE	0165-41-008	Hexagon Bolt
1403	1.02.0870.1.01.2	DE	0165-41-014	Exhaust Manifold
1404	1.02.0871.1.01.3	DE	0165-41-049	Compensator
1405	1.02.0872.1.01.4	DE	0165-43-001	Turbocharger
1406	1.02.0873.1.01.5	DE	0165-43-002	Hexagon Bolt
1407	1.02.0874.1.01.6	DE	0165-43-005	Core Assembly
1408	1.02.0875.1.01.7	DE	0165-43-008	Repair Kit
1409	1.02.0876.1.01.8	DE	0165-43-043	Stud
1410	1.02.0877.1.01.9	DE	0165-43-045	Hexagon Nut
1411	1.02.0878.1.01.1	DE	0165-44-001	Alternator
1412	1.02.0879.1.01.2	DE	0165-44-010	Narrow V-Belt
1413	1.02.0880.1.01.3	DE	0165-44-041	Self Starter
1414	1.02.0881.1.01.4	DE	0165-44-044	Stud
1415	1.02.0882.1.01.5	DE	0165-44-129	Set Narrow V-Belts
1416	1.02.0883.1.01.6	DE	0165-46-001	Mounting Foot
1417	1.02.0884.1.01.7	DE	0165-46-004	Mounting Foot
1418	1.02.0885.1.01.8	DE	0165-48-025	Impulse Transmitter
1419	1.02.0886.1.01.9	DE	0165-48-041	Interconnect Cable
1420	1.02.0887.1.01.1	DE	0165-48-043	Cable Harness
1421	1.02.0888.1.01.2	DE	0165-51-002	Level Switch
1422	1.02.0889.1.01.3	DE	0165-51-015	Temperature Transmitter
1423	1.02.0890.1.01.4	DE	0165-51-023	Pressure Pickup
1424	1.02.0891.1.01.5	DE	0165-51-025	Temperature Transmitter
1425	1.02.0892.1.01.6	DE	0165-51-026	Temperature Transmitter
1426	1.02.0893.1.01.7	DE	0165-51-029	Pressure Sensor
1427	1.02.0894.1.01.8	DE	0165-51-032	Pressure Sensor
1428	1.02.0895.1.01.9	DE	0165-52-001	Cheese Head Screw
1429	1.02.0896.1.01.1	DE	0165-52-002	Cheese Head Screw
1430	1.02.0897.1.01.2	DE	0165-52-005	Blanking Parts
1431	1.02.0898.1.01.3	DE	0165-52-5070	Rot. Shaft Lip Seal
1432	1.02.0899.1.01.4	DE	0165-52-6916	Cylinder Roller Bearing
1433	1.02.0900.1.01.5	DE	0165-52-6928	Rot. Shaft Lip Seal
1434	1.02.0901.1.01.6	DE	0165-56-021	Solenoid
1435	1.02.0902.1.01.7	DE	0165-56-023	Ball Joint
1436	1.02.0903.1.01.8	DE	0165-90-001	Gasket Set
1437	1.02.0904.1.01.9	DE	0165-90-6336	DEUTZ OIL (20 LTR) (DQC-III)
1438	1.02.0905.1.01.1	DE	0165-90-6337	DEUTZ OIL (208 LTR) (DQC-III)
1439	1.02.0906.1.01.2	DE	0165-90-7991	COOLANT (20 LTR.)
1440	1.02.0907.1.01.3	DE	0165-90-7992	COOLANT (208 LTR.)
1441	1.02.0908.1.01.4	DE	1 120 033 009	COVER PLATE
1442	1.02.0909.1.01.5	DE	1 120 283 000	RADIAL SEAL
1443	1.02.0910.1.01.6	DE	1 120 300 018	EXPANSION BUSHING
1444	1.02.0911.1.01.7	DE	1 120 322 003	STOP BUSHING
1445	1.02.0912.1.01.8	DE	1 120 905 039/533	BEARING

1446	1.02.0913.1.01.9	DE	1 120 905 525	BEARING
1447	1.02.0914.1.01.1	DE	1 124 035 177	ROTOR
1448	1.02.0915.1.01.2	DE	1 124 037 001	ROTOR
1449	1.02.0916.1.01.3	DE	1 124 037 002	ROTOR
1450	1.02.0917.1.01.4	DE	1 125 045 107	STATOR
1451	1.02.0918.1.01.5	DE	1 125 047 005	STATOR
1452	1.02.0919.1.01.6	DE	1 125 825 043	DRIVE END SHIELD
1453	1.02.0920.1.01.7	DE	1 125 827 006	DRIVE END SHIELD
1454	1.02.0921.1.01.8	DE	1 125 827 021	DRIVE END SHIELD
1455	1.02.0922.1.01.9	DE	9 451 037 406	FILTER
1456	1.02.0923.1.01.1	DE	1 127 011 016	PARTS SET
1457	1.02.0924.1.01.2	DE	1 127 011 020	PARTS SET ROTOR
1458	1.02.0925.1.01.3	DE	1 127 011 064	PARTS SET ROTOR
1459	1.02.0926.1.01.4	DE	1 127 011 071	PARTS SET
1460	1.02.0927.1.01.5	DE	1 127 011 072	PARTS SET
1461	1.02.0928.1.01.6	DE	1 127 011 083	PARTS SET CLAMP
1462	1.02.0929.1.01.7	DE	1 127 011 171	PARTS SET ROTOR
1463	1.02.0930.1.01.8	DE	1 127 014 021	CARBON
1464	1.02.0931.1.01.9	DE	1 127 014 030/022	CARBON BRUSH SET
1465	1.02.0932.1.01.1	DE	9 451 037 404	FILTER
1466	1.02.0933.1.01.2	DE	1 127 320 316	RECTIFIER
1467	1.02.0934.1.01.3	DE	1 127 320 550/973	RECTIFIER
1468	1.02.0935.1.01.4	DE	1 127 320 973	RECTIFIER
1469	1.02.0936.1.01.5	DE	1 127 320 976	RECTIFIER
1470	1.02.0937.1.01.6	DE	1 197 311 304	REGULATOR
1471	1.02.0938.1.01.7	DE	1 197 311 315	TRANSISTOR REGULATOR
1472	1.02.0939.1.01.8	DE	1 197 311 317	REGULATOR
1473	1.02.0940.1.01.9	DE	1 197 311 320	REGULATOR
1474	1.02.0941.1.01.1	DE	1 414 612 020	DV SPRING
1475	1.02.0942.1.01.2	DE	1 457 431 003	FILTER
1476	1.02.0943.1.01.3	DE	1 464 612 512	DV SPRING
1477	1.02.0944.1.01.4	DE	1 466 100 312	SHAFT
1478	1.02.0945.1.01.5	DE	9 430 034 293	NOZZLE
1479	1.02.0946.1.01.6	DE	1 466 111 361	CAMPLATE
1480	1.02.0947.1.01.7	DE	1 467 010 059	GASKET KIT
1481	1.02.0948.1.01.8	DE	1 467 030 304	FEED PUMP
1482	1.02.0949.1.01.9	DE	2 418 552 035	DELIVERY VALVE
1483	1.02.0950.1.01.1	DE	1 468 336 480	DISTRIBUTOR HEAD
1484	1.02.0951.1.01.2	DE	2 418 552 003	DELIVERY VALVE
1485	1.02.0952.1.01.3	DE	2 418 552 027	DELIVERY VALVE
1486	1.02.0953.1.01.4	DE	1 468 532 247	DELIVERY VALVE
1487	1.02.0954.1.01.5	DE	1 900 900 361	BEARING
1488	1.02.0955.1.01.6	DE	1 900 900 602	BEARING
1489	1.02.0956.1.01.7	DE	1 900 905 167	BEARING
1490	1.02.0957.1.01.8	DE	1 900 910 024	BEARING
1491	1.02.0958.1.01.9	DE	1 900 910 240	BEARING
1492	1.02.0959.1.01.1	DE	2 418 455 045	ELEMENT
1493	1.02.0960.1.01.2	DE	1 900 910 241	BEARING
1494	1.02.0961.1.01.3	DE	1120905031/107/105	BEARING
1495	1.02.0962.1.01.4	DE	2 000 212 000	RADIAL SEAL
1496	1.02.0963.1.01.5	DE	2 000 220 080	STOP BUSHING
1497	1.02.0964.1.01.6	DE	2 418 455 030	ELEMENT
1498	1.02.0965.1.01.7	DE	2 000 301 015	BUSHING
1499	1.02.0966.1.01.8	DE	2 000 301 016	BUSH
1500	1.02.0967.1.01.9	DE	2 000 328 021	STOP BUSHING
1501	1.02.0968.1.01.1	DE	2 000 910 002	BEARING
1502	1.02.0969.1.01.2	DE	2 000 910 005	BEARING
1503	1.02.0970.1.01.3	DE	2 418 455 026	ELEMENT
1504	1.02.0971.1.01.4	DE	2 004 005 023/024	ARMATURE
1505	1.02.0972.1.01.5	DE	2 004 125 083	EXCITATION WINDING
1506	1.02.0973.1.01.6	DE	2 005 825 087	DRIVE END SHAFT
1507	1.02.0974.1.01.7	DE	2 005 825 242	DRIVE END SHAFT
1508	1.02.0975.1.01.8	DE	2 417 010 027	GASKET KIT
1509	1.02.0976.1.01.9	DE	2 006 209 492	PINION
1510	1.02.0977.1.01.1	DE	2 006 382 018	PINION
1511	1.02.0978.1.01.2	DE	2 006 401 527	MULTIPLATE CLUTCH
1512	1.02.0979.1.01.3	DE	2 007 010 032	PARTS SET
1513	1.02.0980.1.01.4	DE	2 007 011 029	TERMINAL PARTS SET
1514	1.02.0981.1.01.5	DE	2 007 011 069	PARTS SET
1515	1.02.0982.1.01.6	DE	2 007 011 070	TERMINAL PARTS SET
1516	1.02.0983.1.01.7	DE	2 007 014 063	CARBON
1517	1.02.0984.1.01.8	DE	2 007 014 070	CARBON
1518	1.02.0985.1.01.9		Repeated item	
1519	1.02.0986.1.01.1	DE	2 120 905 000	DEEP-GROOVE BALL BEARING
1520	1.02.0987.1.01.2	DE	2 120 910 001	CYL. ROLLER BEARING
1521	1.02.0988.1.01.3	DE	2 414 614 002	DV SPRING
1522	1.02.0989.1.01.4	DE	2 417 010 023	GASKET KIT

1523	1.02.0990.1.01.5			Repeated item
1524	1.02.0991.1.01.6	DE	9 451 037 407	FILTER
1525	1.02.0992.1.01.7	DE	9 451 037 409	FILTER
1526	1.02.0993.1.01.8	DE	2102211	REDUCTION
1527	1.02.0994.1.01.9	DE	ABA-50-65/12	HOSE CLIP
1528	1.02.0995.1.01.1	DE	NW110X6MM-90LG	HOSE
1529	1.02.0996.1.01.2	DE	0148-44-24	self starter for BCM
1530	1.02.0997.1.01.3	DE	0148-38-295	SOLENOID VALVE
1531	1.02.0998.1.01.4	DE	0148-16-168/10	PIPE LINE
1532	1.02.0999.1.01.5	DE	0165-20-029	FILTER ELEMENT
1533	1.02.1000.1.01.6	DE	0165-20-030	GASKET SET
1534	1.02.1001.1.01.7	DE	0165-44-131	EYE Bolt(V-belt Tensioning bolts)
1535	1.02.1002.1.01.8	DE	0148-48-017 (0.5BAR)	PRESSURE SWITCH (0.5BAR)
1536	1.02.1003.1.01.9	DE	0148-48-017 (2.5BAR)	PRESSURE SWITCH(2.5BAR)
1537	1.02.1004.1.01.1	DE	0150A-22-043 (01319258)	AIR FILTER CATRIDGE
1538	1.02.1005.1.01.2	DE	0150A-22-044 (118 0871)	AIR FILTER CATRIDGE
1539	1.02.1006.1.01.3	DE	0148-22-3903	AIR FILTER INNER
1540	1.02.1007.1.01.4	DE	0148-22-2303	AIR FILTER OUTER
1541	1.02.1008.1.01.5	DE	0150A-15-009/ 1183574	SPIN ON OIL FILTER
1542	1.02.1009.1.01.6	DE	0150A-20-007/ 1181917	SPIN ON FUEL FILTER
1543	1.02.1010.1.01.7	DE	0150A-22-043 /0131-9258	AIR FILTER CATRIDGE
1544	1.02.1011.1.01.8	DE	0150A-22-044/0118- 0871	AIR FILTER CATRIDGE
1545	1.02.1012.1.01.9	DE	0150A-44-105/40169990	NARROW V BELT
1546	1.02.1013.1.01.1	DE	0150A-39-147/40169990	NARROW V BELT
1547	1.02.1014.1.01.2	DE	0150A-01-095	TENSION PULLEY
1548	1.02.1015.1.01.3	DE	0165-33-012	VACCU/COMPRESSOR HOSE
1549	1.02.1016.1.01.4	DE	0165-20-010-V08	Spin-On Fuel Filter
1550	1.02.1017.1.01.5	DE	0165-15-001-V08	Spin-On Oil Filter
1551	1.02.1018.1.01.6	DE	0165-20-075-V08	Filter Cartridge
1552	1.02.1019.1.01.7	DE	0165-22-248-V08	Filter Insert
1553	1.02.1020.1.01.8	DE	0165-22-249-V08	Safety Cartridge
1554	1.02.1021.1.01.9	DE	0148-22-013	SEALING NUT
1555	1.03.0001.1.01.7	GR	123209450107	NON MARINE AFTER COOLER
1556	1.03.0002.1.01.8	GR	1200240183	DB FILTER 028
1557	1.03.0003.1.01.9	GR	1200240911	FILT. ELEMENT WITH O RING
1558	1.03.0004.1.01.1	GR	1200240912	FLTR INSRT WITH O RING
1559	1.03.0005.1.01.2	GR	1707230112	RUBER SEAL INJECTOR
1560	1.03.0006.1.01.3	GR	103460221016	COGGED BELT BX40
1561	1.03.0007.1.01.4	GR	105292001442	TC .K27 2-2967 MXA 13.2 TBD2V6
1562	1.03.0008.1.01.5	GR	123200190258	SET OF HOSES * TBD V12 RC
1563	1.03.0009.1.01.6	GR	123200190268	SET OF HOSECLIPS TBDV12RC
1564	1.03.0010.1.01.7	GR	123200190278	SET OF O RINGS TBDV12 RC
1565	1.03.0011.1.01.8	GR	123200190448	SET-SEALING RINGS TBD2V12
1566	1.03.0012.1.01.9	GR	123200193557	SET OF GASKET-TBDV12 RC
1567	1.03.0013.1.01.1	GR	123200194357	SET-FLEX F/PIPE TBDV12-II
1568	1.03.0014.1.01.2	GR	123201400507	CR-SHFT ASSY-TBD/V12 SPL
1569	1.03.0015.1.01.3	GR	123201700094	CAMSHAFT V12 FINISHED
1570	1.03.0016.1.01.4	GR	123203100184	DOWEL PIN TBDV12-10X95
1571	1.03.0017.1.01.5	GR	123203210034	PUSH ROD - D2/D4/DL4
1572	1.03.0018.1.01.6	GR	123203410096	TENSION ROLLER-1B GROOVE
1573	1.03.0019.1.01.7	GR	123203410166	TENSION ROLLER ASSY TISCO
1574	1.03.0020.1.01.8	GR	123206230014	BRKT FUEL FILTER
1575	1.03.0021.1.01.9	GR	123207110036	FUEL INJ. PUMP DRIVE
1576	1.03.0022.1.01.1	GR	123207311106	FW PUMP 3-GR WITH 35.4PULLEY
1577	1.03.0023.1.01.2	GR	123207319217	SECONDARY WATER PUMP ASSY
1578	1.03.0024.1.01.3	GR	123207400517	LUBOIL CENTRFG. FILTR ASY
1579	1.03.0025.1.01.4	GR	123209123025	Pipe Aft Clr inlet from Sec water pump
1580	1.03.0026.1.01.5	GR	123209302566	EXHAUST MANIFOLD LAGGED
1581	1.03.0027.1.01.6	GR	123209302576	EXHAUST MANIFOLD LAGGED
1582	1.03.0028.1.01.7	GR	123209311126	EXHAUST ELBOW B-BANK LAGD
1583	1.03.0029.1.01.8	GR	123209311136	EXHAUST ELBOW LAGGED
1584	1.03.0030.1.01.9	GR	123209423905	PIPE-OIL COOLER TO SECON.
1585	1.03.0031.1.01.1	GR	123209424474	Pipe Sec water pump to Aft Clr
1586	1.03.0032.1.01.2	GR	123406520015	FLANG BELLOW
1587	1.03.0033.1.01.3	GR	602001016401	BOLT M16X1.5X75 CL 10.9 B-FORM
1588	1.03.0034.1.01.4	GR	602360102206	LOCKING RING A/4
1589	1.03.0035.1.01.5	GR	604960650901	OILSEAL=110X90X12 MM THK
1590	1.03.0036.1.01.6	GR	604960651332	OIL SEAL (FLYWHEEL SIDE)
1591	1.03.0037.1.01.7	GR	604962000002	VALVE STEAM SEAL
1592	1.03.0038.1.01.8	GR	605411880008	LUB OIL FILTER(232V12)
1593	1.03.0039.1.01.9	GR	606500100006	A V MOUNTG-A2T/4030B
1594	1.03.0040.1.01.1	GR	623200197227	PISTON RINGS SET * TD/TBD
1595	1.03.0041.1.01.2	GR	623201320044	CYLINDER LINER
1596	1.03.0042.1.01.3	GR	623203100104	DOWEL PIN 10X40
1597	1.03.0043.1.01.4	GR	623203250044	TAPPET
1598	1.03.0044.1.01.5	GR	623203300144	BRASS SLEEVE
1599	1.03.0045.1.01.6	GR	623203300154	CU.SLEEVE

1600	1.03.0046.1.01.7	GR	623203320034	VALVE GUIDE D2
1601	1.03.0047.1.01.8	GR	623203450032	INSERTS V S INL/EXH
1602	1.03.0048.1.01.9	GR	623203510034	BOLT M B M18X2.5X135
1603	1.03.0049.1.01.1	GR	623203580024	ADJ.SCREW=M10X1.5X39 LG.
1604	1.03.0050.1.01.2	GR	623204600024	VALVE EX D2 KV 2994
1605	1.03.0051.1.01.3	GR	623204650015	PISTON COOLING NOZZLE STD
1606	1.03.0052.1.01.4	GR	623207030164	VIBRATION DAMPER TBD V12
1607	1.03.0053.1.01.5	GR	623284300037	MAIN-BRG 0.010" U/S(0.25)
1608	1.03.0054.1.01.6	GR	623284306027	BRG CON-ROD LE 0.010"/.25
1609	1.03.0055.1.01.7	GR	623407300046	LUB OIL PUMP ASSY (MAIN)
1610	1.03.0056.1.01.8	GR	100099390664	Flexible Pipe Pressure Guage
1611	1.03.0057.1.01.9	GR	100099391384	Flexible Pipe IOF
1612	1.03.0058.1.01.1	GR	105413100062	Diesel Pre- Filter
1613	1.03.0059.1.01.2	GR	105612412501	Lub. Oil Pressure Gauge
1614	1.03.0060.1.01.3	GR	105652090146	Tachometer Meter
1615	1.03.0061.1.01.4	GR	105685000621	Water Temperature Gauge
1616	1.03.0062.1.01.5	GR	105685090027	HCT Switch
1617	1.03.0063.1.01.6	GR	105782010008	L.L.O.P. Switch
1618	1.03.0064.1.01.7	GR	106900000014	Air Filter Element (Outer)
1619	1.03.0065.1.01.8	GR	106900000015	Air Filter Element (Inner)
1620	1.03.0066.1.01.9	GR	106900000033	O' Ring Prefilter
1621	1.03.0067.1.01.1	GR	123206410094	Lever
1622	1.03.0068.1.01.2	GR	123206500174	Plate
1623	1.03.0069.1.01.3	GR	123299302755	Exhaust Junction
1624	1.03.0070.1.01.4	GR	123299330265	Exhaust Flex Pipe
1625	1.03.0071.1.01.5	GR	602000101065	Bolt for E/M
1626	1.03.0072.1.01.6	GR	602000501640	Hex Bolt
1627	1.03.0073.1.01.7	GR	602011081025	Stud
1628	1.03.0074.1.01.8	GR	602100540100	Lock Nut
1629	1.03.0075.1.01.9	GR	602100540160	Hex Nut
1630	1.03.0076.1.01.1	GR	602421102160	Spring Solenoid
1631	1.03.0077.1.01.2	GR	602701010010	Angular Joint (L)
1632	1.03.0078.1.01.3	GR	602701011010	Angular Joint (LH)
1633	1.03.0079.1.01.4	GR	604015120060	Hose Clip
1634	1.03.0080.1.01.5	GR	604015120072	Hose Clip
1635	1.03.0081.1.01.6	GR	604015301650	Hose Clip
1636	1.03.0082.1.01.7	GR	604015360380	Hose Clip
1637	1.03.0083.1.01.8	GR	604910121000	Gasket Silencer
1638	1.03.0084.1.01.9	GR	604920100814	Copper Washer
1639	1.03.0085.1.01.1	GR	604920101014	Copper Washer
1640	1.03.0086.1.01.2	GR	604920101418	Copper Washer
1641	1.03.0088.1.01.4	GR	607120130004	Lifting Magnet (24V)
1642	1.03.0089.1.01.5	GR	620708610104	Hose Bend
1643	1.03.0090.1.01.6	GR	623203200144	Rod Threaded 115mm
1644	1.03.0091.1.01.7	GR	623208610284	Hose
1645	1.03.0092.1.01.8	GR	623208610294	Hose
1646	1.03.0093.1.01.9	GR	623208610314	Hose
1647	1.03.0094.1.01.1	GR	623208610334	Hose
1648	1.03.0095.1.01.2	GR	623208610344	Hose Water M/F to H.E.
1649	1.03.0096.1.01.3	GR	623208610384	Hose
1650	1.03.0097.1.01.4	GR	E05302000040	INJ.CMPL F002C7Z116
1651	1.03.0098.1.01.5	GR	E23200192847	V12 F.I.PIPE SET-A TYPE
1652	1.03.0099.1.01.6	GR	E23201600106	PISTON(TBD2)+GPIN+CIRCLIP
1653	1.03.0100.1.01.7	GR	E23209390985	INJ O/FLOW PIPE V12-I
1654	1.03.0101.1.01.8	GR	E23209391275	INJ.OVER FLOW PIPE (EMI)D2V12
1655	1.03.0102.1.01.9	GR	P23408550024	CYL HEAD GASKET 132 MM
1656	1.03.0103.1.01.1	GR	TBD232 V12	Engine complete
1657	1.03.0103.1.01.2	GR	2202-0160A	INJECTOR GASKET
1658	1.04.0001.1.01.8	KI	06.001.20.0	CRANK CASE ASSEMBLY
1659	1.04.0002.1.01.9	KI	C-075600003	CAM SHAFT BUSH
1660	1.04.0003.1.01.1	KI	W-075500003	THRUST EASHER SET
1661	1.04.0004.1.01.2	KI	02.002.10.0	OIL SPRAY NOZZLE ASSY
1662	1.04.0005.1.01.3	KI	03.007.01.0	OIL SEAL HOUSING(FEW)
1663	1.04.0006.1.01.4	KI	03.007.06.0	OIL SEAL (115 X 140 X 16 mm)
1664	1.04.0007.1.01.5	KI	03.007.04.0	JOINT FOR OIL SEAL HOUSING
1665	1.04.0008.1.01.6	KI	03.008.10.0	INTERMEDIATE GEAR WITH BUSH
1666	1.04.0009.1.01.7	KI	G-075500003	BUSH FOR INTERMEDIATE GEAR
1667	1.04.0010.1.01.8	KI	03.008.03.0	GEAR SUPPORT
1668	1.04.0011.1.01.9	KI	03.008.04.0	SPLIT BUSH FOR GEAR SUPPORT
1669	1.04.0012.1.01.1	KI	M-075400003	MAIN BEARING SET STD
1670	1.04.0013.1.01.2	KI	M-075400013	MAIN BEARING SET 0.25 U/S
1671	1.04.0014.1.01.3	KI	M-075400023	MAIN BEARING SET 0.50 U/S
1672	1.04.0015.1.01.4	KI	06.073.20.0	CRANK SHAFT ASSEMBLY
1673	1.04.0016.1.01.5	KI	06.017.10.0	CRANK SHAFT PULLEY
1674	1.04.0017.1.01.6	KI	03.016.02.0	BOLT
1675	1.04.0018.1.01.7	KI	03.016.03.0	WASHER
1676	1.04.0019.1.01.8	KI	06.005.10.0	CAM SHAFT ASSEMBLY

1677	1.04.0020.1.01.9	KI	03.006.04.0	CAM SHAFT GEAR
1678	1.04.0021.1.01.1	KI	03.006.02.0	THRUST WAHER
1679	1.04.0022.1.01.2	KI	03.006.03.0	BUSH FOR TACHOMETER
1680	1.04.0023.1.01.3	KI	02.024.01.0	VALVE TAPPET
1681	1.04.0024.1.01.4	KI	02.024.10.0	PUSH ROD
1682	1.04.0025.1.01.5	KI	02.024.33.0	PUSH ROD COVER TUBE
1683	1.04.0026.1.01.6	KI	02.024.04.0	SPRING
1684	1.04.0027.1.01.7	KI	02.024.03.0	SEALING RING CAP
1685	1.04.0028.1.01.8	KI	02.021.30.0	CONNECTING ROD ASSY
1686	1.04.0029.1.01.9	KI	S-075500003	SMALL END BUSH
1687	1.04.0030.1.01.1	KI	B-075400003	L.E. BEARING SET STD
1688	1.04.0031.1.01.2	KI	B-075400013	L.E. BEARING SET 0.25 U/S
1689	1.04.0032.1.01.3	KI	B-075400023	L.E. BEARING SET 0.50 U/S
1690	1.04.0033.1.01.4	KI	02.020.01.0	PISTON ASSY
1691	1.04.0034.1.01.5	KI	02.020.98.0	PISTON RING SET STD
1692	1.04.0035.1.01.6	KI	02.019.01.0	CYLINDER LINER STD
1693	1.04.0036.1.01.7	KI	02.019.03.0	SHIM RING
1694	1.04.0037.1.01.8	KI	02.022.20.0	CYLINDER HEAD ASSY COMPLETE
1695	1.04.0038.1.01.9	KI	02.022.17.0	VALVE GUIDE
1696	1.04.0039.1.01.1	KI	02.022.18.0	WIRE SNAP RING
1697	1.04.0040.1.01.2	KI	02.022.22.0	INLET VALVE
1698	1.04.0041.1.01.3	KI	02.022.08.0	EXHAUST VALVE
1699	1.04.0042.1.01.4	KI	02.022.21.0	SPRING CUP
1700	1.04.0043.1.01.5	KI	02.022.13.0	VALVE SPRING
1701	1.04.0044.1.01.6	KI	02.022.12.0	VALVE COLLECT
1702	1.04.0045.1.01.7	KI	02.022.11.0	VALVE CUP
1703	1.04.0046.1.01.8	KI	02.093.02.0	CYLINDER HEAD BOLT
1704	1.04.0047.1.01.9	KI	02.022.04.0	WASHER
1705	1.04.0048.1.01.1	KI	02.024.50.0	ROCKER PEDASTEL ASSY
1706	1.04.0049.1.01.2	KI	02.024.20.0	VALVE ROCKER ASSY
1707	1.04.0050.1.01.3	KI	02.024.32.0	ROCKER COVER
1708	1.04.0051.1.01.4	KI	02.024.21.0	SEALING WASHER(ROCKER COVER GASKET)
1709	1.04.0052.1.01.5	KI	06.013.01.0	FRONT COVER
1710	1.04.0053.1.01.6	KI	03.013.06.0	OIL SEAL (65 X 85 X 13)
1711	1.04.0054.1.01.7	KI	03.013.05.0	JOINT FOR FRONT COVER
1712	1.04.0055.1.01.8	KI	03.014.20.0	SUB ASSY OF TACHOMETER PLUG
1713	1.04.0056.1.01.9	KI	34.036.60.0	OIL FILLER CAP
1714	1.04.0057.1.01.1	KI	06.010.20.0	LUB OIL PUMP ASSY
1715	1.04.0058.1.01.2	KI	06.008.20.0	SUCTION TUBE ASSY
1716	1.04.0059.1.01.3	KI	03.012.10.0	DELIVERY TUBE WITH 'O' RING
1717	1.04.0060.1.01.4	KI	06.020.01.0	LUB OIL COOLER
1718	1.04.0061.1.01.5	KI	06.075.01.0	OIL SUMP
1719	1.04.0062.1.01.6	KI	06.015.02.0	JOINT FOR OIL SUMP
1720	1.04.0063.1.01.7	KI	06.040.10.0	LUB OIL FILTER ASSY
1721	1.04.0064.1.01.8	KI	06.040.01.0	LUB OIL FILTER ELEMENT
1722	1.04.0065.1.01.9	KI	34.032.30.0	FUEL FILTER ASSY
1723	1.04.0066.1.01.1	KI	34.032.02.0	PRE FILTER ELEMENT
1724	1.04.0067.1.01.2	KI	34.032.03.0	MICRO FILTER ELEMENT
1725	1.04.0068.1.01.3	KI	25.040.01.0	FUEL PIPE (FEED PUMP TO FILTER)
1726	1.04.0069.1.01.4	KI	34.151.04.0	FUEL PIPE (FILTER TO PUMP)
1727	1.04.0070.1.01.5	KI	06.003.10.0	FUEL PUMP ASSY
1728	1.04.0071.1.01.6	KI	02.035.30.0	FUEL INJECTOR ASSY
1729	1.04.0072.1.01.7	KI	42.005.10.0	NOZZLE
1730	1.04.0073.1.01.8	KI	02.035.07.0	BUSH FOR INJECTOR
1731	1.04.0074.1.01.9	KI	06.026.90.0	SET OF HIGH PRESSURE PIPE
1732	1.04.0075.1.01.1	KI	06.027.10.0	LEAK OFF PIPE
1733	1.04.0076.1.01.2	KI	06.085.40.0	COOLING AIR BLOWER ASSY
1734	1.04.0077.1.01.3	KI	06.085.20.0	IMPELLER WITH BUSH
1735	1.04.0078.1.01.4	KI	06.085.20.1	FLY WHEEL WITH STARTER RING
1736	1.04.0079.1.01.5	KI	06.048.10.0	AIR CLEANER ASSY
1737	1.04.0080.1.01.6	KI	06.046.01.0	EXHAUST MAIN FOLD CUM SILENCER
1738	1.04.0081.1.01.7	KI	06.065.20.0	SUB ASSY OF BEND & RAIN CAP ASSY
1739	1.04.0082.1.01.8	KI	06.050.10.0	SET OF JOINT
1740	1.04.0083.1.01.9	KI	06.051.10.0	SET OF 'O' RINGS
1741	1.04.0084.1.01.1	KI	2130-2341F	FUEL RETURN PIPE(INJECTOR)
1742	1.05.0001.1.01.9	SU	4202-0007A	COPPER WASHER
1743	1.05.0002.1.01.1	SU	4202-0008A	COPPER WASHER
1744	1.05.0003.1.01.2	SU	4202-0012A	COPPER WASHER
1745	1.05.0004.1.01.3	SU	4161-0008A	CLAMP
1746	1.05.0005.1.01.4	SU	2067-0002A	FLY WHEEL RING
1747	1.05.0006.1.01.5	SU	2203-0455A	PACKING RUBBER
1748	1.05.0007.1.01.6	SU	2203-0436A	TAPPET COVER GASKET
1749	1.05.0008.1.01.7	SU	4632-0505A	O RING
1750	1.05.0009.1.01.8	SU	4632-0018A	WASHER

1751	1.05.0010.1.01.9	SU	2181-2031G	WASHER
1752	1.05.0011.1.01.1	SU	2203-2126F (New Part No. 2203-2262F)	WASHER
1753	1.05.0012.1.01.2	SU	2181-0060A	WASHER
1754	1.05.0013.1.01.3	SU	2039-0018A	SPACER
1755	1.05.0014.1.01.4	SU	2040-0002A	COLLET
1756	1.05.0015.1.01.5	SU	2202-0162A	WASHER (0.10)
1757	1.05.0016.1.01.6	SU	2202-0163A	WASHER (0.20)
1758	1.05.0017.1.01.7	SU	2202-0164A	WASHER (0.30)
1759	1.05.0018.1.01.8	SU	2202-0158F	GASKET CYLINDER HEAD
1760	1.05.0019.1.01.9	SU	2038-0016A (New Part No. 2038-2013F)	VALVE GUIDE
1761	1.05.0020.1.01.1	SU	4203-2003A	GASKET
1762	1.05.0021.1.01.2	SU	2044-0026C(New Part No. 2044-2013F)	VALVE INSERT
1763	1.05.0022.1.01.3	SU	2036-2005F	VALVE CONE(INLET)
1764	1.05.0023.1.01.4	SU	2044-0025A	VALVE INSERT (EX)
1765	1.05.0024.1.01.5	SU	2037-0024A	VALVE CONE (EX)
1766	1.05.0025.1.01.6	SU	1025-2048F	PISTON COMPLETE
1767	1.05.0026.1.01.7	SU	1027-0073A	PISTON RINGS
1768	1.05.0027.1.01.8	SU	2203-2181F	GASKET
1769	1.05.0028.1.01.9	SU	2203-2182F	GASKET (OIL PAN)
1770	1.05.0029.1.01.1	SU	4632-0034A	O RING
1771	1.05.0030.1.01.2	SU	2202-2066F	GASKET
1772	1.05.0031.1.01.3	SU	2203-2179F	GASKET
1773	1.05.0032.1.01.4	SU	2042-0012A	PUSH ROD
1774	1.05.0033.1.01.5	SU	1030-2012F	BEARING MAIN STD
1775	1.05.0034.1.01.6	SU	1030-2013F	BEARING MAIN 0.25
1776	1.05.0035.1.01.7	SU	1030-0033S (New Part No.1030-2034F)	MAIN BEARING STD
1777	1.05.0036.1.01.8	SU	1030-0033S (New Part No.1030-2035F)	MAIN BEARING 0.25
1778	1.05.0037.1.01.9	SU	2165-0005A	THRUST RING STD
1779	1.05.0038.1.01.1	SU	4637-0215A	BEARING BALL
1780	1.05.0039.1.01.2	SU	4637-0185A	BEARING BALL
1781	1.05.0040.1.01.3	SU	4637-0379A	BEARING BALL
1782	1.05.0041.1.01.4	SU	4627-0045A	CIRCLIP
1783	1.05.0042.1.01.5	SU	4626-0047A	CIRCLIP
1784	1.05.0043.1.01.6	SU	NA	BOLT CON.ROD
1785	1.05.0044.1.01.7	SU	1030-0087A	CON.ROD BEARING STD
1786	1.05.0045.1.01.8	SU	1030-0089A	CON.ROD BEARING 0.25
1787	1.05.0046.1.01.9	SU	2202-0052A	O RING
1788	1.05.0047.1.01.1	SU	4632-0072A	OIL SEAL
1789	1.05.0048.1.01.2	SU	4115-0030A	L.O FILTER
1790	1.05.0049.1.01.3	SU	2203-2189F	GASKET
1791	1.05.0050.1.01.4	SU	4027-0002A	RING(EX.MFLD)
1792	1.05.0051.1.01.5	SU	4113-2011A	AIR CLEANER
1793	1.05.0052.1.01.6	SU	4161-0041A	CLAMP
1794	1.05.0053.1.01.7	SU	4634-0250A	BALL BEARING (BLOWER)
1795	1.05.0054.1.01.8	SU	4651-0554A	V BELT
1796	1.05.0055.1.01.9	SU	3130-0030A	HOSE (TURBO)
1797	1.05.0056.1.01.1	SU	4161-0043A	CLAMP (TURBO)
1798	1.05.0057.1.01.2	SU	2202-2058F	GASKET (TURBO)
1799	1.05.0058.1.01.3	SU	2203-2162F	GASKET (TURBO)
1800	1.05.0059.1.01.4	SU	2203-2190F	GASKET (TURBO)
1801	1.05.0060.1.01.5	SU	2202-2059F	GASKET (TURBO)
1802	1.05.0061.1.01.6	SU	2130-0127A	HOSE (TURBO)
1803	1.05.0062.1.01.7	SU	4161-0034A	CLAMP (TURBO) New Part No.4161
1804	1.05.0063.1.01.8	SU	4632-0135A	O RING
1805	1.05.0064.1.01.9	SU	4202-0014A	WASHER
1806	1.05.0065.1.01.1	SU	4202-0022A	WASHER
1807	1.05.0066.1.01.2	SU	1203-2137G/2270F	SET OF ENGINE GASKET SET
1808	1.05.0067.1.01.3	SU	1203-2135F	SET OF CYLINDER HEAD GASKET
1809	1.05.0068.1.01.4	SU	4531-0059A	FUEL FILTER
1810	1.05.0069.1.01.5	SU	4502-2012F	STOP SOLENOID- 24V
1811	1.05.0070.1.01.6	SU	4502-2011F	STOP SOLENOID- 12V
1812	1.05.0071.1.01.7	SU	3524-2046F	TURBO CHARGER
1813	1.05.0072.1.01.8	SU	4506-2015A	NOZZLE
1814	1.05.0073.1.01.9	SU	4518-0005A	DIAPHRAM LIFT PUMP
1815	1.05.0074.1.01.1	SU	4634-0451A	SEAL RING
1816	1.05.0075.1.01.2	SU	1035-2036	CYLINDER HEAD ENGINE NEW PART NO.1035-2097F
1817	1.05.0076.1.01.3	SU	1115-0016B	OIL FILTER ASSY.NEW PART NO.115-2005F
1818	1.05.0077.1.01.4	SU	1120-0027A	OIL RADIATOR
1819	1.05.0078.1.01.5	SU	1506-2010F	INJECTOR
1820	1.05.0079.1.01.6	SU	1518-0017A	FUEL FEED PUMP
1821	1.05.0080.1.01.7	SU	3502-2034F	FUEL FEED PUMP (B&S)
1822	1.05.0081.1.01.8	SU	2017-0060F	CRANK SHAFT
1823	1.05.0082.1.01.9	SU	2018-2036F	CAM SHAFT
1824	1.05.0083.1.01.1	SU	1129-2055F	INJECTOR PIPE
1825	1.05.0084.1.01.2	SU	4637-0250A	BLOWER BEARING

1826	1.05.0085.1.01.3	SU	2163-0290A	SPACER
1827	1.05.0086.1.01.4	SU	4626-0062A	CIRCLIP
1828	1.05.0087.1.01.5	SU	4606-0008A	LUB OIL SENSOR/OIL TEMP.SWITCH
1829	1.05.0088.1.01.6	SU	4161.0034 (New Part No.4161-2143F)	HOSE
1830	1.05.0089.1.01.7	SU	2012-0030A	FLY WHEEL HOUSING
1831	1.05.0090.1.01.8	SU	4561-0026A	ANTI VIBRATION MOUNTING
1832	1.05.0091.1.01.9	SU	3553-0060A	STARTER
1833	1.05.0092.1.01.1	SU	1852-2021A	ALTERNATOR
1834	1.05.0093.1.01.2		Shifted to Annexure-II	
1835	1.05.0094.1.01.3		Shifted to Annexure-II	
1836	1.05.0095.1.01.4	SU	1521-0036A	OIL PUMP
1837	1.05.0096.1.01.5	SU	3531-0032A	FUEL FILTER
1838	1.05.0097.1.01.6	SU	2130-2350G	PIPE
1839	1.05.0098.1.01.7	SU	2203-0230A	GASKET
1840	1.05.0099.1.01.8	SU	2203-0231A	GASKET
1841	1.05.0100.1.01.9	SU	2097-2213G	COVER
1842	1.05.0101.1.01.1	SU	3203-0017A	GASKET
1843	1.05.0102.1.01.2	SU	2202-2046A	GASKET
1844	1.05.0103.1.01.3	SU	2097-2174A	OIL RADIATOR SHEET
1845	1.05.0104.1.01.4	SU	2130-2312F	PIPE
1846	1.05.0105.1.01.5	SU	2130-2313F	PIPE
1847	1.05.0106.1.01.6	SU	2561-0003A	SHOCK ABSORBER
1848	1.05.0107.1.01.7	SU	2060-0253A	PULLEY
1849	1.05.0108.1.01.8	SU	4176-3533F	SCREW
1850	1.05.0109.1.01.9	SU	2052-2033G	FRONT SUPPORT ASSEMBLY
1851	1.05.0110.1.01.1	SU	2177-0063A	CAP
1852	1.05.0111.1.01.2	SU	1177-2003F	OIL FILLER.PLUG
1853	1.05.0112.1.01.3	SU	2130-2502F	PIPE FROM THE TANK T
1854	1.05.0113.1.01.4	SU	2130-2016A	TUBE
1855	1.05.0114.1.01.5	SU	2104-0113G	INTAKE MANIFOLD
1856	1.05.0115.1.01.6	SU	2013-0289A	COVER
1857	1.05.0116.1.01.7	SU	2013-0267F	COVER
1858	1.05.0117.1.01.8	SU	2054-0001A	BRACKET
1859	1.05.0118.1.01.9	SU	2024-0063A	CYLINDER
1860	1.05.0119.1.01.1	DE	21202009G	RADITOR
1861	1.05.0120.1.01.2		Repeated item	
1862	1.05.0121.1.01.3		Repeated item	
1863	1.05.0122.1.01.4	SU	35242047F	Turbo charger
1864	1.08.0001.1.01.3	CA	1063969	Air Cleaner outer (C-18)
1865	1.08.0002.1.01.4	CA	1063973	Air Cleaner inner (C-18)
1866	1.08.0003.1.01.5	CA	1327167	Air Cleaner outer (C-9)
1867	1.08.0004.1.01.6	CA	1R-0749	FUEL FILTER (C-9)
1868	1.08.0005.1.01.7	CA	AVX13-925LA	V-BELT
1869	1.08.0006.1.01.8	CA	1R-0751	FUEL FILTER (C-9)
1870	1.08.0007.1.01.9	CA	1R-1808	Engine oil Filter (C-9 & C-18)
1871	1.08.0008.1.01.1	CA	275-2096	Lub. Oil Pressure gauge
1872	1.08.0009.1.01.2	CA	326-1643	FUEL FILTER WATER SEPARATOR
1873	1.08.0010.1.01.3	CA	612510	Air Cleaner inner (C-9)
1874	1.08.0011.1.01.4	CA	6N-7054 CAT F 5211F5	V-belt (C-18) for radiator fan
1875	1.08.0012.1.01.5	CA	A-4896	V-belt (C-9) for water pump
1876	1.08.0013.1.01.6	CA	B 1080 B41	V-belt (C-9) for alternator
1877	1.08.0014.1.01.7	CA	C 1610 C61	V-belt (C-9) for radiator fan
1878	1.08.0015.1.01.8	CA	XPB 1500	V-belt (C-18) for alternator
1879	1.08.0016.1.01.9		Shifted to Ann-II	
1880	1.08.0017.1.01.1		Repeated	
1881	1.08.0018.1.01.2	CA	1W3636	ELEMENT AS
1882	1.08.0019.1.01.3	CA	2515886	ELEMENT AS
1883	1.08.0020.1.01.4	CA	4401616	AIR COMPRESSOR
1884	1.08.0021.1.01.5	CA	1W4150	SPIDER A
1885	1.08.0022.1.01.6	CA	2969799	TUBE AS
1886	1.08.0023.1.01.7	CA	1R-0755	FUEL FILTER
1887	1.08.0024.1.01.8	CA	423-8521	FUEL/WATER SEPARATOR
1888	1.08.0025.1.01.9	CA	246-5010	ELEMENT SEC (INNER AIR FILTER)
1889	1.08.0026.1.01.1	CA	246-5009	ELEMENT AS (OUTER AIR FILTER)
1890	1.08.0027.1.01.2	CA	1R-1804	FUEL FILTER
1891	1.08.0028.1.01.3	CA	441-5111	FUEL/WATER SEPARATOR
1892	1.08.0029.1.01.4	CA	7W-2326	OIL FILTER
1893	1.08.0030.1.01.5	CA	110-6326	AIR FILTER
1894	1.08.0031.1.01.6	CA	197-8820 (95A,24V)	Engine 1&2 Alternator
1895	1.08.0032.1.01.7	CA	339-7767 (65A,12V)	Genset alternator
1896	1.08.0033.1.01.8	CA	338-3454(24V)	ENGINE self starter
1897	1.08.0034.1.01.9	CA	3575202 (12V,3.2KW)	GENSET SELF STARTER
1898	1.08.0035.1.01.1	CA	CAT-1W1456	pullly
1899	1.08.0036.1.01.2	CA	CAT-2429537	Seal
1900	1.08.0037.1.01.3	CA	CAT-2761806	Element-fuel
1901	1.08.0038.1.01.4	CA	CAT-0676987	Element-fuel

1902	1.08.0039.1.01.5	CA	CAT-2201523	Filter Oil
1903	1.08.0040.1.01.6	CA	CAT-5516183	Element-Prim
1904	1.08.0041.1.01.7	CA	IML-3E9848	CAT DEO C14 15W40 PAIL20L:IN
1905	1.08.0042.1.01.8	CA	1295429	CORE AS
1906	1.08.0043.1.01.9	CA	1365017	BASE AS
1907	1.08.0044.1.01.1	CA	1375541	PUMP AS
1908	1.08.0045.1.01.2	CA	1614113	PUMP GP-EO 1
1909	1.08.0046.1.01.3	CA	1678130	DAMPER AS
1910	1.08.0047.1.01.4	CA	1977348	TACHOMETER-E
1911	1.08.0048.1.01.5	CA	2336742	VALVE-CHECK
1912	1.08.0049.1.01.6	CA	2345013/2566453	SENSOR GP TEMPERATURE
1913	1.08.0050.1.01.7	CA	2350183	HOSE AS
1914	1.08.0051.1.01.8	CA	2350313	HOSE AIR COM
1915	1.08.0052.1.01.9	CA	2374305	HARNESS AS
1916	1.08.0053.1.01.1	CA	2433820-10/2395025	DRIVING PANEL DISPLAY
1917	1.08.0054.1.01.2	CA	2477133	REGULATOR WATER TEMP
1918	1.08.0055.1.01.3	CA	2661473	ENGINE SPEED SENSOR/SENSOR GP
1919	1.08.0056.1.01.4	CA	2746719/2746718	OIL PRESSURE SENSOR
1920	1.08.0057.1.01.5	CA	3520211	WATER PUMP
1921	1.08.0058.1.01.6	CA	3540049	HARNESS AS
1922	1.08.0059.1.01.7	CA	3584926	TURBO CATRIDGE
1923	1.08.0060.1.01.8	CA	3595392	TURBO GP-BAS
1924	1.08.0061.1.01.9	CA	3848612	PUMP GP-F XF
1925	1.08.0062.1.01.1	CA	4787933	CONT GP-E
1926	1.08.0063.1.01.2	CA	3L1425	BALL BEARING
1927	1.08.0064.1.01.3	CA	4W2683	WATER PRESSURE GAUGE/INDICATOR
1928	1.08.0065.1.01.4	CA	6N0598	PULLEY FAN DRIVE(GROVE)/PULLEY
1929	1.08.0066.1.01.5	CA	6N6490	BRACKET A
1930	1.08.0067.1.01.6	CA	6N7053	VEE BELT SET
1931	1.08.0068.1.01.7	CA	6N7054	VEE BELT
1932	1.08.0069.1.01.8	CA	6N7135	VEE BELT
1933	1.08.0070.1.01.9	CA	7W8132/1182018	VEE BELT
1934	1.08.0071.1.01.1	CA	7C0145	CORE A
1935	1.08.0072.1.01.2	CA	8H9789	BALL BEARING
1936	1.08.0073.1.01.3	CA	1918303	SENSOR
1937	1.08.0074.1.01.4	CA	2746717	SENSOR
1938	1.08.0075.1.01.5	CA	2799830	SENSOR
1939	1.08.0076.1.01.6	CA	3888890	SENSOR
1940	1.08.0077.1.01.7	CA	2399957/4309449	COOLANT LEVEL SENSOR
1941	1.09.0001.1.01.4	AS	F0W02200	AIR CLEANER ELEMENT(Element primary)
1942	1.09.0002.1.01.5	AS	F0W02300	AIR CLEANER ELEMENT (Element safety)
1943	1.09.0003.1.01.6	AS	Gulf Ley power cool 40	Coolant
1944	1.09.0004.1.01.7	AS	X8820800	MAIN FUEL FILTER CRS
1945	1.09.0005.1.01.8	AS	X8800700	WATER FILTER N4
1946	1.09.0006.1.01.9	AS	F7A04800	SPIN ON OIL FILTER N6
1947	1.09.0007.1.01.1	AS	F7B02900	SPIN ON PRE FUEL FILTER
1948	1.09.0008.1.01.2	AS	X7487500	ENGINE SPEED SENSOR
1949	1.09.0009.1.01.3	AS	X7472800	WATER TEMPERATURE SENSOR
1950	1.09.0010.1.01.4	AS	X8820700	TURBO CHARGER
1951	1.09.0011.1.01.5	AS	F7A04700	PRE FUEL FILTER ASSY
1952	1.09.0012.1.01.6	AS	11292055	INJECTOR PIPE
1953	1.09.0013.1.01.7	AS	X3409522	CYLINDER LINER N4&N6
1954	1.09.0014.1.01.8	AS	HAEP38/1	ASSEMBLY OF PISTON AND RINGS
1955	1.09.0015.1.01.9	AS	B9803503	CONNECTING ROD SUB ASSY
1956	1.09.0016.1.01.1	AS	X0200140	BEARING, CONROD UPPER SHELL
1957	1.09.0017.1.01.2	AS	X2708200	TIMING OIL SEAL H N4/N6
1958	1.09.0018.1.01.3	AS	P5104225	MAIN BEARING SET - STD
1959	1.09.0019.1.01.4	AS	X3401010	SLEEVE INJECTOR
1960	1.09.0020.1.01.5	AS	B4P00109	ROCKER SHAFT 1 EBS ASSY (SL.NOs.11,12,14,15,16,17,18,36,37,39,40,41,42,43)
1961	1.09.0021.1.01.6	AS	B4P00106	ROCKER ARM EXHAUST ASSEMBLY EBS (SL.NOs.11,12,14,15,16,17,18,36,37,39,40,41,42,43)
1962	1.09.0022.1.01.7	AS	B6C00501	S/A OF INJECTOR - 630HTF BASELINE (SL.NOs.2,3,4,5) (12)
1963	1.09.0023.1.01.8	AS	XB500100	NOZZLE 630HTF - BASELINE INJECTOR 1NSS

1964	1.09.0024.1.01.9	AS	X0801511	CLAMP - INJECTOR
1965	1.09.0025.1.01.1	AS	B9800901	OIL PUMP SUB ASSY
1966	1.09.0026.1.01.2	AS	B9800604	COMMON RAIL PUMP ASSY
1967	1.09.0027.1.01.3	AS	X3M04800	R WITH WASTE GATE
1968	1.09.0028.1.01.4	AS	X2009600	BOOST PRESSURE SENSOR
1969	1.09.0029.1.01.5	AS	X0675700	INTERNAL WIRING HARNESS
1970	1.09.0030.1.01.6	AS	X0300100	BELT TENSIONER
1971	1.09.0031.1.01.7	AS	FOY00311	GEAR AIR COMPRESSOR Z=32
1972	1.09.0032.1.01.8	AS	10011475	WIRING HARNESS_9m_ N6_CRS ENG_ UTV_ UTS
1973	1.09.0033.1.01.9	AS	10008217	ECU INTERFACE ENG.SAFETYUNIT IP67
1974	1.09.0034.1.01.1	AS	10004232	EXHAUST BELLOW N6 ENG
1975	1.09.0035.1.01.2	AS	F7474000	AIR COMPRESSOR
1976	2.01.0001.1.01.6	KA	310.3.112.03.06. T1	HYDRAULIC PUMP
1977	2.01.0002.1.01.7	KA	310.3.112.04.06. T1	HYDRAULIC PUMP
1978	2.01.0003.1.01.8	KA	310.3.160.03.06 T1	HYDRAULIC PUMP
1979	2.01.0004.1.01.9	KA	310.3.160.04.06 T1	HYDRAULIC PUMP
1980	2.01.0005.1.01.1	KA	310.3.56.03.06 T1	HYDRAULIC PUMP
1981	2.01.0006.1.01.2	KA	310.4.112.03.06	HYDRAULIC PUMP
1982	2.01.0007.1.01.3	KA	310.4.112.04.06	HYDRAULIC PUMP
1983	2.01.0008.1.01.4	KA	310.4.160.03.06	HYDRAULIC PUMP
1984	2.01.0009.1.01.5	KA	310.4.160.04.06	HYDRAULIC PUMP
1985	2.01.0010.1.01.6	KA	310.4.56.03.06 T1	HYDRAULIC PUMP
1986	2.01.0011.1.01.7	KA	6.04.02.620	HYDRAULIC PUMP FOR TRANSMISSION GB
1987	2.01.0012.1.01.8	PL	M6PV82.820142AL3V	HYDRAULIC PUMP
1988	2.01.0013.1.01.9	PL	62.05.4000.325	HYDRAULIC PUMP
1989	2.01.0014.1.01.1	PL	64.04.3000.86	HYDRAULIC PUMP
1990	2.01.0015.1.01.2	PL	229055	HYD.PROPEL DOUBLE PUMP FOR BRM
1991	2.01.0016.1.01.3	KE	733626	EMERGEINCY PUMP
1992	2.01.0017.1.01.4	HA	D-434622	HYD PUMP FOR TRT
1993	2.01.0018.1.01.5		Shifted to Ann II	
1994	2.01.0019.1.01.6	LO	106504	PUMP HYDR PC C4 FLNG/14T SPLN/4.5 IN3
1995	2.01.0020.1.01.7	LO	B68693	PUMP VAN VARIABLE VOL
1996	2.01.0021.1.01.8	PH	4P22	EMERGENCY HYDRAULIC PUMP ASSEMBLY
1997	2.01.0022.1.01.9	PL	62.05.2000.144	PUMP
1998	2.01.0023.1.01.1	PL	HY 709 X 71L/DFR + 28L/DFR	PUMP
1999	2.01.0024.1.01.2		Repeated item	
2000	2.01.0025.1.01.3	CR	H1-P-210-L-A-A-A5-C1-N-D8-C-G2-H5-L-35-L-35-W-P-24- PN-NNN-NNN	HYDRAULIC VARIABLE PISTON PUMP
2001	2.01.0026.1.01.4	CR	H1-P-130-L-B-A-A5-C1-N-D8-G-G2-H6-L-25-L-25-L-P-24- PN-NNN-NNN	HYDRAULIC PUMP-1
2002	2.01.0027.1.01.5	CR	ER-L-130B-LS-25-20-NN-N- 3-S1NP-A1N-AAA-NNN-NNN	HYDRAULIC PUMP-2
2003	2.01.0028.1.01.6	CR	D1P-130-L-A-NPSN-S-D4-N1-C5-NNN-320-20-NN-FS- FS-NNN-NNN	HYDRAULIC PUMP-4
2004	2.01.0029.1.01.7	CR	PRR 048-/044-L-N-07-SS-P1-A4-A3-NN-A4-A3-NN-D- N-/NNN-N-N	DOUBLE GEAR PUMP-1
2005	2.01.0030.1.01.8	CR	PRR 048-/026-L-N-07-SS-P1-A4-A3-NN-A4-A3-NN-D- N-/NNN-N-N	DOUBLE GEAR PUMP-2
2006	2.01.0031.1.01.9	CR	DE2R-25SH-BB-104-25- N104-NNN-000-AX-AN-NNN	GEAR PUMP
2007	2.01.0032.1.01.1	CR	DB9513-20A-00	EMERGENCY BACKUP SYSTEM HYDRAULIC PUMP
2008	2.01.0033.1.01.2	GE	T6DCC-B14-B12-B12-3L02- A100	Triple vane pumps-1
2009	2.01.0034.1.01.3	GE	T67DCC-050-012-008-3R03-B1-M1	Triple vane pumps-2
2010	2.01.0035.1.01.4	GE	T6DCC-B20-B12-B12-3L02-A100	Triple vane pumps-3
2011	2.01.0036.1.01.5	PL	VT11118-1X	AMPLIFIER DRIVE PUMP
2012	2.01.0037.1.01.6		Shifted to Ann II	
2013	2.01.0038.1.01.7		Shifted to Ann II	
2014	2.01.0039.1.01.8		Shifted to Ann II	
2015	2.01.0040.1.01.9		Shifted to Ann II	
2016	2.01.0041.1.01.1		Shifted to Ann II	
2017	2.01.0042.1.01.2	COLMAR	6030031 and Eaton part no 4621-245/4623-245	HYD PUMP DRIVING (T-28)
2018	2.01.0043.1.01.3		Shifted to Ann II	
2019	2.01.0044.1.01.4		Shifted to Ann II	
2020	2.01.0045.1.01.5		Shifted to Ann II	

2021	2.01.0046.1.01.6	Shifted to Ann II		
2022	2.01.0047.1.01.7	PL	HY712x60L/HD1/D350+60L/HD1/D	DOUBLE VARIABLE DISPLACEMENT PUMP
2023	2.01.0048.1.01.8	PL	HY716x95R/HD1D-315/60	DUAL PUMP
2024	2.01.0049.1.01.9	PL	HY720x280L/EP4/38A+22L	VARIABLE DISPLACEMENT PUMP
2025	2.01.0050.1.01.1	PL	HY710Ax180RGP/RNU38A+22	VARIABLE DISPLACEMENT PUMP
2026	2.01.0051.1.01.2	PL	HY710Ax180RGP/RNU38A+06	VARIABLE DISPLACEMENT PUMP
2027	2.01.0052.1.01.3	PL	HY712x130L/DRS	VARIABLE DISPLACEMENT PUMP
2028	2.01.0053.1.01.4	PL	HY709x100L/DFR1	VARIABLE DISPLACEMENT PUMP
2029	2.01.0054.1.01.5	PL	SU1401.414.1.102.1	HYDRAULIC EMERGENCY PUMP REAR
2030	2.01.0055.1.01.6	PL	18049	HYDRAULIC EMERGENCY PUMP FRONT(380V M302G, 7L/MIN, 1500U/ MIN,4KW)
2031	2.01.0056.1.01.7	PL	HY721X165LE8/38A-SAE B	HYD PUMP
2032	2.01.0057.1.01.8	KE	729346	DOBLE PUMP DRIVE
2033	2.01.0058.1.01.9	LO	160241	MOTOR PUMP ASSEMBLY 30HP 74CC PUMP 71CC PUMP
2034	2.01.0059.1.01.1	LO	247922	PUMP GEAR TANDEM .87+.87; B2 13T CCW SAE ORB PORTS
2035	2.01.0060.1.01.2	LO	248126	PUMP HYD GEAR FIX 3.94CIR; B2 13T CCW SAE 61 PORTS
2036	2.01.0061.1.01.3	LO	247633	PUMP DRIVE 3 PAD W/RTD; 2XSAE D4/1XSAE B2/1.596RT
2037	2.02.0001.1.01.7	PL	62.05.4000.24	HYDRAULIC MOTOR FOR BCM
2038	2.02.0002.1.01.8	PL	HY935.N10-P	MOTOR
2039	2.02.0003.1.01.9	PL	SU 126-5011-1-1/A	MOTOR
2040	2.02.0004.1.01.1	KA	210.12.01.03 T1	MOTOR
2041	2.02.0005.1.01.2	KA	310.2.28.01.03	MOTOR
2042	2.02.0006.1.01.3	KA	410.0.107W A4F10/A2FM107/61WXAB010J-S	MOTOR
2043	2.02.0007.1.01.4	Shifted to Ann II		
2044	2.02.0008.1.01.5	PL	HY935.N10	MOTOR
2045	2.02.0009.1.01.6	PL	62.05.1000.339	MOTOR
2046	2.02.0010.1.01.7	PL	62.05.4000.34	HYD MOTOR
2047	2.02.0011.1.01.8	KA	HYS909X160HA1T/50/280BAR	DRIVE MOTOR
2048	2.02.0012.1.01.9	GE	A0350003	Emergency oil pump ass.
2049	2.02.0013.1.01.1	GE	BS550(IND)-22-10-11-00	HYDRAULIC MOTOR ASSEMBLY- DRIVING
2050	2.02.0014.1.01.2	GE	BS550(IND)-22-11-15-00	HYDRAULIC MOTOR ASSEMBLY - WORKING
2051	2.02.0015.1.01.3	CR	H1-B-210-A-A-TA-DAN-A-TB-DN-LN-N-A-30-NN-080-Z-29- NNN	HYDRAULIC MOTOR-2
2052	2.02.0016.1.01.4	CR	CA50	HYDRAULIC MOTOR
2053	2.02.0017.1.01.5	CR	11160334(TMT315EMD)	HYDRAULIC MOTOR-4
2054	2.02.0018.1.01.6	CR	151Z3264(TMT315)	HYDRAULIC MOTOR-5
2055	2.02.0019.1.01.7	CR	TMT470EMD	HYDRAULIC MOTOR-6
2056	2.02.0020.1.01.8	CR	11119830(TMT250EMD)	HYDRAULIC MOTOR-7
2057	2.02.0021.1.01.9	CR	MSE082 115 F09 2A50 BE	HYDRAULIC MOTOR-8
2058	2.02.0022.1.01.1	CR	A2FM63/61W-VAB027H	HYDRAULIC MOTOR-9
2059	2.02.0023.1.01.2	CR	TMT400EMD	HYDRAULIC MOTOR-10
2060	2.02.0024.1.01.3	CR	M5AS 016 ZN24 A1Y 00000 42	HYDRAULIC MOTOR-11
2061	2.02.0025.1.01.4	CR	MOTO4A01B0000AOA	HYDRAULIC MOTOR-12
2062	2.02.0026.1.01.5	CR	1303111	HYDRAULIC MOTOR-13
2063	2.02.0027.1.01.6	CR	BS550(IND)-22-14-13-00	HYDRAULIC MOTOR ASSEMBLY
2064	2.02.0028.1.01.7	CR	BS550(IND)-22-13-10-00	HYDRAULIC MOTOR ASSEMBLY
2065	2.02.0029.1.01.8	CR	BS550(IND)-22-15-11-00	HYDRAULIC MOTOR ASSEMBLY
2066	2.02.0030.1.01.9	CR	40103552	VARIABLE PLUNGER MOTOR
2067	2.02.0031.1.01.1	Shifted to Ann II		
2068	2.02.0032.1.01.2	Shifted to Ann II		
2069	2.02.0033.1.01.3	Shifted to Ann II		
2070	2.02.0034.1.01.4	Shifted to Ann II		
2071	2.02.0035.1.01.5	Shifted to Ann II		
2072	2.02.0036.1.01.6	PL	HYD MOTOR	HY701X12LI and Denision part no TM4C-012-2L00-A1
2073	2.02.0037.1.01.7	PL	HYDRAULIC MOTOR	HY701X12RE and Denision part no TM4C-012-2R00-A1
2074	2.02.0038.1.01.8	PL	HY949x170HA1TU-60/230	VARIABLE DISPLACEMENT MOTOR
2075	2.02.0039.1.01.9	PL	HY938x55/MS/FS	HYDRAULIC MOTOR (DTS Motor)
2076	2.02.0040.1.01.1	PL	HY910x32/VBB040	HYDRAULIC MOTOR
2077	2.02.0041.1.01.2	PL	HY952x160E2AA/107/30L	VARIABLE DISPLACEMENT MOTOR (Cutter chain)
2078	2.02.0042.1.01.3	PL	HYS909x107HA1TF/QMAX98CM3	VARIABLE DISPLACEMENT MOTOR (Screen motor)
2079	2.02.0043.1.01.4	PL	HY940x490	HYDRAULIC MOTOR

2080	2.02.0044.1.01.5	PL	HY940x390	HYDRAULIC MOTOR
2081	2.02.0045.1.01.6	PL	HY912x250+DGRF314/154-5311	MOTOR+BRAKE
2082	2.02.0046.1.01.7	PL	HY910x90/61W-VAB010	PISTON MOTOR
2083	2.02.0047.1.01.8	PL	HYS909x55HA1T/40/200BAR	VARIABLE DISPLACEMENT MOTOR
2084	2.02.0048.1.01.9	PL	HY925N32	Hydraulic motor (Chord tensioning)
2085	2.02.0049.1.01.1	PL	HY.701.N08.L	Hydraulic Motor
2086	2.02.0050.1.01.2	PL	HY952W45X160T2DA-28A/47/152	VARIABLE DISPLACEMENT MOTOR
2087	2.02.0051.1.01.3	PL	HY944N50	MOTOR
2088	2.02.0052.1.01.4	LO	152547	MOTOR HYD GEAR FX 1.37CIR; A2 KEY BI 12FORB
2089	2.02.0053.1.01.5	LO	247647	MOTOR HYD HST VAR 250CC; 15T PROP CNTRL
2090	2.02.0054.1.01.6	PL	62. 05.4000.422	MOTOR
2091	2.03.0001.1.01.8	PL	HY940X200-SO SUBSTITUTE HY940X200	MOTOR
2092	2.03.0002.1.01.9			
2093	2.03.0003.1.01.1	PL	62.05.1000.350	STOP VALVE
2094	2.03.0004.1.01.2		Shifted to Ann II	
2095	2.03.0005.1.01.3		Shifted to Ann II	
2096	2.03.0006.1.01.4		Shifted to Ann II	
2097	2.03.0007.1.01.5		Shifted to Ann II	
2098	2.03.0008.1.01.6	PL	62.05.3000.378	HYDRAULIC VALVE
2099	2.03.0009.1.01.7		Repeated item	
2100	2.03.0010.1.01.8	PL	62.05.3000.516	HYD.CONTROL VALVE
2101	2.03.0011.1.01.9	PL	62.05.3000.575	CONTROL VALVE
2102	2.03.0012.1.01.1		Shifted to Ann II	
2103	2.03.0013.1.01.2		Shifted to Ann II	
2104	2.03.0014.1.01.3		Shifted to Ann II	
2105	2.03.0015.1.01.4	PL	62.05.3000.713	HYDRAULIC VALVE
2106	2.03.0016.1.01.5	PL	62.05.4000.266	PRESSURE VALVE
2107	2.03.0017.1.01.6			
2108	2.03.0018.1.01.7	PL	62.05.4000.385	HYDRAULIC VALVE
2109	2.03.0019.1.01.8	PL	62.05.4000.386	CONTROL VALVE
2110	2.03.0020.1.01.9	PL	62-05-2000-138	CONTROL VALVE
2111	2.03.0021.1.01.1	PL	62.05.2000.109	VALVE
2112	2.03.0022.1.01.2	PL	79965/2105	SAFETY VALVE
2113	2.03.0023.1.01.3	PL	79965/2120	SAFETY VALVE
2114	2.03.0024.1.01.4	PL	HY.151.204	VALVE BLOCK WITH PROPORTIONAL VALVE FEEDER FOR 09-3X
2115	2.03.0025.1.01.5		Repeated item	
2116	2.03.0026.1.01.6	PL	HY.511.38.160 BAR	PRESSURE RELIEF VALVE / SATELLITE BY PASS VALVE
2117	2.03.0027.1.01.7	PL	HY-06-RSM	DC VALVE FOR LOGIC VALVE
2118	2.03.0028.1.01.8	PL	HY151.13/3	CHECK VALVE
2119	2.03.0029.1.01.9	PL	HY151.13/5	CHECK VALVE
2120	2.03.0030.1.01.1	PL	HY151.187/75 BAR	PROP. CONTROL VALVE
2121	2.03.0031.1.01.2	PL	HY151.188/5	RADIATOR SAFETY VALVE
2122	2.03.0032.1.01.3	PL	62.05.3000.235	THREE-WAY COCK
2123	2.03.0033.1.01.4		Shifted to Annexure II	
2124	2.03.0034.1.01.5	PL	HY151.190	SAFETY VALVE
2125	2.03.0035.1.01.6	PL	HY151.215	SAFETY VALVE
2126	2.03.0036.1.01.7	PL	HY151.217/5BAR	CHECK VALVE
2127	2.03.0037.1.01.8	PL	HY151.33/0,5BAR06	CHECK VALVE
2128	2.03.0038.1.01.9	PL	HY151.33/0,5BAR12	CHECK VALVE
2129	2.03.0039.1.01.1	PL	HY151.33/5BAR16	CHECK VALVE
2130	2.03.0040.1.01.2	PL	HY151.33/5BAR24	CHECK VALVE
2131	2.03.0041.1.01.3	PL	HY-151-172A WITH HY-511-38/160 BAR	SATELLITE BYPASS VALVE
2132	2.03.0042.1.01.4	PL	HY155.11	LOCKING BLOCK
2133	2.03.0043.1.01.5	PL	HY157.103 SUB. HY157.80	CURRENT REGULATION VALVE
2134	2.03.0044.1.01.6	PL	HY157.106/270	FLOW CONTROL VALVE
2135	2.03.0045.1.01.7	PL	HY-157-27-160 BAR	HYD SAFTY VLAVE
2136	2.03.0046.1.01.8		Shifted to Annexure II	
2137	2.03.0047.1.01.9	PL	HY511.50/350 SUB. HY511.50/315	SAFETY VALVE
2138	2.03.0048.1.01.1		Shifted to Annexure II	
2139	2.03.0049.1.01.2	PL	HY511.52/60LT SUB. 62.05.3000.568	VALVE BLOCK
2140	2.03.0050.1.01.3	PL	HY6RSU-SRP	HYDRALIC VALVE
2141	2.03.0051.1.01.4	PL	HYA10-RPE50.D	PROP. CONTROL VALVE
2142	2.03.0052.1.01.5		Shifted to Annexure II	
2143	2.03.0053.1.01.6	PL	HY-M10RMEEEJ	CONTROL VALVE BLOCK
2144	2.03.0054.1.01.7	PL	HY-M10RMJ	CONTROL VALVE BLOCK
2145	2.03.0055.1.01.8	PL	HY-M10RMJJ	CONTROL VALVE BLOCK
2146	2.03.0056.1.01.9	PL	HYN.25-RPE2-325.TDSO151	PROPORTIONAL VALVE
2147	2.03.0057.1.01.1		Shifted to Annexure II	
2148	2.03.0058.1.01.2	PL	I79965/2080 SUB. I79965/1080	SAFETY VALVE
2149	2.03.0059.1.01.3	PL	167507	VENTED RELIEF VALVE
2150	2.03.0060.1.01.4	KE	187898	VALVE BANK SOL TYPE BRM
2151	2.03.0061.1.01.5	KE	729345	CONTROL VALVE BANK FOR BRM

2152	2.03.0062.1.01.6	KE	732159	VALVE BRM
2153	2.03.0063.1.01.7	KE	733668	VALVE LOCK FOR BRM
2154	2.03.0064.1.01.8	KE	735893	VALVE BANK MANUAL 5 SELECTION
2155	2.03.0065.1.01.9	KE	4107030	ELECTRO VALVE (24V)
2156	2.03.0066.1.01.1		Shifted to Ann II	
2157	2.03.0067.1.01.2		Shifted to Ann II	
2158	2.03.0068.1.01.3		Shifted to Ann II	
2159	2.03.0069.1.01.4		Shifted to Ann II	
2160	2.03.0070.1.01.5		Shifted to Ann II	
2161	2.03.0071.1.01.6		Shifted to Ann II	
2162	2.03.0072.1.01.7		Shifted to Ann II	
2163	2.03.0073.1.01.8		Shifted to Ann II	
2164	2.03.0074.1.01.9		Shifted to Ann II	
2165	2.03.0075.1.01.1		Shifted to Ann II	
2166	2.03.0076.1.01.2		Shifted to Ann II	
2167	2.03.0077.1.01.3	AM	00L06G001	T.C VALVE T 28
2168	2.03.0078.1.01.4	AM	00LO554001	TV VALVE T-28
2169	2.03.0079.1.01.5	AM	OWC/DE/12	STOP VALVE FOR T 28
2170	2.03.0080.1.01.6	AM	OWC/DE/34	STOP VALVE FOR T-28
2171	2.03.0081.1.01.7	PH	4P11	PILOT OPERATED CHECK VALVE
2172	2.03.0082.1.01.8	PH	4P15	3/4" CHECK VALVE
2173	2.03.0083.1.01.9	PH	4P17	1/2" CHECK VALVE
2174	2.03.0084.1.01.1	PH	4P31	SHUT OFF VALVE
2175	2.03.0085.1.01.2	PH	4P41	VALVE BRAKE (4 SIGMENT)
2176	2.03.0086.1.01.3	PH	5P11	SECONDARY RELIEF VALVE
2177	2.03.0087.1.01.4	PH	8P18	OVER CENTRE VALVE
2178	2.03.0088.1.01.5	PH	0017159 C	RAIL WHEEL/CRAWLER DRIVE SELECTING (COMMANDO CYL.)
2179	2.03.0089.1.01.6	PH	6100046	SELECTOR VDM 07D-V-1-G (EMERGENCY WORKING)
2180	2.03.0090.1.01.7	PH	101011	VALVE CHK 5000PSI 160GPM; HYD 3PSI CRACK 32 SLIPIN
2181	2.03.0091.1.01.8	LO	100563	VALVE DRIVER CARD
2182	2.03.0092.1.01.9	LO	101481	NOZZLE-125GPM 1-1/2 NH MOUNT
2183	2.03.0093.1.01.1	LO	107697	SOLENOID VALVE .38 24VDC
2184	2.03.0094.1.01.2	LO	118547	VALVE ASSY DIRECTION CTRL SIZE 10 5000PSI 20GPM
2185	2.03.0095.1.01.3		Shifted to Ann II	
2186	2.03.0096.1.01.4	LO	165583	VALVE CHK 5000P 15GPM HYD D03 PILOT A B FROM P
2187	2.03.0097.1.01.5	LO	166225	SUBPLATE VALVE D05 OFFSET; 1.50 THK 1.25 OFFSET
2188	2.03.0098.1.01.6	LO	3 RD	PRESSURE REGULATOR
2189	2.03.0099.1.01.7	KA	D-633 R16KA-MONSM2	SERVO VALVE
2190	2.03.0100.1.01.8	KA	K/V 4/3 5KO.6.G.6	HYD CONTROL VALVE
2191	2.03.0101.1.01.9	KA	KV 4/2 5KO-10-G6/KV4/3-5KO-10G6	HYD.CONTROL VALVE
2192	2.03.0102.1.01.1	KA	KV4/2.5KO.6.G.51A	HYD.CONTROL VALVE
2193	2.03.0103.1.01.2	KA	KV4/3 5KO 10 G2	HYD. CONTROL VALVE
2194	2.03.0104.1.01.3	KA	MPKV 10/3MP 204	REDUCING VALVE
2195	2.03.0105.1.01.4	KA	MPKV 16/3 F3R22404	SAFETY VALVE
2196	2.03.0106.1.01.5	KA	MPKV 25/3 FIV204/MKPV25/3FIV2	SAFETY VALVE
2197	2.03.0107.1.01.6	PL	HY152.03	STOPCOCK
2198	2.03.0108.1.01.7	PL	II50172/2A1L+A66269 SUBSTITUTE I26684	STOP COCK
2199	2.03.0109.1.01.8	PL	ST-SILED24V	TERMINAL
2200	2.03.0110.1.01.9		Shifted to Ann II	
2201	2.03.0111.1.01.1		Repeated item	
2202	2.03.0112.1.01.2		Shifted to Ann II	
2203	2.03.0113.1.01.3		Repeated item	
2204	2.03.0114.1.01.4	PL	HY.511.39.A	pressure reducing valve
2205	2.03.0115.1.01.5		Repeated item	
2206	2.03.0116.1.01.6	PL	62.05.3000.379-STKL SUBSTITUTE 62.05.3000.379	CONTROL VALVE
2207	2.03.0117.1.01.7	KA	DPZO-A37-LD/DE18	Proportional Valve
2208	2.03.0118.1.01.8	GE	CDC16A-23-09-01-00	Servo valve bank
2209	2.03.0119.1.01.9	GE	496A0600DWG/08	Valve bank
2210	2.03.0120.1.01.1	GE	WXBT-20A	Single-way valve
2211	2.03.0121.1.01.2	GE	WZT-DN20-3/4-087	Safety valve
2212	2.03.0122.1.01.3	GE	SC3/4	Shutter valve
2213	2.03.0123.1.01.4	GE	EQT4-62-07-500-1	Reversing valve
2214	2.03.0124.1.01.5	GE	PA12679-02-33	Two-posi. five-way solenoid valve
2215	2.03.0125.1.01.6	GE	PA12706-02-33	Three-posi. five-way solenoid valve (intermediate unloading)
2216	2.03.0126.1.01.7	GE	PA12705-02-33	Three-posi. five-way solenoid valve
2217	2.03.0127.1.01.8	GE	RFU 444-1/4	Flow control valve
2218	2.03.0128.1.01.9	CR	SV13-10-0-0-00	Solenoid Operated DRectional Manifold
2219	2.03.0129.1.01.1	CR	DG4V-3-2C-M-U-H-60	Solenoid Operated DRectional Manifold-1

2220	2.03.0130.1.01.2	CR	DG4V-3-6C-M-U-H5-60	Solenoid Operated DRectional Manifold-2
2221	2.03.0131.1.01.3	CR	SV3-10-0-0-00	Solenoid Operated DRectional Manifold-6
2222	2.03.0132.1.01.4	CR	SVJO.S08.03.00	Solenoid Operated Di- Rectional Manifold-8
2223	2.03.0133.1.01.5	CR	1800575	Solenoid Operated Di- Rectional Manifold-9
2224	2.03.0134.1.01.6	CR	HIC00419	Solenoid Operated Di- Rectional Manifold-10
2225	2.03.0135.1.01.7	CR	1800573	Solenoid Operated Di- Rectional Manifold-11
2226	2.03.0136.1.01.8	CR	1800572	Solenoid Operated Di- Rectional Manifold-12
2227	2.03.0137.1.01.9	CR	1800580	Solenoid Operated Di- Rectional Manifold-13
2228	2.03.0138.1.01.1	CR	1800574	Solenoid Operated Di- Rectional Manifold-14
2229	2.03.0139.1.01.2	CR	PKS9581RF-1/4-4633	Two-position and five-port solenoid valve-1
2230	2.03.0140.1.01.3	CR	PKS9581RF-1/2-4633	Two-position and five-port solenoid valve-9
2231	2.03.0141.1.01.4	CR	PKS9581RFE-1/4-24 VDC	Three-position and five-port valve-1
2232	2.03.0142.1.01.5	CR	40101858	THREE WAY VALVE OF WIPER
2233	2.03.0143.1.01.6		Shifted to Ann II	
2234	2.03.0144.1.01.7	PL	HY153.02	Four Way Valve
2235	2.03.0145.1.01.8		Shifted to Ann II	
2236	2.03.0146.1.01.9		Shifted to Ann II	
2237	2.03.0147.1.01.1		Shifted to Ann II	
2238	2.03.0148.1.01.2		Shifted to Ann II	
2239	2.03.0149.1.01.3		Shifted to Ann II	
2240	2.03.0150.1.01.4		Shifted to Ann II	
2241	2.03.0151.1.01.5		Shifted to Ann II	
2242	2.03.0152.1.01.6		Shifted to Ann II	
2243	2.03.0153.1.01.7		Shifted to Ann II	
2244	2.03.0154.1.01.8		Shifted to Ann II	
2245	2.03.0155.1.01.9	PL	PVG32/159U8169(4FACH)	PROP. CONTROL VALVE
2246	2.03.0156.1.01.1	PL	PVG32/159U8167(3FACH)	PROP. CONTROL VALVE
2247	2.03.0157.1.01.2	PL	PVG32/159U8168(3FACH)	PROP. CONTROL VALVE
2248	2.03.0158.1.01.3	PL	DV16-1.1/5-P-S	VALVE
2249	2.03.0159.1.01.4	PL	HY151.03/1.5KPL.	CHECK VALVE
2250	2.03.0160.1.01.5	PL	HY151.34	CHECK VALVE
2251	2.03.0161.1.01.6	PL	HY155.10-A	CHECK VALVE
2252	2.03.0162.1.01.7	PL	HY100.07	CHECK THROTTLE
2253	2.03.0163.1.01.8	PL	HY157.96	CURRENT REGULATION VALVE
2254	2.03.0164.1.01.9	PL	HY157.109	CURRENT REGULATION VALVE
2255	2.03.0165.1.01.1	PL	HY152.04	STOPCOCK
2256	2.03.0166.1.01.2	PL	HY151.177-00/SAE	Changeover valve
2257	2.03.0167.1.01.3	SI	237-6500POS-06	THROTTLE CUM CHECK VALVE
2258	2.03.0168.1.01.4	SI	237-6500POS-13	BRIDGE LIFTING DIRECTION CONTROL VALVE
2259	2.03.0169.1.01.5	SI	237-6500POS-14	LETAL MOVEMENT DIRECTION CONTROL VALVE
2260	2.03.0170.1.01.6	LO	103776	VALVE BALL 3000PSI 57 GPM HYD 2061 2061C HANDLE
2261	2.03.0171.1.01.7	LO	111701	VALVE CHECK 0.38 NPT
2262	2.03.0172.1.01.8	LO	125910	VALVE SOL 1.50 NPT N CLSD 24 VDC
2263	2.03.0173.1.01.9	PL	HY151.172A	HYD VALVE (SATELLITE BYPASS VALVE)
2264	2.03.0174.1.01.1	PL	HY151.103A	HYD Servo Block without Valve
2265	2.03.0175.1.01.2	PL	HY157.48-A OR Sub Part no. HY157.17	RADIATOR
2266	2.03.0176.1.01.3	LO	B78865	Valve C3W Distribution
2267	2.03.0177.1.01.4	LO	A65990	Valve Ball 2.50 NPT Bronze 600#WOG
2268	2.03.0178.1.01.5	Colmar	H5535300	HYD SERVO CONTROL
2269	2.03.0179.1.01.6	KE	142862	CONTROL THROTTLE
2270	2.03.0180.1.01.7	KE	148607	MOTION CONTROL VALVE
2271	2.03.0181.1.01.8	KE	228104	VALVE BANK MANUAL
2272	2.03.0182.1.01.9	KE	228105	VALVE BANK MANUAL
2273	2.03.0183.1.01.1	KE	230153	MAXIMUM TORQUE VALVE
2274	2.03.0184.1.01.2	LO	236366	DIVIDER FLOW 2 SECT GEAR; 5.1-14.9 GPM PER SECTION
2275	2.03.0185.1.01.3	LO	101010	HOUSING CHECK VALVE 2461C SLIPIN SIZE 32 VALVE
2276	2.03.0186.1.01.4	LO	239282	VALVE CRTG PO CHECK; T11A PO OPEN
2277	2.03.0187.1.01.5	LO	173050	VALVE DIAPHRAGM 1.50 SPRINGLESS
2278	2.03.0188.1.01.6	LO	179684	VALVE REPAIR KIT 1.50; DIAPHRAGM BUNA N

2279	2.03.0189.1.01.7	LO	161649	HOUSING CHECK VALVE 2461C; SLIPIN SIZE 32 VALVE ALUM
2280	2.03.0190.1.01.8	LO	A32718	VALVE BALL 1.00 NPT BRONZE 600#WOG W/LOCK
2281	2.03.0191.1.01.9	LO	A64284	VALVE BALL 0.50 NPT BRONZE
2282	2.03.0192.1.01.1	LO	A65037	VALVE BALL .75 NPT BRONZE 600#WOG W/LOCK
2283	2.03.0193.1.01.2	LO	231298	VALVE BALL 32 FNPT; BRONZE 600PSI CWP W/LOCK
2284	2.03.0194.1.01.3	LO	209733	VALVE BALL REMOTE OPER NC; 16FBSPP 04BSPP 24VDC
2285	2.03.0195.1.01.4	LO	101682	BALL VALVE 32-61 MODIFIED
2286	2.03.0196.1.01.5	LO	A28748	VALVE SHUTTLE .50 FNPT
2287	2.03.0197.1.01.6	PL	HY511.54	Pressure limiting valve
2288	2.03.0198.1.01.7	PL	62.05.4000.372 SUB:HY511. 71/ W/ 15/ 42	Hydraulic Valves
2289	2.04.0001.1.01.9	PL	61.02.235	PUMP CYL.
2290	2.04.0002.1.01.1	PL	62.05.2000.184	CYL ROLLER CLAMP BCM
2291	2.04.0003.1.01.2	PL	62.05.3000.300	CYLINDER
2292	2.04.0004.1.01.3	PL	62.05.3000.353	HYD CYLINDER FOR BCM
2293	2.04.0005.1.01.4	PL	62.05.3000.60PL	CYLINDER ASCENDING SIDE FOR BCM
2294	2.04.0006.1.01.5	PL	62.05.3000.61PL	CYLINDER DESCENDING SIDE
2295	2.04.0007.1.01.6	PL	62.05.3000.63PL	HYD. CYLINDER FOR BCM
2296	2.04.0008.1.01.7	PL	62.05.3000.69PL	CYLINDER
2297	2.04.0009.1.01.8	PL	62.05.3204	PISTON ROD WITH PISTON
2298	2.04.0010.1.01.9	PL	62.11.305	HYD CYLINDER
2299	2.04.0011.1.01.1	PL	64.14.1055	PISTON
2300	2.04.0012.1.01.2	PL	64.14.1058	LIFTING CLAMP CYLINDER
2301	2.04.0013.1.01.3	PL	64.14.1059	LIFTING CLAMP CYLINDER
2302	2.04.0014.1.01.4	PL	CU 311-3007A LI	HOOK UP DOWN CYLINDER
2303	2.04.0015.1.01.5	PL	CU 311-3007A RE	HOOK UP DOWN CYLINDER
2304	2.04.0016.1.01.6	PL	EL-T2111.G4	CYLINDER BLOCK
2305	2.04.0017.1.01.7	SI	F1666	BRIDGE LIFTING CYLINDER
2306	2.04.0018.1.01.8	SI	F1667	BRAKE CYLINDER
2307	2.04.0019.1.01.9	SI	F1668	EXTRA LIFTING LOWERING CYLINDER
2308	2.04.0020.1.01.1	SI	F1669	RAIL CLAMP CYLINDER
2309	2.04.0021.1.01.2	PL	HY600.05A(A)	DAMPER CYLINDER
2310	2.04.0022.1.01.3	PL	HZD06.080.040.003 SUB. HZD06.080.040.001	GUIDE BUSH
2311	2.04.0023.1.01.4	PL	HZD10.080.040.0710.010 SUB. HZD10.080.040.0710.1.001	PISTON ROD WITH PISTON
2312	2.04.0024.1.01.5	PL	HZD10.080.040.0760.001	PISTON ROD WITH PISTON
2313	2.04.0025.1.01.6	PL	HZD10.080.040.0760.010	PISTON ROD WITH PISTON
2314	2.04.0026.1.01.7	PL	HZD10.080.040.0835.010	PISTON ROD WITH PISTON
2315	2.04.0027.1.01.8	PL	HZDGB.063.036.0765.1.010	CYLINDER
2316	2.04.0028.1.01.9	PL	HZDGB.080.040.0760.1.001	TAMPING UNIT LIFTING LOWRING [UP/DOWN] CYL
2317	2.04.00291.01.1	PL	HZDPA.063.036.0715.1.001	CYLINDER
2318	2.04.0030.1.01.2	PL	HZDPA.080.040.0710.1.002	CYLINDER
2319	2.04.0031.1.01.3	PL	HZDPA.080.040.0760.1.001	CYLINDER
2320	2.04.0032.1.01.4	PL	HZDPA.080.040.0835.01.001	HYD CYLINDER FOR TAMPING UNIT UP / DOWN [IMPORTED] own PLASSER INDIA
2321	2.04.0033.1.01.5	PL	HZDQB.080.040.0600.1.001	CYLINDER
2322	2.04.0034.1.01.6	PL	HZGB.040.025.0130.1	BRAKE CYLINDER
2323	2.04.0035.1.01.7	PL	HZGB.040.025.0170.1	LOCKING CYLINDER
2324	2.04.0036.1.01.8	PL	HZGB.050.036.0080.001	CYLINDER
2325	2.04.0037.1.01.9	PL	HZGB.063.036.0100.1	CLAMP CYLINDER
2326	2.04.0038.1.01.1	PL	HZGB.063.036.0190.1	HYD CYLINDER FOR FRM
2327	2.04.00391.01.2	PL	HZGB.063.036.0400.1	HYD CYLINDER FOR FRM
2328	2.04.0040.1.01.3	PL	HZGB.063.036.0775.1	HYD CYLINDER FOR FRM
2329	2.04.00411.01.4	PL	HZGB.063.36.0190.1	HYD. CYLINDER FOR BCM
2330	2.04.0042.1.01.5	PL	HZGB.063.36.0425.1	CYLINDER
2331	2.04.0043.1.01.6	PL	HZGB.080.036.0180.2	SATELLITE SUPPORT CYLINDER
2332	2.04.0044.1.01.7	PL	HZGB.080.036.0305.1	CYLINDER
2333	2.04.0045.1.01.8	PL	HZGB.080.036.1000.1	CYLINDER
2334	2.04.0046.1.01.9	PL	HZGB.080.045.0200.2 Sub. HZGB.080.045.0200.1	HYD. CYLINDER
2335	2.04.00471.01.1	PL	HZGB.080.050.0900.1	CYLINDER
2336	2.04.0048.1.01.2	PL	HZGB.100.063.0200.1	CYLINDER
2337	2.04.0049.1.01.3	PL	HZGB.100.063.1000.1	CYLINDER
2338	2.04.0050.1.01.4	PL	HZGB.125.063.0250.1	CYLINDER
2339	2.04.0051.1.01.5	PL	HZGB.125.063.0950.1	CYLINDER
2340	2.04.0052.1.01.6	PL	HZGB.125.090.1000.1	CYLINDER
2341	2.04.0053.1.01.7	PL	HZMB.080.045.0160.2	CYLINDER
2342	2.04.0054.1.01.8	PL	HZMB.100.045.0120.2	CYLINDER
2343	2.04.0055.1.01.9	PL	HZMB.100.063.0600.2.041	HYD CYLINDER FOR BCM
2344	2.04.0056.1.01.1	PL	HZMB.100.063.1400.2.040	HYD CYLINDER FOR BCM

2345	2.04.0057.1.01.2	PL	HZMB.100.063.1600.2.001	HYD CYLINDER FOR BCM
2346	2.04.0058.1.01.3	PL	HZMB.125.063.2100.1.001	HYD CYLINDER FOR BCM
2347	2.04.0059.1.01.4	PL	HZMBV.100.063.1170.2	HYD CYLINDER FORFRM
2348	2.04.0060.1.01.5	PL	HZMBV.125.090.2250.1	HYD CYLINDER FOR BCM
2349	2.04.0061.1.01.6	PL	HZPA.050.036.0800.1.001+ yoke HZ 60.01.2	CYLINDER
2350	2.04.0062.1.01.7	PL	HZQB.080.050.0800.1.003	BOOSTING CYLINDER
2351	2.04.0063.1.01.8	PL	HZQk.125.050.0410.2.001	HYD CYLINDER FOR BCM
2352	2.04.0064.1.01.9	PL	HZSA 163.153N	T/U LOCK CYLINDER
2353	2.04.0065.1.01.1	PL	HZSI-G.50.429	FORK CYLINDER
2354	2.04.0066.1.01.2	PL	NZGB.080.045.0200.2	HYD CYLINDER FORFRM
2355	2.04.0067.1.01.3	PL	NZGB.100.045.0300.1.001	LINING CYLINDER
2356	2.04.0068.1.01.4	PL	NZGB.100.050.0400.1	LATERAL CONTROL CYLINDER
2357	2.04.0069.1.01.5	PL	NZGB.125.050.0450.1.002	TRACK LIFTING CYLINDER
2358	2.04.0070.1.01.6	PL	RM08A.27.0130	CYLINDER
2359	2.04.0071.1.01.7	PL	UD 50.1900	SUPPORT CYLINDER
2360	2.04.0072.1.01.8	PL	UD 50.200	SUPPORT CYL
2361	2.04.0073.1.01.9	PL	UD 50.2200	SUPPORT CYLINDER
2362	2.04.0074.1.01.1	PL	UD 65.1177	NUT FOR T.UNIT LIFT CYL
2363	2.04.0075.1.01.2	PL	UD160.50-DG	BRAKE CYLINDER
2364	2.04.0076.1.01.3	PL	UD313.3305LI	HOOK UP DOWN CYLINDER WITH YOKE
2365	2.04.0077.1.01.4	PL	UD313.3305RE	HOOK UP DOWN CYLINDER WITH YOKE
2366	2.04.0078.1.01.5	PL	UD50.100	CYLINDER
2367	2.04.0079.1.01.6	PL	UD50.1950-A WITHOUT ROLLER	CYLINDER
2368	2.04.0080.1.01.7	PL	UD50.2800	CYLINDER
2369	2.04.0081.1.01.8	PL	UD50.3100	SUPPORT CYLINDER
2370	2.04.0082.1.01.9	PL	UD50.3700	SUPPORT CYLINDER
2371	2.04.0083.1.01.1	PL	UD50.3900(A)	WHEEL SUPPORT CYLINDER
2372	2.04.0084.1.01.2	KE	174977 / 781965	WING IN AND OUTER CYL
2373	2.04.0085.1.01.3	KE	184092	WING TEMP.I/O CYLINDER
2374	2.04.0086.1.01.4	KE	218527	WING TILTING CYLINDER
2375	2.04.0087.1.01.5	KE	662984	ASSEMBLY PISTON ROD
2376	2.04.0088.1.01.6	KE	707917	PLOW BROOM U/D CYLINDER
2377	2.04.0089.1.01.7	KE	730563	PLOW I/O CYLINDER
2378	2.04.0090.1.01.8	KE	781967	WING TILT CYLINDER
2379	2.04.0091.1.01.9	KE	781970	HYD. CYLINDER
2380	2.04.0092.1.01.1	KE	1260637	WORKING CYLINDER
2381	2.04.0093.1.01.2	AM	0017311 C	CLAMP LIFT CYLINDER
2382	2.04.0094.1.01.3		Shifted to Ann-II	
2383	2.04.0095.1.01.4	PH	1P3	PISTON HAFT I
2384	2.04.0096.1.01.5	PH	1P6	PISTON HAFT II
2385	2.04.0097.1.01.6	PH	5P10	SLEW CYLINDER
2386	2.04.0098.1.01.7	LO	113604	CYLINDER HYD 2.00BX1.50R 6.00S HEAD MT THD ROD
2387	2.04.0099.1.01.8	LO	117534	CYLINDER HYD 3.50BX1.50RX14.00S
2388	2.04.0100.1.01.9	LO	119467	CYLINDER HYD 1.50BX1.00RX7.00S
2389	2.04.0101.1.01.1	LO	124422	CYLINDER HYD 1.50B 1.00R 07.00S PORTS AT ROD END
2390	2.04.0102.1.01.2	LO	159321	AXLE SUPPORT WELDT
2391	2.04.0103.1.01.3	LO	159322	AXLE SUPPORT ASSY
2392	2.04.0104.1.01.4	KA	1023.48.65.000	HYD CYL for LIFTING THE RAISING & LINING DEVEFOR TRACK LIFTING WITH YOKE
2393	2.04.0105.1.01.5	PL	HZDGB.080.040.0710.1.001WITHUD67.1400.11	CYLINDER+GUIDE BUSH
2394	2.04.0106.1.01.6	PL	HZDGB.080.040.0760.1.001WITH UD67.1400.11	CYLINDER+GUIDE BUSH
2395	2.04.0107.1.01.7	PL	HZQB.050.036.0600.1.002	CYLINDER WITHOUT PRESSURE HEAD
2396	2.04.0108.1.01.8		Repeated item	
2397	2.04.0109.1.01.9	PL	HZMBV.080.050.0400.2.001	CYLINDER
2398	2.04.0110.1.01.1	PL	HZPA.050.036.0800.1.001	CYLINDER
2399	2.04.0111.1.01.2	PL	HZMB.080.045.0120.2	CYLINDER
2400	2.04.0112.1.01.3	PL	HZGB.063.036.0190.1.001	CYLINDER
2401	2.04.0113.1.01.4	PL	HZGB.063.036.0200.1	CYLINDER
2402	2.04.0114.1.01.5	PL	HZPB.040.025.0220.2.001	CYLINDER
2403	2.04.0115.1.01.6	PL	HZMB.063.040.0600.1.009	CYLINDER
2404	2.04.0116.1.01.7	PL	62.05.3000.63PL.S20	CYLINDER
2405	2.04.0117.1.01.8	PL	HZMB.050.025.0300.1	CYLINDER
2406	2.04.0118.1.01.9	PL	HZMB.080.050.1780.1.001	CYLINDER
2407	2.04.0119.1.01.1	PL	HZMB.063.036.0250.2	CYLINDER
2408	2.04.0120.1.01.2	PL	HZMB.063.025.0365.2	CYLINDER
2409	2.04.0121.1.01.3	PL	HZPK.063.036.0560.1.005	CYLINDER
2410	2.04.0122.1.01.4		Repeated item	
2411	2.04.0123.1.01.5	PL	NZGB.080.036.0950.1	CYLINDER
2412	2.04.0124.1.01.6	PL	19X1200	S.S.STRIP
2413	2.04.0125.1.01.7	PL	2013-08-00.85 SUBSTITUTE 1620-M	NUT
2414	2.04.0126.1.01.8	PL	2020-01-00.31 SUBSTITUTE NW2-400BAR	HOSE
2415	2.04.0127.1.01.9		Shifted to Annexure II	

2416	2.04.0128.1.01.1		Shifted to Annexure II	
2417	2.04.0129.1.01.2	PL	404-23034-1	RING
2418	2.04.0130.1.01.3		Shifted to Annexure II	
2419	2.04.0131.1.01.4	PL	62.14.2182	NUT
2420	2.04.0132.1.01.5	PL	HZGB.063.040.0320.1.043	Hydraulic Cylinder
2421	2.04.0133.1.01.6	PL	HZGB.063.036.0050.1.001	Hydraulic Cylinder
2422	2.04.0134.1.01.7	PL	HZDGB.080.040.0760.1.010	PISTON ROD
2423	2.04.0135.1.01.8	GE	CDCK16A-56-02-03-00	Traversing cylinder inst.
2424	2.04.0136.1.01.9	PL	HZDGB.063.036.0800.1.001 HW	TAMPING UNIT LIFTING CYL
2425	2.04.0137.1.01.1	PL	HZDPA.080.040.0810.1.002	Hydraulic Cylinder
2426	2.04.0138.1.01.2	PL	HZDPA.080.040.0810.1.002P A	Hydraulic Cylinder
2427	2.04.0139.1.01.3	PL	HZDPA.080.040.0835.1.001P A	TAMPING UP/DN CYLINDER
2428	2.04.0140.1.01.4	AM	17311	Extra Lifting Cylinder (Grips lift cylinder)
2429	2.04.0141.1.01.5	CR	40105638	HOOK LIFTING CYLINDER
2430	2.04.0142.1.01.6		Shifted to Annexure II	
2431	2.04.0143.1.01.7	GE	CDCK16A-56-09	Lining cylinder
2432	2.04.0144.1.01.8	GE	TE03-80.01.001.00	Left lifting cylinder
2433	2.04.0145.1.01.9	GE	TE03-80.01.001.00Re	Right lifting cylinder
2434	2.04.0146.1.01.1	GE	CDCK16A-50(I)-02-0 9-01	Unit traversing cylinder
2435	2.04.0147.1.01.2	GE	YD432D-02(II)-01-02	Car body support cylinder
2436	2.04.0148.1.01.3	GE	DCL32-02(I)-07-04	Axle box support cylinder
2437	2.04.0149.1.01.4	GE	CDCK16A-50(I)-02-0 8-01	Frame traversing cylinder
2438	2.04.0150.1.01.5	GE	CDC16A-50(II)-10-05	Pressing cylinder
2439	2.04.0151.1.01.6	CR	Φ110/80-1620.2040_BS550 (IND)-07	HYDRAULIC CYLINDER- 1-1
2440	2.04.0152.1.01.7	CR	Φ80/45-120.380_BS550 (IND)-07	HYDRAULIC CYLINDER- 2-1
2441	2.04.0153.1.01.8	CR	Φ80/40-150.60_BS550 (IND)- 07	HYDRAULIC CYLINDER3-1
2442	2.04.0154.1.01.9	CR	Φ63/36-120.460_BS550 (IND)-07	HYDRAULIC CYLINDER4-1
2443	2.04.0155.1.01.1	CR	Φ100/70-830.1200_BS550 (IND)-07	HYDRAULIC CYLINDER5-1
2444	2.04.0156.1.01.2	CR	Φ63/45-1020.1340_BS500W (IND)-08	HYDRAULIC CYLINDER- 7-1
2445	2.04.0157.1.01.3	CR	Ø80/40-880.1110_BS550 (IND)-10	HYDRAULIC CYLINDER-8-1
2446	2.04.0158.1.01.4	CR	Φ80/45-300.600_BS550 (IND)-11	HYDRAULIC CYLINDER-9-1
2447	2.04.0159.1.01.5	CR	Φ50/36-212.495_BS550 (IND)-11	HYDRAULIC CYLINDER-10
2448	2.04.0160.1.01.6	CR	Φ90/50-305.617_BS550 (IND)-13	HYDRAULIC CYLINDER-11-1
2449	2.04.0161.1.01.7	CR	Φ90/45-1100.1597_BS500W (IND)-13	HYDRAULIC CYLINDER- 12-1
2450	2.04.0162.1.01.8	CR	Φ80/45-130.265_BS500W (IND)-13	HYDRAULIC CYLINDER-13-1
2451	2.04.0163.1.01.9	CR	Φ90/45-600.947_BS500W (IND)-13	HYDRAULIC CYLINDER-14-1
2452	2.04.0164.1.01.1	CR	Φ110/80-170.1350_BS500W (IND)-13	HYDRAULIC CYLINDER- 15-1
2453	2.04.0165.1.01.2	CR	Φ63/32-325.570_BS500W (IND)-13	HYDRAULIC CYLINDER-16-1
2454	2.04.0166.1.01.3	CR	Φ63/45-210.455_BS500W (IND)-13	HYDRAULIC CYLINDER-17-1
2455	2.04.0167.1.01.4	CR	Φ110/80- 1620.2040_BS550(IND)-07	HYDRAULIC CYLINDER-1
2456	2.04.0168.1.01.5	CR	Φ80/45- 120.380_BS550(IND)-07	HYDRAULIC CYLINDER-2
2457	2.04.0169.1.01.6	CR	JB/T7940.2- M10X1(GB/T1153)	ANGLE HYDRAULIC GREASE NIPPLE
2458	2.04.0170.1.01.7	CR	Φ80/40- 150.600_BS550(IND)-07	HYDRAULIC CYLINDER-1
2459	2.04.0171.1.01.8	CR	Φ63/36- 120.460_BS550(IND)-07	HYDRAULIC CYLINDER-2
2460	2.04.0172.1.01.9	CR	Ø80/40- 880.1110_BS550(IND)-10	HYDRAULIC CYLINDER
2461	2.04.0173.1.01.1	CR	Φ90/50-305.617_BS550	CYLINDER
2462	2.04.0174.1.01.2	CR	BS500W(IND)-13-01-17-00	CYLINDER BASE
2463	2.04.0175.1.01.3	CR	Φ90/45- 1100.1597_BS500W(IND)-13	CYLINDER-1
2464	2.04.0176.1.01.4	CR	Φ80/45- 130.265_BS500W(IND)-13	CYLINDER-2
2465	2.04.0177.1.01.5	CR	Φ90/45- 600.947_BS500W(IND)-13	CYLINDER-3
2466	2.04.0178.1.01.6	CR	Φ110/80- 170.1350_BS500W(IND)-13	CYLINDER-4
2467	2.04.0179.1.01.7	CR	Φ63/32- 325.570_BS500W(IND)-13	CYLINDER-1
2468	2.04.0180.1.01.8	CR	Φ63/45- 210.455_BS500W(IND)-13	CYLINDER-2

2469	2.04.0181.1.01.9	CR	23085460	CYLINDER(HOOK IN/OUT)
2470	2.04.0182.1.01.1	CR	40105431	CYLINDER(FOR CLAMP ROLLER)
2471	2.04.0183.1.01.2	CR	40102431	CYLINDER (BIG CYL)LIFTING UNIT UP/DOWN
2472	2.04.0184.1.01.3	CR	40102430	CYLINDER(LIFTING UNIT LEFT/RIGHT)
2473	2.04.0185.1.01.4	CR	40105368	CYLINDER(HOOK UP/DOWN)
2474	2.04.0186.1.01.5	CR	40103578/40095751	Hydraulic cylinder sealing ring (full set)
2475	2.04.0187.1.01.6	CR	40103558/40095762	Hydraulic cylinder sealing ring (full set)
2476	2.04.0188.1.01.7	CR	40104985	HYDRAULIC CYL.(TAMPING FRAME AND ROTOARY EQUIP)
2477	2.04.0189.1.01.8	CR	40102642	HYDRAULIC CYL(ROTARY CYL. ASSEMBLY)
2478	2.04.0190.1.01.9	CR	40102640	LIFTING OIL CYL.
2479	2.04.0191.1.01.1	CR	40104956	CYLINDER(LIFTING UNIT LIFTING CYL.)
2480	2.04.0192.1.01.2	CR	40106838	CYLINDER(FRONT CLAMP ROLLER)
2481	2.04.0193.1.01.3	CR	23077185	CYLINDER(INSTALLATION OF FORWARD/BACKWARD CYL)
2482	2.04.0194.1.01.4	CR	40102433	CYLINDER(INSTALLATION OF FORWARD/BACKWARD CYL.)
2483	2.04.0195.1.01.5	CR	40106876	LIFTING HYD. CYL.
2484	2.04.0196.1.01.6	PL	NZGB.100.050.0100.2.001	AHM INCLINATION CYLINDER
2485	2.04.0197.1.01.7	PL	HZMB.050.036.0125.2.001	AHM INCLINATION LOCKING CYLINDER
2486	2.04.0198.1.01.8	PL	UD50.3900/HUB40MM	AXLE SUPPORT CYLINDER
2487	2.04.0199.1.01.9	PL	HZMB.100.063.0350.1.002	DTS LIFTING CYLINDER
2488	2.04.0200.1.01.1	PL	NZGB.080.036.0360.1	DTS LATERAL SHIFTING CYLINDER
2489	2.04.0201.1.01.2	PL	NZMBV.125.063.0645.2.001	CHAIN TENSION CYLINDER
2490	2.04.0202.1.01.3	PL	HZGB.150.090.1250.1.001	TROUGH LIFTING CYLINDER
2491	2.04.0203.1.01.4	PL	HZGB.100.063.1200.1.001	TROUGH LATERAL SHIFTING CYLINDER
2492	2.04.0204.1.01.5	PL	RE08.03.719	CUTTER BAR ELBOW LOCKING CYLINDER
2493	2.04.0205.1.01.6	PL	NZGB.100.050.0700.1	CLAMP 1 LIFTING CYLINDER
2494	2.04.0206.1.01.7	PL	NZGB.063.040.0540.1	CLAMP1 EXTENDED CYLINDER
2495	2.04.0207.1.01.8	PL	NZMBV.080.045.0900.1	CLAMP1 LINING CYLINDER
2496	2.04.0208.1.01.9	PL	HZMB.048.025.0110.2.001	CLAMP1 CLAMPS OPEN/CLOSE CYLINDER
2497	2.04.0209.1.01.1	PL	HZGB.050.036.0100.1.001	CLAMP2 CLAMPS OPEN/CLOSE CYLINDER
2498	2.04.0210.1.01.2	PL	HZMBV.080.036.0580.1.001	CLAMP2 LIFTING CYLINDER
2499	2.04.0211.1.01.3	PL	NZGB.080.045.0800.1	CLAMP2 LINING CYLINDER
2500	2.04.0212.1.01.4	PL	NZGB.100.050.0135.1	CLAMP2 INCLINATION CYLINDER
2501	2.04.0213.1.01.5	PL	HZGB.050.036.0160.2.001	PLOUGH PLATE OPEN/CLOSE CYLINDER
2502	2.04.0214.1.01.6	PL	NZGB.040.025.0670.1	CUTTER BAR LIFT CYLINDER
2503	2.04.0215.1.01.7	PL	RE11.00.500	A1 BELT CLAMPING CYL(TENSION)
2504	2.04.0216.1.01.8	PL	W33.200E	BALLAST DISTRIBUTING CYLINDER
2505	2.04.0217.1.01.9	PL	NZMBV.125.063.0150.2	CLAMP1 INCLINATION CYLINDER
2506	2.04.0218.1.01.1	PL	SU1600.502.3.11.19	DTS HYDRAULIC LOCK CYLINDER
2507	2.04.0219.1.01.2	PL	NZGB.080.050.0255.1	Troughs feeder plate in/out cylinder
2508	2.04.0220.1.01.3	PL	NZMBV.080.036.0170.001	FRAME INCLINATION ADJUSTMENT
2509	2.04.0221.1.01.4	PL	HZMBV.063.036.0350.1	A2 BELT SUSPENSION CYLINDER
2510	2.04.0222.1.01.5	PL	NZGB.063.036.0400.1	A3 BELT SUSPENSION CYLINDER
2511	2.04.0223.1.01.6	PL	HZMBV.050.025.0450.1	TOTAL EXCAVATION CHUTE ADJUSTMENT CYLINDER
2512	2.04.0224.1.01.7	PL	RE 150.3.002-1 and Sub Part no. 64.14.1119 or 64.14.1120	HYD CYLINDER
2513	2.04.0225.1.01.8	PL	UD50.550	HYD CYLINDER
2514	2.04.0226.1.01.9	PL	HZ60.01-2.001	FORK HEAD
2515	2.04.0227.1.01.1	PL	HZ60.01-2.005	FORK HEAD
2516	2.04.0228.1.01.2	PL	HZ60.01-2.007	FORK HEAD
2517	2.04.0229.1.01.3	PL	HZ60.01-2.014	FORK HEAD
2518	2.04.0230.1.01.4	PL	HZ60-30H8.38.50-1	YOKE
2519	2.04.0231.1.01.5	PL	HZ70.01-2.001	ROD END
2520	2.04.0232.1.01.6	PL	HZ70.01-2.002	ROD END
2521	2.04.0233.1.01.7	PL	HZ70.01-2.003	ROD END
2522	2.04.0234.1.01.8	PL	HZ70.01-5.001	JOINT HEAD
2523	2.04.0235.1.01.9	PL	HZ80.01-1	ROD END
2524	2.04.0236.1.01.1	PL	HZ80.01-2	ROD END
2525	2.04.0237.1.01.2	PL	HZ80.01-2.001	JOINT HEAD
2526	2.04.0238.1.01.3	PL	HZ80.01-3	ROD END
2527	2.04.0239.1.01.4	PL	HZ80.01-3.002	ROD END
2528	2.04.0240.1.01.5	LO	241420	CYLINDER HYD 2.50BX1.50R; 17.56S
2529	2.04.0241.1.01.6	LO	209554	CYLINDER HYD 2.00BX1.25R; 2.25S CLVS

2530	2.04.0242.1.01.7	LO	210333	CYLINDER HYD 1.50BX1.00R; 2.62S EYE X CLEVIS
2531	2.04.0243.1.01.8	LO	206799	CYL HYD 2.00B X 1.25R; 10.00S MTS FEEDBACK
2532	2.04.0244.1.01.9	LO	211893	CYL HYD 1.50B X .75R; 8.00S TRUNNION MOUNT
2533	2.04.0245.1.01.1	LO	252351-26	CYLINDER BUSHING KIT #2
2534	2.04.0246.1.01.2	LO	242914	BLOCK CYLINDER MOUNT
2535	2.04.0247.1.01.3	PL	HZGB.100.045.0300.1	CYLINDER
2536	2.04.0248.1.01.4	PL	6408.400004	Chain Tension Cylinder
2537	2.06.0001.1.01.2	LO	114722-0011.13	HOSE ASSEMBLY 06 08FORFS STR 5300P; 08FORFS STR
2538	2.06.0002.1.01.3	LO	130805-0112.00	HOSE ASSEMBLY 04 04FORFS STR 6500P; 04FORFS EL90
2539	2.06.0003.1.01.4	LO	114722-0011.63	HOSE ASSEMBLY 06 08FORFS STR 5300P; 08FORFS STR
2540	2.06.0004.1.01.5	LO	229107	HOSE CLAMP T-BOLT; 5.28 - 5.59
2541	2.06.0005.1.01.6	LO	252351-208	HOSE REPAIR KIT - SMALL
2542	2.06.0006.1.01.7	LO	H18527	FLANGE SPLIT CLAMP HALF 1.50 3000 PSI CODE 61
2543	2.06.0007.1.01.8	LO	H18528	FLANGE SPLIT CLAMP HALF 2.00 3000 PSI CODE 61
2544	2.07.0001.1.01.3		Shifted to Ann -II	
2545	2.07.0002.1.01.4	LO	2023251 SUBSTITUTE	BEF-WN-OBW MOUNTING BRACKET
2546	2.07.0003.1.01.5	LO	HY157.100	OIL COOLER
2547	2.07.0004.1.01.6	PL	HY.157.39	Hyd cooler
2548	2.07.0005.1.01.7	GE	20L	Accumulator-1
2549	2.07.0006.1.01.8	GE	SB330H-32A1/112A9- 330A	Accumulator-2
2550	2.07.0007.1.01.9	GE	CDCM 16A-23-01-01-00	Hydraulic oil tank body
2551	2.07.0008.1.01.1	LO	252351-156	HYDRAULIC POWER MAINTENANCE KIT, SMALL
2552	2.07.0009.1.01.2	LO	252351-157	HYDRAULIC POWER MAINTENANCE KIT, LARGE
2553	2.07.0010.1.01.3	LO	252351-158	HYDRAULIC POWER REPAIR KIT, SMALL
2554	2.07.0011.1.01.4	LO	252351-159	HYDRAULIC POWER REPAIR KIT, LARGE
2555	2.07.0012.1.01.5	LO	252351-160	HYDRAULIC POWER OVERHAUL KIT
2556	2.07.0013.1.01.6	LO	252351-161	HYDRAULIC BUGGY SYSTEM AINTENANCE KIT, SMALL
2557	2.07.0014.1.01.7	LO	252351-162	HYDRAULIC BUGGY SYSTEM AINTENANCE KIT, LARGE
2558	2.07.0015.1.01.8	LO	252351-163	HYDRAULIC BUGGY SYSTEM REPAIR KIT, SMALL
2559	2.07.0016.1.01.9	LO	252351-164	HYDRAULIC BUGGY SYSTEM REPAIR KIT, LARGE
2560	2.07.0017.1.01.1	LO	252351-165	HYDRAULIC BUGGY SYSTEM OVERHAUL KIT
2561	2.07.0018.1.01.2	LO	151959	COOLER OIL 250PSI 200GPM; 4861C 12FORB 2000PSI
2562	2.07.0019.1.01.3	LO	247736	COOLER OIL 250PSI 150GPM; 4061C 12FORB 1650PSI
2563	2.07.0020.1.01.4	LO	114901	CLAMP ACCUMULATOR HD; 9.1 IN DIA BLADDER STYLE
2564	2.07.0021.1.01.5	LO	125684	BREATHER TANK KLEENVENT 10 GALLON NOMINAL SIZE
2565	2.07.0022.1.01.6	LO	161652	MANIFOLD MACH 5000P 160G; HYD SLIPIN SIZE 32 2461C
2566	2.07.0023.1.01.7	LO	A24453	BREATHER
2567	2.07.0024.1.01.8	LO	252351-205	HYDRAULIC REPAIR KIT - SMALL
2568	2.07.0025.1.01.9	LO	H17401	FLANGE SPLIT CLAMP HALF 1.00 3000 PSI CODE 61
2569	2.07.0026.1.01.1	LO	252351-195	WATER SYSTEM MAINTENANCE KIT, SMALL
2570	2.07.0027.1.01.2	LO	252351-196	WATER SYSTEM MAINTENANCE KIT, LARGE
2571	2.07.0028.1.01.3	LO	252351-197	WATER SYSTEM REPAIR KIT, SMALL
2572	2.07.0029.1.01.4	LO	252351-198	WATER SYSTEM REPAIR KIT, LARGE
2573	2.07.0030.1.01.5	LO	252351-126	WATER SYSTEM MAINTENANCE KIT, SMALL
2574	2.07.0031.1.01.6	LO	252351-127	WATER SYSTEM MAINTENANCE KIT, LARGE
2575	2.07.0032.1.01.7	LO	252351-128	WATER SYSTEM REPAIR KIT, SMALL
2576	2.07.0033.1.01.8	LO	252351-129	WATER SYSTEM REPAIR KIT, LARGE
2577	2.07.0034.1.01.9	LO	252351-10	WATER SYSTEM KIT #1
2578	2.07.0035.1.01.1	LO	111540	WATER PUMP REPAIR KIT
2579	2.07.0036.1.01.2	LO	252351-56	WATER SYSTEM KIT #2
2580	2.07.0037.1.01.3	LO	214604	NOZZLE FIRE HOSE; 16FBSPP 8/15/30 GPM
2581	2.07.0038.1.01.4	LO	252351-218	WATER SYSTEM KIT

2582	2.07.0039.1.01.5	LO	156658	FAN OILER COOLER
2583	2.07.0040.1.01.6	LO	252351-214	OIL COOLER KIT
2584	2.07.0041.1.01.7	PL	62.05.6000.11	COOLING UNIT
2585	2.07.0042.1.01.8	PL	HY155.13 (SUB HY155.01)	LOCKING BLOCK
2586	2.08.0001.1.01.4	PL	455800001	BREATHER
2587	2.08.0002.1.01.5	PL	1181061 SUB. 1175893	FILTER ELEMENT
2588	2.08.0003.1.01.6	PL	2040SM	FILTER ELEMENT
2589	2.08.0004.1.01.7	PL	62.05.1000.113 ES	FILTER ELEMENT
2590	2.08.0005.1.01.8	PL	62.05.1000.187	FILTER ELEMENT
2591	2.08.0006.1.01.9	PL	62.05.1000.256	FILTER ELEMENT
2592	2.08.0007.1.01.1	PL	62.05.1000.270	FILTER ELEMENT
2593	2.08.0008.1.01.2	PL	62.05.1000.271	FILTER COMPLETE WITH ELEMENT
2594	2.08.0009.1.01.3	PL	62.05.1000.272	FILTER ELEMENT OF CONTROL PRESSURE FOR BCM
2595	2.08.0010.1.01.4	PL	62.05.1000.273	FILTER ELEMENT
2596	2.08.0011.1.01.5	PL	62.05.1000.293	FILTER ELEMENT
2597	2.08.0012.1.01.6	PL	62.05.1000.296	FILTER ELEMENT
2598	2.08.0013.1.01.7	PL	62.05.1000.424	FILTER ELEMENT
2599	2.08.0014.1.01.8	PL	62.05.1000.424/KOPF	FILTER HEAD
2600	2.08.0015.1.01.9	PL	62.05.1000.471	FILTER ELEMENT
2601	2.08.0016.1.01.1	PL	62.05.2000.95	HYDRAULIC FILTER
2602	2.08.0017.1.01.2	PL	62.05.2000.95ES	FILTER ELEMENT
2603	2.08.0018.1.01.3	PL	62.05.2000.96	FILTER ELEMENT
2604	2.08.0019.1.01.4	PL	62.05.4000.247	MAIN GEAR LUB FILTER FOR BCM
2605	2.08.0020.1.01.5	PL	62.05.4000.247ES	FILTER ELEMENT
2606	2.08.0021.1.01.6	PL	62.05.4000.274 ES	FILTER ELEMENT
2607	2.08.0022.1.01.7		Repeated item	
2608	2.08.0023.1.01.8	PL	64.04.3000.87	FILTER ELEMENT
2609	2.08.0024.1.01.9		Repeated item	
2610	2.08.0025.1.01.1	KA	CCH-802-FUI	SUCTION FILTER
2611	2.08.0026.1.01.2	KA	CRC4-10FUI	RETURN FILTER
2612	2.08.0027.1.01.3	PL	DL.40.60.3E	FILTER ELEMENT FOR SERVO VALVE
2613	2.08.0028.1.01.4	PL	DL.40.60.H	SERVO FILTER COMPLETE
2614	2.08.0029.1.01.5	PL	EA1392	FILTER ELEMENT
2615	2.08.0030.1.01.6	PL	HYS.501.90.10 ES	FILTER ELEMENT FOR HYD VARIABLE PUMP
2616	2.08.0031.1.01.7	PL	HYR.501.330.25ES	RETURN FILTER
2617	2.08.0032.1.01.8	PL	HY151.187ES	FILTER ELEMENT
2618	2.08.0033.1.01.9	PL	HY-501.03.05/ES	FILTER ELEMENT
2619	2.08.0034.1.01.1	PL	HYD 501.225.10 / ES	FILTER ELEMENT
2620	2.08.0035.1.01.2	PL	HYD.501.1	PROPORTIONALE FILTER HOUSING BODY
2621	2.08.0036.1.01.3	PL	HY-D501.10.10/H300W/ES FILTEREINSATZ	FILTER ELEMENT
2622	2.08.0037.1.01.4	PL	HY-D501.225.25DS	SEAL KIT
2623	2.08.0038.1.01.5	PL	HY-D501.225.25ES	FILTER ELEMENT
2624	2.08.0039.1.01.6	PL	HY-D501.32.10/DS	SEAL KIT
2625	2.08.0040.1.01.7	PL	HY-D501.32.10/ES	FILTER
2626	2.08.0041.1.01.8	PL	HY-D501.5.10ES	FILTER ELEMENT
2627	2.08.0042.1.01.9	PL	HY-D501.60.10	FILTER
2628	2.08.0043.1.01.1	PL	HYD-501-225-25H	FILTER BODY
2629	2.08.0044.1.01.2	PL	HYD-501-32-10H	FILTER
2630	2.08.0045.1.01.3	PL	HY-D506.10.30	FILTER
2631	2.08.0046.1.01.4	PL	HY-D506.10.30ES	FILTER ELEMENT
2632	2.08.0047.1.01.5	PL	HY-D507.140.10/ES	FILTER CARTRIDGE
2633	2.08.0048.1.01.6	PL	HY-E507.800.03 SUB. ELFL3-10-1.0	FILTER
2634	2.08.0049.1.01.7	PL	HY-L507.1600.3 SUB. 62.05.1000.425	VENTILATOR FILTER
2635	2.08.0050.1.01.8	PL	HY-R501.330.10	RETURN FLOW FILTER COMPLETE
2636	2.08.0051.1.01.9	PL	HY-R501.330.10A/ES	FILTER ELEMENT
2637	2.08.0052.1.01.1	PL	HY-R501.330.10ES	FILTER ELEMENT
2638	2.08.0053.1.01.2	PL	HY-R501.330.25	RETURN FLOW FILTER COMPLETE
2639	2.08.0054.1.01.3		Repeated item	
2640	2.08.0055.1.01.4	PL	HY-R507.05.01H SUB. HY-R508.05.01	FILTER
2641	2.08.0056.1.01.5		Repeated item	
2642	2.08.0057.1.01.6	PL	HY-R508.05.01DS	SEAL KIT
2643	2.08.0058.1.01.7	PL	HY-S501.160.P10ES	FILTER ELEMENT
2644	2.08.0059.1.01.8	PL	HY-S501.160.P10H	FILTER
2645	2.08.0060.1.01.9	PL	HY-S501.180.10ES	FILTER ELEMENT
2646	2.08.0061.1.01.1	PL	HY-S501.300.P10H	FILTER
2647	2.08.0062.1.01.2	PL	HY-S501.300.P10H/ES	FILTER ELEMENT
2648	2.08.0063.1.01.3	PL	HY-S501.350.200ES	FILTER ELEMENT
2649	2.08.0064.1.01.4	PL	HY-S501.360.150	SUCTION FILTER COMPLETE
2650	2.08.0065.1.01.5	PL	HY-S501.360.150ES	FILTER ELEMENT
2651	2.08.0066.1.01.6	PL	HY-S501.460.150	SUCTION FILTER COMPLETE
2652	2.08.0067.1.01.7	PL	HY-S501.460.150/DS	SEAL KIT
2653	2.08.0068.1.01.8	PL	HY-S501.460.150ES	FILTER
2654	2.08.0069.1.01.9	PL	HY-S501.560.150ES	FILTER ELEMENT

2655	2.08.0070.1.01.1	Repeated item		
2656	2.08.0071.1.01.2	PL	HYS-501-160-P10	FILTER BODY
2657	2.08.0072.1.01.3	KE	140732	BRM FILTER
2658	2.08.0073.1.01.4	KE	126664	SUCTION STRAINER ELEMENT
2659	2.08.0074.1.01.5	KE	176664	SUCTION FILTER FOR BRM
2660	2.08.0075.1.01.6	KE	735438	CORE CIRCUIT FILTER CHOKE
2661	2.08.0076.1.01.7	AM	F1030/6	HYD FILTER ASSY FOR TROLLEY T28
2662	2.08.0077.1.01.8	Shifted to Annexure-II		
2663	2.08.0078.1.01.9	Shifted to Annexure-II		
2664	2.08.0079.1.01.1	AM	FBD CA-30/6	HYD. FILTER FOR T-28
2665	2.08.0080.1.01.2	AM	FBD CR-160-3/5180015	HYD. FILTER FOR T-28
2666	2.08.0081.1.01.3	PH	81400750	FILTER ELEMENT FOR CRT-5633(STAINER)
2667	2.08.0082.1.01.4	PH	4P1	FILTER BREATHER
2668	2.08.0083.1.01.5	PH	4P2	RETURN FILTER ASSEMBLY
2669	2.08.0084.1.01.6	PH	91550014 (6884505)	DDGB FILTER ASSEMBLY
2670	2.08.0085.1.01.7	LO	100550	CARTR RELIEF 100-3000 SUN T3A CAVITY 50 GPM
2671	2.08.0086.1.01.8	LO	106021	BREATHING PRESS/VAC; 5 PSI/0.3PSI/.75 MNPT
2672	2.08.0087.1.01.9	LO	124239	FILTER HYD 100PSI 100GPM 2461C TANK BPS VIS GA
2673	2.08.0088.1.01.1	LO	132615	FILTER ASSY COOLING FAN
2674	2.08.0089.1.01.2	LO	142988	FILTER HYD 3000PSI 100GPM; 2461C BYP SWITCH
2675	2.08.0090.1.01.3	LO	A44044	STRAINER Y-TYPE 1.50 NPT 20 MESH SS SCREEN
2676	2.08.0091.1.01.4	PL	BF8X-F00-3MY SUBSTITUTE FLE.001/4"ZG.1234D	FILTER
2677	2.08.0092.1.01.5	PL	62.05.1000.427	FILTER
2678	2.08.0093.1.01.6	PL	62.05.1000.428	FILTER ELEMENT
2679	2.08.0094.1.01.7	Repeated item		
2680	2.08.0095.1.01.8	Repeated item		
2681	2.08.0096.1.01.9	Repeated item		
2682	2.08.0097.1.01.1	PL	75250/597/MUL	VENTILATOR
2683	2.08.0098.1.01.2	PL	HY-D501.225.25H	Z.F.FILTER COMPLETE
2684	2.08.0099.1.01.3	PL	HY-D501.225.10A-B/ES	FILTER ELEMENT
2685	2.08.0100.1.01.4	Repeated item		
2686	2.08.0101.1.01.5	Shifted to Ann II		
2687	2.08.0102.1.01.6	Repeated item		
2688	2.08.0103.1.01.7	Repeated item		
2689	2.08.0104.1.01.8	Repeated item		
2690	2.08.0105.1.01.9	PL	SFS330	Filter Element
2691	2.08.0106.1.01.1	PL	ELFP4F3W1.0/-03061632 or ELFP4F10W1.0/3061632-MS	FILTER ELEMENT
2692	2.08.0107.1.01.2	PL	HY721X78/SPEISEFILTER/ES	FILTER ELEMENT (VARIABLE PUMP)
2693	2.08.0108.1.01.3	PL	HY-D501.10.30/H300W	FILTER ELEMENT COMPLETE
2694	2.08.0109.1.01.4	PL	HY-D507.140.10	FILTER ELEMENT COMPLETE
2695	2.08.0110.1.01.5	PL	HY-S501.560.150H and Sub part no. HY-S501.560.150H	SUCTION FILTER COMPLETE
2696	2.08.0111.1.01.6	PL	S80/120 and Sub Part no.S80/150	FILTER ELEMENT
2697	2.08.0112.1.01.7	PL	628-36724-1	FILTER
2698	2.08.0113.1.01.8	PL	BF3-10-1.0	Ventilation filter R3/4"
2699	2.08.0114.1.01.9	PL	HY.L501.6000.10	Aeration filter
2700	2.08.0115.1.01.1	GE	DFBN/HC330TF5D1.0-L24	High pressure filter
2701	2.08.0116.1.01.2	GE	DFBN/HC60G10D1.1- L24	High pressure filter-2
2702	2.08.0117.1.01.3	GE	GE770017	Oil suction filter-1
2703	2.08.0118.1.01.4	GE	GE770020	Oil suction filter-2
2704	2.08.0119.1.01.5	GE	GE770012	Oil return filter
2705	2.08.0120.1.01.6	GE	BD-YS-20	Piping filter-1
2706	2.08.0121.1.01.7	GE	BD-YS-25	Piping filter-2
2707	2.08.0122.1.01.8	CR	0240 D 010 ON	FILTER CARTRIDGE-1-1
2708	2.08.0123.1.01.9	CR	0330R025W	FILTER CARTRIDGE-2
2709	2.08.0124.1.01.1	CR	0160 D 010 ON	FILTER CARTRIDGE-3
2710	2.08.0125.1.01.2	CR	AND95G10B	FILTER CARTRIDGE-4-1
2711	2.08.0126.1.01.3	CR	0950 R 010 ON	FILTER CARTRIDGE-5-1
2712	2.08.0127.1.01.4	CR	0500 D 010 ON	FILTER CARTRIDGE-6
2713	2.08.0128.1.01.5	CR	ELFL P 3 F 03 W 1.0	FILTER CARTRIDGE-9
2714	2.08.0129.1.01.6	CR	QUQ2.5-20X3.0	FILTER-1
2715	2.08.0130.1.01.7	CR	1340130	FILTER-2
2716	2.08.0131.1.01.8	CR	2201523	FILTER-3
2717	2.08.0132.1.01.9	AM	60700001	Hydraulic Filter (CA160/3)
2718	2.08.0133.1.01.1	AM	60701005	Hydraulic Filter (CA500/3)

2719	2.08.0134.1.01.2	PH	4P33	Return Filter element
2720	2.08.0135.1.01.3	CR	40093869	ZF oil filter
2721	2.08.0136.1.01.4	CR	40091493	Suction filter
2722	2.08.0137.1.01.5	CR	40091492	Suction filter
2723	2.08.0138.1.01.6	CR	40095474	Return filter
2724	2.08.0139.1.01.7	CR	40095613	Servo filter
2725	2.08.0140.1.01.8	CR	40093909	Proportional filter
2726	2.08.0141.1.01.9	CR	YB-31 338001	ZF FILTER
2727	2.08.0142.1.01.1	CR	80242980176	Online filtration
2728	2.08.0143.1.01.2	PL	0501.333.764	ZF FILTER ELEMENT
2729	2.08.0144.1.01.3		Shifted to Ann -II	
2730	2.08.0145.1.01.4		Shifted to Ann -II	
2731	2.08.0146.1.01.5	PL	HY-R507.05.01HES	Hydraulic Superfine Filter
2732	2.08.0147.1.01.6	PL	OF5S10P6N2B05ES	Filtering unit
2733	2.08.0148.1.01.7	PL	1300 R 005 ON/-KB-387 or 1300R005BN3HC/-KB-SO387	Filtration unit filter cartridge
2734	2.08.0149.1.01.8	PL	HY-D507.140.10	Filter complete
2735	2.08.0150.1.01.9	PL	HY-D501.32.10H	Filter complete
2736	2.08.0151.1.01.1	PL	HY-D501.225.10A-B	Filter complete
2737	2.08.0152.1.01.2	PL	HY-D506.10.30H-300W OR HY-D506.10.30H-350W OR HY157.87	FILTER ELEMENT COMPLETE
2738	2.08.0153.1.01.3	PL	62.05.1000.113	Filter
2739	2.08.0154.1.01.4	PL	501333764	Pressure Filter
2740	2.08.0155.1.01.5	PL	62.05.1000.269A	FILTER ELEMENT (DUCT) COMPLETE
2741	2.08.0156.1.01.6	PL	62.05.1000.470A	FILTER ELEMENT COMPLETE
2742	2.08.0157.1.01.7	PL	HY501.03.05	OIL FILTER UNIT
2743	2.08.0158.1.01.8	PL	HY-D501.10.30/H300W/ES	FILTER ELEMENT
2744	2.08.0159.1.01.9	CRCC HTEC	SE360.130.F0	Suction filter
2745	2.08.0160.1.01.1	CRCC HTEC	SE460.130.S0	Suction filter
2746	2.08.0161.1.01.2	CRCC HTEC	RF ON 330D L 10FD 1.X/-2M0	Return filter
2747	2.08.0162.1.01.3	CRCC HTEC	DF ON 60 T C 10 CD 1.1/-2M0	Proportional filter
2748	2.08.0163.1.01.4	CRCC HTEC	DF ON 240 T E 10 CD 1.1/-2M0	Servo Filter
2749	2.08.0164.1.01.5	CRCC HTEC	OF5M30V1U2N5DM005E	Emergency back up oil filter
2750	2.08.0165.1.01.6	CRCC HTEC	0060 D 010 ON	Proportional filter element
2751	2.08.0166.1.01.7	CRCC HTEC	0240 D 010 ON	Servo Filter element
2752	2.08.0167.1.01.8	CRCC HTEC	N5DM005	Emergency back up oil filter element
2753	2.08.0168.1.01.9	KE	733692	FILTER (CASE DRAIN) ASSY
2754	2.08.0169.1.01.1	KE	714374	FILTER (CHARGE FLOW) ASSY
2755	2.08.0170.1.01.2	LO	252351-81	FILTER KIT #1
2756	2.08.0171.1.01.3	LO	A93360	ELEMENT FILTER KW WATER REMOVAL
2757	2.08.0172.1.01.4	PL	62.05. 1000.269	DUCT FILTER
2758	2.08.0173.1.01.5	PL	62.05.1000.292	FILTER
2759	2.09.0001.1.01.5	PL	100,97X5,33-N-DIN-3371-NBR90	SEAL SET EXTRA LIFTING CYL. O,RING
2760	2.09.0002.1.01.6	PL	62.05.1000.338DS	SEAL KIT (FOR BCM ONLY)
2761	2.09.0003.1.01.7	PL	62.05.1000.374/DS	SEAL KIT (FOR BCM ONLY)
2762	2.09.0004.1.01.8	PL	62.05.2000.111/DS	SEAL KIT (FOR BCM ONLY)
2763	2.09.0005.1.01.9	PL	62.05.3000.300DS	SEAL KIT (FOR BCM ONLY)
2764	2.09.0006.1.01.1	PL	62.05.4000.241/DS	SEAL KIT (FOR BCM ONLY)
2765	2.09.0007.1.01.2	PL	62.05.4000.254/DS	SEAL KIT (FOR BCM ONLY)
2766	2.09.0008.1.01.3	PL	64.03.4000.114/DS	SEAL KIT (FOR BCM ONLY)
2767	2.09.0009.1.01.4		Shifted to Ann II	
2768	2.09.0010.1.01.5	PL	EL-T76.10MO	REPAIR SET
2769	2.09.0011.1.01.6	PL	HY155.11DS	SEAL KIT
2770	2.09.0012.1.01.7	PL	HY156.09DS	SEAL KIT
2771	2.09.0013.1.01.8	PL	HY72SX/DS	SEAL KIT
2772	2.09.0014.1.01.9	PL	HY916N/DS	SEAL KIT
2773	2.09.0015.1.01.1	PL	HY925N12.5/D-DS	SEAL KIT
2774	2.09.0016.1.01.2	PL	HY938X55/MS-DS	SEAL KIT
2775	2.09.0017.1.01.3	PL	HZ02.080.050.001	SEAL KIT (FOR BCM ONLY)
2776	2.09.0018.1.01.4	PL	HZ02.040.025	SEAL KIT (FOR BCM ONLY)
2777	2.09.0019.1.01.5	PL	HZ02.063.036	SEAL KIT (FOR BCM ONLY)
2778	2.09.0020.1.01.6	PL	HZ02.080.036	SEAL KIT (FOR BCM ONLY)
2779	2.09.0021.1.01.7	PL	HZ02.100.045	SEAL KIT (FOR BCM ONLY)
2780	2.09.0022.1.01.8	PL	HZ02.100.050	SEAL KIT (FOR BCM ONLY)
2781	2.09.0023.1.01.9	PL	HZ02.125.050	SEAL KIT (FOR BCM ONLY)
2782	2.09.0024.1.01.1	PL	NZ01.050	SEAL KIT (FOR BCM ONLY)
2783	2.09.0025.1.01.2	PL	NZ01.063	SEAL KIT (FOR BCM ONLY)
2784	2.09.0026.1.01.3	PL	NZ01.080	SEAL KIT (FOR BCM ONLY)
2785	2.09.0027.1.01.4	PL	NZ01.100	SEAL KIT (FOR BCM ONLY)
2786	2.09.0028.1.01.5	PL	NZ01.125	SEAL KIT (FOR BCM ONLY)
2787	2.09.0029.1.01.6	AM	ORL050005 &6S	SEAL KIT CHAIN TENSION CYL EURO TRACK
2788	2.09.0030.1.01.7	PL	S14-09944	SEAL KIT (FOR BCM ONLY)
2789	2.09.0031.1.01.8	PL	UD 50-3200 DS	SEAL KIT(FOR TAMPERS)

2790	2.09.0032.1.01.9	PL	UD50.100 DS	SEAL KIT(FOR TAMPERS)
2791	2.09.0033.1.01.1	PL	UD50.1900 DS	SEAL SET FOR SATELLITE AXLE SUPPORT CYL.
2792	2.09.0034.1.01.2	PL	UD50.1950 ADS	SEAL SET FOR MACHINE SUPPORT CYL.
2793	2.09.0035.1.01.3	PL	UD50.200 DS	SEAL KIT(FOR TAMPERS)
2794	2.09.0036.1.01.4	PL	UD50.2200 DS	SEAL SET FOR WHEEL SUPPORT CYL.
2795	2.09.0037.1.01.5	PL	UD50.2800 DS	SEAL SET FOR AXLE SUPPORT CYL.
2796	2.09.0038.1.01.6	PL	UD50.550 DS	SEAL KIT(FOR TAMPERS)
2797	2.09.0039.1.01.7	KE	80829	SEAL SET FOR BRM
2798	2.09.0040.1.01.8	KE	174975	SEAL SET(FOR BRM)
2799	2.09.0041.1.01.9	KE	218537	SEAL KIT BRM
2800	2.09.0042.1.01.1	KE	350644	OIL SEAL
2801	2.09.0043.1.01.2	KE	657884	OIL SEAL
2802	2.09.0044.1.01.3	KE	660167	SEAL KIT
2803	2.09.0045.1.01.4	KE	663059	SEAL SHAFT FOR BRM
2804	2.09.0046.1.01.5	AM	0016057S	SEAL SET FOR WHEEL CYL
2805	2.09.0047.1.01.6	AM	0017012S	SEAL SET VERTICAL / HORIZONTAL CYL. FOR T28
2806	2.09.0048.1.01.7	AM	0017018S	SEAL SET FOR VERTICAL CYL T 28
2807	2.09.0049.1.01.8	AM	0017159 S	SEAL SET FOR COMMANDO CYL T 28
2808	2.09.0050.1.01.9	AM	0017311 S	SEAL SET FOR CLAMP LIFTING CYL T28
2809	2.09.0051.1.01.1	AM	0021013/0170125	SEAL SET FOR TROLLEY LILFT T 28
2810	2.09.0052.1.01.2	AM	160575	SEAL SET WHEEL CYL T28
2811	2.09.0053.1.01.3	AM	90179016	SEAL SET FOR WHEEL CYLINDER
2812	2.09.0054.1.01.4	AM	90179023	SEAL SET
2813	2.09.0055.1.01.5	PH	30211015	RETAINER OIL SEAL
2814	2.09.0056.1.01.6	PH	30212012	SPACER SEAL
2815	2.09.0057.1.01.7	PH	1P15	SEAL SET FOR SLEW CYL
2816	2.09.0058.1.01.8	PH	1P4	SEAL SET FOR SLEWING CYLINDER
2817	2.09.0059.1.01.9	PH	2P12	SEAL SET FOR COLUMN CYL UTV CRANE
2818	2.09.0060.1.01.1	PH	2P12S	SEAL SET FOR UTV COLUMN CYL
2819	2.09.0061.1.01.2	PH	3P19	SEAL FOR 3RD EXT BOOM CYL UTV
2820	2.09.0062.1.01.3	PH	3P19S	SEAL SET FOR 3RD EXTENSION CYLINDER
2821	2.09.0063.1.01.4	PH	3P20	SEAL FRO 2ND EXT BOOM CYL UTV
2822	2.09.0064.1.01.5	PH	3P20-S	SEAL SET FOR 2ND EXTENSION CYLINDER
2823	2.09.0065.1.01.6	PH	3P27	SEAL FOR 1ST EXT BOOM CYL UTV
2824	2.09.0066.1.01.7	PH	3P27S	SEAL SET FOR 1ST EXTENSION CYLINDER
2825	2.09.0067.1.01.8	PH	3P28S	SEAL SET FOR BOOM CYL UTV
2826	2.09.0068.1.01.9	PH	5P10S	SEAL SET FOR SLEW CYLINDER
2827	2.09.0069.1.01.1	PH	8P13	SEAL SET FOR 1ST BOOM CYL
2828	2.09.0070.1.01.2	PH	8P5	SEAL SET FOR 3RD BOOM CYL
2829	2.09.0071.1.01.3	PH	8P8	SEAL SET FOR 2ND BOOM CYL
2830	2.09.0072.1.01.4	LO	124942	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
2831	2.09.0073.1.01.5	LO	124943	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
2832	2.09.0074.1.01.6	LO	124945	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
2833	2.09.0075.1.01.7	PL	62.05.2000.43DS	SEAL KIT
2834	2.09.0076.1.01.8	PL	62.05.3000.184DS	SEAL KIT
2835	2.09.0077.1.01.9	PL	90X75X1.6B1MS	SHIM
2836	2.09.0078.1.01.1	PL	A2/100X112X12/7-PU	WIPER
2837	2.09.0079.1.01.2	PL	A60X68X2DIN76030CU	SEAL RING
2838	2.09.0080.1.01.3	PL	HZ02.080.040	SEAL SET
2839	2.09.0081.1.01.4	PL	HZ05.050.025	PISTON
2840	2.09.0082.1.01.5	PL	HZ05.080.045	PISTON
2841	2.09.0083.1.01.6	PL	HZ05.125.050	PISTON
2842	2.09.0084.1.01.7	KA	GC1023.07.62.000	Seal For Hydraulic Cylinder
2843	2.09.0085.1.01.8	KA	1023.41.08.000-01	Seal For Hydraulic Cylinder
2844	2.09.0086.1.01.9	KA	1023.41.10.000.01	Seal For Hydraulic Cylinder
2845	2.09.0087.1.01.1	CR	FA80.92.2.7.2/12	Scraper seal-7
2846	2.09.0088.1.01.2	CR	GS80.95.1.6.3	Stern Seal-8
2847	2.09.0089.1.01.3	CR	TPM110.85.22.4.6.35	Combined Seal-5
2848	2.09.0090.1.01.4	CR	FA40.48.6.5/7	Scraper seal-5
2849	2.09.0091.1.01.5	CR	GS40.50.7.4.2	Stern seal-6
2850	2.09.0092.1.01.6	CR	FA36.44.6.5/7	Scraper seal-6
2851	2.09.0093.1.01.7	CR	TPM63.47.18.4.6.35	Combined Seal-4
2852	2.09.0094.1.01.8	CR	GS36.46.7.4.2	Stern Seal-7
2853	2.09.0095.1.01.9	CR	FA70.80.6.5.3/7	Scraper seal-8
2854	2.09.0096.1.01.1	CR	GS70.85.1.6.3	Stern Seal-9

2855	2.09.0097.1.01.2	CR	TPM100.75.22.4.6.35	Combined Seal-6
2856	2.09.0098.1.01.3	CR	GS45.60.1.6.3	STERN SEAL-1
2857	2.09.0099.1.01.4	CR	TPM80.60.22.4.6.35	COMBINED SEAL-1
2858	2.09.0100.1.01.5	CR	FK45.56.8.5/9	SCRAPPER SEAL-2
2859	2.09.0101.1.01.6	CR	TPM50.40.12.5.4	Combined Seal-2
2860	2.09.0102.1.01.7	CR	TPM90.70.22.4.6.35	Combined Seal-12
2861	2.09.0103.1.01.8	CR	FA50.60.5/7	Scraper Seal-15
2862	2.09.0104.1.01.9	CR	GS45.55.7.4.2	Stern Seal-12
2863	2.09.0105.1.01.1	CR	FA45.55.5/7	Scraper Seal-12
2864	2.09.0106.1.01.2	CR	FA32.40.5/7	Scraper seal-9
2865	2.09.0107.1.01.3	CR	GS32.42.7.4.2	Stern Seal-10
2866	2.09.0108.1.01.4	CR	TPM63.48.20.5	Combined Seal-7
2867	2.09.0109.1.01.5	GE	CDCK16A-56-02-07	Gasket-1
2868	2.09.0110.1.01.6	GE	GB/T97.3 36	Gasket-2
2869	2.09.0111.1.01.7	GE	HZ01.063(HD01.063)+HZD02.063.036	Lifting cylinder seal
2870	2.09.0112.1.01.8	CR	40100378-048	SEAL, OIL
2871	2.09.0113.1.01.9	CR	40100378-052	SEAL, OIL-2
2872	2.09.0114.1.01.1	CR	82008021478	piston seal
2873	2.09.0115.1.01.2	CR	82008021479	cylinder head seal
2874	2.09.0116.1.01.3	CR	82008021488	piston seal
2875	2.09.0117.1.01.4	CR	82008021489	cylinder head seal
2876	2.09.0118.1.01.5	CR	82008021504	piston seal
2877	2.09.0119.1.01.6	CR	82008021505	cylinder head seal
2878	2.09.0120.1.01.7	CR	82010040052	piston seal
2879	2.09.0121.1.01.8	CR	82010040053	cylinder head seal
2880	2.09.0122.1.01.9	CR	40095761	LIFTING/LINING CYLINDER SEAL
2881	2.09.0123.1.01.1	CR	40095751	CLAMP OIL CYLINDER SEAL
2882	2.09.0124.1.01.2	CR	40095760	LIFTING CYLINDER SEAL
2883	2.09.0125.1.01.3	CR	40095762	LINING CYLINDER SEAL
2884	2.09.0126.1.01.4	CR	40095753	LIFTING HOOK SIDEWAYS SEAL
2885	2.09.0127.1.01.5	CR	40095752	TOOL TILTING CYLINDER SEAL
2886	2.09.0128.1.01.6	CR	40095754	TAMPING BAT OIL SEAL
2887	2.09.0129.1.01.7	CR	40095755	OIL CYLINDER SEALING ELEMENT
2888	2.09.0130.1.01.8	CR	40095759	OIL CYLINDER SEALING ELEMENT
2889	2.09.0131.1.01.9	CR	40095758	OIL CYLINDER SEALING ELEMENT
2890	2.09.0132.1.01.1	CR	40095757	OIL CYLINDER SEALING ELEMENT
2891	2.09.0133.1.01.2	CR	40095756	OIL CYLINDER SEALING ELEMENT
2892	2.09.0134.1.01.3	CR	41028010	SQUEEZING CYLINDER SEAL
2893	2.09.0135.1.01.4	CR	57.15.3.53	O ring-13
2894	2.09.0136.1.01.5	CR	60318	O ring-14
2895	2.09.0137.1.01.6	CR	20261425	Plate
2896	2.09.0138.1.01.7	PL	HY-S501.300.P10/DS	Seal kit
2897	2.09.0139.1.01.8	PL	HY-R507.05.01H/DS	seal kit
2898	2.09.0140.1.01.9	PL	HY-D507.140.10/DS	seal kit
2899	2.09.0141.1.01.1	PL	HY-D506.10.30/DS	Seal kit
2900	2.09.0142.1.01.2	Colmar	112500015	KIT SEAL 70/35
2901	2.09.0143.1.01.3	Colmar	112500016	KIT SEAL 70/40
2902	2.09.0144.1.01.4	Colmar	112500017	KIT SEAL 80/60
2903	2.09.0145.1.01.5	Colmar	112500018	KIT SEAL 100/60
2904	2.09.0146.1.01.6	Colmar	112500019	KIT SEAL 140/90
2905	2.09.0147.1.01.7	Colmar	112500020	KIT SEAL 85/70
2906	2.09.0148.1.01.8	Colmar	112500021	KIT SEAL 100/60
2907	2.09.0149.1.01.9	LO	101173	SEAL KIT FOR T-3 AND T-5 CAV BUNA N (FOR VALVES 100506 & 100550)
2908	2.09.0150.1.01.1	LO	140479	SEAL KIT D05 SEAL PLATE WITH O-RINGS
2909	2.09.0151.1.01.2	LO	252351-80	HYDRAULIC VALVE KIT #4
2910	2.09.0152.1.01.3	LO	246599	SEAL KIT D03 BUNA-N
2911	2.09.0153.1.01.4	LO	H100120	O-RING 2.675ID X .103CS AS568-147 70DURO BUNA-N
2912	2.09.0154.1.01.5	LO	H100719	PLUG O-RING BOSS #3 SOCKET HD
2913	2.09.0155.1.01.6	LO	H17527	O-RING 1.296ID X .139CS AS568-219 90DURO BUNA-N
2914	2.09.0156.1.01.7	LO	H18533	O-RING 1.859ID X .139CS AS568-225 90DURO BUNA-N
2915	2.09.0157.1.01.8	LO	H18534	O-RING 2.234ID X .139CS AS568-228 90DURO BUNA-N (O-RING FOR 101683)
2916	2.09.0158.1.01.9	LO	H20942	O-RING .924ID X .116CS AS568-912 90DURO BUNA-N
2917	2.09.0159.1.01.1	LO	H22082	O-RING .239ID X .070CS; AS568-010 70DURO BUNA-N
2918	2.09.0160.1.01.2	LO	H22084	O-RING .364ID X .070CS AS568-012 70DURO BUNA-N
2919	2.09.0161.1.01.3	LO	H22086	O-RING .489ID X .070CS AS568-014 70DURO BUNA-N

2920	2.09.0162.1.01.4	LO	H22104	O-RING .612ID X .103CS AS568-114 70DURO BUNA-N (MIN QTY 10)
2921	2.09.0163.1.01.5	LO	H22149	O-RING 4.484ID X .139CS AS568-246 70DURO BUNA-N
2922	2.09.0164.1.01.6	LO	H22150	O-RING 4.609ID X .139CS AS568-247 70DURO BUNA-N
2923	2.09.0165.1.01.7	LO	H22153	O-RING 4.984ID X .139CS AS568-250 70DURO BUNA-N
2924	2.09.0166.1.01.8	LO	H26773	GROMMET FILTER
2925	2.09.0167.1.01.9	LO	H26776	O-RING 5.234ID X .139CS AS568-252 70DURO BUNA-N
2926	2.09.0168.1.01.1	LO	H79238	O-RING .489ID X .070CS AS568-014 75DURO VITON
2927	2.09.0169.1.01.2	LO	H90932	O-RING .426ID X .070CS AS568-013 70DURO VITON
2928	2.09.0170.1.01.3	LO	H91095	O-RING .364ID X .070CS AS568-012 75DURO VITON
2929	2.09.0171.1.01.4	LO	H22089	O-RING .614ID X .070CS AS568-016 70DURO BUNA-N
2930	2.09.0172.1.01.5	LO	H94205	O-RING 3.359ID X .139CS AS568-237 90DURO BUNA-N
2931	2.09.0173.1.01.6	LO	H30261	O-RING .799ID X .103CS AS568-117 70DURO BUNA-N
2932	2.10.0001.1.01.6	PL	5140-20-03.00	PRESSURE GAUGE CONNECTION
2933	2.10.0002.1.01.7	CR	JB/T7940.1-M10X1	STRAIGHT HYDRAULIC GREASE NIPPLE
2934	2.10.0003.1.01.8	CR	30031100	GREASE NIPPLE
2935	2.10.0004.1.01.9	LO	H114571	ADAPTER ELBOW 45 8 MOR/8 MORFS
2936	2.10.0005.1.01.1	LO	H19724	ADAPTER PLUG SAE 04 MOR HEX HEAD
2937	2.10.0006.1.01.2	LO	H19725	ADAPTER PLUG 08MORB
2938	2.10.0007.1.01.3	LO	H20463	ADAPTER STRAIGHT 32 MP/32 MJC
2939	2.10.0008.1.01.4	LO	H33007	ADAPTER PLUG 12 MOR
2940	2.10.0009.1.01.5	LO	H94167	ADAPTER STRAIGHT 08MORB 12MORFS
2941	2.10.0010.1.01.6	LO	H94198	ADAPTER TEE ORFS 8MORFS/8MORFS/8MOR
2942	2.10.0011.1.01.7	LO	A64687	COUPLING SOCKET 2 NPT
2943	2.11.0001.1.01.7	PL	1Z-MS	DIRT COLLECTOR
2944	2.11.0002.1.01.8	PL	62.05.3000.83	DIRT INDICATOR
2945	2.11.0003.1.01.9	PL	64.07.1000.201-A SUBST 64.07.1000.41	DIRT INDICATOR
2946	2.11.0004.1.01.1	PL	64.07.1000.202-A	DIRT INDICATOR
2947	2.11.0005.1.01.2	PL	64.07.1000.269	DIRT INDICATOR
2948	2.11.0006.1.01.3	PL	64.07.1000.270	MANOMETER O.CHROMRS.
2949	2.11.0007.1.01.4	PL	HY151.192	PRESSURE GAUGE PILOT VALVE
2950	2.11.0008.1.01.5	PL	HY154.27 SUB. G/63.250-1/4/B	MONOMETER SWITCH
2951	2.11.0009.1.01.6	PL	HY-154-05H	PRESSURE GAUGE ISOLATOR
2952	2.11.0010.1.01.7	KE	762684	BROOM MOTOR PRESSURE GAUGE
2953	2.11.0011.1.01.8	AM	60720004	PRESSURE GAUGE T-28
2954	2.11.0012.1.01.9	LO	A91362	SIGHT GAUGE ASSY 12 INCH FRT MTG SEALS THERM
2955	2.11.0013.1.01.1	GE	YY224B	Torque Converter oil Pressure gauge
2956	2.11.0014.1.01.2	GE	GE500108	Pressure gauge
2957	2.11.0015.1.01.3	GE	YCS100- II	Duplex pressure gauge
2958	2.11.0016.1.01.4	GE	FLG250YMM10	Liquid level and temperature gauge
2959	2.11.0017.1.01.5	LO	244174	GAUGE, DIFFERENTIAL PRESSURE
2960	2.11.0018.1.01.6	LO	124337	GAUGE PRESS 0-3000 BOTT -4 MOR BRASS W/SILICONE
2961	2.11.0019.1.01.7	LO	125545	GAUGE PRESS 30HG-15 BOTT .25 NPT BRASS
2962	2.11.0020.1.01.8	LO	252351-49	GAUGE REPAIR KIT #3
2963	3.01.0001.1.01.7			Shifted to Ann-II
2964	3.01.0002.1.01.8			Shifted to Ann-II
2965	3.01.0003.1.01.9			Shifted to Ann-II
2966	3.01.0004.1.01.1	PL	90246	VALVE
2967	3.01.0005.1.01.2			Shifted to Ann-II
2968	3.01.0006.1.01.3	PL	90250	VALVE
2969	3.01.0007.1.01.4	PL	90294	VALVE
2970	3.01.0008.1.01.5	PL	90295	VALVE
2971	3.01.0009.1.01.6	PL	275200	PRESSURE REGULATOR
2972	3.01.0010.1.01.7	PL	501313375	SOLENOID VALVE
2973	3.01.0011.1.01.8	PL	185095/024 SUB. NO.170897/024	IDLER VALVE
2974	3.01.0012.1.01.9	PL	90187 DS, 90187 ES, 4324-069-202	KIT FOR AIR DRYER
2975	3.01.0013.1.01.1	PL	90245-A SUB. 90245	OVER FLOW VALVE
2976	3.01.0014.1.01.2	PL	90251-52	VALVE
2977	3.01.0015.1.01.3			Item shifted to Ann II
2978	3.01.0016.1.01.4			Item shifted to Ann II

2979	3.01.0017.1.01.5	Item shifted to Ann II		
2980	3.01.0018.1.01.6	PL	90419/90420	SOLENOID VALVE
2981	3.01.0019.1.01.7	PL	I12556	SOLENOID VALVE
2982	3.01.0020.1.01.8	PL	I28456/0500	UNLOADER VALVE
2983	3.01.0021.1.01.9	PL	I28473/0380	VALVE
2984	3.01.0022.1.01.1	PL	I69500/00024	VALVE
2985	3.01.0023.1.01.2	PL	I82555/024	VALVE
2986	3.01.0024.1.01.3	PL	I85095/024	VALVE
2987	3.01.0025.1.01.4	PL	I39387	COCK
2988	3.01.0026.1.01.5	KE	138038	BROOM LOCK / UNLOCK VALVE
2989	3.01.0027.1.01.6	KE	37022	BALL VALVE 2 WAY
2990	3.01.0028.1.01.7	KE	280033	VALVE SAFETY
2991	3.01.0029.1.01.8	PH	UTVI-06 27/00	ELECTRO PNEUMATIC GOVERNOR
2992	3.01.0030.1.01.9	PH	UTVI-06 50/00	SHUT OFF WITH VENT
2993	3.01.0031.1.01.1	PH	UTVI-06 53/00	SINGLE SOLENOID VALVE (MFH-1/8")
2994	3.01.0032.1.01.2	LO	158626	MOISTURE SEPARATOR W/ AUTO DRAIN
2995	3.01.0033.1.01.3	LO	162301	VALVE CHECK 200PSI CV6 AIR 16FNPT 5PSI CRCK BUNA
2996	3.01.0034.1.01.4	LO	162700	VALVE DRCT 200PSI AIR 2W2P 20FNPT SOL NO
2997	3.01.0035.1.01.5	LO	A22010	VALVE DRCT 150 PSI CV7 AIR 04MNPT MAN DRAW COCK
2998	3.01.0036.1.01.6	LO	A66642	VALVE AIR SOLENOID
2999	3.01.0037.1.01.7	LO	A70947	VALVE BRONZE CHECK .75
3000	3.01.0038.1.01.8	KA	V71-22A	PNEUMATIC DITRIBUTOR
3001	3.01.0039.1.01.9	KA	VV-32SH 24 V / TU 4151-001-20725946-97	ELECTRO-PNEUMATIC VALVE
3002	3.01.0040.1.01.1	Shifted to Ann II		
3003	3.01.0041.1.01.2	PL	90189-A SUBSTITUTE 90188	PRESSURE REGULATOR
3004	3.01.0042.1.01.3	PL	90190-A SUBSTITUTE 90184	PRESSURE REGULATOR
3005	3.01.0043.1.01.4	Shifted to Ann-II		
3006	3.01.0044.1.01.5	Shifted to Ann-II		
3007	3.01.0045.1.01.6	PL	90323	STOP COCK
3008	3.01.0046.1.01.7	PL	90381	Valve
3009	3.01.0047.1.01.8	Repeated item		
3010	3.01.0048.1.01.9	Repeated item		
3011	3.01.0049.1.01.1	PL	90386	VALVE
3012	3.01.0050.1.01.2	Shifted to Ann II		
3013	3.01.0051.1.01.3	PL	90342 SUBSTITUTE 90337	VALVE
3014	3.01.0052.1.01.4	PL	90343 SUBSTITUTE 90339	VALVE
3015	3.01.0053.1.01.5	Shifted to Ann-II		
3016	3.01.0054.1.01.6	Shifted to Ann-II		
3017	3.01.0055.1.01.7	PL	90384TR	SUPPORT FOR VALVE
3018	3.01.0056.1.01.8	Shifted to Ann-II		
3019	3.01.0057.1.01.9	Shifted to Ann-II		
3020	3.01.0058.1.01.1	Shifted to Ann-II		
3021	3.01.0059.1.01.2	PL	90361	NON-RETURN VALVE
3022	3.01.0060.1.01.3	PL	90418	Non Return Value
3023	3.01.0061.1.01.4	Repeated item		
3024	3.01.0062.1.01.5	PL	169500/00024	Magnetic Valve
3025	3.01.0063.1.01.6	PL	204069	EMERGENCY BRAKE VALVE KEY
3026	3.01.0064.1.01.7	PL	90385	EMERGENCY BRAKE VALVE
3027	3.01.0065.1.01.8	Shifted to Ann-II		
3028	3.01.0066.1.01.9	PL	90359-IND	CUTT OFF ANGLE COCK VALVE
3029	3.01.0067.1.01.1	Shifted to Ann II		
3030	3.01.0068.1.01.2	PL	Plasser Part no. 90183	Pneumatic Pressure Reducing Valve 1/2"
3031	3.01.0069.1.01.3	Shifted to Ann II		
3032	3.01.0070.1.01.4	ZF	4420191151	VALVE
3033	3.01.0071.1.01.5	GE	TB/T1041	Dust filter check valve
3034	3.01.0072.1.01.6	CR	I799652090	HIGH PRESSURE SAFETY VALVE
3035	3.01.0073.1.01.7	CR	VCHC40-06G	ONE-WAY VALVE-1
3036	3.01.0074.1.01.8	CR	E321K10-2995-481865C2	SOLENOID VALVE-1
3037	3.01.0075.1.01.9	CR	PKPD36335	ONE-WAY VALVE-2
3038	3.01.0076.1.01.1	CR	4690713	EXHAUST GAS STORAGE VALVE-1
3039	3.01.0077.1.01.2	CR	VNA301A-20A-B	PNEUMATIC VENT VALVE
3040	3.01.0078.1.01.3	CR	KPS35(060-3105)	PRESSURE REGULATOR
3041	3.01.0079.1.01.4	CR	PK04021321	BALL VALVE-1
3042	3.01.0080.1.01.5	CR	KR014658-DR4263	SEQUENCE VALVE
3043	3.01.0081.1.01.6	CR	K-631.561AZ	BRAKE VALVE
3044	3.01.0082.1.01.7	CR	PK04022027	BALL VALVE-2
3045	3.01.0083.1.01.8	CR	4691321	EXHAUST GAS STORAGE VALVE-2
3046	3.01.0084.1.01.9	CR	I17154-AE4103	SHUTTLE VALVE
3047	3.01.0085.1.01.1	CR	PKS9561RF-1/2	PNEUMATIC CONTROL VALVE-1
3048	3.01.0086.1.01.2	CR	PD55649-000	PRESS. REDUCE VALVE
3049	3.01.0087.1.01.3	CR	K-665.631B	DRIVING SAFETY VALVE
3050	3.01.0088.1.01.4	CR	PKVBA10-02/04	PRESSURIZING VALVE

3051	3.01.0089.1.01.5	CR	PKS9561RF-1/4	PNEUMATIC CONTROMALVE-2
3052	3.01.0090.1.01.6	CR	RV-08	ONE-WAY VALVE-3
3053	3.01.0091.1.01.7	CR	K-703.701R	BRAKE CONTROMALVE
3054	3.01.0092.1.01.8	CR	K-665.181	BRAKE CONTROLLER
3055	3.01.0093.1.01.9	CR	SV-3-1/8-B-SA	VALVE
3056	3.01.0094.1.01.1	CR	40079276	SOLENOID VALVE(AIR BRAKING SYSTEM)
3057	3.01.0095.1.01.2	CR	40090981	SOLENOID NONRETURN VALVE
3058	3.01.0096.1.01.3	CR	40079232	PNEUMATIC PRESSURE REGULATING VALVE
3059	3.01.0097.1.01.4	GE	ZTFD-01	Double-pipe electric control air horn assembly
3060	3.01.0098.1.01.5	PL	II91917/02120 and Sub Part no. I79965/2120	safety valve(12.0 Bar)
3061	3.01.0099.1.01.6	PL	II91917/02105	safety valve(10.5 Bar)
3062	3.01.0100.1.01.7	PL	9753035040/DR	Pressure regulator
3063	3.01.0101.1.01.8	PL	86704NC.8301.02400	valve(for 10 secs)
3064	3.01.0102.1.01.9	PL	90105EW	automatic drain valve
3065	3.01.0103.1.01.1	PL	90357	pressure reducing valve
3066	3.01.0104.1.01.2	PL	II52077	Drivers brake valve FB-11S
3067	3.01.0105.1.01.3	PL	90372	Auxiliary brake unit(KR-5)
3068	3.01.0106.1.01.4	PL	I89454	BRAKE LOAD VALVE (FLOW DIVIDER)
3069	3.01.0107.1.01.5	PL	90354	ON-OFF BRAKE CHANGE OVER DEVICE
3070	3.01.0108.1.01.6	LO	A86731	REGULATOR AIR
3071	3.01.0109.1.01.7	LO	229955	GAS SPRING ASSY 250LB; 18.07 RET 13.77 STROKE
3072	3.01.0110.1.01.8	LO	A37072	EVACUATOR VALVE
3073	3.02.0001.1.01.8			Shifted to Ann-II
3074	3.02.0002.1.01.9			Shifted to Ann-II
3075	3.02.0003.1.01.1			Shifted to Ann-II
3076	3.02.0004.1.01.2	PL	90374/A-DB	AUTOMATIC TRAIN STOP VALVE
3077	3.02.0005.1.01.3	PL	90375	TWO-WAY COCK
3078	3.02.0006.1.01.4			Repeated item
3079	3.02.0007.1.01.5	PL	90371	2 WAY VALVE
3080	3.02.0008.1.01.6	PL	1154444/5852 SUB:128577/585	AIR BRAKE CYLINDER 10"
3081	3.02.0009.1.01.7	PL	90205/52803	PNEUMATIC BRAKE CYLINDER 8"
3082	3.02.0010.1.01.8	PL	90217/370	PNEU. BRAKE CYLINDER-6"
3083	3.02.0011.1.01.9	PL	90218DS-10"	BRAKE CYL SEAL 10"
3084	3.02.0012.1.01.1	PL	90226 , BGS-12"	PNEUMATIC BRAKE CYLINDER
3085	3.02.0013.1.01.2	PL	90227/37002	PNEUMATIC BRAKE CYLINDER 8"
3086	3.02.0014.1.01.3	PL	90227DS	BRAKE CYLINDER SEAL KIT-6"
3087	3.02.0015.1.01.4	PL	90291-500 LG	HOSE
3088	3.02.0016.1.01.5			Repeated item
3089	3.02.0017.1.01.6	PL	90364 DS	SEAL KIT
3090	3.02.0018.1.01.7	PL	I26964 SUB. 90227-8"	PISTON RUBBER PACKING
3091	3.02.0019.1.01.8	PL	II54444/5852 SUB. I28577/585	BRAKE CYLINDER
3092	3.02.0020.1.01.9	PL	IRFD110	DUAL POWER DRIVER
3093	3.02.0021.1.01.1	PL	UD 67-1802	BRACKET UNIMAT SUSPENSION
3094	3.02.0022.1.01.2	PL	UD210.29	BRAKE BLOCK
3095	3.02.0023.1.01.3	PL	UD210.42-DB	KEY
3096	3.02.0024.1.01.4	PL	UD214.5700BLI	BRAKE ASSEMBLY REAR
3097	3.02.0025.1.01.5	KE	115880	BRAKE CHAMBER
3098	3.02.0026.1.01.6	KE	197535	VALVE PARKING BRAKE 197535
3099	3.02.0027.1.01.7	KE	197536	SERVICE BRAKE VALVE
3100	3.02.0028.1.01.8	KE	229080	BRAKE CYLINDER
3101	3.02.0029.1.01.9	KE	662983	BRAKE CHAMBER DIAPHRAGM
3102	3.02.0030.1.01.1	KE	720921	BRAKE VALVE
3103	3.02.0031.1.01.2	PH	UTV1-06/10/00	SHUT OFF COCK 3/4"
3104	3.02.0032.1.01.3	PH	UTV1-06/17/00	THROTTLE LEVER VALVE
3105	3.02.0033.1.01.4	PH	UTV1-06/22/00	REDUCING VALVE
3106	3.02.0034.1.01.5			Shifted to Ann II
3107	3.02.0035.1.01.6	PH	UTV1-06/35/00	RELAY VALVE
3108	3.02.0036.1.01.7	PH	UTV1-06/46/00	PARKING BRAKE CYLINDER
3109	3.02.0037.1.01.8	PH	UTVI-06/02/00	AFTER COOLER
3110	3.02.0038.1.01.9			Shifted to Ann II
3111	3.02.0039.1.01.1	PH	UTVI-06/09/00	J-1 SAFETY VALVE
3112	3.02.0040.1.01.2	PH	UTVI-06/15/00	PARKING BRAKE VALVE
3113	3.02.0041.1.01.3	PH	UTVI-06/47/00	BRAKE CYLINDER WITHOUT TRUNION
3114	3.02.0042.1.01.4	PH	UTVI-06-14/00	D CHECK VALVE
3115	3.02.0043.1.01.5	LO	A28749	VALVE RELAY J-1 SUSPENSION MOUNTED
3116	3.02.0044.1.01.6	LO	A48635	VALVE RELAY J-1.6-16 SUSPENSION MOUNTED
3117	3.02.0045.1.01.7	LO	A75396	VALVE RELAY J1.6-16 FLOOR MOUNTED
3118	3.02.0046.1.01.8	LO	B23652	VALVE AIR BREAK AUTOMATIC A-9

3119	3.02.0047.1.01.9	LO	B37308	VALVE DIFF CONTROL
3120	3.02.0048.1.01.1	LO	D28747	VALVE BRAKE INDEPENDENT H-2-FX 0-65 PSI
3121	3.02.0049.1.01.2	PL	90218/58502	PNEUMATIC BRAKE CYLINDER 10"
3122	3.02.0050.1.01.3	PL	90235	PILOT VALVE
3123	3.02.0051.1.01.4	PL	90319-IND	BRAKE HOSE ASSY.
3124	3.02.0052.1.01.5	CR	K-679.507	ANGLE COCK (LEFT)
3125	3.02.0053.1.01.6	CR	K-679.520	ANGLE COCK (RIGHT)
3126	3.02.0054.1.01.7	CR	HU20051	TREAD BRAKE UNIT(WITH PARKING BRAKE)
3127	3.02.0055.1.01.8	PL	CA215.3723	Pneumatic brake cylinder
3128	3.02.0056.1.01.9	CR	40086032	AIR CYLINDER
3129	3.03.0001.1.01.9	PL	2E34.150B	PNUE. CYLINDER
3130	3.03.0002.1.01.1		Shifted to Ann-II	
3131	3.03.0003.1.01.2	PL	64.03.4000.62	PNUE. CYLINDER
3132	3.03.0004.1.01.3		Shifted to Ann-II	
3133	3.03.0005.1.01.4	PL	PN1Z-0.25/10/30	PN. CYLINDER WORK MODE THROTTLE
3134	3.03.0006.1.01.5	PL	PN1Z-ML.50/12/63	COUPLING CYLINDER
3135	3.03.0007.1.01.6	PL	PN2Z.KF.50/18/88-50/18/44	PNE. CYLINDER
3136	3.03.0008.1.01.7	PL	PN2Z-KF.35/18/102UB	PNEUMATIC CYLINDER
3137	3.03.0009.1.01.8	PL	PN2Z-KF.50/18/28	PNEUMATIC CYLINDER
3138	3.03.0010.1.01.9		Shifted to Ann-II	
3139	3.03.0011.1.01.1	PL	PN4Z-70/20x200x200	PNEUMATIC CYLINDER (4-POSITION)
3140	3.03.0012.1.01.2	PL	UD150.2312	FORK HEAD
3141	3.03.0013.1.01.3	KE	191243	PLOW LOCK CYLINDER
3142	3.03.0014.1.01.4	PH	UTV1.06.40.00	CYLINDER PNEUMATIC
3143	3.03.0015.1.01.5	PL	40.400-1.37	PNEUMATIC CYLINDER
3144	3.03.0016.1.01.6		Shifted to Ann-II	
3145	3.03.0017.1.01.7	PL	PN4Z-70/20X230X230	4-POSITION CYLINDER
3146	3.03.0018.1.01.8	PL	6009720 SUBSTITUTE DOS-1205-W	FEMALE CONNECTOR
3147	3.03.0019.1.01.9	PL	C10-L	ADAPTOR
3148	3.03.0020.1.01.1	PL	C15-L	ADAPTOR
3149	3.03.0021.1.01.2	PL	C38-S	ADAPTOR
3150	3.03.0022.1.01.3	PL	CP15LR1/2BSP	ADAPTOR
3151	3.03.0023.1.01.4	PL	CP18-LR1/2BSP	ADAPTOR
3152	3.03.0024.1.01.5	PL	CV15-L	ADAPTOR
3153	3.03.0025.1.01.6	PL	CX-18LN1/2NPTF	ADAPTOR
3154	3.03.0026.1.01.7	PL	ES14I	QUICK RELEASE COUPLING
3155	3.03.0027.1.01.8	PL	SFP38SN-1.1/2NPTF	ADAPTOR
3156	3.03.0028.1.01.9	GE	DCM32A-06-02-01	Brake cylinder
3157	3.03.0029.1.01.1	CR	CP95SF40-80	PNEUMATIC CYLINDER
3158	3.03.0030.1.01.2	CR	SMB-10075-6318-4500	PNEUMATIC CYLINDER-9
3159	3.03.0031.1.01.3	CR	AZ5035-50-00	PNEUMATIC CYLINDER-11
3160	3.03.0032.1.01.4	CR	40105548	PN. CYLINDER(SWING ARM ASSEMBLY)
3161	3.03.0033.1.01.5	PL	PN-Z02/ 50/ 900	Pneumatic Cylinder
3162	3.04.0001.1.01.1	CR	JRDG16-800	HIGH TEMP. HOSE 1
3163	3.04.0002.1.01.2	CR	K-301.091	BRAKE HOSE
3164	3.06.0001.1.01.3	PL	64.03.4000.218-31LI	COOLING COIL WITH FERRULE
3165	3.06.0002.1.01.4	PL	64.03.4000.218-31RE	COILING COIL WITH FERRULE
3166	3.06.0003.1.01.5	PL	64.03.4000.278	PNEUMATIC COOLING SYSTEM
3167	3.06.0004.1.01.6	PL	64.03.4243	COOLING COIL
3168	3.06.0005.1.01.7	PL	64.03.4244	COOLING COIL
3169	3.06.0006.1.01.8	PL	64.03.4245	COOLING COIL
3170	3.06.0007.1.01.9	PL	64.03.4246	COOLING COIL
3171	3.06.0008.1.01.1	PL	DL.90.37A	COOLING COIL WITH FERRULE
3172	3.06.0009.1.01.2	PL	GP45-4-A19,50OHM/0,8A	COIL
3173	3.06.0010.1.01.3	KE	144216	AIR PRESSUR GAUGE
3174	3.06.0011.1.01.4	PH	UTV1-06/08/00	AIR STRAINER
3175	3.06.0012.1.01.5	PH	UTVI-06/42/00	TRANSMISSION AIR SERVICE UNIT
3176	3.06.0013.1.01.6	PL	P 7-63	WIPER
3177	3.06.0014.1.01.7	LO	148464	ELEMENT AIR FILTER; PRIMARY
3178	3.06.0015.1.01.8	LO	A71633	VALVE CHECK CARTRIDGE T13A CAVITY 4 PSI
3179	3.06.0016.1.01.9	LO	B86483	FILTER ELEMENT KZ5; 5 MICRON 3.88D 9.06L
3180	3.06.0017.1.01.1		Shifted to Ann II	
3181	3.06.0018.1.01.2	PL	453.58A	COLLECTOR DRIER
3182	3.06.0019.1.01.3	PL	677.80B	HOSE LINE
3183	3.06.0020.1.01.4	PL	90157-A	AIR TANK 100L
3184	3.06.0021.1.01.5	PL	90215(M22X1,5)	CONTAINER VENTILATION
3185	3.06.0022.1.01.6		Shifted to Ann II	
3186	3.06.0023.1.01.7		Shifted to Ann II	
3187	3.06.0024.1.01.8	PL	90358K	CHECKING CONNECTOR
3188	3.06.0025.1.01.9	PL	GIA 20EB	BRAKE PRESSUURE SWITCH
3189	3.06.0026.1.01.1	KA	U43102A-03 TS2010101044-95	Compressor

3190	3.06.0027.1.01.2	GE	BDE1000N2W2.0-RV 0.02	Air filter, dehumidification
3191	3.06.0028.1.01.3	CR	I34768	PNEUMATIC FILTER-1-1
3192	3.06.0029.1.01.4	CR	LCQ-1/2	PNEUMATIC FILTER-2
3193	3.06.0030.1.01.5	CR	LCQ-1/4	PNEUMATIC FILTER-3
3194	3.06.0031.1.01.6	CR	432 055-00	PNEUMATIC FILTER-4
3195	3.06.0032.1.01.7	CR	432 500-00	FILTER CARTRIDGE
3196	3.06.0033.1.01.8	CR	432 700-00	PNEUMATIC FILTER-5
3197	3.06.0034.1.01.9	CR	AF40-04D-A	PNEUMATIC FILTER-6
3198	3.06.0035.1.01.1	CR	890L/min	AIR COMPRESSOR
3199	3.06.0036.1.01.2	CR	RPO 600 LLA(H)	ROTARY COMPRESSOR (WITH HYDRAULIC MOTOR)
3200	3.06.0037.1.01.3	CR	TDS0550G/DH2.5/24VDC/PK-KM	DRYER AND CONTROL SYSTEM
3201	3.06.0038.1.01.4	CR	YYS1-100Z-DC24V-12bar	DUPLEX PRESSURE GAUGE
3202	3.06.0039.1.01.5	CR	YYD-100Z-DC24V-12bar	SINGLE NEEDLE PRESSURE GAUGE
3203	3.06.0040.1.01.6	CR	ZLS10/8-10bar-4-20mA	SINGLE NEEDLE ELECTRIC PRESSURE GAUGE
3204	3.06.0041.1.01.7	CR	GZD7053B1	HIGH TONE HORN
3205	3.06.0042.1.01.8	CR	GZD7053F1	LOW TONE HORN
3206	3.06.0043.1.01.9	CR	100L-Φ377	AIR RESERVOIR-1
3207	3.06.0044.1.01.1	CR	15L-Φ203	AIR RESERVOIR-2
3208	3.06.0045.1.01.2	CR	200L-Φ508	AIR RESERVOIR-3
3209	3.06.0046.1.01.3	CR	57L-Φ300	AIR RESERVOIR-4
3210	3.06.0047.1.01.4	CR	SDB-121/2	Dehumidification air filter
3211	3.06.0048.1.01.5	CR	40079234	AIR OILER
3212	3.06.0049.1.01.6		Shifted to Ann II	
3213	3.06.0050.1.01.7		Shifted to Ann II	
3214	3.06.0051.1.01.8		Shifted to Ann II	
3215	3.06.0052.1.01.9		Shifted to Ann II	
3216	3.06.0053.1.01.1		Shifted to Ann II	
3217	3.06.0054.1.01.2		Shifted to Ann II	
3218	3.06.0055.1.01.3		Shifted to Ann II	
3219	3.06.0056.1.01.4		Shifted to Ann II	
3220	3.06.0057.1.01.5	PL	90157E	Pneumatic Tank-2 Nos.
3221	3.06.0058.1.01.6	PL	PN-LVE1000L	AIR SUPPLY UNIT
3222	3.06.0059.1.01.7	LO	163036-SP	Air compressor 50 HP
3223	3.06.0060.1.01.8	LO	153160	ELEMENT AIR FILTER; SECONDARY
3224	3.06.0061.1.01.9	LO	131585	PRE-CLEANER; AC/PRESSURISER
3225	3.06.0062.1.01.1	LO	C84385	RESERVOIR AUX 2500 CU IN 14.00 DIA X 20.25
3226	3.06.0063.1.01.2	LO	A65235	GAUGE PRESS 0-160 PSI BAR 04MNPT 2.5D BACK SIL
3227	3.06.0064.1.01.3	LO	118215	RESERVOIR AIR; 10 GAL
3228	3.06.0065.1.01.4	LO	163140	GAUGE PRESSURE PANEL 0-100 PSI/0-6.9 BAR
3229	3.06.0066.1.01.5	LO	252351-118	PNEUMATIC SYSTEM MAINTENANCE KIT, SMALL
3230	3.06.0067.1.01.6	LO	252351-119	PNEUMATIC SYSTEM MAINTENANCE KIT, MED
3231	3.06.0068.1.01.7	LO	252351-120	PNEUMATIC SYSTEM MAINTENANCE KIT, LARGE
3232	3.06.0069.1.01.8	LO	252351-130	AIR SYSTEM MAINTENANCE KIT, SMALL
3233	3.06.0070.1.01.9	LO	252351-131	AIR SYSTEM MAINTENANCE KIT, LARGE
3234	3.06.0071.1.01.1	LO	252351-132	AIR SYSTEM REPAIR KIT, SMALL
3235	3.06.0072.1.01.2	LO	252351-133	AIR SYSTEM REPAIR KIT, LARGE
3236	3.06.0073.1.01.3	LO	252351-154	PNEUMATIC SYSTEM MAINTENANCE KIT, MED
3237	3.06.0074.1.01.4	LO	252351-155	PNEUMATIC SYSTEM MAINTENANCE KIT, LARGE
3238	3.06.0075.1.01.5	LO	127532	DUPLEX GAUGE-AIR (BC-BP) DUAL SCALE PSI AND KPA
3239	3.06.0076.1.01.6	LO	158630	COALESCING PRE-FILTER .01 MICRON W/ AUTO DRAIN
3240	3.06.0077.1.01.7	LO	158635	DRAIN KIT
3241	3.06.0078.1.01.8	LO	A15560	HORN AIR
3242	3.06.0079.1.01.9	LO	A67604	AIR FILTER AND BRACKET
3243	3.06.0080.1.01.1	LO	D75161	AIR CHIME WHISTLE
3244	3.07.0001.1.01.4	PL	2E34.150BDS	SEAL KIT
3245	3.07.0002.1.01.5	PL	90201DS	SEAL KIT
3246	3.07.0003.1.01.6	PL	90202DS	SEAL KIT
3247	3.07.0004.1.01.7	PL	90217DS	BRAKE CYLINDER SEAL KIT-6"
3248	3.07.0005.1.01.8	PL	PN4Z-100/DS	SEAL KIT
3249	3.07.0006.1.01.9	PL	S24-10352	SEAL KIT
3250	3.07.0007.1.01.1	PL	90345/46/DS SUBSTITUTE 90346DS	SEAL KIT

3251	3.07.0008.1.01.2	PL	90364DS	SEAL KIT
3252	3.07.0009.1.01.3	PL	90419DS	SEAL KIT
3253	3.07.0010.1.01.4	PL	90344DS	SEAL KIT
3254	3.07.0011.1.01.5	PL	611.2441.256	CABLE OPERATED SWITCH
3255	3.07.0012.1.01.6	PL	C-30850/2	AIR CLEANER ELEMENT
3256	3.07.0013.1.01.7	LO	252351-94	AIR VALVE KIT #4
3257	4.01.0001.1.01.8	PL	24830	P C B
3258	4.01.0002.1.01.9	KE	733331	PCB
3259	4.01.0003.1.01.1	PL	942600	P C B
3260	4.01.0004.1.01.2	PL	6144217	JACK
3261	4.01.0005.1.01.3	PL	2-166010-1	P.C.B STRIP/48POL
3262	4.01.0006.1.01.4	PL	27128 SUB. 27C128	E-PROM-"HI" PROGRAMMED
3263	4.01.0007.1.01.5	PL	2764-A	EPROM-HI
3264	4.01.0008.1.01.6	PL	27C256-25	E-PROM-"HI" PROGRAMMED
3265	4.01.0009.1.01.7	PL	4214AP	MULTIPLICATOR
3266	4.01.0010.1.01.8	PL	64.07.1000.217	P C B
3267	4.01.0011.1.01.9	PL	64.07.5000.139	P C B
3268	4.01.0012.1.01.1	PL	64.07.5000.159	P C B
3269	4.01.0013.1.01.2	PL	82C55A-2*	PIO MODUL
3270	4.01.0014.1.01.3	PL	ADG508FBNZ SUB. HI1-0508-5	MULTIPLEXER
3271	4.01.0015.1.01.4	PL	BS62LV256PIP55 SUB. UPD43256BCZ-7OLL	RAM
3272	4.01.0016.1.01.5	PL	D27C512-200 SUB. 27C512	E-PROM-"HI" PROGRAMMED
3273	4.01.0017.1.01.6	PL	D580C320-MNL-25MHZ	MICRO CONTROLLER
3274	4.01.0018.1.01.7	PL	DS80C320-QNL-33MHZ/PLCC44 SUB. NB0C251SB12	MICRO CONTROLLER
3275	4.01.0019.1.01.8	PL	EK 207 V.00 B	PCB
3276	4.01.0020.1.01.9	PL	EK 430 DV	PCB
3277	4.01.0021.1.01.1	PL	EK-1.1/23LV1-00	PCB
3278	4.01.0022.1.01.2	PL	EK-100 V 00	PCB
3279	4.01.0023.1.01.3	PL	EK-104 V 00	PCB
3280	4.01.0024.1.01.4	PL	EK-1044V-00	PCB
3281	4.01.0025.1.01.5	PL	EK-1054V-00/1,5A	PCB
3282	4.01.0026.1.01.6	PL	EK-110-00A	P C B [MICRO CONTROLLER]
3283	4.01.0027.1.01.7	PL	EK-1116	P C B
3284	4.01.0028.1.01.8	PL	EK-120V-00	P C B
3285	4.01.0029.1.01.9	PL	EK-132-V-00	P C B
3286	4.01.0030.1.01.1	PL	EK-140V-00	P C B
3287	4.01.0031.1.01.2	PL	EK-144V-00	P C B
3288	4.01.0032.1.01.3	PL	EK-150V-00B	P C B
3289	4.01.0033.1.01.4	PL	EK-152 00	P C B
3290	4.01.0034.1.01.5	PL	EK16V-00	P C B
3291	4.01.0035.1.01.6	PL	EK-176V-00/1,5A-B	P C B
3292	4.01.0036.1.01.7	PL	EK-176V-00C	P C B
3293	4.01.0037.1.01.8	PL	EK-182V-00	P C B
3294	4.01.0038.1.01.9	PL	EK-193V.00	P C B
3295	4.01.0039.1.01.1	PL	EK-197-00A	P C B
3296	4.01.0040.1.01.2	PL	EK-1AP7-00B	P C B
3297	4.01.0041.1.01.3	PL	EK-202V-00B SUB. EK-202V.00A	P C B
3298	4.01.0042.1.01.4	PL	EK-2033LV-00	P C B
3299	4.01.0043.1.01.5	PL	EK-2038-LV-00	P C B
3300	4.01.0044.1.01.6	PL	EK-2039LV-00	P C B
3301	4.01.0045.1.01.7	PL	EK-2041LV-00A	P C B
3302	4.01.0046.1.01.8	PL	EK-2042LV-00A	P C B
3303	4.01.0047.1.01.9	PL	EK-2072LV-00	P C B
3304	4.01.0048.1.01.1	PL	EK-2140LV-00	P C B
3305	4.01.0049.1.01.2	PL	EK-2157LV-00	P C B
3306	4.01.0050.1.01.3	PL	EK-217	P C B
3307	4.01.0051.1.01.4	PL	EK-2173LV-00A	P C B
3308	4.01.0052.1.01.5	PL	EK-2186LV-00A	P C B
3309	4.01.0053.1.01.6	PL	EK-2187LV-00A	P C B
3310	4.01.0054.1.01.7	PL	EK-2188LV-00A	P C B
3311	4.01.0055.1.01.8	PL	EK-2195-LV-00	P C B
3312	4.01.0056.1.01.9	PL	EK-2255LV-00	P C B
3313	4.01.0057.1.01.1	PL	EK-2286LV-00	P C B
3314	4.01.0058.1.01.2	PL	EK-229-LV01	P C B
3315	4.01.0059.1.01.3	PL	EK-2324LV-00	P C B
3316	4.01.0060.1.01.4	PL	EK-2343LV-00A	P C B
3317	4.01.0061.1.01.5	PL	EK-2351LV-00	P C B
3318	4.01.0062.1.01.6	PL	EK-2360-LV-00	P C B
3319	4.01.0063.1.01.7	PL	EK-2433 LV-00 / EK 2039 LV-00	P C B
3320	4.01.0064.1.01.8	PL	EK-24V-00A	P C B
3321	4.01.0065.1.01.9	PL	EK-255-LV-00B	P C B
3322	4.01.0066.1.01.1	PL	EK-2684LV-00	P C B
3323	4.01.0067.1.01.2	PL	EK-275-LV-02	P C B
3324	4.01.0068.1.01.3	PL	EK-277LV-00	P C B
3325	4.01.0069.1.01.4	PL	EK-280-LV-00	P C B
3326	4.01.0070.1.01.5			Shifted to Ann-II

3327	4.01.0071.1.01.6	PL	EK-290LV-00A	P C B
3328	4.01.0072.1.01.7	PL	EK-3045LV-00	P C B
3329	4.01.0073.1.01.8	PL	EK-3049LV-00	P C B
3330	4.01.0074.1.01.9	PL	EK-3069LV-00	P C B
3331	4.01.0075.1.01.1	PL	EK-319LV-00	P C B
3332	4.01.0076.1.01.2	PL	EK-335LV-00	P C B
3333	4.01.0077.1.01.3	PL	EK-345LV-00	P C B
3334	4.01.0078.1.01.4	PL	EK-346LV-00	P C B
3335	4.01.0079.1.01.5	PL	EK-347LV-00B	P C B
3336	4.01.0080.1.01.6	PL	EK-348LV-00	P C B
3337	4.01.0081.1.01.7	PL	EK-349LV-00	P C B
3338	4.01.0082.1.01.8	PL	EK-429DV-00	P C B
3339	4.01.0083.1.01.9	PL	EK-430DV-00	P C B
3340	4.01.0084.1.01.1	PL	EK-501P.00 WITHOUT E-PROM	P C B
3341	4.01.0085.1.01.2	PL	EK-502-P-00A WITHOUT E-PROM	P C B
3342	4.01.0086.1.01.3	PL	EK-503P.00 WITHOUT E-PROM	P C B
3343	4.01.0087.1.01.4	PL	EK-552P-00	P C B
3344	4.01.0088.1.01.5	PL	EK-553P-00B	P C B
3345	4.01.0089.1.01.6	PL	EK-553P-04	FRONT PLATE
3346	4.01.0090.1.01.7	PL	EK-554P-00A	P C B
3347	4.01.0091.1.01.8	PL	EK-557P-00	P C B
3348	4.01.0092.1.01.9	PL	EK-602-E-00	P C B
3349	4.01.0093.1.01.1	PL	EK-603E-00	P C B
3350	4.01.0094.1.01.2	PL	EK-638MC-00C SUB. EK-638MC-00B	MICRO CONTROLLER
3351	4.01.0095.1.01.3	PL	EK-650-00	P C B
3352	4.01.0096.1.01.4	PL	EK-650P-00A WITHOUT E-PROM SUBST. EK-650P.00	P C B
3353	4.01.0097.1.01.5	PL	EK-650PX-00 WITHOUT E-PROM	P C B
3354	4.01.0098.1.01.6	PL	EK-651P-00-A	P C B
3355	4.01.0099.1.01.7	PL	EK-652P-00	P C B
3356	4.01.0100.1.01.8	PL	EK-653P/S-00B SUB. EK-653P.00	P C B
3357	4.01.0101.1.01.9	PL	EK-654E-00	P C B
3358	4.01.0102.1.01.1	PL	EK-657P-00A SUB. EK-657P.00	P C B
3359	4.01.0103.1.01.2	PL	EK-658P-00	P C B
3360	4.01.0104.1.01.3	PL	EK-662P-00A	P C B
3361	4.01.0105.1.01.4	PL	EK-664P-00D SUB. EK-664P-00 WITHOUT E-PROM	P C B
3362	4.01.0106.1.01.5	PL	EK727A.00	P C B
3363	4.01.0107.1.01.6	PL	EK-79V-00	P C B
3364	4.01.0108.1.01.7	PL	EK-805SV-00D SUB. EK-805SV-00C	POWER SUPPLY +5V
3365	4.01.0109.1.01.8	PL	EK-80V-00	PCB
3366	4.01.0110.1.01.9	PL	EK-812SV-00C SUB. EK-812SV-00A	PCB
3367	4.01.0111.1.01.1		Shifted to Ann-II	
3368	4.01.0112.1.01.2	PL	EK-816SV-00	PCB
3369	4.01.0113.1.01.3	PL	EK-819SV-00/GT	PCB
3370	4.01.0114.1.01.4	PL	EK-851SV-00	PCB
3371	4.01.0115.1.01.5	PL	EK-97V.00A	PCB
3372	4.01.0116.1.01.6	PL	EK-F3-00	PCB
3373	4.01.0117.1.01.7	PL	EL SUT 59	PCB
3374	4.01.0118.1.01.8	PL	EL-T 1116.00	PCB
3375	4.01.0119.1.01.9	PL	EL-T 1135-6428	POWER SUPPLY
3376	4.01.0120.1.01.1	PL	EL-T 1163	PCB
3377	4.01.0121.1.01.2	PL	EL-T 1340 00 A1	PCB
3378	4.01.0122.1.01.3	PL	EL-T 1442	PCB
3379	4.01.0123.1.01.4	PL	EL-T 156/5156	PCB
3380	4.01.0124.1.01.5	PL	EL-T 347-LV-00	PCB
3381	4.01.0125.1.01.6	PL	EL-T 442-00	PCB
3382	4.01.0126.1.01.7	PL	EL-T 5031 00	PCB
3383	4.01.0127.1.01.8	PL	EL-T 5096	PCB
3384	4.01.0128.1.01.9	PL	EL-T 5348.00B	PCB
3385	4.01.0129.1.01.1	PL	EL-T 5851.00B/ ULN 20617	PCB
3386	4.01.0130.1.01.2	PL	EL-T 631-01A	PCB
3387	4.01.0131.1.01.3	PL	EL-T 7050-200	POWER SUPPLY
3388	4.01.0132.1.01.4	PL	EL-T 998-00A	P C B
3389	4.01.0133.1.01.5	PL	EL-T-1190-00A	P C B
3390	4.01.0134.1.01.6	PL	EL-T-1318.00	P C B
3391	4.01.0135.1.01.7	PL	EL-T1340.00A	P C B
3392	4.01.0136.1.01.8	PL	EL-T1420.00	P C B
3393	4.01.0137.1.01.9	PL	EL-T-1442-00A	P C B
3394	4.01.0138.1.01.1	PL	EL-T-1807, EK-812	RACK WITH PCB EK-812
3395	4.01.0139.1.01.2	PL	EL-T406.00C	P C B
3396	4.01.0140.1.01.3	PL	EL-T4241.00	MOUNTING PLATE
3397	4.01.0141.1.01.4	PL	EL-T50058.00A	P C B
3398	4.01.0142.1.01.5	PL	EL-T-5024-00	P C B
3399	4.01.0143.1.01.6	PL	EL-T-5025-00A	P C B
3400	4.01.0144.1.01.7	PL	EL-T-5031-002	P C B
3401	4.01.0145.1.01.8	PL	EL-T-5034	P C B

3402	4.01.0146.1.01.9	PL	EL-T5034.00	P C B
3403	4.01.0147.1.01.1	PL	EL-T-5035-00	P C B
3404	4.01.0148.1.01.2	PL	EL-T5088.00	P C B
3405	4.01.0149.1.01.3	PL	EL-T5093.00A	P C B
3406	4.01.0150.1.01.4	PL	EL-T-5103	P C B
3407	4.01.0151.1.01.5	PL	ELT-5104.00	P C B
3408	4.01.0152.1.01.6	PL	EL-T5105.00	P C B
3409	4.01.0153.1.01.7	PL	EL-T-5131-00	P C B
3410	4.01.0154.1.01.8	PL	EL-T-5140-00	P C B
3411	4.01.0155.1.01.9	PL	EL-T5149.00	P C B
3412	4.01.0156.1.01.1	PL	EL-T-5156-00	P C B
3413	4.01.0157.1.01.2	PL	EL-T-5177-00	P C B
3414	4.01.0158.1.01.3	PL	ELT-5226-00A	P C B
3415	4.01.0159.1.01.4	PL	EL-T5227.00	PERIODS
3416	4.01.0160.1.01.5	PL	EL-T-5227-002	P C B
3417	4.01.0161.1.01.6	PL	EL-T-5231-00	P C B
3418	4.01.0162.1.01.7	PL	EL-T5234.00	P C B
3419	4.01.0163.1.01.8	PL	EL-T-5255-00A	P C B
3420	4.01.0164.1.01.9	PL	EL-T-5348-00	P C B
3421	4.01.0165.1.01.1	PL	EL-T-5352-00	P C B
3422	4.01.0166.1.01.2	PL	EL-T5354.00	P C B
3423	4.01.0167.1.01.3	PL	EL-T-5390-00	P C B
3424	4.01.0168.1.01.4	PL	EL-T-5391-00	P C B
3425	4.01.0169.1.01.5	PL	EL-T-5501-00	P C B
3426	4.01.0170.1.01.6	PL	EL-T-5507	P C B
3427	4.01.0171.1.01.7	PL	EL-T5529.00	P C B
3428	4.01.0172.1.01.8	PL	EL-T-5533-00A	P C B
3429	4.01.0173.1.01.9	PL	EL-T-5534-001 RE	P C B
3430	4.01.0174.1.01.1	PL	EL-T-5587.00	P C B
3431	4.01.0175.1.01.2	PL	EL-T-5592.00	P C B
3432	4.01.0176.1.01.3	PL	EL-T5593.00	P C B
3433	4.01.0177.1.01.4	PL	EL-T5596.00A	P C B
3434	4.01.0178.1.01.5	PL	EL-T-5598-00	P C B
3435	4.01.0179.1.01.6	PL	EL-T-5618	MICRO CONTROLLER X-LASER
3436	4.01.0180.1.01.7	PL	ELT-5621-00	PCB [LCD DISPLAY]
3437	4.01.0181.1.01.8	PL	ELT-5630-00C	P C B
3438	4.01.0182.1.01.9	PL	EL-T5672.00A	P C B
3439	4.01.0183.1.01.1	PL	EL-T-5721-00	P C B
3440	4.01.0184.1.01.2	PL	EL-T5735.00	P C B
3441	4.01.0185.1.01.3	PL	EL-T5851.00B SUB. ULN2061M	ADAPTOR PR.CIRCUIT BOARD
3442	4.01.0186.1.01.4	PL	EL-T5874.00A	P C B
3443	4.01.0187.1.01.5	PL	EL-T5898.00B	P C B
3444	4.01.0188.1.01.6	PL	EL-T5949.00	P C B
3445	4.01.0189.1.01.7	PL	EL-T5950.00A	P C B
3446	4.01.0190.1.01.8	PL	EL-T-6109-00	P C B
3447	4.01.0191.1.01.9	PL	ELT700-00030 SUB. EL-T7050.400-PE/A	POWER SUPPLY
3448	4.01.0192.1.01.1	PL	ELT700-00031 SUB. EL-T7050.200-PE/A	POWER SUPPLY
3449	4.01.0193.1.01.2	PL	ELT-701-00031 SUB. EL-T7050.200-PE/A	POWER SUPPLY
3450	4.01.0194.1.01.3	PL	EL-T-7050-400	POWER PACK
3451	4.01.0195.1.01.4	PL	EL-T-7155-00	P C B
3452	4.01.0196.1.01.5	PL	ELT-H00-00001	CONTROL DEVICE AIR DRYER
3453	4.01.0197.1.01.6	PL	EP910ILC-15(LP12.1)	PROGRAMME-E-PROME
3454	4.01.0198.1.01.7	PL	M27C64A-15FN SUB. 2764A	E-PROM-"HI" PROGRAMMED
3455	4.01.0199.1.01.8	PL	ST644/1H	TRANSFORMER
3456	4.01.0200.1.01.9	PL	VT 300 5G	AMPLIFIER CORD FOR REXROTH PUMP
3457	4.01.0201.1.01.1	PL	VT-3005-5032-A-822	P C B
3458	4.01.0202.1.01.2		Shifted to Ann-II	
3459	4.01.0203.1.01.3	PL	VT5036S1X/R5	AMPLIFIER
3460	4.01.0204.1.01.4	LO	110280	TRANSFORMER CT 1600:5
3461	4.01.0205.1.01.5	LO	114348	PLC MOD DIGITAL INPUT 16 INPUTS 24 VOLTS DC
3462	4.01.0206.1.01.6	LO	114351	PLC MOD DIGITAL OUTPUT 16 CONTACT OUTPUTS 2 AMPS
3463	4.01.0207.1.01.7	LO	114352	PLC 1756 INPUT ANALOG 16 SINGLE-END 8 DIFF
3464	4.01.0208.1.01.8	LO	114353	PLC MOD RTD INPUT 6 ISOLATED RTD INPUTS
3465	4.01.0209.1.01.9	LO	114354	PLC MOD ANALOG OUTPUT 8 VOLTAGE/CURRENT OUTPUTS
3466	4.01.0210.1.01.1	LO	114355	PLC MOD COUNTER 2 HIGH SPEED COUNTERS
3467	4.01.0211.1.01.2	LO	114357	PLC MOD CONTROL NET REDUNTANT COMM INTERFACE
3468	4.01.0212.1.01.3	LO	114358	PLC MOD DEVICE NET SCANNER INTERFACE
3469	4.01.0213.1.01.4	LO	114476	PLC MOD IFM DIN RAIL MOUNT
3470	4.01.0214.1.01.5	LO	114477	PLC MOD IFM DIN RAIL MOUNT

3471	4.01.0215.1.01.6	LO	114489	PLC MOD IFM DIN RAIL MOUNT
3472	4.01.0216.1.01.7	LO	123402	PLC POWER SUPPLY 24VDC 75W OUTPUT @ 60 DEG C
3473	4.01.0217.1.01.8	LO	123408	PLC MOD ETHERNET COMM INTERFACE
3474	4.01.0218.1.01.9	LO	124334	PLC 1756 COMM MODBUS INTERFACE
3475	4.01.0219.1.01.1	LO	126312	PCB ATTENUATOR VOLTAGE
3476	4.01.0220.1.01.2	LO	126629	PCB CALIBRATION SCR
3477	4.01.0221.1.01.3	LO	126632	PCB AMPLIFIER ISOLATION
3478	4.01.0222.1.01.4	LO	126645	PCB SCR DVDT AND FIRING BD
3479	4.01.0223.1.01.5	LO	128268	PLC 1794 CONTROL NET REDUNDANT COMM INTERFACE
3480	4.01.0224.1.01.6	LO	128269	PLC 1794 ANALOG I/O VOLTAGE/CURRENT 4IN 2OUT
3481	4.01.0225.1.01.7	LO	128270	PLC 1794 DIGITAL INPUT 16 24VDC INPUTS
3482	4.01.0226.1.01.8	LO	128271	PLC 1794 DIGITAL OUTPUT 8 RELAY CONTACT OUTPUTS
3483	4.01.0227.1.01.9	LO	156459	PLC 1756 CONTROLLER CONTROLLOGIX 8M RAM
3484	4.01.0228.1.01.1	KA	1023.14.21.230	PCB SEMI AUTO WORKING
3485	4.01.0229.1.01.2	KA	1023.14.22.220	PCB LINING
3486	4.01.0230.1.01.3	KA	1023.14.22.280	PCB ASSEMBLY
3487	4.01.0231.1.01.4	PL	EL-T5024.00A	P C B
3488	4.01.0232.1.01.5	PL	EL-T5025.00A	P C B
3489	4.01.0233.1.01.6	PL	EL-T5031.00	P C B
3490	4.01.0234.1.01.7	PL	EL-T5035.00	P C B
3491	4.01.0235.1.01.8	PL	1023.14.22.330	P C B
3492	4.01.0236.1.01.9	PL	EK-1.1/1LV1-00	P C B
3493	4.01.0237.1.01.1	PL	EK-100V.00	P C B
3494	4.01.0238.1.01.2	PL	EK-110MC-00B/3,84M SUBSTITUTE EK-110V.00A	P C B
3495	4.01.0239.1.01.3	PL	EK-16V-00B	P C B
3496	4.01.0240.1.01.4	PL	EK-197V-00B SUBSTITUTE EK-197V.00A	P C B
3497	4.01.0241.1.01.5	PL	EK-1AP13-00A	P C B
3498	4.01.0242.1.01.6	PL	EK-202V-00B SUBSTITUTE EK-202V.00A	P C B
3499	4.01.0243.1.01.7	PL	EK-2038LV-00	P C B
3500	4.01.0244.1.01.8	PL	EK-207V-00B SUBSTITUTE EK-207V-00A	P C B
3501	4.01.0245.1.01.9	PL	EK-2195LV-00	P C B
3502	4.01.0246.1.01.1	PL	EK-229LV-00	P C B
3503	4.01.0247.1.01.2	PL	EK-2360LV-00	P C B
3504	4.01.0248.1.01.3	PL	EK-275LV-00	P C B
3505	4.01.0249.1.01.4		Repeated item	
3506	4.01.0250.1.01.5	PL	EK-3069LV-00A	P C B
3507	4.01.0251.1.01.6	PL	EK-319LV-00C	P C B
3508	4.01.0252.1.01.7	PL	EK-345LV-00	P C B
3509	4.01.0253.1.01.8	PL	EK-347LV-00B	P C B
3510	4.01.0254.1.01.9	PL	EK-429DV-00D	P C B
3511	4.01.0255.1.01.1	PL	EK-430DV-00D	P C B
3512	4.01.0256.1.01.2	PL	EK-432DV-00	P C B
3513	4.01.0257.1.01.3	PL	EK-433DV-00	P C B
3514	4.01.0258.1.01.4	PL	EK-501P.00WITHOUTE-PROM	P C B
3515	4.01.0259.1.01.5	PL	EK-502P.00AWITHOUTE-PROM	P C B
3516	4.01.0260.1.01.6	PL	EK-503P.00WITHOUTE-PROM	P C B
3517	4.01.0261.1.01.7	PL	EK-520A-00C	P C B
3518	4.01.0262.1.01.8	PL	EK-520CA-00	P C B
3519	4.01.0263.1.01.9	PL	EK-522CA-00A	P C B
3520	4.01.0264.1.01.1	PL	EK-523CA-00C	P C B
3521	4.01.0265.1.01.2	PL	EK-602E-00	P C B
3522	4.01.0266.1.01.3	PL	EK-637MC-00D/185F	P C B
3523	4.01.0267.1.01.4	PL	EK-637MC-00D/186F	P C B
3524	4.01.0268.1.01.5	PL	EK-637MC-00D/235	P C B
3525	4.01.0269.1.01.6	PL	EK-638MC-00C SUBSTITUTE EK-638MC-00B	P C B
3526	4.01.0270.1.01.7	PL	EK-650P-00AWITHOUTE-PROM SUBSTITUTE EK-650P.00	P C B
3527	4.01.0271.1.01.8	PL	EK-650PX-00WITHOUTE-PROM	P C B
3528	4.01.0272.1.01.9	PL	EK-651P-00A	P C B
3529	4.01.0273.1.01.1	PL	EK-652P-00A SUBSTITUTE EK-652P.00	P C B
3530	4.01.0274.1.01.2	PL	EK-653P/S-00B SUBSTITUTE EK-653P.00	P C B
3531	4.01.0275.1.01.3	PL	EK-657P-00A SUBSTITUTE EK-657P.00	P C B
3532	4.01.0276.1.01.4	PL	EK-664P-00D SUBSTITUTE EK-554P-00A	P C B
3533	4.01.0277.1.01.5	PL	EK-664P-00D SUBSTITUTE EK-664P-00	P C B
3534	4.01.0278.1.01.6	PL	EK-706AR-00A	P C B
3535	4.01.0279.1.01.7	PL	EK-727A-00	P C B
3536	4.01.0280.1.01.8	PL	EK-754P-00D/195	P C B
3537	4.01.0281.1.01.9	PL	EK-754P-00D/253	P C B
3538	4.01.0282.1.01.1	PL	EK-758P-00	P C B

3539	4.01.0283.1.01.2	PL	EK-805SV-00/GT	P C B
3540	4.01.0284.1.01.3	PL	EK-805SV-00D SUBSTITUTE EK-805SV-00C	P C B
3541	4.01.0285.1.01.4	PL	EK-812SV-00	P C B
3542	4.01.0286.1.01.5	PL	EK-812SV-00C SUBSTITUTE EK-812SV-00A	P C B
3543	4.01.0287.1.01.6		Repeated item	
3544	4.01.0288.1.01.7	PL	EK-821SV-00	P C B
3545	4.01.0289.1.01.8	PL	ELB-EP0-00A-MBI	P C B
3546	4.01.0290.1.01.9	PL	ELB-EP0-01-MBI	P C B
3547	4.01.0291.1.01.1	PL	ELB-EP0-01-TS	P C B
3548	4.01.0292.1.01.2	PL	ELB-KD0-01-MBI	P C B
3549	4.01.0293.1.01.3	PL	ELB-KN0-01	P C B
3550	4.01.0294.1.01.4	PL	ELB-KR0-25	P C B
3551	4.01.0295.1.01.5	PL	ELB-KV0-00-11	P C B
3552	4.01.0296.1.01.6	PL	ELB-SM0-05-MLC60	MICROCONTROLLER
3553	4.01.0297.1.01.7	PL	ELF3-40.1	FILTER
3554	4.01.0298.1.01.8	PL	EL-SU-T59.00	PR.CIRCUIT BOARD COMPLETE
3555	4.01.0299.1.01.9	PL	EL-T1157.00	P C B
3556	4.01.0300.1.01.1	PL	EK-819SV-00(02)	POWER SUPPLY
3557	4.01.0301.1.01.2	PL	ELB-EPO-00A-MBI	MICROPROCESSOR MODULE
3558	4.01.0302.1.01.3	PL	ELB-L00-10	P.C.B. MODULE
3559	4.01.0303.1.01.4	PL	EL-T1163.00	P C B
3560	4.01.0304.1.01.5	PL	EL-T50029.00	P C B
3561	4.01.0305.1.01.6	PL	EL-T50031.00A/100 SUBSTITUTE TRI-24V-100SEC	P C B
3562	4.01.0306.1.01.7	PL	EL-T5096.00	P C B
3563	4.01.0307.1.01.8	PL	EL-T5571.00B	PRINTED CIRCUIT BOARD F.PENDULUM
3564	4.01.0308.1.01.9	PL	EL-T5923.00	PCB
3565	4.01.0309.1.01.1	PL	EL-T5927.00A	P.C.B. MODULE
3566	4.01.0310.1.01.2	PL	PS-3-65-300	DC/AC CONVERTER
3567	4.01.0311.1.01.3	PL	1,50MM2/BANDWARE	JACKET
3568	4.01.0312.1.01.4	PL	7705	VOLTAGE STABILIZER
3569	4.01.0313.1.01.5	KA	161.14.22.220	Lifting PCB
3570	4.01.0314.1.01.6	KA	161.11.73.210	Lining PCB
3571	4.01.0315.1.01.7	KA	161.14.21.280	PCB Proportional Deepening
3572	4.01.0316.1.01.8	KA	HBE 440.24 & TP461340.000	Control Unit of Servo Valve
3573	4.01.0317.1.01.9	KA	TU25.7301-CC66-90 IEM 102-1-01-2 EM 102-1-05-2	Control Unit Servo Valve
3574	4.01.0318.1.01.1	KA	MCBP 461-161.432	Power Supply PCB
3575	4.01.0319.1.01.2	KA	161.14.22.330	Pendulum PCB
3576	4.01.0320.1.01.3	KA	461161420	Versine PCB
3577	4.01.0321.1.01.4	KA	461264547	Front Tower Lifting PCB
3578	4.01.0322.1.01.5	PL	EK-99V-00A	PCB Complete
3579	4.01.0323.1.01.6	PL	EL-T 5353.00	PCB
3580	4.01.0324.1.01.7	KA	1023.14.12.030	Pendulum PCB
3581	4.01.0325.1.01.8	KA	161.14.21.210	Tamping Unit PCB
3582	4.01.0326.1.01.9	KA	1023.14.12.020	PCB Lifting
3583	4.01.0327.1.01.1	KA	MCBP 461264.547	Front Tower Lifting PCB (Setting Device Lift/Slew)
3584	4.01.0328.1.01.2	PL	EK-855.SV	PCB
3585	4.01.0329.1.01.3	PL	64.07.5000.169	PCB
3586	4.01.0330.1.01.4	PL	EK29V.00	PRINTED CIRCUIT BOARD
3587	4.01.0331.1.01.5	PL	EK.152V.00	P.C.B (CPL)
3588	4.01.0332.1.01.6	PL	EL-T.5384.00	P.C.B (CPL)
3589	4.01.0333.1.01.7	PL	EK353 P/S-00B	PRINTED CIRCUIT BOARD
3590	4.01.0334.1.01.8	PL	EK664P.00B(EK654P.00IR)	P.C.B
3591	4.01.0335.1.01.9	CR	K-393.171	SEPERATE BRAKING MODULE
3592	4.01.0336.1.01.1	CR	6ES7155-6AU00-0CN0	INTERFACE MODULE
3593	4.01.0337.1.01.2	CR	MCR-VDC-UI-B-DC	VOLTAGE MEASURING MODULE
3594	4.01.0338.1.01.3	CR	6ES7138-6CG00-0BA0	TIME STAMP MODULE
3595	4.01.0339.1.01.4	CR	6ES7131-6BH01-0BA0	DIGITAL INPUT MODULE (16 digital input module)
3596	4.01.0340.1.01.5	CR	6ES7132-6BH01-0BA0	DIGITAL OUTPUT MODULE (16 digital output module)
3597	4.01.0341.1.01.6	CR	6ES7132-6BD20-0BA0	4 points digital output module
3598	4.01.0342.1.01.7	CR	6ES7134-6HD01-0BA1	analog input module
3599	4.01.0343.1.01.8	CR	6ES7135-6HD00-0BA1	analog output module
3600	4.01.0344.1.01.9	CR	QUINT-PS/24DC/24DC/10	DC/DC power supply
3601	4.01.0345.1.01.1	PL	64.07.5000.197	PRINTED CIRCUIT BOARD CPL
3602	4.01.0346.1.01.2	PL	64.07.5000.218	PRINTED CIRCUIT BOARD CPL
3603	4.01.0347.1.01.3	PL	EK-509CA-00B, SUB : EK- 509CA-00A	PRINTED CIRCUIT BOARD POPULATED

3604	4.01.0348.1.01.4	PL	EK-513CA-00B	PRINTED CIRCUIT BOARD CPL
3605	4.01.0349.1.01.5	PL	64.07.5000.158	PRINTED CIRCUIT BOARD CPL
3606	4.01.0350.1.01.6	PL	EK-521CA-00	PRINTED CIRCUIT BOARD CPL
3607	4.01.0351.1.01.7	PL	EK-761P-00B	MICROPROCESSOR MODULE
3608	4.01.0352.1.01.8	PL	ELB-EPO-00A-SLAVE	MICRO PROCESSOR CARD FOR MBI
3609	4.01.0353.1.01.9	PL	EL-T3123LV-00B	PRINTED CIRCUIT BOARD CPL
3610	4.01.0354.1.01.1	PL	EL-T5115.00	PRINTED CIRCUIT BOARD CPL
3611	4.01.0355.1.01.2	PL	EL-T5843.00A	PRINTED CIRCUIT BOARD CPL
3612	4.01.0356.1.01.3	PL	EL-T5847.00A	PRINTED CIRCUIT BOARD CPL
3613	4.01.0357.1.01.4	PL	EK-637MC-00D/187F	MICRO CONTROLLER FOR SQUEEZING
3614	4.01.0358.1.01.5	PL	ELB-EMO-03-EXTS/300F	MICRO CONTROLLER FOR AUTO POSITION
3615	4.01.0359.1.01.6	PL	EL-T5967.00	PRINTED CIRCUIT BOARD CPL
3616	4.01.0360.1.01.7	PL	ELB-SMO-37A-0006-MCL126	VALVE CARD
3617	4.01.0361.1.01.8	PL	ELB-M00-01-001MCL164	PRINTED CIRCUIT BOARD
3618	4.01.0362.1.01.9	PL	ELB-LAO-27	VOLTAGE STABILISER
3619	4.01.0363.1.01.1	PL	EL-AM30.00	EXTENSION 16IN+OUTPUTS
3620	4.01.0364.1.01.2	PL	EL-AM30.03	EXTENSION 4IN+ 4OUT ANALOG
3621	4.01.0365.1.01.3	PL	EL-AM30.05	INPUT COUNTER MODULE
3622	4.01.0366.1.01.4	PL	EL-AM40.00/01	CONNECTING BLOCK FOR EL-AM30.00
3623	4.01.0367.1.01.5	PL	EL-AM40.03/01	CONNECTING BLOCK FOR EL-AM30.03
3624	4.01.0368.1.01.6	PL	EL-AM40.05/01	CONNECTING BLOCK FOR EL-AM30.05
3625	4.01.0369.1.01.7	PL	MINI-PS-12-24DC/5-15DC/2	POWER SUPPLY
3626	4.01.0370.1.01.8	PL	EL-AM60.00	POWER SUPPLY
3627	4.01.0371.1.01.9	PL	RPMD60-2415SG	POWER SUPPLY DC15V/4A
3628	4.01.0372.1.01.1	PL	EK-1AP4-00/1,5A	PCB
3629	4.01.0373.1.01.2	PL	EL-AM20.00	NODE MODULE,CANOPEN
3630	4.01.0374.1.01.3	PL	EL-AM30.01	EXTENSION/32 INPUTS
3631	4.01.0375.1.01.4	PL	EL-AM30.08	ANALOGUE 8 INPUT MODULE
3632	4.01.0376.1.01.5	PL	ELB-EMO-03-16	MICRO CONTROLLER
3633	4.01.0377.1.01.6	PL	ELB-EMO-03-08	MICRO CONTROLLER
3634	4.01.0378.1.01.7	PL	EK-532CA-00	PCB
3635	4.01.0379.1.01.8	PL	EL-T50059.002	PCB
3636	4.01.0380.1.01.9	PL	EK-1030V-00	PCB
3637	4.01.0381.1.01.1	PL	EK-2314LV.00	PCB
3638	4.01.0382.1.01.2	PL	EL-T7162.00	DC/DC CONVERTER
3639	4.01.0383.1.01.3	PL	EL-AM20.01	NODE MODULE,CANOPEN
3640	4.01.0384.1.01.4	PL	EL-T5058.00	PCB
3641	4.01.0385.1.01.5	PL	EK-2214LV.00a	PCB
3642	4.01.0386.1.01.6	PL	EL-T7219.00	DC/DC CONVERTER
3643	4.01.0387.1.01.7	PL	CPU/1-0076-1	CENTRAL CPU
3644	4.01.0388.1.01.8	PL	CPU/1-0076-2	CENTRAL CPU
3645	4.01.0389.1.01.9	PL	ERA-26.08	PR.CIRCUIT BOARD COMPLETE
3646	4.01.0390.1.01.1	PL	EK-761P-00-SPS	PCB
3647	4.01.0391.1.01.2	PL	ELB-SMO-05-MCL60	PCB
3648	4.01.0392.1.01.3	PL	EL-AM30.06	PWM module
3649	4.01.0393.1.01.4	PL	EL-AM40.01	FOR EL-AM30.01
3650	4.01.0394.1.01.5	PL	170-C23NKF10-A1G-TY-N	Star delta starter
3651	4.01.0395.1.01.6	PL	EK-513CA-00	PRINTED CIRCUIT BOARD CPL LINING ADAPTER
3652	4.01.0396.1.01.7	PL	EK-528CA-00A	PRINTED CIRCUIT BOARD CPL
3653	4.01.0397.1.01.8	PL	EK-638MC-00B/174-14F SUBSTITUTE EK-638MC-00C/174-14F or ELB-EMO-03-16/289F	PRINTED CIRCUIT BOARD CPL (LIFTING -U CONTROLLER)
3654	4.01.0398.1.01.9	PL	EK-638MC-00B/175-14F SUBSTITUTE EK-638MC-00C/175-14F or ELB-EMO-03-16/290F	PRINTED CIRCUIT BOARD CPL (LEVELLING -U CONTROLLER)
3655	4.01.0399.1.01.1	PL	EK-638MC-00B/176-14F SUBSTITUTE EK-638MC-00C/176-14F or ELB-EMO-03-16/291F	PRINTED CIRCUIT BOARD CPL (LINING - U CONTROLLER)

3656	4.01.0400.1.01.2	PL	EK-638MC-00B/211 OR EK-638MC-00C/211 OR ELB-EM0-03-16/307	PRINTED CIRCUIT BOARD CPL
3657	4.01.0401.1.01.3	PL	EK-3122LV-00C	PRINTED CIRCUIT BOARD CPL
3658	4.01.0402.1.01.4	PL	EK-3123V-00B, SUB : EK-3123V-00A	PRINTED CIRCUIT BOARD CPL
3659	4.01.0403.1.01.5	PL	ELB-EP0-01-SPS	PRINTED CIRCUIT BOARD CPL
3660	4.01.0404.1.01.6	PL	ELB-M00-01-001 MCL163	UNIVERSAL MODULE (DERAIL SAFETY)
3661	4.01.0405.1.01.7	PL	ELB-SM0-00	PRINTED CIRCUIT BOARD CPL
3662	4.01.0406.1.01.8	PL	ELB-SM0-19A-001-MCL120	PRINTED CIRCUIT BOARD CPL
3663	4.01.0407.1.01.9	PL	ELB-SM0-30-A-000-MCL123 OR ELB-SM0-30-000-MCL123	ALC ADAPTER BOARD
3664	4.01.0408.1.01.1	PL	ELB-SM0-37A-2008-MCL126	VALVE STAGE
3665	4.01.0409.1.01.2	PL	EL-T631.01-GT-A	PRINTED CIRCUIT BOARD CPL
3666	4.01.0410.1.01.3	PL	EL-T895.00	PRINTED CIRCUIT BOARD CPL
3667	4.01.0411.1.01.4	PL	EL-T5151.00	PRINTED CIRCUIT BOARD CPL
3668	4.01.0412.1.01.5	PL	EL-T5534.001R-C/ EL-T5534.001R-A	PRINTED CIRCUIT BOARD CPL
3669	4.01.0413.1.01.6	PL	EL-T5961.00	PRINTED CIRCUIT BOARD CPL
3670	4.01.0414.1.01.7	PL	EL-T50016.00	PRINTED CIRCUIT BOARD CPL
3671	4.01.0415.1.01.8	PL	EL-T50056.00/EL-T50056-MA.00	PRINTED CIRCUIT BOARD CPL
3672	4.01.0416.1.01.9	PL	EL-AM10.00	MODULE
3673	4.01.0417.1.01.1	PL	ELB-SA0-22-B OR ELB-SA0-22	DC DC FILTER
3674	4.01.0418.1.01.2	PL	ELB-SM0-01	TEMPERATURE DISPLAY UNIT
3675	4.01.0419.1.01.3	PL	ELB-SM0-01-UU2	DISPLAY UNIT
3676	4.01.0420.1.01.4	PL	ELB-SM0-01-UU4	DISPLAY UNIT
3677	4.01.0421.1.01.5	PL	ELB-SM0-03-MCL95	DIGITAL ANALOG MODUL
3678	4.01.0422.1.01.6	PL	ELB-SM0-07-102-MCL180	UNIVERSAL MODULE
3679	4.01.0423.1.01.7	PL	ELB-SM0-16-A-300-MCL148	MBI MDULE 16 O/P SIGNALS
3680	4.01.0424.1.01.8	PL	ELB-SM0-17-A-300-MCL124	MBI MDULE 16 DIN
3681	4.01.0425.1.01.9	PL	ELB-SM0-31-001-MCL142	DATA COLLECTOR
3682	4.01.0426.1.01.1	PL	ELB-SM0-32-A-001-MCL115	ON BOARD ELECTRICAL SYSTEM MONITORING MODULE
3683	4.01.0427.1.01.2	PL	ELB-SM0-32-MCL115 OR ELB-SM0-32-A-000-MCL115	ON BOARD ELECTRICAL SYSTEM MONITORING
3684	4.01.0428.1.01.3	PL	ELB-ES0-01-A-MCL140 OR ELB-ES0-01-MCL140 OR ELB-ES0-01-000-MCL140	POWER SUPPLY 170W
3685	4.01.0429.1.01.4	PL	EL-T5950.002A/EL-T5950.00-2K-A	FET PULSE AMPLIFIER
3686	4.01.0430.1.01.5	PL	EL-TH00-0000 and Sub Part no. PWD00A-400-19	AMPLIFIER MODULE
3687	4.01.0431.1.01.6	PL	ELB-M00-01-001-MCL168	UNIVERSAL MODULE
3688	4.01.0432.1.01.7	PL	ELB-M00-01-411-MCL162	MICROCONTROLLER
3689	4.01.0433.1.01.8	LO	A81904	Terminal Block Power
3690	4.01.0434.1.01.9	LO	173682	TRANS 480V 120V 750VA
3691	4.01.0435.1.01.1	LO	173729	TRANS 150A-5A 4VA CT
3692	4.01.0436.1.01.2	LO	134819	TIMER BOARD
3693	4.01.0437.1.01.3	LO	229492	Micro processor T1 69677-010
3694	4.01.0438.1.01.4	LO	114961	POWER SUPPLY 480/24 40A DIN RAIL MOUNT
3695	4.01.0439.1.01.5	LO	128272	PLC 1794 TERMINAL BASE
3696	4.01.0440.1.01.6	LO	128274	PLC 1794 TERMINAL BASE FUSED OUTPUTS
3697	4.01.0441.1.01.7	LO	116798	TRANSFORMER 10KVA 240X480-120/240VAC 1PHASE
3698	4.01.0442.1.01.8	LO	247861	GENERATOR; 900 KW
3699	4.01.0443.1.01.9	LO	108541	POWER SUPPLY (UPS) 120V 1500VA RACKMOUNT 6 OUTLET
3700	4.01.0444.1.01.1	LO	104243	TRANSFORMER 120/12VAC 50VA W/ FUSE CLIP
3701	4.01.0445.1.01.2	LO	A37756	TRANSFORMER 480-120V
3702	4.01.0446.1.01.3	LO	101440	POWER SUPPLY 12VDC 57AMP
3703	4.01.0447.1.01.4	LO	252351-39	POWER SUPPLY KIT #2
3704	4.01.0448.1.01.5	LO	252351-54	POWER SUPPLY KIT #3
3705	4.01.0449.1.01.6	LO	A47415	POWER SUPPLY 10 VDC
3706	4.01.0450.1.01.7	PL	EK-3112LV.00	PCB
3707	4.01.0451.1.01.8	PL	EK-2048LV. 00	PCB
3708	4.01.0452.1.01.9	PL	ELB-EM0-02	PCB
3709	4.01.0453.1.01.1	PL	ELB-EM0-01	PCB
3710	4.01.0454.1.01.2	PL	ELB-LOO.20	PCB
3711	4.01.0455.1.01.3	PL	EK-637MC-00C	MICROCONTROL LER
3712	4.01.0456.1.01.4	PL	ELW-SM0-05	UNIVERSAL MODULE
3713	4.01.0457.1.01.5	PL	EK-2683LV.00	VIBRATION CONTROL PCB
3714	4.01.0458.1.01.6	PL	EK-152MC-OOB /	PCB
3715	4.01.0459.1.01.7	PL	EL-T5033.00	PCB
3716	4.01.0460.1.01.8	PL	EL-T5100. 00	PCB
3717	4.01.0461.1.01.9	PL	EL-T5895. 00	PCB
3718	4.01.0462.1.01.1	PL	EK-1.1 / 2LV2. 00	PCB
3719	4.01.0463.1.01.2	PL	EK- 1.1/ 5LV2.00	PCB
3720	4.01.0464.1.01.3	PL	EL-T5258.00A	PCB
3721	4.01.0465.1.01.4	PL	EL-T5259. 00A	PCB

3722	4.01.0466.1.01.5	PL	EL-T5271.OOA	PCB
3723	4.01.0467.1.01.6	PL	EL-T5376.OOA	PCB
3724	4.01.0468.1.01.7	PL	EL-T5825.OOA	PCB
3725	4.01.0469.1.01.8	PL	EL-T5865.OOA	PCB
3726	4.01.0470.1.01.9	PL	EK-526MC.OOA	MICROCONTROL LER
3727	4.01.0471.1.01.1	PL	EK-2349 LV.00	PCB
3728	4.01.0472.1.01.2	PL	EL-T5686.00	PCB
3729	4.01.0473.1.01.3	PL	EL-T5722.00	PCB
3730	4.01.0474.1.01.4	PL	EL-T4S1.07B	PCB
3731	4.01.0475.1.01.5	PL	EL-T5586.00	PCB
3732	4.01.0476.1.01.6	PL	EK-528CA.OOA	PCB
3733	4.01.0477.1.01.7	PL	EK-620MC.00	MICROCONTROL LER
3734	4.01.0478.1.01.8	PL	EK-2345LV.00	PCB
3735	4.01.0479.1.01.9	PL	EK-527CA.00	PCB
3736	4.01.0480.1.01.1	PL	62.07.1000.341	PCB
3737	4.01.0481.1.01.2	PL	ELB-SM0-04-MCL56	MICROCONTROLLER
3738	4.02.0001.1.01.9	PL	805468	TRANSISTOR
3739	4.02.0002.1.01.1	PL	100V/0.1MF	CAPACITOR
3740	4.02.0003.1.01.2	PL	100V/470/PF	CAPACITOR
3741	4.02.0004.1.01.3	PL	10MUEF50V/AXIAL	CAPACITOR
3742	4.02.0005.1.01.4	PL	10NF100V/VERTICAL/R=5MM SUB. 100V/10NF/R=5MM	CAPACITOR
3743	4.02.0006.1.01.5	PL	10UF/50V	CONDENSOR
3744	4.02.0007.1.01.6	PL	18PF	CAPACITOR
3745	4.02.0008.1.01.7	PL	1A600V1N4005	DIODE
3746	4.02.0009.1.01.8	PL	1MUEF50V-TA/R=2,5MM	CAPACITOR
3747	4.02.0010.1.01.9	PL	1N4148	DIODE
3748	4.02.0011.1.01.1	PL	1N5629A	ZENNER DIODE
3749	4.02.0012.1.01.2	PL	1N5637A	DIODE
3750	4.02.0013.1.01.3	PL	1N5642	DIODE
3751	4.02.0014.1.01.4	PL	1N5644A	DIODE
3752	4.02.0015.1.01.5	PL	2.2UF/50V	CONDENSOR
3753	4.02.0016.1.01.6	PL	2.2UF/63V	CONDENSOR
3754	4.02.0017.1.01.7	PL	255.36B	RELAY FOR KK2000 A/C WEBASTO
3755	4.02.0018.1.01.8	PL	2N2905A (BSV 15)	TRANSISTOR
3756	4.02.0019.1.01.9	PL	2N3019 SUB. BSW-67	TRANSISTOR
3757	4.02.0020.1.01.1	PL	2N3055	TRANSISTOR
3758	4.02.0021.1.01.2	PL	330PF100V/VERTICAL/R=5MM SUB. 100V/330PF/R=5MM	CAPACITOR
3759	4.02.0022.1.01.3	PL	35V/4.7MF	CAPACITOR
3760	4.02.0023.1.01.4	PL	3A1000VIN5408	DIODE
3761	4.02.0024.1.01.5	PL	4.7MUEF50V-TA/R=5MM	CAPACITOR
3762	4.02.0025.1.01.6	PL	4.7MF/10V	CONDENSOR
3763	4.02.0026.1.01.7	PL	40V/470MF	CAPACITOR
3764	4.02.0027.1.01.8	PL	40V470MUEF/AXIAL	CAPACITOR
3765	4.02.0028.1.01.9	PL	40V47MUEF/TA/VERT	CAPACITOR
3766	4.02.0029.1.01.1	PL	50V/10MF	CAPACITOR
3767	4.02.0030.1.01.2	PL	50V1000MF	CAPACITOR
3768	4.02.0031.1.01.3	PL	50V22MUEF/AXIAL/BIPOL SUB. 63V22MUEF/AXIAL/BIPOL	CAPACITOR
3769	4.02.0032.1.01.4	PL	556/DIP14-POL	INTEGRATED CIRCUIT
3770	4.02.0033.1.01.5	PL	63V/0.22MUEF/AXIAL	CAPACITOR
3771	4.02.0034.1.01.6	PL	63V/10MF	CAPACITOR
3772	4.02.0035.1.01.7	PL	63V/1MF	CAPACITOR
3773	4.02.0036.1.01.8	PL	63V/220MUEF/AXIAL	CAPACITOR
3774	4.02.0037.1.01.9	PL	63V2.2MUEF/AXIAL	CONDENSOR
3775	4.02.0038.1.01.1	PL	68NF100V/VERTICAL/R=5MM SUB. 100V/68NF/R=5MM	CAPACITOR
3776	4.02.0039.1.01.2	PL	68NF100V/VERTIKAL/R=5MM	CAPACITOR
3777	4.02.0040.1.01.3	PL	68UF	CONDENSOR
3778	4.02.0041.1.01.4	PL	747DIP14-POL.	INTEGRATED CIRCUIT
3779	4.02.0042.1.01.5	PL	7805/TO220	VOLTAGE REGULATOR
3780	4.02.0043.1.01.6	PL	7805/TO3	VOLTAGE REGULATOR
3781	4.02.0044.1.01.7	PL	7812/TO220	VOLTAGE REGULATOR
3782	4.02.0045.1.01.8	PL	7812/TO3	VOLTAGE REGULATOR
3783	4.02.0046.1.01.9	PL	7815/TO220	VOLTAGE REGULATOR
3784	4.02.0047.1.01.1	PL	7824C/TO220AB	VOLTAGE REGULATOR
3785	4.02.0048.1.01.2	PL	BC182A	TRANSISTOR
3786	4.02.0049.1.01.3	PL	BC212A	TRANSISTOR
3787	4.02.0050.1.01.4	PL	BC546B	TRANSISTOR
3788	4.02.0051.1.01.5	PL	BC549B	TRANSISTOR
3789	4.02.0052.1.01.6	PL	BC556B	TRANSISTOR
3790	4.02.0053.1.01.7	PL	BD677	TRANSISTOR
3791	4.02.0054.1.01.8	PL	BD678	TRANSISTOR
3792	4.02.0055.1.01.9	PL	BD681	TRANSISTOR
3793	4.02.0056.1.01.1	PL	BDV64B	TRANSISTOR
3794	4.02.0057.1.01.2	PL	BDV65B	TRANSISTOR

3795	4.02.0058.1.01.3	PL	BSX46-10	TRANSISTOR
3796	4.02.0059.1.01.4	PL	BUF634	INTEGRATED CIRCUIT
3797	4.02.0060.1.01.5	PL	BUZ-20	TRANSISTOR
3798	4.02.0061.1.01.6	PL	C-MOS4001B	CIRCUIT
3799	4.02.0062.1.01.7	PL	C-MOS4014B	CIRCUIT
3800	4.02.0063.1.01.8	PL	C-MOS4023B	INTEGRATED CIRCUIT
3801	4.02.0064.1.01.9	PL	C-MOS4029B	INTEGRATED CIRCUIT
3802	4.02.0065.1.01.1	PL	C-MOS4040B	INTEGRATED CIRCUIT
3803	4.02.0066.1.01.2	PL	C-MOS4042B	INTEGRATED CIRCUIT
3804	4.02.0067.1.01.3	PL	C-MOS4049B	INTEGRATED CIRCUIT
3805	4.02.0068.1.01.4	PL	C-MOS4050B	INTEGRATED CIRCUIT
3806	4.02.0069.1.01.5	PL	C-MOS4059BPN	INTEGRATED CIRCUIT
3807	4.02.0070.1.01.6	PL	C-MOS4060B	CIRCUIT
3808	4.02.0071.1.01.7	PL	C-MOS4081B	INTEGRATED CIRCUIT
3809	4.02.0072.1.01.8	PL	C-MOS4082B	INTEGRATED CIRCUIT
3810	4.02.0073.1.01.9	PL	C-MOS4093B	INTEGRATED CIRCUIT
3811	4.02.0074.1.01.1	PL	C-MOS4094B	INTEGRATED CIRCUIT
3812	4.02.0075.1.01.2	PL	C-MOS4099B	INTEGRATED CIRCUIT
3813	4.02.0076.1.01.3	PL	C-MOS4500B	INTEGRATED CIRCUIT
3814	4.02.0077.1.01.4	PL	C-MOS4504B	INTEGRATED CIRCUIT
3815	4.02.0078.1.01.5	PL	C-MOS4512B	INTEGRATED CIRCUIT
3816	4.02.0079.1.01.6	PL	C-MOS4514B	INTEGRATED CIRCUIT
3817	4.02.0080.1.01.7	PL	C-MOS4555B	INTEGRATED CIRCUIT
3818	4.02.0081.1.01.8	PL	EL-T1218S	RELAY
3819	4.02.0082.1.01.9	PL	EL-T1501.00	INTEGRATED CIRCUIT
3820	4.02.0083.1.01.1	PL	EL-T295S	RELAY
3821	4.02.0084.1.01.2	PL	EL-T470S-T SUB. EL-T470S (GKLV-A/K/B)	RELAY
3822	4.02.0085.1.01.3	PL	EL-T470S-T SUB. EL-T470S	RELAY
3823	4.02.0086.1.01.4	PL	EL-T5610.00 SUB. FZH241	INTEGRATED CIRCUIT
3824	4.02.0087.1.01.5	PL	ELT7002/S2-L2	RELAY
3825	4.02.0088.1.01.6	PL	EL-T7003	RELAY SOCKET
3826	4.02.0089.1.01.7	PL	EL-T7011	RELAY
3827	4.02.0090.1.01.8	PL	EL-T7018	RELAY
3828	4.02.0091.1.01.9	PL	EL-T7045/12	RELAY
3829	4.02.0092.1.01.1	PL	EL-T7045/24V	RELAY
3830	4.02.0093.1.01.2	PL	EL-T7064/24	RELAY
3831	4.02.0094.1.01.3	PL	EL-T7068	DIODE
3832	4.02.0095.1.01.4	PL	EL-T7077.032 SUB. ZR012026	TIME RELAY
3833	4.02.0096.1.01.5	PL	EL-T7077.032 SUB. ZR012036	TIME RELAY
3834	4.02.0097.1.01.6	PL	EL-T7077.032 SUB. ZR012056	TIME RELAY
3835	4.02.0098.1.01.7	PL	EL-T7125	RELAY
3836	4.02.0099.1.01.8	PL	EL-T7125-NA	RELAY
3837	4.02.0100.1.01.9	PL	EL-T7178	RELAY
3838	4.02.0101.1.01.1	PL	EL-T7284.00	RELAY
3839	4.02.0102.1.01.2	PL	FZK105	INTEGRATED CIRCUIT
3840	4.02.0103.1.01.3	PL	GAL16V8D-25NS/LP(14.1) SUB. GAL16V8D-25NS/LP(1.8.B.9)	INTEGRATED CIRCUIT WITH PROGRAMME
3841	4.02.0104.1.01.4	PL	GAL16V8D-25NS/LP(LP2.1) SUB. GAL16V8D-25NS/LP(2.5.4.6)	INTEGRATED CIRCUIT WITH PROGRAMME
3842	4.02.0105.1.01.5	PL	GAL16V8D-25NS/LP(LP3.1) SUB. GAL16V8D-25NS/LP(2.0.2.2)	INTEGRATED CIRCUIT WITH PROGRAMME
3843	4.02.0106.1.01.6	PL	HC-MOS74HC08AN	CIRCUIT
3844	4.02.0107.1.01.7	PL	HC-MOS74HC125N	CIRCUIT
3845	4.02.0108.1.01.8	PL	HC-MOS74HC132AN	CIRCUIT
3846	4.02.0109.1.01.9	PL	HC-MOS74HC161N	CIRCUIT
3847	4.02.0110.1.01.1	PL	HC-MOS74HC251N	CIRCUIT
3848	4.02.0111.1.01.2	PL	HC-MOS74HC259N	CIRCUIT
3849	4.02.0112.1.01.3	PL	HC-MOS74HC365N	CIRCUIT
3850	4.02.0113.1.01.4	PL	HC-MOS74HC366N	CIRCUIT
3851	4.02.0114.1.01.5	PL	HC-MOS74HC4514N	CIRCUIT
3852	4.02.0115.1.01.6	PL	HC-MOS74HC540N	CIRCUIT
3853	4.02.0116.1.01.7	PL	HC-MOS74HCT14	CIRCUIT
3854	4.02.0117.1.01.8	PL	HEF4731BP SUB. C-MOS4731B	INTEGRATED CIRCUIT
3855	4.02.0118.1.01.9	PL	ICL7660CPA	CIRCUIT
3856	4.02.0119.1.01.1	PL	IN4007	DIODE
3857	4.02.0120.1.01.2	PL	LM124J	INTEGRATED CIRCUIT
3858	4.02.0121.1.01.3	PL	LM139J	INTEGRATED CIRCUIT
3859	4.02.0122.1.01.4	PL	LT1001CN8 SUB. OP02C/DIP8-POL	INTEGRATED CIRCUIT
3860	4.02.0123.1.01.5	PL	MCT6 SUB. CNY74-2	INTEGRATED CIRCUIT
3861	4.02.0124.1.01.6	PL	MSK0041 SUB. LH0041CG	INTEGRATED CIRCUIT
3862	4.02.0125.1.01.7	PL	NE555P/DIP8-POL SUB. 555/DIP8-POL	CIRCUIT
3863	4.02.0126.1.01.8	PL	OP11EPZ SUB. OP11GP	INTEGRATED CIRCUIT
3864	4.02.0127.1.01.9	PL	PA-76A SUB. PA-25	AMPLIFIER
3865	4.02.0128.1.01.1	PL	PCF8574P	CIRCUIT
3866	4.02.0129.1.01.2	PL	REF-01-CPZ SUB. REF-01-CP	INTEGRATED CIRCUIT
3867	4.02.0130.1.01.3	PL	REL-26-01/24VAC, SUB GM10/24LQ203024	RELAY

3868	4.02.0131.1.01.4	PL	RM732024	RELAY
3869	4.02.0132.1.01.5	PL	RM738024	RELAY
3870	4.02.0133.1.01.6	PL	SAA1029	INTEGRATED CIRCUIT
3871	4.02.0134.1.01.7	PL	SN74F573	CIRCUIT
3872	4.02.0135.1.01.8	PL	SN74HC-125	INTEGRATED CIRCUIT
3873	4.02.0136.1.01.9	PL	SN74HC-355	INTEGRATED CIRCUIT
3874	4.02.0137.1.01.1	PL	SN74HC-366	INTEGRATED CIRCUIT
3875	4.02.0138.1.01.2	PL	TAA765A SUB. TAA765A/SMD-GESOCKET	AMPLIFIER
3876	4.02.0139.1.01.3	PL	TCA2465	AMPLIFIER
3877	4.02.0140.1.01.4	PL	TL071ACP SUB. OPA131PA	AMPLIFIER
3878	4.02.0141.1.01.5	PL	TL084CDP	INTEGRATED CIRCUIT
3879	4.02.0142.1.01.6	PL	TN2-5V	RELAY
3880	4.02.0143.1.01.7	PL	UA741-CP/DIP8 SUB. 741DIP8-POL	INTEGRATED CIRCUIT
3881	4.02.0144.1.01.8	PL	ULN2803A	INTEGRATED CIRCUIT
3882	4.02.0145.1.01.9	PL	ULN2804A	TRANSISTOR
3883	4.02.0146.1.01.1	PL	ZPY10	DIODE
3884	4.02.0147.1.01.2	PL	ZR5MF025	TIME RELAY
3885	4.02.0148.1.01.3	KE	164032	RELAY
3886	4.02.0149.1.01.4	LO	100642	RELAY 24VDC 2P TIMER 0.1SEC - 600 HRS
3887	4.02.0150.1.01.5	LO	103482	CONTROL MODULE SCR-2
3888	4.02.0151.1.01.6	LO	103488	BRIDGE RECTIFIER
3889	4.02.0152.1.01.7	LO	114960	SURGE SUPPRESSOR 120V 20A DIN RAIL MOUNT
3890	4.02.0153.1.01.8	LO	116489	RELAY 2PDT 240VAC 10A
3891	4.02.0154.1.01.9	LO	117872	SOLENOID DRIVER CAMERA TILT SOLENOID
3892	4.02.0155.1.01.1	LO	119058	RELAY 3-NO, 1-NC 24VDC POSITIVE-GUIDED CONTACTS
3893	4.02.0156.1.01.2	LO	119705	RECTIFIER ASSY GENERATOR 900KW
3894	4.02.0157.1.01.3	LO	123703	RELAY 24VDC 1 DIN RAIL SPDT TERMINAL BLOCK RELAY
3895	4.02.0158.1.01.4	LO	126642	SURGE SUPPRESSOR 480V
3896	4.02.0159.1.01.5	LO	126994	RELAY 24VDC 10 AMP DPDT
3897	4.02.0160.1.01.6	LO	128988	FILTER HARMONIC SUPPRESSION FOR 480V 3P POWER SUPPLY
3898	4.02.0161.1.01.7	LO	130558	ROTOR EXCITER W/POWEREX DIODES
3899	4.02.0162.1.01.8	LO	131544	SURGE PROTECTOR
3900	4.02.0163.1.01.9	LO	144090	SOLENIOD 24V SERVO
3901	4.02.0164.1.01.1	LO	149424	RELAY 24VDC 4PDT BLADE WITH LIGHT AND SURGE SUPP
3902	4.02.0165.1.01.2	LO	149425	RELAY 24VDC DPDT BLADE WITH LIGHT AND SURGE SUPP
3903	4.02.0166.1.01.3	LO	149563	SOLENOID ASSY 24 VDC DIN COIL CORE TUBE NUT ORINGS
3904	4.02.0167.1.01.4	LO	152644	COIL STD 24V DC
3905	4.02.0168.1.01.5	LO	159508	FORWARD DIODE
3906	4.02.0169.1.01.6	LO	159509	REVERSE DIODE
3907	4.02.0170.1.01.7	LO	A79413	RELAY
3908	4.02.0171.1.01.8	LO	A91267	RELAY TIMER DPDT 100-240V; 0.1 SEC TO 600 HOURS
3909	4.02.0172.1.01.9	LO	B75057	ACTUATOR LINEAR 120VAC
3910	4.02.0173.1.01.1	KA	DEM 102.1.05.2 SETTING 1.5KGF/CM2	PRESSURE TRANSDUCER RELAY
3911	4.02.0174.1.01.2	KA	DEM102.1.01.2 SETTING 0 KGF/CM2	PRESSURE TRANSDUCER RELAY
3912	4.02.0175.1.01.3	KA	G2R.ISNDI 24 VDC	TIME RELAY
3913	4.02.0176.1.01.4	PL	ADC80AG-12	CONVERTER
3914	4.02.0177.1.01.5	PL	ADDAC80N-CBI-V SUBSTITUTE DAC80CBI-V	CONVERTER
3915	4.02.0178.1.01.6	PL	ADS574KP	CONVERTER
3916	4.02.0179.1.01.7	PL	AQW214J	RELAY
3917	4.02.0180.1.01.8	PL	AQW614J	RELAY
3918	4.02.0181.1.01.9	PL	ASL035.9214.1	DIODE
3919	4.02.0182.1.01.1	PL	EL-T5226.00	TIME RELAY
3920	4.02.0183.1.01.2	PL	ELT-700-00036	RELAY 300A 24V
3921	4.02.0184.1.01.3	PL	EL-T7002/S3	RELAY
3922	4.02.0185.1.01.4	PL	EL-T7077.032 SUBSTITUTE ZR012026	TIME RELAY
3923	4.02.0186.1.01.5	PL	EL-T7077.032 SUBSTITUTE ZR012036	TIME RELAY
3924	4.02.0187.1.01.6	PL	EL-T7077.032 SUBSTITUTE ZR012056	TIME RELAY
3925	4.02.0188.1.01.7	PL	SKR20/08	DIODE WITHOUT HEAT SINK
3926	4.02.0189.1.01.8	PL	H3T/24V/0.1-5SEC	TIME RELAY
3927	4.02.0190.1.01.9	PL	ELT-700-00017 SUBSTITUTE ZR4MF025-L	TIME RELAY
3928	4.02.0191.1.01.1	PL	H3FA-SB/12-24VDC	Time relay
3929	4.02.0192.1.01.2	PL	25536B SUBSTITUTE 255.36B	RELAY FOR KK2000 A/C WEBASTO
3930	4.02.0193.1.01.3	PL	ELT-700-00022	RELAY 50A 24V NC&NO
3931	4.02.0194.1.01.4	PL	33200220	RELAY
3932	4.02.0195.1.01.5	PL	332002250	RELAY
3933	4.02.0196.1.01.6	PL	332209203	RELAY

3934	4.02.0197.1.01.7	PL	335215143	RELAY
3935	4.02.0198.1.01.8	PL	EL-T470S-T SUBSTITUTE EL-T470S	RELAY
3936	4.02.0199.1.01.9	PL	EL-T7002/S2	RELAY
3937	4.02.0200.1.01.1	L	REL26.01/24VAC SUBSTITUTE GM10/24LQ203024	RELAY
3938	4.02.0201.1.01.2	PL	0331802100 SUBSTITUTE 0331801300	RELAY
3939	4.02.0202.1.01.3	PL	EL-T7002/L2	RELAY
3940	4.02.0203.1.01.4	PL	288-414 SUBSTITUTE EL-T7284.00	RELAY
3941	4.02.0204.1.01.5	PL	EL-T470S-T SUBSTITUTE EL-T470S(GKLV- A/K/B)	RELAY
3942	4.02.0205.1.01.6	PL	27128 SUBSTITUTE 27C128	E-PROM-"HI" PROGRAMMED
3943	4.02.0206.1.01.7	PL	EL-T 663	Relay
3944	4.02.0207.1.01.8	PL	EL-T 277	Relay
3945	4.02.0208.1.01.9	KA	PH-116 (For GP6.5)	Relay Controller
3946	4.02.0209.1.01.1	KA	TU16-523-583-80	Relay PHE-31G 24B Tropicalized Construction
3947	4.02.0210.1.01.2	KA	MY41N-D2,24VDC	Relay OMRAN MY41N-D2, 24VDC With Block
3948	4.02.0211.1.01.3	KA	G2R1-SNBI 24VDC	Electromagnetic Relay FA OMRAN With Block
3949	4.02.0212.1.01.4	KA	LG12DC4.521.901<0425.001TU	K2 Relay
3950	4.02.0213.1.01.5		Repeated item	
3951	4.02.0214.1.01.6	KA	PYF14A-E (OMRAN)	Relay
3952	4.02.0215.1.01.7	KA	GTL-1A-T 24VDC With Block PTLF-06	Relay
3953	4.02.0216.1.01.8	KA	LOGO 1.12/24 RCD.6EDI.052.2MDOO-OBA6	Relay
3954	4.02.0217.1.01.9	KA	BK17-31-P-35-400-ind-38	Pressure Transducer Relay
3955	4.02.0218.1.01.1		Repeated item	
3956	4.02.0219.1.01.2	KA	BJ1-64B 2VV1-IOC	K2 Relay II 112 PC4.521
3957	4.02.0220.1.01.3	KA	RCO.6EDI.052.2MDOO-OBA6	Time Relay KT3
3958	4.02.0221.1.01.4	KA	BL-64, 24V, 3-3C. TU16-674.039- 86	Time Relay
3959	4.02.0222.1.01.5	KA	DP12 RS/PC 4521.901.Bgo.425.001TU	Relay K2
3960	4.02.0223.1.01.6	KA	VL-64, 24V, 1-10C, EXPORT TU16.674.039.86	Timer Relay
3961	4.02.0224.1.01.7	KA	VI-64, UHL4.1, 27V, 3-3C TU-16- 674.039.86	Time Relay
3962	4.02.0225.1.01.8	KA	P2RF-14/25-E	MV41 N-02, 24 VOC With Block
3963	4.02.0226.1.01.9	KA	PLTF-06	G2R-1 SNDI-24VOC With Block
3964	4.02.0227.1.01.1	KA	901.01.0425.001.TU	GTL-IA-T 24 VOC With Block
3965	4.02.0228.1.01.2	KA	LOGO/12/24RCD 6ED1052- 2MDOO-OBA6	Logic Module Siemens
3966	4.02.0229.1.01.3	KA	PC4.520.201.01 TTO.425.080 TU PC4.520.208-01 PC4.520.216-01	Relay PTC-32G Constr.
3967	4.02.0230.1.01.4	KA	PGC-32<PC4.520.201- 01ZKO.452.080 TU PC4. 520.208- 01 PC4.520.216-01	K9 Relay
3968	4.02.0231.1.01.5	KA	DEM102-1-02, Setting on 0Kg/Cm square TU25- 73.01.0066-90	Pressure Transducer Relay
3969	4.02.0232.1.01.6	KA	PC4.520.201.01.TT0.452.080 TU PC4.520.208-01 PC4.520.216-01	Relay PTTC-32G Constr
3970	4.02.0233.1.01.7	GE	3062	Relay-1
3971	4.02.0234.1.01.8	GE	A0230002	Relay-2
3972	4.02.0235.1.01.9	GE	A0230001	Relay-3
3973	4.02.0236.1.01.1	CR	PLC-RSC-24DC/21HC	RELAY-1
3974	4.02.0237.1.01.2	CR	PLC-RSC-24DC/21	RELAY-2
3975	4.02.0238.1.01.3	CR	PLC-RSC-24DC/21-21	RELAY-3
3976	4.02.0239.1.01.4	CR	XPSAF5130	SAFETY RELAY-1
3977	4.02.0240.1.01.5	CR	SE-100C/SCHMERSAL	SAFETY RELAY-2
3978	4.02.0241.1.01.6	CR	TL-16A/1P-24VDC	PULSE RELAY
3979	4.02.0242.1.01.7	CR	40098525	POWER RELAY 120A
3980	4.02.0243.1.01.8	CR	40098529	POWER RELAY 60A
3981	4.02.0244.1.01.9	CR	40096416	SAFETY RELAY
3982	4.02.0245.1.01.1	PL	PNOZX2	Emergency -off relay
3983	4.02.0246.1.01.2	PL	ZR5MF011I	Multi function Timer relay
3984	4.02.0247.1.01.3	PL	LQ617048	impulse relay
3985	4.02.0248.1.01.4	PL	RIF-1-BPT/2X21	RELAY BASE
3986	4.02.0249.1.01.5	PL	PR1-BSC2/2X21	Relay base
3987	4.02.0250.1.01.6	PL	332002258	RELAY
3988	4.02.0251.1.01.7	PL	RIF-LDP-12-24DC	relay catridge
3989	4.02.0252.1.01.8	PL	0333002250	RELAY
3990	4.02.0253.1.01.9	PL	PP.BOP.0522	POWER RELAY 60A
3991	4.02.0254.1.01.1	PL	ELB-S00-01	DECOUPLING CAPACITOR
3992	4.02.0255.1.01.2	LO	173686	DB 0.10A 1P 277V EXCITATION
3993	4.02.0256.1.01.3	LO	125692	RECTIFIER ASSEMBLY

3994	4.02.0257.1.01.4	LO	215332	DIODE STANDARD POLARITY
3995	4.02.0258.1.01.5	LO	215333	DIODE REVERSE POLARITY
3996	4.02.0259.1.01.6	LO	107081	RELAY BASE
3997	4.02.0260.1.01.7	LO	205279	COIL 24VDC DIN;DO3 FITS REV C VALVE
3998	4.02.0261.1.01.8	LO	134829	RELAY BASE 8 PIN OCTAL
3999	4.02.0262.1.01.9	LO	A35629	RELAY STARTER (REPLACES A71826)
4000	4.02.0263.1.01.1	LO	A70104	RELAY BASE
4001	4.02.0264.1.01.2	LO	A84468	SOCKET RELAY 2 POLE
4002	4.02.0265.1.01.3	LO	246786	RELAY CLIP ASSEMBLY
4003	4.02.0266.1.01.4	LO	208622	COIL 24VDC DIN D05;FITS REV B VALVES
4004	4.02.0267.1.01.5	PL	ELW-LS0-01	DC/DC CONVERTER
4005	4.02.0268.1.01.6	PL	EL-T7154. 00	DC/ DC CONVERTER
4006	4.03.0001.1.01.1	PL	40001.01	CONTACT ELEMENT
4007	4.03.0002.1.01.2	PL	333009002	TEMPERATURE SWITCH
4008	4.03.0003.1.01.3	PL	341003004	BATTERY MAIN SWITCH
4009	4.03.0004.1.01.4	PL	342309006	IGNITION SWITCH
4010	4.03.0005.1.01.5	PL	344400008	OIL PRESSURE SWITCH
4011	4.03.0006.1.01.6	PL	352222006	SOCKET
4012	4.03.0007.1.01.7	PL	604145007	INDUCTIVE TRANSMETER
4013	4.03.0008.1.01.8	ZF	60412320196	MODULATOR
4014	4.03.0009.1.01.9	PL	0242-12	TEMPERATURE SWITCH
4015	4.03.0010.1.01.1	PL	1174555 SUB. 1182840	TEMPERATURE SWITCH
4016	4.03.0011.1.01.2	PL	1175981 / 1182841	TRANSDUCER / PRESSURE SWITCH
4017	4.03.0012.1.01.3	PL	1182708 SUB. 1178104	TEMPERATURE SWITCH
4018	4.03.0013.1.01.4	PL	230.112/005/011 SUB. 230.112/003/006	OIL PRESSURE SWITCH
4019	4.03.0014.1.01.5	PL	232.011/017/017	TEMPERATURE SWITCH
4020	4.03.0015.1.01.6	PL	232.011/017/032	TEMPERATURE SWITCH
4021	4.03.0016.1.01.7	PL	25436NHLD	SWITCH
4022	4.03.0017.1.01.8	PL	31-902-9	COVER (HOOD)
4023	4.03.0018.1.01.9	PL	323.803/001/006	TEMPERATURE SWITCH
4024	4.03.0019.1.01.1	PL	323.803/002/002	TEMPERATURE SWITCH
4025	4.03.0020.1.01.2		Shifted to Annx-II	
4026	4.03.0021.1.01.3	PL	452-K34FN2/100A	CIRCUIT BREAKER
4027	4.03.0022.1.01.4	PL	4609X-101/1KOHM SUB. 90-916870	RESISTOR CIRCUIT
4028	4.03.0023.1.01.5	PL	4880L / 2-166010-1	CONECTOR / PCB STRIP 48 PIN MALE / FEMALE
4029	4.03.0024.1.01.6	PL	5140-06-07-00	CONNECTION
4030	4.03.0025.1.01.7	PL	6041232018 / 0899202498	MODULE
4031	4.03.0026.1.01.8		Shifted to Annx-II	
4032	4.03.0027.1.01.9	PL	64-07-3000-1006	SWITCH BOX
4033	4.03.0028.1.01.1	PL	64-07-3000-1007	SWITCH BOX
4034	4.03.0029.1.01.2	PL	7101S/Z	TUMBLER SWITCH
4035	4.03.0030.1.01.3	PL	7103S/Z	SWITCH
4036	4.03.0031.1.01.4	PL	BX1/1X24V	EBE STEP SWITCH
4037	4.03.0032.1.01.5	PL	CHO-180	SWITCH COMPLETE
4038	4.03.0033.1.01.6	PL	EL-T 1050 DL2 / ROT	TOMMY HEAD
4039	4.03.0034.1.01.7	PL	EL-T 1050.DL3/GREEN	SWITCH
4040	4.03.0035.1.01.8	PL	EL-T 1301 4018	COLLETTE
4041	4.03.0036.1.01.9	PL	EL-T 1301-5601	SWITCH
4042	4.03.0037.1.01.1	PL	EL-T 1301-5602	PUSH BUTTON
4043	4.03.0038.1.01.2	PL	EL-T 1301-5604	KEY BUTTON
4044	4.03.0039.1.01.3	PL	EL-T 1301-5605	OPEL SQUARE SWITCH
4045	4.03.0040.1.01.4	PL	EL-T 455 C	CLUTCH FLANGE
4046	4.03.0041.1.01.5	PL	EL-T 455 F	RING
4047	4.03.0042.1.01.6	PL	EL-T 455 F KKLR	CAP
4048	4.03.0043.1.01.7	PL	EL-T 455 J	ENGINE BODY
4049	4.03.0044.1.01.8	PL	EL-T 455 T	FLANGE
4050	4.03.0045.1.01.9	PL	EL-T1301.1205	PUSH BUTTON
4051	4.03.0046.1.01.1	PL	EL-T1301.4013	BUTTON
4052	4.03.0047.1.01.2	PL	EL-T1301.4413	BUTTON
4053	4.03.0048.1.01.3	PL	EL-T2111.G6	SWITCH BOX
4054	4.03.0049.1.01.4	PL	EL-T5538.00	SWITCHING OF MEASUREMENT INPUTS
4055	4.03.0050.1.01.5	PL	EL-T5539.00	SWITCHING OF MEASUREMENT INPUTS
4056	4.03.0051.1.01.6	PL	EL-T-6446-00	L P MODULE
4057	4.03.0052.1.01.7	PL	EL-T7012	SWITCH
4058	4.03.0053.1.01.8	PL	EL-T7027	KNOB
4059	4.03.0054.1.01.9	PL	EL-T-7052	STEP SWITCH
4060	4.03.0055.1.01.1	PL	EL-T-7126/10 AMP	CIRCUIT BREAKER
4061	4.03.0056.1.01.2	PL	EL-T-7126/15 AMP	CIRCUIT BREAKER
4062	4.03.0057.1.01.3	PL	EL-T-7126/20 AMP.	CIRCUIT BREAKER
4063	4.03.0058.1.01.4	PL	EL-T-7126/35 AMP	CIRCUIT BREAKER
4064	4.03.0059.1.01.5	PL	EL-T-7126/5 AMP	CIRCUIT BREAKER

4065	4.03.0060.1.01.6	PL	EL-T-7126-40A	CIRCUIT BREAKER / LOADESTER SWITCH
4066	4.03.0061.1.01.7	PL	EL-T-7140/4	STEP SWITCH
4067	4.03.0062.1.01.8	PL	EL-T7140/5	SWITCH
4068	4.03.0063.1.01.9	PL	EL-T7190-14	SELECTING SWITCH
4069	4.03.0064.1.01.1	PL	EL-T7190-22	SWIVEL PUSH BUTTON
4070	4.03.0065.1.01.2	PL	EL-T7190-24	CROSS-SWIVEL PUSH BUTTON
4071	4.03.0066.1.01.3	PL	EL-T7190-A5	SWITCH
4072	4.03.0067.1.01.4	PL	EL-T7190-C4	MUSHROOMM BUTTON
4073	4.03.0068.1.01.5	PL	EL-T7190-C44	MUSHROOM BUTTON RED/30MM
4074	4.03.0069.1.01.6	PL	EL-T7190-C64	MUSHROOM BUTTON BLUE/30MM
4075	4.03.0070.1.01.7	PL	EL-T7190-D2	SWITCH HEAD
4076	4.03.0071.1.01.8	PL	EL-T7190-D3	SWITCH HEAD
4077	4.03.0072.1.01.9	PL	EL-T7190-D5	SWITCH HEAD
4078	4.03.0073.1.01.1	PL	EL-T7190-F	FLANGE FOR CONTACT ELEMENT
4079	4.03.0074.1.01.2	PL	EL-T7190-O	CONTACT ELEMENT
4080	4.03.0075.1.01.3	PL	EL-T7190-S	CONTACT ELEMENT
4081	4.03.0076.1.01.4	PL	EL-T7225.00 SUB. EL-T7157	CONVERTER
4082	4.03.0077.1.01.5	PL	G X 1/1 X 12V	SWITCH
4083	4.03.0078.1.01.6	PL	GA 10 BAR 2410203024	SWITCH
4084	4.03.0079.1.01.7	PL	IR6220	POWER SWITCH
4085	4.03.0080.1.01.8	PL	MR2-5	SWITCH
4086	4.03.0081.1.01.9	PL	MV-3	MICRO SWITCH
4087	4.03.0082.1.01.1	KE	182891	TOGGLE SWITCH
4088	4.03.0083.1.01.2	KE	182981	SWITCH TOGGLE-SPST
4089	4.03.0084.1.01.3	KE	182985	SWITCH TOGGLE-DPOT
4090	4.03.0085.1.01.4	KE	560507	PRESSURE SWITCH
4091	4.03.0086.1.01.5	PH	UTVI-07 25/00	BY PASS SWITCH
4092	4.03.0087.1.01.6	PH	UTVI-07 26/00	IGNITION S/W
4093	4.03.0088.1.01.7		Item shifted to Ann -II	
4094	4.03.0089.1.01.8	LO	102245	SWITCH SELECTOR KNOB 4W
4095	4.03.0090.1.01.9	LO	106223	SWITCH PB BLACK; SQUARE FLUSH MOUNT
4096	4.03.0091.1.01.1	LO	106354	SWITCH PB GREEN; SQUARE FLUSH MOUNT
4097	4.03.0092.1.01.2	LO	106357	SWITCH PB MUSHHEAD RED SQUARE PUSH/PULL MAINT
4098	4.03.0093.1.01.3	LO	106362	SWITCH PB ILLUM RED; SQUARE FLUSH MOUNT
4099	4.03.0094.1.01.4	LO	106365	SWITCH PB ILLUM GREEN; SQUARE EXTENDED MOUNT
4100	4.03.0095.1.01.5	LO	106368	SWITCH PB ILLUM ORANGE; SQUARE EXTENDED MOUNT
4101	4.03.0096.1.01.6	LO	106384	SWITCH SEL 3 POS MAINT; SQUARE BLACK
4102	4.03.0097.1.01.7	LO	107889	SWITCH TOGGLE DPDT 2POS
4103	4.03.0098.1.01.8	LO	108601	CONTACTOR REVERSE 15.0 HP 120VAC COIL 1NO/1NC SIDE
4104	4.03.0099.1.01.9	LO	112882	SWITCH SELECTOR 3 POS SPRG RTN BOTH SIDES
4105	4.03.0100.1.01.1	LO	112886	PUSH BUTTON FLUSH HEAD BLACK
4106	4.03.0101.1.01.2	LO	115390	VALVE DRCT 125PSI 5GPM H2O 12FNPT NO SOL 24V DC
4107	4.03.0102.1.01.3	LO	116863	SWITCH 22 TO 125-PSI -04 SAE BOSS
4108	4.03.0103.1.01.4	LO	119117	SWITCH PB MUSHHEAD RED; PUSH MAINT/TURN RELEASE
4109	4.03.0104.1.01.5	LO	126637	SWITCH PB 2POS 30.5MM E-STOP
4110	4.03.0105.1.01.6	LO	129420	CONT DS 480V 1NO AUX
4111	4.03.0106.1.01.7	LO	131682	SWITCH PSI 360 TO 1700 04MORB
4112	4.03.0107.1.01.8	LO	132107	SWITCH DS 600V 3P 16A; NON-FUSIBLE
4113	4.03.0108.1.01.9	LO	133029	SWITCH PRESSURE 5 PSI 1/4 MNPT/FORM C/INCREASE
4114	4.03.0109.1.01.1	LO	134816	CONT MS 23A 480V 3P; 120VAC COIL 1NO AUX
4115	4.03.0110.1.01.2	LO	134820	CONT PRESSURE DIGITAL
4116	4.03.0111.1.01.3	LO	135446	METER MULTI-FUNCTION POWER MONITOR
4117	4.03.0112.1.01.4	LO	136265	SWITCH PRESS DIRT ALARM FOR SCHROEDER RET FLTR
4118	4.03.0113.1.01.5	LO	146192	COMP SWITCH 8 PORT
4119	4.03.0114.1.01.6	LO	150561	SWITCH DIRT ALARM DIN 43650 CONN
4120	4.03.0115.1.01.7	LO	156468	HEAD ROTARY ACTUATED; LIMIT SWITCH
4121	4.03.0116.1.01.8	LO	159718	OBS-USE 134820; WAS PURGE CONTROL BOARD
4122	4.03.0117.1.01.9	LO	166964	SWITCH SEQUENTIAL CAMERA

4123	4.03.0118.1.01.1	LO	A34785	CONTACTOR - POWER; 1200 AMP.
4124	4.03.0119.1.01.2	LO	A36970	CONTACTOR FIELD
4125	4.03.0120.1.01.3	LO	A83596	CONTACTS-AUX 2NO 2NC
4126	4.03.0121.1.01.4	LO	B83382	CONTACT BLOCK 1-NO 1-NC
4127	4.03.0122.1.01.5	LO	B83383	KNOB-YELLOW MUSHROOM; ENGRAVED-PUSH HOT RAIL
4128	4.03.0123.1.01.6	LO	B85228	CONTACTOR DC 12VDC COIL
4129	4.03.0124.1.01.7	PL	2050205 SUBSTITUTE OBW-KHS-M02	WEATHER HOOD
4130	4.03.0125.1.01.8		Repeated item	
4131	4.03.0126.1.01.9	PL	437-K60-1-06-125A	BATTERY SAFETY SWITCH
4132	4.03.0127.1.01.1	PL	437-K60-1-06-160A	BATTERY SAFETY SWITCH
4133	4.03.0128.1.01.2	PL	7201S/Z	TUMBLER SWITCH
4134	4.03.0129.1.01.3	PL	7205S/Z	KEY BUTTON
4135	4.03.0130.1.01.4	PL	90450R2/20	PRESSURE SWITCH
4136	4.03.0131.1.01.5	PL	90451M2/20	PRESSURE SWITCH
4137	4.03.0132.1.01.6	PL	90451R0/2	PRESSURE SWITCH
4138	4.03.0133.1.01.7	PL	EL-T7190-S844	EMERGENCY BUTTON RED
4139	4.03.0134.1.01.8	PL	EL-T6684.00	SWITCH CABINET, POPULATED
4140	4.03.0135.1.01.9	PL	EL-T7052	STEP SWITCH
4141	4.03.0136.1.01.1	PL	EL-T7190-G0	KEY SWITCH
4142	4.03.0137.1.01.2	PL	EL-T1050-D2	SWITCH
4143	4.03.0138.1.01.3	PL	EL-T1050-D3	SWITCH
4144	4.03.0139.1.01.4	PL	EL-T1050-DL3/GRUEN	SWITCH
4145	4.03.0140.1.01.5	PL	EL-T1050-DL3/ROT	SWITCH
4146	4.03.0141.1.01.6	PL	EL-T1050-DL3/WEISS,FL,RSSLS	SWITCH
4147	4.03.0142.1.01.7	PL	EL-T1058-14	SWITCH
4148	4.03.0143.1.01.8	PL	EL-T1058-22	SWITCH
4149	4.03.0144.1.01.9	PL	EL-T1058-24	SWITCH
4150	4.03.0145.1.01.1	PL	EL-T7250-CF1B2 SUBSTITUTE EL-T1301.5605	PUSH BUTTON
4151	4.03.0146.1.01.2	PL	EL-T7250-CW4B2 SUBSTITUTE EL-T1301.5602	PUSH BUTTON
4152	4.03.0147.1.01.3	PL	EL-T7190-G2 SUBSTITUTE EL-T 1050-G2	KEY SWITCH
4153	4.03.0148.1.01.4	PL	EL-T7250-CW8B2	ILLUMINATED PUSH-BUTTON
4154	4.03.0149.1.01.5	KA	1023.14.23.300	Joy Stick For Cross Level
4155	4.03.0150.1.01.6	KA	8P15K-218231-54U 2.8.3 Inputs	Limit Switch
4156	4.03.0151.1.01.7	CR	NI12U-EG18SK-AP6X	INDUCTIVE SWITCH
4157	4.03.0152.1.01.8	CR	BS500W(IND)-13-20-14	INDUCTIVE SWITCH PED
4158	4.03.0153.1.01.9	CR	3SE3-120/1JA(Short arm)	TRAVEL SWITCH
4159	4.03.0154.1.01.1	PL	EL-T700-00019-350A	RELAY 24V, 350A
4160	4.03.0155.1.01.2	PL	EL-T700-00018	RELAY 24V, 500A
4161	4.03.0156.1.01.3	PL	46.61.9.024.4000T	RELAY 24V, 16A
4162	4.03.0157.1.01.4	PL	4213436 and Sub :4194093	RELAY
4163	4.03.0158.1.01.5	PL	4219245 and Sub : 4213663	RELAY
4164	4.03.0159.1.01.6	PL	EL-T700-00050-5A	RELAY
4165	4.03.0160.1.01.7	PL	EL-T700-00050-7.5A/E.T.A	RELAY
4166	4.03.0161.1.01.8	PL	EL-T700-00050-10A	RELAY
4167	4.03.0162.1.01.9	PL	EL-T7274 SUBSTITUTE EMG10-REL/KSR-G24/21-LC	RELAY
4168	4.03.0163.1.01.1	PL	LQ612048/LQ252024/LQ229 024/D-MAT-400	IMPULSE RELAY
4169	4.03.0164.1.01.2	PL	REL-MR-24DC/21-21AU	RELAY 24V,8A
4170	4.03.0165.1.01.3	PL	REL-MR-24DC/21HCAU	RELAY 24V,16A
4171	4.03.0166.1.01.4	PL	ELT-700-00050-10A	POWER RELAY
4172	4.03.0167.1.01.5	PL	ELT-700-00050-5A	POWER RELAY
4173	4.03.0168.1.01.6	PL	232.011/017/033 and 232.011/017/011	TEMPERATURE SWITCH
4174	4.03.0169.1.01.7	PL	TWR3/4MO/40 GRAD C/AUS	TEMPERATURE SWITCH
4175	4.03.0170.1.01.8	GE	P56N-200KN14HR	Pressure switch
4176	4.03.0171.1.01.9	GE	YK-3	Liquid level switch
4177	4.03.0172.1.01.1	GE	XS218BLPAM12	Proximity switch-1
4178	4.03.0173.1.01.2	GE	XS630B4PAM12	Proximity switch-2
4179	4.03.0174.1.01.3	GE	GQ22-11/ self-reset	Red wave switch-1
4180	4.03.0175.1.01.4	GE	GQ22-11/self-locking	Red wave switch-2
4181	4.03.0176.1.01.5	CR	061B000066	PRESSURE SWITCH-1
4182	4.03.0177.1.01.6	CR	XB4-BS8445	40 ROTARY RESET RED BUTTON
4183	4.03.0178.1.01.7	CR	BAE311 301/BA303	EMERGENCY STOP BUTTON
4184	4.03.0179.1.01.8	CR	N-30-S-SA	SWITCH
4185	4.03.0180.1.01.9	CR	061B000966	PRESSURE SWITCH-2
4186	4.03.0181.1.01.1	CR	061B001066	PRESSURE SWITCH-3
4187	4.03.0182.1.01.2	CR	40077914	3 POSITION SWITCH
4188	4.03.0183.1.01.3	CR	40013840	PROXIMITY SWITCH
4189	4.03.0184.1.01.4	CR	40029740	LIMIT SWITCH
4190	4.03.0185.1.01.5	CR	80082411	PROXIMITY SWITCH
4191	4.03.0186.1.01.6	CR	40085400	PROXIMITY SWITCH

4192	4.03.0187.1.01.7	CR	40098624	PULL TYPE START BUTTON
4193	4.03.0188.1.01.8	CR	40082411	PROXIMITY SWITCH
4194	4.03.0189.1.01.9	CR	40091845	LIMIT SWITCH
4195	4.03.0190.1.01.1	CR	40082351	TWO WAY SWITCH
4196	4.03.0191.1.01.2	CR	40065040	TWO WAY SWITCH
4197	4.03.0192.1.01.3	CR	40069410	AIR BRAKING SYSTEM/PRESSURE SWITCH
4198	4.03.0193.1.01.4	PL	II50197/1	Indirect brake valve limit switch
4199	4.03.0194.1.01.5	PL	NI30U-M30-AP6X-H1141	Inductive switch
4200	4.03.0195.1.01.6	PL	S-8.70.1	Inductive switch
4201	4.03.0196.1.01.7	PL	PVD6/7/23/23-SH	5 POSITION TUMBLER SWITCH
4202	4.03.0197.1.01.8	PL	100-K09KF10	Contactor
4203	4.03.0198.1.01.9	PL	100-K09ZJ400	Contactor
4204	4.03.0199.1.01.1	PL	TWR3/4MO/90 GRAD C/AUS	TEMPERATURE SWITCH
4205	4.03.0200.1.01.2	PL	1695326	SWITCH
4206	4.03.0201.1.01.3	PL	EBC602.9E.904M	SWITCH
4207	4.03.0202.1.01.4	PL	PP7554/4,2-3,8	PRESSURE SWITCH
4208	4.03.0203.1.01.5	PL	EL-T1050-GO	SWITCH
4209	4.03.0204.1.01.6	PL	EL-T7123 and EL-T7123/85 GRAD	PROXIMITY SWITCH
4210	4.03.0205.1.01.7	PL	EL-T7144.00	PROXIMITY SWITCH
4211	4.03.0206.1.01.8	PL	EL-T7250-CF6B2	ILLUMINATED PUSH BUTTON BLUE
4212	4.03.0207.1.01.9	LO	113882	LOCKING LEVER KIT ENGINE BATTERY SWITCH(KD SWITCHES)
4213	4.03.0208.1.01.1	LO	162552	SWITCH DISCONNECT 600V 3P 200A NON FUSIBLE
4214	4.03.0209.1.01.2	LO	173671	Cont MS 65A 120V 3ph
4215	4.03.0210.1.01.3	LO	173672	Cont 65A 120V 3P
4216	4.03.0211.1.01.4	LO	173673	Cont 50A 120V 3P
4217	4.03.0212.1.01.5	LO	153456	Cont OL 25-100A 1 NC 1 NO for S3 Contactor
4218	4.03.0213.1.01.6	LO	229549	Cont OL 1-4A 1 NC 1 NO for S00 Contactor
4219	4.03.0214.1.01.7	LO	229550	Cont MS 9A 480V 3P 120V Ac 50/60Hz Coil 1 No
4220	4.03.0215.1.01.8	LO	229551	Cont MS 80A 480V 3P 120V Ac 50/60Hz Coil 1 No
4221	4.03.0216.1.01.9	LO	103925	CB 25A 3P 480V
4222	4.03.0217.1.01.1	LO	118142	PS 12VDC 21A
4223	4.03.0218.1.01.2	LO	126450	CONT MS 480V 4 NO AUX FROUNT MOUNT
4224	4.03.0219.1.01.3	LO	126452	CONT CB 480V 1NO AUX
4225	4.03.0220.1.01.4	LO	127780	SWITCH DS 3P 600V 100A 1NO ENCLOSED NON FUSIBLE
4226	4.03.0221.1.01.5	LO	513882	Engine battery switch
4227	4.03.0222.1.01.6	LO	129422	SWITCH DS 600V 3P 100A NON-FUSIBLE
4228	4.03.0223.1.01.7	LO	245294	SWITCH SEQUENTIAL CAMERA; 4 IN 1 OUT BNC
4229	4.03.0224.1.01.8	LO	252351	ELECTRICAL SWITCHES KIT #4
4230	4.03.0225.1.01.9	LO	101439	CONTACTOR DC 24VDC NCNO
4231	4.03.0226.1.01.1	LO	252351-4	ELECTRICAL SWITCHES KIT #3
4232	4.03.0227.1.01.2	LO	245875	SWITCH PB 2POS MOM BLK; ROUND FLUSH MOUNT
4233	4.03.0228.1.01.3	LO	245932	CONTACT BLK 1NO-1NC; SCREW TERMINAL
4234	4.03.0229.1.01.4	LO	247927	CONTACT BLK 1 NO; SCREW TERMINAL
4235	4.03.0230.1.01.5	LO	247928	CONTACT BLK 1NC; SCREW TERMINAL
4236	4.03.0231.1.01.6	LO	252351-6	ELECTRICAL SWITCHES KIT #5
4237	4.03.0232.1.01.7	LO	245879	SWITCH PB 2POS MOM RED; ROUND FLUSH MOUNT ILLUM
4238	4.03.0233.1.01.8	LO	246517	SWITCH PB 2POS MOM ORG; 22MM ILLUM ROUND EXTENDED
4239	4.03.0234.1.01.9	LO	252351-7	ELECTRICAL SWITCHES KIT #6
4240	4.03.0235.1.01.1	LO	245899	SWITCH SS 3POS MTN BLK; 22MM ROUND KNOB
4241	4.03.0236.1.01.2	LO	252351-8	ELECTRICAL SWITCHES KIT #7
4242	4.03.0237.1.01.3	LO	245888	SWITCH SS 2POS MTN GRN; 22MM ILLUM ROUND KNOB
4243	4.03.0238.1.01.4	LO	252351-9	ELECTRICAL SWITCHES KIT #8
4244	4.03.0239.1.01.5	LO	109475	SWITCH TOGGLE 3 POS MOMEN BLACK NYLON
4245	4.03.0240.1.01.6	LO	247953	SWITCH SS 4POS MTN BLK; 22MM ROUND KNOB
4246	4.03.0241.1.01.7	LO	252351-15	LIGHT KIT #4
4247	4.03.0242.1.01.8	LO	242830	SWITCH PB MUSHHEAD RED; PUSH MAINT/TURN RELEASE
4248	4.03.0243.1.01.9	LO	252351-40	ELECTRICAL SWITCHES KIT #9

4249	4.03.0244.1.01.1	LO	252351-41	ELECTRICAL SWITCHES KIT #6
4250	4.03.0245.1.01.2	LO	126588	SWITCH TS 3POS MOM
4251	4.03.0246.1.01.3	LO	252351-47	ELECTRICAL SWITCHES KIT #10
4252	4.03.0247.1.01.4	LO	252351-62	ELECTRICAL SWITCHES #11
4253	4.03.0248.1.01.5	LO	A25902	COVER-SWITCH
4254	4.03.0249.1.01.6	LO	A38587	SWITCH 3-WAY 15A 120/277VAC
4255	4.03.0250.1.01.7	LO	252351-88	ELECTRICAL SWITCHES KIT #12
4256	4.03.0251.1.01.8	LO	252351-107	ELECTRICAL SWITCHES KIT #13
4257	4.03.0252.1.01.9	LO	175801	SWITCH LS 1NO 1NC TOP PLUNGER CONNECTOR
4258	4.03.0253.1.01.1	LO	148473	SWITCH PRESSURE ANTI-RESTART
4259	4.03.0254.1.01.2	PL	PVD6/ 7/ 16/23-	5-POSTION TUMBLER SWITCH
4260	4.03.0255.1.01.3	PL	ELT-700-00035-S	BATTERY MAIN SWITCH
4261	4.03.0256.1.01.4	PL	HLU110-5KT	SELECTING SWITCH
4262	4.04.0001.1.01.2	PL	1801.1831	LED BLACK
4263	4.04.0002.1.01.3	PL	1178104	TEMPERATURE SWITCH
4264	4.04.0003.1.01.4	PL	3900062901	VACUUM SWITCH
4265	4.04.0004.1.01.5	PL	035-4210/ROT	LED RED
4266	4.04.0005.1.01.6	PL	035-4212/GRUEN	LED GREEN
4267	4.04.0006.1.01.7	PL	0868609/24VDC-8STELLING SUB. 0868165/24VDC-8ST	TAMPING ACTION COUNTER
4268	4.04.0007.1.01.8	PL	1032-04-01-0421	GEAR BOX
4269	4.04.0008.1.01.9	PL	1032-04-01-1309	GEAR BOX FOR CSM
4270	4.04.0009.1.01.1	PL	1181559 Sub.1180423/1182489	OIL PRESSURE SWITCH
4271	4.04.0010.1.01.2	PL	1413/ERSAT	INDICATOR
4272	4.04.0011.1.01.3	PL	323.801/028/001	TEMPERATURE SENSOR
4273	4.04.0012.1.01.4	PL	62.05.2000.43/A	PRESSURE SWITCH
4274	4.04.0013.1.01.5	PL	64.02.2182	DRIVE SHAFT
4275	4.04.0014.1.01.6		Shifted to Annx-II	
4276	4.04.0015.1.01.7	PL	64.07.1000.55	PRESSURE SWITCH
4277	4.04.0016.1.01.8		Shifted to Annx-II	
4278	4.04.0017.1.01.9	PL	811.65A SUB. 317.38A	TEMP.CONTROL
4279	4.04.0018.1.01.1	PL	EL-T7005.00E/B SUBSTITUTE EL-T7005.00E/A	VOLTMETER
4280	4.04.0019.1.01.2	PL	EL-T521/10B-SPULE	MAGNET
4281	4.04.0020.1.01.3	PL	90450-R0/2	PRESSURE SWITCH
4282	4.04.0021.1.01.4	PL	90451-R2/20	PRESSURE SWITCH
4283	4.04.0022.1.01.5	PL	9700511140 SUB. 1261885	WORKING CYLINDER
4284	4.04.0023.1.01.6	PL	A5500044	TEMPERATURE SENSOR
4285	4.04.0024.1.01.7	PL	AS10DIN71802/M6	ANGLE JOINT
4286	4.04.0025.1.01.8	PL	AS13DIN71802/M8	ANGLE JOINT
4287	4.04.0026.1.01.9	PL	AS16DIN71802/M10	ANGLE JOINT
4288	4.04.0027.1.01.1	PL	AS19DIN71802/M14X1,5	ANGLE JOINT
4289	4.04.0028.1.01.2	PL	DL-230-118/ELT-1004-800LG	FLEXIBLE SHAFT(IMPORTED) / RPM CABLE
4290	4.04.0029.1.01.3	PL	DZ 95/G 9300/HUB70	PULL CABLE
4291	4.04.0030.1.01.4	PL	DZ.60/G.1500/HUB 100	PULL CABLE
4292	4.04.0031.1.01.5	PL	DZ160/G=1500/HUB200	PULL CABLE
4293	4.04.0032.1.01.6	PL	EK-501CA-00B	U-ADAPTER FOR CMS SYSTEM
4294	4.04.0033.1.01.7	PL	EK-503CA-00B	N-ADAPTER FOR CMS SYSTEM
4295	4.04.0034.1.01.8	PL	EL-T 1064	INDICATOR
4296	4.04.0035.1.01.9	PL	ELT 1264.00W/B	REVOLUTION COUNTER
4297	4.04.0036.1.01.1	PL	EL-T 1473-10V	INDICATOR DIGITAL
4298	4.04.0037.1.01.2	PL	EL-T 1473-2V	INDICATOR
4299	4.04.0038.1.01.3	PL	EL-T 155-03-650LG	DRIVE SHAFT
4300	4.04.0039.1.01.4	PL	EL-T7004.00E/B SUBSTITUTE EL-T7004.00E/A	VOLTMETER
4301	4.04.0040.1.01.5	PL	EL-T 155-03-850LG	DRIVE SHAFT
4302	4.04.0041.1.01.6	PL	EL-T 336-00-E	MOVING COIL INSTRUMENT
4303	4.04.0042.1.01.7	PL	EL-T 439-00-E	VOLT METER
4304	4.04.0043.1.01.8	PL	EL-T 7004.00E/B SUB EL-T 7004.00E/A	VOLTMETER
4305	4.04.0044.1.01.9	PL	EL-T 7013-00	AMPERMETER
4306	4.04.0045.1.01.1	PL	EL-T 7036-00E	AMPERE METER
4307	4.04.0046.1.01.2	PL	EL-T 7055/700AF	ENCODER
4308	4.04.0047.1.01.3	PL	EL-T 7055/7F	ENCODER
4309	4.04.0048.1.01.4	PL	EL-T 7138-00A	PRESSURE GAUGE
4310	4.04.0049.1.01.5	PL	EL-T 790	INDICATOR (MEASURING DEVICE)
4311	4.04.0050.1.01.6	PL	EL-T 970-00A	INDICATOR
4312	4.04.0051.1.01.7	PL	EL-T-1001-00B Sub: EL-T 1001-001	PRESSURE GAUGE
4313	4.04.0052.1.01.8	PL	EL-T1022-01-00-142	ANGLE GEAR FOR CSM
4314	4.04.0053.1.01.9	PL	EL-T1199.00-BR/L-LINKS	DRIVE CONTROL LEVER
4315	4.04.0054.1.01.1	PL	EL-T1200.00A/ ERSATZ SUB. EL-T1200.00 /ERSATZ	THERMOMETER
4316	4.04.0055.1.01.2	PL	EL-T1200/100/A/ ERSATZ SUBSTITUTE EL-T1200/100/ERSATZ	THERMOMETER
4317	4.04.0056.1.01.3	PL	EL-T1200/100/B	THERMOMETER
4318	4.04.0057.1.01.4	PL	EL-T1255.00B SUB. EL-T1255.00A	ENGINE HOUR METER
4319	4.04.0058.1.01.5	PL	EL-T-1256-00A , EL-T-1001-00A /ERSATZ2	PRESSURE GAUGE

4320	4.04.0059.1.01.6	PL	EL-T1259.00/250/B	TEMPERATURE INDICATOR/THERMOMETER
4321	4.04.0060.1.01.7	PL	EL-T-1261-00	VOLT METER
4322	4.04.0061.1.01.8	PL	EL-T-1262-00	AMPERE METER
4323	4.04.0062.1.01.9	PL	EL-T1263.00 /120/ERSATZ SUB. EL-T1263.00/120	TACHOMETER
4324	4.04.0063.1.01.1	PL	EL-T1263.00/120/A	TACHOMETER
4325	4.04.0064.1.01.2	PL	EL-T1264.00W/ B/ ERSATZ SUB. EL-T1264.00W /ERSATZ	REVOLUTION COUNTER
4326	4.04.0065.1.01.3	PL	EL-T-1264-00B	RPM METER (REVOLUTION COUNTER)
4327	4.04.0066.1.01.4	PL	EL-T1343.11	VALVE CONTROL
4328	4.04.0067.1.01.5	PL	EL-T140.07	SHAFT
4329	4.04.0068.1.01.6	PL	EL-T1413/ ERSATZ/KM/H-LED	INDICATOR
4330	4.04.0069.1.01.7	PL	EL-T-1423-00	INDICATOR
4331	4.04.0070.1.01.8	PL	EL-T155.03-150LG	DRIVE SHAFT
4332	4.04.0071.1.01.9	PL	EL-T155.03-800LG	DRIVE SHAFT
4333	4.04.0072.1.01.1	PL	EL-T-1585/20V	DIGITAL DISPLAY
4334	4.04.0073.1.01.2	PL	EL-T-2060/125KM/II-WK/ERSATZ	TECHOGRAPH
4335	4.04.0074.1.01.3	PL	EL-T2078.17	GEAR WHEEL
4336	4.04.0075.1.01.4	PL	EL-T2113.00C	TACHOMETER
4337	4.04.0076.1.01.5	PL	EL-T2168.00	CAN BUS CONNECTOR
4338	4.04.0077.1.01.6	PL	EL-T4004.03	GUARD
4339	4.04.0078.1.01.7	PL	EL-T5690.00	DISPLAY
4340	4.04.0079.1.01.8	PL	EL-T7005.00E/B SUB. EL-T7005.00E/A	VOLTMETER
4341	4.04.0080.1.01.9	PL	EL-T-7009.00E/A	SERVO CURRENT MET/DRIV
4342	4.04.0081.1.01.1	PL	EL-T-7013-00 / ERSATZ	AMP METER
4343	4.04.0082.1.01.2	PL	EL-T7055/7AF	ROTARY ENCODER
4344	4.04.0083.1.01.3	PL	EL-T7066.00E/B SUB. EL-T7066.00E/A	VOLTMETER
4345	4.04.0084.1.01.4	PL	EL-T-7089.00/10V	DIGITAL DISPLAY
4346	4.04.0085.1.01.5	PL	EL-T-7093-00E	AMPERE METER
4347	4.04.0086.1.01.6	PL	EL-T-7097-00E	AMPERE METER
4348	4.04.0087.1.01.7	PL	EL-T7100.00E/B SUB. EL-T7100.00E/A	VOLTMETER
4349	4.04.0088.1.01.8	PL	EL-T7138.00A/ ERSATZ SUB. EL-T7138.00/ ERSATZ	PRESSURE GAUGE
4350	4.04.0089.1.01.9	PL	EL-T7164.00A	SIGNAL COLUMN
4351	4.04.0090.1.01.1	PL	EL-T-790-00E	DIGITAL DISPLAY
4352	4.04.0091.1.01.2	PL	EL-T80.00E/A SUB. EL-T80.00E	MOVING COIL INSTRUMENT
4353	4.04.0092.1.01.3	PL	EL-T-80-00	GALVANOMETER
4354	4.04.0093.1.01.4	PL	EL-T978.00E/B SUB. EL-T978.00E/A	AMPEREMETER
4355	4.04.0094.1.01.5	PL	EL-T-978-00	M A METER
4356	4.04.0095.1.01.6	PL	G 10700/HOB-70/D2/95/1	PULL CABLE
4357	4.04.0096.1.01.7	PL	G 11300/HOB-70/02/95	PULL CABLE
4358	4.04.0097.1.01.8	PL	GP-10S	PRESSURE GAUGE
4359	4.04.0098.1.01.9	PL	L06.125.05.100	TEMPERATURE CONTROL
4360	4.04.0099.1.01.1	PL	EL-T7130.02	RECORDING PAPER
4361	4.04.0100.1.01.2	PL	L6188A2002	FLUIDMETER
4362	4.04.0101.1.01.3	PL	PIS-3020	PRESSURE SWITCH
4363	4.04.0102.1.01.4	PL	PIS-3070	PRESSURE SWITCH
4364	4.04.0103.1.01.5	PL	SMD108214/ROT/GRUEN	LED RED & GREEN
4365	4.04.0104.1.01.6	PL	SMDD06004/ROT SUB. .035.4210/ROT	LED RED
4366	4.04.0105.1.01.7	PL	SMDD06104/GELB SUB. .035.4212/GELB	LED YELLOW
4367	4.04.0106.1.01.8	PL	SMDD08214/GRUEN SUB. .035.4214/ YELLOW	LED GREEN
4368	4.04.0107.1.01.9	PL	VT17370-1X	AMPLIFIER M/C Dr. CSM
4369	4.04.0108.1.01.1		Shifted to Annexure-II	
4370	4.04.0109.1.01.2	KE	144211	WATER TEMP. GAUGE
4371	4.04.0110.1.01.3	KE	144224	SENDER AIR/OIL PRESSURE
4372	4.04.0111.1.01.4	KE	144225	SENDER WATER TEMPERATURE
4373	4.04.0112.1.01.5	KE	144230	OIL PRESSURE GAUGE
4374	4.04.0113.1.01.6	KE	181582	HOURLY METER BRM
4375	4.04.0114.1.01.7	KE	182898	VOLTMETER
4376	4.04.0115.1.01.8	KE	716880	SENDER TACHOMETER
4377	4.04.0116.1.01.9	KE	719655	SPEEDOMETER
4378	4.04.0117.1.01.1	KE	729646	SENDER FUEL LEVEL GAUGE
4379	4.04.0118.1.01.2	KE	735100	TACHOMETER
4380	4.04.0119.1.01.3	KE	745359	SENDER OF SPEEDOMETER
4381	4.04.0120.1.01.4	AM	766689	SPEEDOMETER SENSOR
4382	4.04.0121.1.01.5	PH	UTVI-09 01/00	LUB OIL PRESSURE SENSOR
4383	4.04.0122.1.01.6	PH	UTVI-09 02/00	HIGH WATER TEMPERATURE SENSOR
4384	4.04.0123.1.01.7	LO	103485	HED SENSOR
4385	4.04.0124.1.01.8	LO	106333	SENSOR 0-50 AMP AC 4-20MA
4386	4.04.0125.1.01.9	LO	113622	MODULE OPTICAL ISOLATOR ENCODER INTERFACE
4387	4.04.0126.1.01.1	LO	117096	CYL ASSY DERAIL DETECTION WITH PROXIMITY SWITCH
4388	4.04.0127.1.01.2	LO	118574	RTD SPRING LOADED
4389	4.04.0128.1.01.3	LO	126639	METER VDC 0-750

4390	4.04.0129.1.01.4	LO	126640	METER IDC 0-1500
4391	4.04.0130.1.01.5	LO	126643	SENSOR SW TEMP 85 DEG C SPDT
4392	4.04.0131.1.01.6	LO	131121	ENG/GEN CONTROLER INTEGRATED DISPLAY
4393	4.04.0132.1.01.7	LO	134828	CONV RTD TEMP 4-20MA
4394	4.04.0133.1.01.8	LO	143887	SENSOR FLUID LEVEL 4-20MA 24 LONG 3/4 MNPT
4395	4.04.0134.1.01.9	LO	160634	SENSOR HEAD FINAL ASSY UNIT 1
4396	4.04.0135.1.01.1	LO	160635	SENSOR HEAD FINAL ASSY UNIT 2
4397	4.04.0136.1.01.2	LO	12.3802	SPEEDOMETER INDICATOR
4398	4.04.0137.1.01.3	LO	E1622 IP 66	CURRENT CONTROL INDICATOR
4399	4.04.0138.1.01.4	LO	IP 4027.3	POSITION INDICATOR WITH KOG DOG
4400	4.04.0139.1.01.5	LO	IP 4027.4	POSITION INDICATOR WITH DOG
4401	4.04.0140.1.01.6	LO	IP 4027.5	POSITION INDICATOR WITH DOG
4402	4.04.0141.1.01.7	KA	IP 4027.9	POSITION INDICATOR WITH RETURNSPRING
4403	4.04.0142.1.01.8	PL	1047402 SUBSTITUTE DS50-P1112	DISTANCE SENSOR
4404	4.04.0143.1.01.9	PL	1174555 SUBSTITUTE 1182840	TEMPERATURE SWITCH
4405	4.04.0144.1.01.1	PL	1182484 SUBSTITUTE 1180418	OIL PRESSURE SWITCH
4406	4.04.0145.1.01.2	PL	1182485 SUBSTITUTE 1180419	OIL PRESSURE SWITCH
4407	4.04.0146.1.01.3		Repeated item	
4408	4.04.0147.1.01.4	PL	ATF-500PT SUBSTITUTE A5500044	SENSOR
4409	4.04.0148.1.01.5	PL	B28CP SUBSTITUTE B28DJ	INDICATION BULB
4410	4.04.0149.1.01.6	PL	EL-T1200.00A/ERSATZ SUBSTITUTE EL-T1200.00/ERSATZ	THERMOMETER
4411	4.04.0150.1.01.7	PL	EL-T1200.00B	THERMOMETER
4412	4.04.0151.1.01.8	PL	EL-T1200/100/A/ERSATZ SUBSTITUTE EL-T1200/100/ERSATZ	THERMOMETER
4413	4.04.0152.1.01.9	PL	EL-T1259.00/185/B SUBSTITUTE EL-T1259.00/185/A	THERMOMETER
4414	4.04.0153.1.01.1	PL	EL-T1259.00/250/B SUBSTITUTE EL-T1259.00/250/A	THERMOMETER
4415	4.04.0154.1.01.2	PL	EL-T1263.00/120/B	SPEEDOMETER
4416	4.04.0155.1.01.3	PL	EL-T1263.00/120/ERSATZ SUBSTITUTE EL-T1263.00/120	TACHOMETER
4417	4.04.0156.1.01.4	PL	EL-T2105.00POS.4.16-39	DISTANCE TRANSDUCER
4418	4.04.0157.1.01.5	PL	EL-T2113.00C SUBSTITUTE EL-T2113.00	TACHOMETER
4419	4.04.0158.1.01.6	PL	EL-T273B SUBSTITUTE EL-T273A	CONNECTOR
4420	4.04.0159.1.01.7	PL	EL-T7089.00/10	INDICATOR
4421	4.04.0160.1.01.8	PL	EL-T7089.00/50	INDICATOR
4422	4.04.0161.1.01.9	PL	EL-T7100.00E/B SUBSTITUTE EL-T7100.00E/A	VOLTMETER
4423	4.04.0162.1.01.1	KA	PVA20-Y-3000-CB	Tachometer Indicator
4424	4.04.0163.1.01.2	KA	MCB11.461264.546	Depth Indicator Display (Setting Device)
4425	4.04.0164.1.01.3	KA	M42300.44.15-0-15B-15T	Volt Meter
4426	4.04.0165.1.01.4	KA	N16226TT A.700.815	Indicator for Current Checkout
4427	4.04.0166.1.01.5	KA	6251-AAAA-AZO (ELFA 36.885.22) With Cable Input (ELFA 55-023-72)	Galvenometer
4428	4.04.0167.1.01.6	KA	PVIOI-MD2	Display
4429	4.04.0168.1.01.7	KA	Display Logo TD/LOGO 6ED 10554MH00-0BAO	Tamping Cycle Display
4430	4.04.0169.1.01.8	KA	6ED1 055-4MH00-0BAO	Display Siemens Logo TD
4431	4.04.0170.1.01.9	PL	EL-T7197.00E	Amperemeter
4432	4.04.0171.1.01.1	ZF	065050178/0659050181	ZF LOCK UP SENSER
4433	4.04.0172.1.01.2	PL	EL-T596.00HG/B	ANGLE SENSOR
4434	4.04.0173.1.01.3	PL	EL-T970.00B	INDICATOR
4435	4.04.0174.1.01.4	GE	254-9175	Digital display gauge
4436	4.04.0175.1.01.5	GE	106-0031	Voltage gauge
4437	4.04.0176.1.01.6	GE	185-5980	Counter
4438	4.04.0177.1.01.7	PL	EL-T905-00002-I/70	ANGEL SENSOR
4439	4.04.0178.1.01.8	PL	ELT-200-00002-904-5-LI-U	ROTARY ENCODER
4440	4.04.0179.1.01.9	PL	ELT-200-00002-904-5-RE-U	ROTARY ENCODER
4441	4.04.0180.1.01.1	GE	TCT1000-202541C502-150C	Temperature sensor
4442	4.04.0181.1.01.2	GE	HDA 7446-A-400-000	Pressure sensor
4443	4.04.0182.1.01.3	CR	40108000	SENSOR, RPM
4444	4.04.0183.1.01.4	CR	SCP01-010-34-07(SCK-145)	PRESSURE SENSOR
4445	4.04.0184.1.01.5	CR	437-035-002C	SPEED ODOMETER
4446	4.04.0185.1.01.6	GE	750 type	Depth sensor
4447		COLMAR	9990018 ans revised Part no.51902004 and Treeffe part no. BTF-40/K	Remote Control Assembly
	4.04.0186.1.01.7			
4448	4.04.0187.1.01.8	PL	UM30-213113	Ultrasonic sensor
4449	4.04.0188.1.01.9	PL	UM30-214113	Ultrasonic sensor
4450	4.04.0189.1.01.1	PL	S-6.117.4	Brake pressure dector
4451	4.04.0190.1.01.2	PL	ETS7246-A-008	Temperature sensor

4452	4.04.0191.1.01.3	PL	AS1008-C-000	Aqua sensor
4453	4.04.0192.1.01.4	PL	HDD1L 16ND20	Pulse transducer (speed sensor)
4454	4.04.0193.1.01.5	PL	ELT-906-00001-I/800	measuring transducer
4455	4.04.0194.1.01.6	PL	ELT-906-00004-I/3500	measuring transducer
4456	4.04.0195.1.01.7	PL	ELT-906-00001-I/600	measuring transducer
4457	4.04.0196.1.01.8	PL	ELT-902-00002-I	Measures versine
4458	4.04.0197.1.01.9	PL	ELT-902-00001-I	Measures versine
4459	4.04.0198.1.01.1	PL	ELT-906-00001-I/3500	Transducer
4460	4.04.0199.1.01.2	PL	ELT-906-00007-I/800	Transducer
4461	4.04.0200.1.01.3	PL	ELT-906-00010-I/800	Transducer
4462	4.04.0201.1.01.4	PL	ELT-906-00001-I/400	Transducer
4463	4.04.0202.1.01.5	PL	EL-T9125.05	Carrier F tachom shaft (speedometer)
4464	4.04.0203.1.01.6	PL	NI75U-CP80-VP4X2	Clamp2 rail sensor
4465	4.04.0204.1.01.7	PL	S-8.72.2	Inductive sensor
4466	4.04.0205.1.01.8	PL	S-8.72.3	Inductive sensor
4467	4.04.0206.1.01.9	PL	EL-T2078.01	Wheel collar
4468	4.04.0207.1.01.1	PL	EL-T2105.03	Wheel
4469	4.04.0208.1.01.2	PL	ROTARY ENCODER	EL-T-200-00002-904-5-RE
4470	4.04.0209.1.01.3	PL	EL-T2170.G1	INDUCTIVE SENSOR
4471	4.04.0210.1.01.4	PL	KPPG166	SPEED SENSOR
4472	4.04.0211.1.01.5	LO	236305	PLC MOD TEMP AI KIT; 6 ISO INPUT RTD(replaces 114353)
4473	4.04.0212.1.01.6	LO	252351-220	SENSOR KIT
4474	4.04.0213.1.01.7	LO	252351-50	SENSOR KIT #2
4475	4.04.0214.1.01.8	LO	249182	SENSOR HEAD UNIT
4476	4.04.0215.1.01.9	LO	126571	THERMOWELL 12MOR 316SS .5 NPT 10.5 RELAXED
4477	4.04.0216.1.01.1	LO	248466	SENSOR TANK LEVEL; 1320 GAL
4478	4.04.0217.1.01.2	PL	EL-T7168. OOB	SPEEDOMETER/ 130KM/ H/ 24V -1
4479	4.04.0218.1.01.3	PL	676.38A	THERMOSTART
4480	4.05.0001.1.01.3	PL	2155.01	TRANSDUCER
4481	4.05.0002.1.01.4	PL	501317159	TRANSDUCER
4482	4.05.0003.1.01.5	PL	750131053	FILTER ELEMENT
4483	4.05.0004.1.01.6	PL	0,1%0,25WTK25/1,2MOHM	RESISTANCE
4484	4.05.0005.1.01.7	PL	0,1%0,25WTK25/1,3KOHM	RESISTANCE
4485	4.05.0006.1.01.8	PL	0,1%0,25WTK25/1,5KOHM	RESISTANCE
4486	4.05.0007.1.01.9	PL	0,1%0,25WTK25/100KOHM	RESISTANCE
4487	4.05.0008.1.01.1	PL	0,1%0,25WTK25/10KOHM	RESISTANCE
4488	4.05.0009.1.01.2	PL	0,1%0,25WTK25/11KOHM	RESISTANCE
4489	4.05.0010.1.01.3	PL	0,1%0,25WTK25/12,1KOHM	RESISTANCE
4490	4.05.0011.1.01.4	PL	0,1%0,25WTK25/13KOHM	RESISTANCE
4491	4.05.0012.1.01.5	PL	0,1%0,25WTK25/14KOHM	RESISTANCE
4492	4.05.0013.1.01.6	PL	0,1%0,25WTK25/150KOHM	RESISTANCE
4493	4.05.0014.1.01.7	PL	0,1%0,25WTK25/15KOHM	RESISTANCE
4494	4.05.0015.1.01.8	PL	0,1%0,25WTK25/15OHM	RESISTANCE
4495	4.05.0016.1.01.9	PL	0,1%0,25WTK25/16,3KOHM	RESISTANCE
4496	4.05.0017.1.01.1	PL	0,1%0,25WTK25/169KOHM	RESISTANCE
4497	4.05.0018.1.01.2	PL	0,1%0,25WTK25/18KOHM	RESISTANCE
4498	4.05.0019.1.01.3	PL	0,1%0,25WTK25/1KOHM	RESISTANCE
4499	4.05.0020.1.01.4	PL	0,1%0,25WTK25/1MOHM	RESISTANCE
4500	4.05.0021.1.01.5	PL	0,1%0,25WTK25/2,49KOHM	RESISTANCE
4501	4.05.0022.1.01.6	PL	0,1%0,25WTK25/200KOHM	RESISTANCE
4502	4.05.0023.1.01.7	PL	0,1%0,25WTK25/200-OHM	RESISTANCE
4503	4.05.0024.1.01.8	PL	0,1%0,25WTK25/20KOHM	RESISTANCE
4504	4.05.0025.1.01.9	PL	0,1%0,25WTK25/220-OHM	RESISTANCE
4505	4.05.0026.1.01.1	PL	0,1%0,25WTK25/24,3KOHM	RESISTANCE
4506	4.05.0027.1.01.2	PL	0,1%0,25WTK25/24,9KOHM	RESISTANCE
4507	4.05.0028.1.01.3	PL	0,1%0,25WTK25/255KOHM	RESISTANCE
4508	4.05.0029.1.01.4	PL	0,1%0,25WTK25/28KOHM	RESISTANCE
4509	4.05.0030.1.01.5	PL	0,1%0,25WTK25/2KOHM	RESISTANCE
4510	4.05.0031.1.01.6	PL	0,1%0,25WTK25/3,4KOHM	RESISTANCE
4511	4.05.0032.1.01.7	PL	0,1%0,25WTK25/3,92KOHM	RESISTANCE
4512	4.05.0033.1.01.8	PL	0,1%0,25WTK25/330OHM	RESISTANCE
4513	4.05.0034.1.01.9	PL	0,1%0,25WTK25/33KOHM	RESISTANCE
4514	4.05.0035.1.01.1	PL	0,1%0,25WTK25/36,5KOHM	RESISTANCE
4515	4.05.0036.1.01.2	PL	0,1%0,25WTK25/39KOHM	RESISTANCE
4516	4.05.0037.1.01.3	PL	0,1%0,25WTK25/4,22KOHM	RESISTANCE
4517	4.05.0038.1.01.4	PL	0,1%0,25WTK25/4,7KOHM	RESISTANCE
4518	4.05.0039.1.01.5	PL	0,1%0,25WTK25/4,99KOHM	RESISTANCE
4519	4.05.0040.1.01.6	PL	0,1%0,25WTK25/475OHM	RESISTANCE
4520	4.05.0041.1.01.7	PL	0,1%0,25WTK25/47OHM	RESISTANCE
4521	4.05.0042.1.01.8	PL	0,1%0,25WTK25/5,1KOHM	RESISTANCE
4522	4.05.0043.1.01.9	PL	0,1%0,25WTK25/5,9KOHM	RESISTANCE
4523	4.05.0044.1.01.1	PL	0,1%0,25WTK25/50KOHM	RESISTANCE
4524	4.05.0045.1.01.2	PL	0,1%0,25WTK25/51KOHM	RESISTANCE
4525	4.05.0046.1.01.3	PL	0,1%0,25WTK25/56,2KOHM	RESISTANCE
4526	4.05.0047.1.01.4	PL	0,1%0,25WTK25/560 OHM	RESISTANCE

4527	4.05.0048.1.01.5	PL	EL-T993.00-HG	TRANSDUCER
4528	4.05.0049.1.01.6	PL	0,1%0,25WTK25/6.49KOHM	RESISTANCE
4529	4.05.0050.1.01.7	PL	0,1%0,25WTK25/680OHM	RESISTANCE
4530	4.05.0051.1.01.8	PL	0,1%0,25WTK25/68KOHM	RESISTANCE
4531	4.05.0052.1.01.9	PL	0,1%0,25WTK25/7KOHM	RESISTANCE
4532	4.05.0053.1.01.1	PL	0,1%0,25WTK25/9,1KOHM	RESISTANCE
4533	4.05.0054.1.01.2	PL	0,5W1%15OHM	RESISTANCE
4534	4.05.0055.1.01.3	PL	0,5W1%3,3OHM	RESISTANCE
4535	4.05.0056.1.01.4	PL	0,5W1%33OHM	RESISTANCE
4536	4.05.0057.1.01.5	PL	0,5W1%47OHM	RESISTANCE
4537	4.05.0058.1.01.6	PL	100KOHM/T18	POTENTIOMETER
4538	4.05.0059.1.01.7	PL	100KOHM/T93YBQ	TRIMM POTENTIOMETER
4539	4.05.0060.1.01.8	PL	10KOHM	PRE-SET POTENTIOMETER
4540	4.05.0061.1.01.9	PL	10KOHM/PD2310/5A170MA	POTENTIOMETER
4541	4.05.0062.1.01.1	PL	10KOHM/T18	POTENTIOMETER
4542	4.05.0063.1.01.2	PL	10KOHM/T93YBQ	TRIMM POTENTIOMETER
4543	4.05.0064.1.01.3	PL	10KOHM0620017	POTENTIOMETER
4544	4.05.0065.1.01.4	PL	1183692 SUB. 1182841	TRANSDUCER
4545	4.05.0066.1.01.5	PL	1KOHM/T18	POTENTIOMETER
4546	4.05.0067.1.01.6	PL	1KOHM/T93YBQ	TRIMM POTENTIOMETER
4547	4.05.0068.1.01.7	PL	1W5%470OHM SUB. 1W10%470OHM	RESISTANCE
4548	4.05.0069.1.01.8	PL	2 MMD-BONDEZVG	CHORD WIRE 2 MM
4549	4.05.0070.1.01.9	PL	2.2KOHMT93YBQ	TRIMM POTENTIOMETER
4550	4.05.0071.1.01.1	PL	20 KSL-/- 5 SKLA	POTENTIOMETER
4551	4.05.0072.1.01.2	PL	20 KQ-10 SKALA/K-200G	POTENTIOMETER 20 K OHM
4552	4.05.0073.1.01.3	PL	200KOHM/T93YBQ	TRIMM POTENTIOMETER
4553	4.05.0074.1.01.4	PL	20K OHM-5-S KALA/K 200G	POTENTIOMETER
4554	4.05.0075.1.01.5	PL	20KOHM/T18	POTENTIOMETER
4555	4.05.0076.1.01.6	PL	20KOHM/T93YBQ	TRIMM POTENTIOMETER
4556	4.05.0077.1.01.7	PL	20KOHM+-SSKALA/K200-G	POTENTIOMETER
4557	4.05.0078.1.01.8	PL	210.033/041/001	ANGLE GEAR
4558	4.05.0079.1.01.9	PL	2155-0100-0002 Sub: 2155-01	TRANSDUCER
4559	4.05.0080.1.01.1	PL	220KOHM0620013	POTENTIOMETER
4560	4.05.0081.1.01.2	PL	22KOHM/T93YBQ	TRIMM POTENTIOMETER
4561	4.05.0082.1.01.3	PL	25W8.2OHM5%	RESISTANCE
4562	4.05.0083.1.01.4	PL	2KOHM/T18	POTENTIOMETER
4563	4.05.0084.1.01.5	PL	2OHM/2W	RESISTANCE
4564	4.05.0085.1.01.6	PL	2OHM/7W	RESISTANCE
4565	4.05.0086.1.01.7	PL	2OHM-1WATT	RESISTANCE
4566	4.05.0087.1.01.8	PL	323.801/003/001	TRANSDUCER
4567	4.05.0088.1.01.9	PL	323.801/004/002	TRANSDUCER
4568	4.05.0089.1.01.1	PL	323.805/001/001	TRANSDUCER
4569	4.05.0090.1.01.2	PL	340-807/001/100	TRANSDUCER
4570	4.05.0091.1.01.3	PL	4,7KOHMT93YBQ	TRIMM POTENTIOMETER
4571	4.05.0092.1.01.4	PL	47KOHM/T93YBQ	TRIMM POTENTIOMETER
4572	4.05.0093.1.01.5	PL	47KOHM0620017	POTENTIOMETER
4573	4.05.0094.1.01.6	PL	50W/1KOHM	RESISTANCE
4574	4.05.0095.1.01.7	PL	50W1OHM5%	RESISTANCE
4575	4.05.0096.1.01.8	PL	5KOHM/T18	POTENTIOMETER
4576	4.05.0097.1.01.9	PL	5W/470OHM	RESISTANCE
4577	4.05.0098.1.01.1	PL	5W/500OHM	RESISTANCE
4578	4.05.0099.1.01.2	PL	7W2% 2.2 OHM	RESISTANCE
4579	4.05.0100.1.01.3	PL	7W2%1OHM	RESISTANCE
4580	4.05.0101.1.01.4	PL	B380C1500M	RECTIFIER
4581	4.05.0102.1.01.5	PL	DF17/1S1.140BAD	PULSE GENERATOR
4582	4.05.0103.1.01.6	PL	EL-140-07	SHAFT
4583	4.05.0104.1.01.7	PL	EL-T 1041.01A	ROLLER
4584	4.05.0105.1.01.8	Shifted to Annexure-II		
4585	4.05.0106.1.01.9	PL	EL-T 1043	POTENTIOMETER
4586	4.05.0107.1.01.1	PL	EL-T 1062	POTENTIOMETER
4587	4.05.0108.1.01.2	PL	EL-T 2001-05	CHAIN BELT
4588	4.05.0109.1.01.3	PL	EL-T 213-06D	CARRIER
4589	4.05.0110.1.01.4	PL	EL-T 5112-00	POTENTIOMETER
4590	4.05.0111.1.01.5	PL	EL-T 576-0-80	CHORD WIRE
4591	4.05.0112.1.01.6	PL	EL-T 576-2.00	CHORD WIRE
4592	4.05.0113.1.01.7	PL	EL-T 928-01	ARM
4593	4.05.0114.1.01.8	PL	EL-T1041.12 (5X0,6)	SPRING
4594	4.05.0115.1.01.9	PL	EL-T1199.00-BR/L-RECHTS	TRANSDUCER
4595	4.05.0116.1.01.1	PL	EL-T1330.00LI	TRANSDUCER
4596	4.05.0117.1.01.2	PL	EL-T1330.00RE	TRANSDUCER
4597	4.05.0118.1.01.3	PL	EL-T1330.17	ROD
4598	4.05.0119.1.01.4	PL	EL-T152.04	CABLE PULLEY
4599	4.05.0120.1.01.5	PL	EL-T152.07	SHAFT
4600	4.05.0121.1.01.6	PL	EL-T152.161	STRIP
4601	4.05.0122.1.01.7	PL	EL-T2002.00/700	TRANSDUCER
4602	4.05.0123.1.01.8	PL	EL-T2007.00A	TRANSDUCER
4603	4.05.0124.1.01.9	PL	EL-T2013.04	SHAFT

4604	4.05.0125.1.01.1	PL	EL-T2013.17	LINING
4605	4.05.0126.1.01.2	PL	EL-T2013.23	STRIP
4606	4.05.0127.1.01.3	PL	EL-T2021.G1	SPIRIT LEVEL COMPLETE
4607	4.05.0128.1.01.4	PL	EL-T2036.43	LEVEL,SPIRIT MEASURING DEVICE
4608	4.05.0129.1.01.5	PL	EL-T2053.02	GEAR WHEEL
4609	4.05.0130.1.01.6	PL	EL-T2111.G3	LINEAR-WESENSOR.O.GRUNDPL.
4610	4.05.0131.1.01.7	PL	EL-T2117.00	PULSE DRIVE
4611	4.05.0132.1.01.8	PL	EL-T2118.00A-LINKS	TRANSDUCER
4612	4.05.0133.1.01.9	PL	EL-T-2118/4	TRANSDUCER
4613	4.05.0134.1.01.1	PL	EL-T213.01B	STRIP
4614	4.05.0135.1.01.2	PL	EL-T213.02B	ROD
4615	4.05.0136.1.01.3	PL	EL-T213.05	BUFFER STOP
4616	4.05.0137.1.01.4	PL	EL-T213.06G/1	CARRIER(BRASS)
4617	4.05.0138.1.01.5	PL	EL-T213.08	COVER
4618	4.05.0139.1.01.6	PL	EL-T213.28	SPRING
4619	4.05.0140.1.01.7	PL	EL-T213.33	BUSH
4620	4.05.0141.1.01.8	PL	EL-T213.34	PULLEY
4621	4.05.0142.1.01.9	PL	EL-T213.35	LEVER
4622	4.05.0143.1.01.1	PL	EL-T213.36	SPACER BUSH
4623	4.05.0144.1.01.2	PL	EL-T271SB SUB. EL-T271SA	CONNECTOR
4624	4.05.0145.1.01.3	PL	EL-T272SB SUB. EL-T272SA	CONNECTOR
4625	4.05.0146.1.01.4	PL	EL-T274B SUB. EL-T274A	CONNECTOR
4626	4.05.0147.1.01.5	PL	EL-T376.07	CABLE PULLEY
4627	4.05.0148.1.01.6	PL	EL-T376.15	COVER
4628	4.05.0149.1.01.7	PL	EL-T376.16	BEARING STAND
4629	4.05.0150.1.01.8	PL	EL-T376.283	ZERO-LIMIT
4630	4.05.0151.1.01.9	PL	EL-T376.284	SCREW
4631	4.05.0152.1.01.1	PL	EL-T376.285	BLOCK
4632	4.05.0153.1.01.2	PL	EL-T490.04	ROLLER
4633	4.05.0154.1.01.3	PL	EL-T490.10	SPRING
4634	4.05.0155.1.01.4	PL	EL-T5016.00A	POTENTIOMETER
4635	4.05.0156.1.01.5	PL	EL-T-5016-00	DEPTH INDICATOR (POTENOMETER)
4636	4.05.0157.1.01.6	PL	EL-T5112.00A	POTENTIOMETER
4637	4.05.0158.1.01.7	PL	EL-T566.01Z/S-5.14.1.2	COUPLING
4638	4.05.0159.1.01.8	PL	EL-T596.02A	CABLE PULLEY
4639	4.05.0160.1.01.9	PL	EL-T596.10	SPUR WHEEL
4640	4.05.0161.1.01.1	PL	EL-T596.11	GASKET
4641	4.05.0162.1.01.2	PL	EL-T609.29	SPRING
4642	4.05.0163.1.01.3	PL	EL-T609.32	ROD
4643	4.05.0164.1.01.4	PL	EL-T609.45	ROD
4644	4.05.0165.1.01.5	PL	EL-T7008/1100	DIGITAL POTENTIOMETER
4645	4.05.0166.1.01.6	PL	EL-T7033	POTENTIOMETER
4646	4.05.0167.1.01.7	PL	EL-T7072/100K	POTENTIOMETER
4647	4.05.0168.1.01.8	PL	EL-T7072/10K	POTENTIOMETER
4648	4.05.0169.1.01.9	PL	EL-T7072/1K	POTENTIOMETER
4649	4.05.0170.1.01.1	PL	EL-T7072/20K	POTENTIOMETER
4650	4.05.0171.1.01.2	PL	EL-T7072/2K	POTENTIOMETER
4651	4.05.0172.1.01.3	PL	EL-T7072/50K	POTENTIOMETER
4652	4.05.0173.1.01.4	PL	EL-T7072/5K	POTENTIOMETER
4653	4.05.0174.1.01.5	PL	EL-T7072C/200K	POTENTIOMETER
4654	4.05.0175.1.01.6	PL	EL-T7135.00B-JUSTIERT	TRANSDUCER
4655	4.05.0176.1.01.7	PL	EL-T750.00ES	TRANSDUCER
4656	4.05.0177.1.01.8		Shifted to Ann-II	
4657	4.05.0178.1.01.9	PL	EL-T750.15	ROPE CLAMP
4658	4.05.0179.1.01.1	PL	ELT902T1D-01	VERSINE TRANSDUCER
4659	4.05.0180.1.01.2	PL	ELT902T1F-01	TRANSDUCER
4660	4.05.0181.1.01.3	PL	ELT-903-00001-U/1000	ROLLER CHORD TRANSDUCER
4661	4.05.0182.1.01.4	PL	ELT-903-00001-U/2000	ROLLER CHORD TRANSDUCER
4662	4.05.0183.1.01.5	PL	ELT903T1A-01	ROLLER CHORD TRANSDUCER
4663	4.05.0184.1.01.6	PL	ELT904T1D-01A	PROPORTIONAL TRANSDUCER
4664	4.05.0185.1.01.7	PL	ELT904T1Q-01	LONGITUDINAL LEVEL TRANSDUCER
4665	4.05.0186.1.01.8	PL	EL-T920.04A	CARRIER
4666	4.05.0187.1.01.9	PL	EL-T920.14	DISC
4667	4.05.0188.1.01.1	PL	EL-T920.15	CABLE PULLY
4668	4.05.0189.1.01.2	PL	EL-T920.16	ROPE CLAMP
4669	4.05.0190.1.01.3	PL	III97105/1	SPRING
4670	4.05.0191.1.01.4	PL	MSW100-1101-06	ROD
4671	4.05.0192.1.01.5	PL	MSW100-1101-07	ROD
4672	4.05.0193.1.01.6	PL	N03330116	RESISTOR
4673	4.05.0194.1.01.7	PL	RM12-103J	RESISTOR NETWORK
4674	4.05.0195.1.01.8	PL	RM8-103J	RESISTOR NETWORK
4675	4.05.0196.1.01.9	PL	TQ441-01/01 YUER-1572	LIMIT INDICATOR
4676	4.05.0197.1.01.1	BH	4-20 MA DC SINGLE INPUT 0.5 OHM	CURRENT TRANSDUCER FOR DTS
4677	4.05.0198.1.01.2	LO	105055	SCR BRICK 800A 3000V
4678	4.05.0199.1.01.3	LO	126641	TRANS 117:36V 36VA CT 50/60 HZ, 1P

4679	4.05.0200.1.01.4	LO	126653	SCR TRACTION BRIDGE; 3 MODE DRIVE SYSTEM
4680	4.05.0201.1.01.5	LO	129527	TRANSDUCER PRESS 200PSI 04MORB 6-30VDC 4-20MA
4681	4.05.0202.1.01.6	LO	157290	TRANSDUCER PRESS 3000PSI 06MORB 7-35VDC 4-20MA
4682	4.05.0203.1.01.7	LO	A47129	POTENTIOMETER 5K SL
4683	4.05.0204.1.01.8	LO	C90410	REGULATOR VOLTAGE 63VDC 12 AMP CONTINUOUS
4684	4.05.0205.1.01.9	KA	TGU	LIAD SPEAKER DEVICE
4685	4.05.0206.1.01.1	PL	1183692 SUBSTITUTE 1182841	TRANSDUCER
4686	4.05.0207.1.01.2	PL	1W5%470OHM SUBSTITUTE 1W10%470OHM	RESISTANCE
4687	4.05.0208.1.01.3	PL	2155-01000002 SUBSTITUTE 2155-01	TRANSDUCER
4688	4.05.0209.1.01.4	PL	340.807/001/001	TRANSDUCER
4689	4.05.0210.1.01.5		Shifted to Ann II	
4690	4.05.0211.1.01.6		Shifted to Ann II	
4691	4.05.0212.1.01.7	PL	5W10%270OHM	RESISTANCE
4692	4.05.0213.1.01.8	PL	7W2%2.2OHM	RESISTANCE
4693	4.05.0214.1.01.9		Shifted to Ann II	
4694	4.05.0215.1.01.1	PL	EL-T1041.01A SUBSTITUTE EL-T1041.01AKPL	ROLLER
4695	4.05.0216.1.01.2	PL	EL-T1041.12(5X0.6)	SPRING
4696	4.05.0217.1.01.3	PL	EL-T1050-DL2/ BLAU	TOMMY HEAD
4697	4.05.0218.1.01.4	PL	EL-T1050-DL2/ROT	TOMMY HEAD
4698	4.05.0219.1.01.5	PL	EL-T1050-DL2/WEISS	TOMMY HEAD
4699	4.05.0220.1.01.6	PL	EL-T1050-DL3/BLAU	TOMMY HEAD
4700	4.05.0221.1.01.7	PL	EL-T1050-DL5/ GELB	TOMMY HEAD
4701	4.05.0222.1.01.8	PL	EL-T1062	POTENTIOMETER (10KOHM)
4702	4.05.0223.1.01.9		Shifted to Ann II	
4703	4.05.0224.1.01.1	PL	EL-T152.02	COVER
4704	4.05.0225.1.01.2	PL	EL-T2031.04	HOUSING
4705	4.05.0226.1.01.3	PL	EL-T2031.14	FITTING
4706	4.05.0227.1.01.4	PL	EL-T2070.00	CHORD GUIDANCE
4707	4.05.0228.1.01.5	PL	EL-T2070.01	SUPPORT
4708	4.05.0229.1.01.6	PL	EL-T4386.00	CHORD GUIDANCE
4709	4.05.0230.1.01.7	PL	EL-T576.10B	STEEL CHORD
4710	4.05.0231.1.01.8	PL	EL-T596.09	GEAR WHEEL
4711	4.05.0232.1.01.9	PL	EL-T67.02A	CARRIER
4712	4.05.0233.1.01.1	KA	6.54.00.008	Centimeter Transducer (Encoder)
4713	4.05.0234.1.01.2	KA	MGB115.461161.545	Potentiometer Setting Device
4714	4.05.0235.1.01.3	PL	EL-T200-00001-902-5-U	Absolute Valve Transducer
4715	4.05.0236.1.01.4	PL	EL-T200-00001-903-1-U-1000	Absolute Valve Transducer
4716	4.05.0237.1.01.5	CR	PD 210-10K/J 4BM	POTENTIOMETER
4717	4.05.0238.1.01.6	PL	ELT-908-00003-I	ACCELERATOR
4718	4.05.0239.1.01.7	PL	EL-T7287.00/ S-6.102/ISO	INCLINOMETER
4719	4.05.0240.1.01.8	PL	ELT-908-00001-I/L	ACCELERATOR
4720	4.05.0241.1.01.9	PL	EL-T700-00083-5/+5	POTENTIOMETER 20K - 5/+5 SKALA
4721	4.05.0242.1.01.1	PL	EL-T700-00083-0/10 sub 20KOHM0-10SKALA/K200-G	POTENTIOMETER
4722	4.05.0243.1.01.2	PL	EL-T7008/350 and 50KOHM2003	POTENTIOMETER
4723	4.05.0244.1.01.3	PL	ELB-LA0-25- 10KOHM/10KOHM0620017	POTENTIOMETER
4724	4.05.0245.1.01.4	PL	ELB-LA0-26-22KOHM or 22KOHM0620013	POTENTIOMETER
4725	4.05.0246.1.01.5	PL	ELB-LA0-26- 100KOHM/100KOHM0620013	POTENTIOMETER
4726	4.05.0247.1.01.6	PL	226.801/015/001	TRANSDUCER
4727	4.05.0248.1.01.7	PL	EL-T902-00004-D-U	TRANSDUCER (RECORDER CHORD)
4728	4.05.0249.1.01.8	PL	EL-T902-00004-U	TRANSDUCER
4729	4.05.0250.1.01.9	PL	EL-T902-00005-GL-U	TRANSDUCER (VERSINE)
4730	4.05.0251.1.01.1	PL	EL-T902-00005-U	TRANSDUCER ((VERSINE))
4731	4.05.0252.1.01.2	PL	EL-T903-00001-I/500	TRANSDUCER (RECORDER CHORD)
4732	4.05.0253.1.01.3	PL	EL-T903-00001-U/1000	TRANSDUCER (T UNIT UP/DN)
4733	4.05.0254.1.01.4	PL	EL-T903-00001-U/2000	TRANSDUCER (ROLLER CHORD)
4734	4.05.0255.1.01.5	PL	EL-T903-00001-U/2500	TRANSDUCER (EXTENSION LIMITATION)
4735	4.05.0256.1.01.6	PL	EL-T904-00001-2	TRANSDUCER LHS (LEVELLING)
4736	4.05.0257.1.01.7	PL	EL-T904-00001-3	TRANSDUCER RHS (LEVELLING)
4737	4.05.0258.1.01.8	PL	EL-T904-00005LI-U/50	TRANSDUCER COMPLETE (LEVELLING)

4738	4.05.0259.1.01.9	PL	EL-T904-00005LI-U/170	TRANSDUCER COMPLETE (LEVELLING)
4739	4.05.0260.1.01.1	PL	EL-T904-00005LI-U/470	TRANSDUCER COMPLETE (LEVELLING)
4740	4.05.0261.1.01.2	PL	EL-T904-00005RE-U/50	TRANSDUCER COMPLETE (LEVELLING)
4741	4.05.0262.1.01.3	PL	EL-T904-00005RE-U/170	TRANSDUCER COMPLETE (LEVELLING)
4742	4.05.0263.1.01.4	PL	EL-T904-00005RE-U/470	TRANSDUCER COMPLETE (LEVELLING)
4743	4.05.0264.1.01.5	PL	EL-T904-00010-U	TRANSDUCER (LOGITUDINAL)
4744	4.05.0265.1.01.6	PL	EL-T905-00006-U/50	TRANSDUCER
4745	4.05.0266.1.01.7	PL	EL-T905-00002-U/90	TRANSDUCER
4746	4.05.0267.1.01.8	PL	EL-T906-00001-I/800	TRANSDUCER
4747	4.05.0268.1.01.9	PL	EL-T906-00001-U/1000	TRANSDUCER (ROLLER CHORD)
4748	4.05.0269.1.01.1	PL	EL-T906-00001-U/2000	TRANSDUCER (ROLLER CHORD)
4749	4.05.0270.1.01.2	PL	EL-T906-00008-I/3500	TRANSDUCER
4750	4.05.0271.1.01.3	PL	EL-T906-00009-I/1600	TRANSDUCER
4751	4.05.0272.1.01.4	PL	EL-T908-00003-U	POTENTIAL METER (WORK DRIVE, ACCELERATOR)
4752	4.05.0273.1.01.5	PL	EL-T9137.00	TRANSDUCER
4753	4.05.0274.1.01.6	PL	S-6.117.3	TRANSDUCER
4754	4.05.0275.1.01.7	PL	S-6.117.4	PRESSURE TRANSDUCER
4755	4.05.0276.1.01.8	PL	S-6.117.7	PRESSURE TRANSDUCER
4756	4.05.0277.1.01.9	PL	EL-T200-00001-902-4-U	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4757	4.05.0278.1.01.1	PL	EL-T200-00001-903-1-U/1000	ABSOLUTE VALUE TRANSDUCER (T UNIT UP/DN)
4758	4.05.0279.1.01.2	PL	EL-T200-00001-903-1-U/2000	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4759	4.05.0280.1.01.3	PL	EL-T200-00002-905-2-1-0-70	ROTARY ENCODER
4760	4.05.0281.1.01.4	PL	EL-T200-00001-906-1-U/1000	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4761	4.05.0282.1.01.5	PL	EL-T200-00001-906-1-1-800	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4762	4.05.0283.1.01.6	PL	EL-T200-00002-904-5LI-U	ABSOLUTE VALUE TRANSDUCER (LEVELLING)
4763	4.05.0284.1.01.7	PL	EL-T200-00002-904-5RE-U	ABSOLUTE VALUE TRANSDUCER (LEVELLING)
4764	4.05.0285.1.01.8	PL	EL-T200-00001A	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4765	4.05.0286.1.01.9	PL	EL-T200-00002A	ABSOLUTE VALUE TRANSDUCER (ROTARY ENCODER)
4766	4.05.0287.1.01.1	PL	ELT-200-00001-903-1-U-1000	ABSOLUTE VALUE TRANSDUCER
4767	4.05.0288.1.01.2	PL	ELT-906-00001-U/1000	ROLLER CHORD TRANSDUCER
4768	4.05.0289.1.01.3	PL	ELT-200-00001-906-1-U- 1000	ABSOLUTE VALUE TRANSDUCER
4769	4.05.0290.1.01.4	PL	ELT-904-00005LI-U/170	LEVELLING TRANSDUCER
4770	4.05.0291.1.01.5	PL	ELT-904-00005RE-U/170	LEVELLING TRANSDUCER
4771	4.05.0292.1.01.6	PL	ELT-902-00005-U	VERSINE TRANSDUCER
4772	4.05.0293.1.01.7	PL	EL-T2085	TRANSDUCER
4773	4.05.0294.1.01.8	PL	S-6.117.1(0-400 BAR)	PRESSURE TRANSDUCER-1
4774	4.05.0295.1.01.9	PL	ELT-200-00001-902-5-U	ABSOLUTE VALUE TRANSDUCER
4775	4.05.0296.1.01.1	CR	40089140	DIGITAL POTENTIONMETER
4776	4.05.0297.1.01.2	CR	40092217	LIFTING POTENTIOMETER
4777	4.05.0298.1.01.3	PL	2159-01000003	TRANSDUCER
4778	4.05.0299.1.01.4	CR	2005331	HOOK TRANSDUCER
4779	4.05.0300.1.01.5	CR	2009092	T/U UP DOWN/TRANSDUCER
4780	4.05.0301.1.01.6	PL	S-6.117.1	Pressure transducer
4781	4.05.0302.1.01.7	PL	S-6.117.3	Pressure transducer
4782	4.05.0303.1.01.8	PL	S-6.117.5	Pressure transducer
4783	4.05.0304.1.01.9	PL	NTB-1301Y-03-OEM	Reservoir level transducer
4784	4.05.0305.1.01.1	PL	S-7.105.1	Signal transmitter
4785	4.05.0306.1.01.2	PL	P30LL0FRR103MA	POTENTIOMETER
4786	4.05.0307.1.01.3	PL	90297/-40GRAD	TRANSDUCER
4787	4.05.0307.1.01.4	PL	EL-T902-00004-I	TRANSDUCER

4788	4.05.0308.1.01.5	PL	EL-T200-00001-902-4-I	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
4789	4.05.0309.1.01.6	PL	EL-T2013.00G1	SWIVEL PART
4790	4.05.0310.1.01.7	PL	EL-T856.02	HOLDER L.H.S. FOR TRANSDUCER
4791	4.05.0311.1.01.8	PL	EL-T856.03	BRACKET R.H.S. FOR TRANSDUCER
4792	4.06.0001.1.01.4	PL	EL-T 133.00	PENDULUM ASSEMBLY
4793	4.06.0002.1.01.5	PL	EL-T 2111.00B	PENDULUM
4794	4.06.0003.1.01.6	PL	EL-T-2021-00-1A	PENDULUM
4795	4.06.0004.1.01.7	PL	EL-T-2036-00A	PENDULUM
4796	4.06.0005.1.01.8	PL	EL-T2111.23	SHIELD
4797	4.06.0006.1.01.9	PL	EL-T2111.24	HOSE
4798	4.06.0007.1.01.1	PL	EL-T2111.25	HOSE
4799	4.06.0008.1.01.2	PL	ELT-7035	PENDULUM
4800	4.06.0009.1.01.3	PL	EL-T.700-000-10	PENDULUM SOCKET
4801	4.06.0010.1.01.4	PL	EL-T2076.04	COVER
4802	4.06.0011.1.01.5	PL	EL-T901-00001	PENDULUM
4803	4.06.0012.1.01.6	PL	EL-T2111.G1 OR EL-T2111.G1A	PENDULAM
4804	4.07.0001.1.01.5	PL	DAT 2 x0.25	DATA CABLE
4805	4.07.0002.1.01.6	PL	DAT 2 x0.5	DATA CABLE
4806	4.07.0003.1.01.7	PL	DAT 6x2 x0.20	DATA CABLE
4807	4.07.0004.1.01.8	PL	DAT 6x2 x0.50	DATA CABLE
4808	4.07.0005.1.01.9	AM	6100048	CABLE VDO 8A - T 28
4809	4.07.0006.1.01.1	AM	9900019	CABLE M30 - T28
4810	4.07.0007.1.01.2	LO	115084	LASER CUTOFF CABLE INTERMEDIATE
4811	4.07.0008.1.01.3	LO	115491	CABLE ASSY SERVO VALVE 10 FT PIGTAIL
4812	4.07.0009.1.01.4	LO	128079	PLC CABLE ANALOG 39 IN.; PLC MOD TO IFM
4813	4.07.0010.1.01.5	LO	128080	PLC CABLE ANALOG 39 IN.; PLC MOD TO IFM
4814	4.07.0011.1.01.6	LO	128082	PLC CABLE DIGITAL 39 IN.; PLC MOD TO IFM
4815	4.07.0012.1.01.7	LO	128084	PLC CABLE ANALOG 39 IN; PLC MOD TO IFM
4816	4.07.0013.1.01.8	LO	155255	CABLE CAMERA EXT 10 FT ORIAN VIII
4817	4.07.0014.1.01.9	LO	159313	CABLE ODOMETER 85 FT; ORIAN VIII
4818	4.07.0015.1.01.1	LO	162396	CABLE CONTROL 64 FT ORIAN VIII
4819	4.07.0016.1.01.2	LO	162397	CABLE HEATER 64 FT ORIAN VIII
4820	4.07.0017.1.01.3	LO	162398	CABLE CAMERA 64 FT ORIAN VIII
4821	4.07.0018.1.01.4	LO	162423	CABLE LASER CUTOFF 60 FT ECU TO CUTOFF ENCLOSURE
4822	4.07.0019.1.01.5	LO	163427	KLD ORIAN VIII GP; 110VAC 100 FT CABLE
4823	4.07.0020.1.01.6	LO	163430	CABLE CONTROL 100 FT; ORIAN VIII
4824	4.07.0021.1.01.7	LO	163431	CABLE HEATER 100 FT; ORIAN VIII
4825	4.07.0022.1.01.8	LO	163432	CABLE CAMERA 100 FT; ORIAN VIII
4826	4.07.0023.1.01.9	PL	0.5AWG20BLAU/TSR20-728	WIRE
4827	4.07.0024.1.01.1	PL	BETATrans-35MM2 SUBSTITUTE LAPPTHERM145-35MM2/SCHWARZ	SINGLE CABLE CORE
4828	4.07.0025.1.01.2	PL	ELB-000-00006-EN-0.35M	NETWORK CABLE
4829	4.07.0026.1.01.3	PL	ELB-000-00006-EN-4M	NETWORK CABLE
4830	4.07.0027.1.01.4	PL	ELB-000-00005-EN-6M	NETWORK CABLE
4831	4.07.0028.1.01.5	PL	ELB-000-00006-EN-3M	CABLE PRE ASSEMBLED M12MSD 3M
4832	4.07.0029.1.01.6	PL	PLTHFLEX-4X2X0,15CAT6 PUR SK	NETWORK CABLE
4833	4.07.0030.1.01.7	LO	163429	CABLE LASER CUTOFF 100 FT ECU TO CUTOFF ENCLOSURE
4834	4.07.0031.1.01.8	LO	158377	CABLE DEVICENET CROSSOVER
4835	4.07.0032.1.01.9	LO	163665	CABLE ODOMETER 100FT; ORIAN VIII
4836	4.07.0033.1.01.1	LO	249198	LASER CUTOFF CABLE; INTERMEDIATE
4837	4.07.0034.1.01.2	LO	233941	CCU MAIN POWER CABLE
4838	4.07.0035.1.01.3	LO	252351-78	RAIL PROFILE CABLE KIT
4839	4.07.0036.1.01.4	LO	249194	SH CABLE CAMERA 35FT
4840	4.07.0037.1.01.5	LO	249197	LASER CUTOFF CABLE; 35FT
4841	4.07.0038.1.01.6	LO	100266	COAX CABLE RG-59/U (MIN QTY 10)
4842	4.07.0039.1.01.7	LO	126065	CONNECTOR CORD 0.50 90; CORD RANGE .125-.25
4843	4.07.0040.1.01.8	LO	114824	CONTROLNET CABLE (MIN QTY 10)
4844	4.07.0041.1.01.9	LO	127233	RTD CABLE ASSEMBLY 10FT
4845	4.07.0042.1.01.1	LO	123505	RTD 3 WIRE W/20FT LEAD
4846	4.07.0043.1.01.2	LO	250683	CABLE ASSY 8/4 X 180IN; 86IN FIRESLEEVE
4847	4.07.0044.1.01.3	LO	206263	CABLE ASSEMBLY 15 FT FEEDBACK; SHIELD CASE
4848	4.07.0045.1.01.4	LO	A47375	FIRESLEEVE (MINIMUM QTY 10)
4849	4.07.0046.1.01.5	LO	A84300	FIRESLEEVE .75 ID ORANGE

4850	4.08.0001.1.01.6	PL	31.5001	FUSE SOCKET
4851	4.08.0002.1.01.7	PL	19556	FUSE SOCKET
4852	4.08.0003.1.01.8	PL	19560	FUSE HOLDER
4853	4.08.0004.1.01.9	PL	29554	BRACKET
4854	4.08.0005.1.01.1	PL	1191017003	FUSE/80A
4855	4.08.0006.1.01.2	PL	1191017004	FUSE/30A
4856	4.08.0007.1.01.3	PL	1191017005	FUSE/50A
4857	4.08.0008.1.01.4	PL	1191017006	FUSE/100A
4858	4.08.0009.1.01.5	PL	1191017007	FUSE/125A
4859	4.08.0010.1.01.6	PL	1904520018	FUSE/16A
4860	4.08.0011.1.01.7	PL	0031.7601 SUB. 19560	FUSE HOLDER
4861	4.08.0012.1.01.8	PL	0034.6621 SUB. 19372K/4,0A	FUSE
4862	4.08.0013.1.01.9	PL	0118772-11MN60	BRACKET
4863	4.08.0014.1.01.1	PL	1022-01-32-1000-KURZ	ANGULAR GEAR
4864	4.08.0015.1.01.2	PL	1022-01-32-1428 / SUBS 1022-01-00-142	ANGLE GEAR
4865	4.08.0016.1.01.3	PL	1022-01-35-1000LG	ANGLE GEAR
4866	4.08.0017.1.01.4	PL	1032-04-01-1389 / 1032-04-01-1383	GEAR BOX
4867	4.08.0018.1.01.5	PL	1032-54-01-0356	GEAR BOX
4868	4.08.0019.1.01.6	PL	1080-4-749	SOCKET
4869	4.08.0020.1.01.7	PL	2-05893	STRIP
4870	4.08.0021.1.01.8	PL	272/0,5A	FUSE
4871	4.08.0022.1.01.9	PL	272/1A	FUSE
4872	4.08.0023.1.01.1	PL	272/2A	FUSE
4873	4.08.0024.1.01.2	PL	272/3,15A	FUSE
4874	4.08.0025.1.01.3	PL	272/4A	FUSE
4875	4.08.0026.1.01.4	PL	272/5A	FUSE
4876	4.08.0027.1.01.5	PL	275/1A	FUSE
4877	4.08.0028.1.01.6	PL	275/2A	FUSE
4878	4.08.0029.1.01.7	PL	275/3A	FUSE
4879	4.08.0030.1.01.8	PL	275/4A	FUSE
4880	4.08.0031.1.01.9	PL	280099-0 SUB. 0659055105	PLUG HOUSING/8POL
4881	4.08.0032.1.01.1	PL	5X20/0,2AFLINK SUB. 5X20/200MA	FUSE
4882	4.08.0033.1.01.2	PL	5X20/10AFLINK	FUSE
4883	4.08.0034.1.01.3	PL	5X20/1AFLINK	FUSE
4884	4.08.0035.1.01.4	PL	5X20/2AFLINK	FUSE
4885	4.08.0036.1.01.5	PL	5X20/3,15AFLINK	FUSE
4886	4.08.0037.1.01.6	PL	5X20/4AFLINK	FUSE
4887	4.08.0038.1.01.7	PL	5X20/6,3AFLINK	FUSE
4888	4.08.0039.1.01.8	PL	AK100000	SILICONE OIL
4889	4.08.0040.1.01.9	PL	AK2000	SILICONE OIL
4890	4.08.0041.1.01.1	PL	AK-5000	SILICON OIL
4891	4.08.0042.1.01.2	PL	BU06OZ	SOCKET
4892	4.08.0043.1.01.3	PL	BU08OZ	SOCKET
4893	4.08.0044.1.01.4	PL	BU14OZ	I.C.SOCKET/14POL
4894	4.08.0045.1.01.5	PL	BU16OZ	I.C.SOCKET/16POL
4895	4.08.0046.1.01.6	PL	BU18OZ	I.C.SOCKET/18POL
4896	4.08.0047.1.01.7	PL	BU24OZ(DIL 24MZ)	SOCKET
4897	4.08.0048.1.01.8	PL	BU28DZ	SOCKET
4898	4.08.0049.1.01.9	PL	CNY17/IV	OPTO-COUPLER
4899	4.08.0050.1.01.1	PL	EL-T 271 SA	PLUG
4900	4.08.0051.1.01.2		Shifted to Ann-II	
4901	4.08.0052.1.01.3	PL	EL-T 7126/25 AMPS	CIRCUIT BREAKER
4902	4.08.0053.1.01.4	PL	EL-T 7126/35A	CIRCUIT BREAKER
4903	4.08.0054.1.01.5		Shifted to Ann-II	
4904	4.08.0055.1.01.6	PL	EL-T190.8	PLUG
4905	4.08.0056.1.01.7	PL	EL-T376.282	ANGLE
4906	4.08.0057.1.01.8	PL	EL-T-4111-00 / EL-T-4112-00	RAIL
4907	4.08.0058.1.01.9	PL	EL-T576.08	CHORD WIRE
4908	4.08.0059.1.01.1	PL	EL-T-576-1-35	CHORD WIRE FOR TRANSDUCER
4909	4.08.0060.1.01.2	PL	EL-T596.05	AXLE
4910	4.08.0061.1.01.3	PL	EL-T596.12	SOCKET
4911	4.08.0062.1.01.4	PL	EL-T609.31LI	BRACKET
4912	4.08.0063.1.01.5	PL	EL-T609.31RE	BRACKET
4913	4.08.0064.1.01.6	PL	EL-T67.00C	CARRIER
4914	4.08.0065.1.01.7	PL	EL-T7056S-6POL. SUB. EL-T7056S	PLUG
4915	4.08.0066.1.01.8	PL	EL-T-7059-00	ELECTRIC LIFTING CYLINDER
4916	4.08.0067.1.01.9		Shifted to Ann-II	
4917	4.08.0068.1.01.1		Shifted to Ann-II	
4918	4.08.0069.1.01.2	PL	EL-T82	PLUG
4919	4.08.0070.1.01.3	PL	EL-T953K	BRACKET
4920	4.08.0071.1.01.4	PL	EL-T-966-00	TEST ADAPTER
4921	4.08.0072.1.01.5	PL	HC-49/U SUB. HC-43U	QUARTZ
4922	4.08.0073.1.01.6	PL	JK020014	RAIL
4923	4.08.0074.1.01.7	PL	LA22.5D-100-24VDC	MOTOR
4924	4.08.0075.1.01.8	PL	MBK10	TERMINAL
4925	4.08.0076.1.01.9	PL	MBK3	TERMINAL
4926	4.08.0077.1.01.1	PL	TF183	TRANSISTOR SOCKET

4927	4.08.0078.1.01.2	PL	TF53	TRANSISTOR SOCKET
4928	4.08.0079.1.01.3	PL	UD230.380 POS1.15	CHORD GUIDE DEVICE
4929	4.08.0080.1.01.4	PL	ZKR118	SOCKET
4930	4.08.0081.1.01.5	KE	183834	CIRCUIT BREAKER 15AMPS
4931	4.08.0082.1.01.6	KE	183835	CIRCUIT BREAKER 20AMPS
4932	4.08.0083.1.01.7	LO	100682	CONNECTOR MALE BNC COAX
4933	4.08.0084.1.01.8	LO	103710	FUSE 5 AMP 600 VOLT TIME DELAY
4934	4.08.0085.1.01.9	LO	103715	FUSE 1250 AMP 700 VOLT; HIGH SPEED
4935	4.08.0086.1.01.1	LO	103731	CB 15A 3P 480V ASSY DIN RAIL MOUNT
4936	4.08.0087.1.01.2	LO	103733	CB 30A 3P 480V ASSY DIN RAIL MOUNT
4937	4.08.0088.1.01.3	LO	103736	CB 70A 3P 480V ASSY DIN RAIL MOUNT
4938	4.08.0089.1.01.4	LO	105199	OVERLOAD IEC 64.0-82.0A C-2000 SERIES
4939	4.08.0090.1.01.5	LO	106429	OVERLOAD IEC 2.5-4.1A C2000 SERIES
4940	4.08.0091.1.01.6	LO	109955	FUSE HOLDER TERMINAL BLK
4941	4.08.0092.1.01.7	LO	114497	OVERLOAD E3 PLUS 9-45A FOR 100-C30...C43
4942	4.08.0093.1.01.8	LO	115991	CONT OL 5.4-27.0A FOR 100-C09..100-C23
4943	4.08.0094.1.01.9	LO	115992	CONT OL 1.0-5.0A FOR 100-C09..100-C23
4944	4.08.0095.1.01.1	LO	116399	CB 63A 1P 480V
4945	4.08.0096.1.01.2	LO	116658	CB 2500A 3P 600V CRADLE; E3 FRAME DRAWOUT
4946	4.08.0097.1.01.3	LO	117535	CB 15A 3P 480V T1 FRAME MOLDED CASE
4947	4.08.0098.1.01.4	LO	117536	CB 20A 3P 480V; T1 FRAME MOLDED CASE
4948	4.08.0099.1.01.5	LO	118944	CB DISC CABLE; 36 INCH
4949	4.08.0100.1.01.6	LO	120600	TERMINAL FEMALE MOTOR #6; PIGTAIL CONNECTOR
4950	4.08.0101.1.01.7	LO	123729	CB 2.5A 3P 480V 1.6A-2.5A OVERLOAD
4951	4.08.0102.1.01.8	LO	123731	CB 10A 3P 480V 6.3A-10.0A OVERLOAD
4952	4.08.0103.1.01.9	LO	123732	CB 16A 3P 480V 10.0A-16.0A OVERLOAD
4953	4.08.0104.1.01.1	Shifted to Ann-II		
4954	4.08.0105.1.01.2	LO	123739	CB 90A 3P 480V 63.0A-90.0A OVERLOAD
4955	4.08.0106.1.01.3	LO	123825	CB 63A 2P 480V 30MA GFI PROTECTION
4956	4.08.0107.1.01.4	LO	124236	CB 16A 2P 480V
4957	4.08.0108.1.01.5	LO	126512	CB 175A 3P 600V S3 FRAME MOLDED CASE
4958	4.08.0109.1.01.6	LO	126631	CB 400A 3P 600V S5 FRAME MOULDED CASE
4959	4.08.0110.1.01.7	LO	126849	STANDOFF THRD MALE/FEMALE; .25X2.00 8-32 THREAD
4960	4.08.0111.1.01.8	LO	128989	CB 250A 3P 600V HIGH; T4 FRAME MOLDED CASE
4961	4.08.0112.1.01.9	LO	129614	CB 80A 3P 480V ASSY DIN RAIL MOUNT
4962	4.08.0113.1.01.1	LO	134679	TERMINAL MALE MOTOR #8; PIGTAIL CONNECTOR
4963	4.08.0114.1.01.2	LO	134826	CB 100A 4P 480V; 30MA GFI PROTECTION
4964	4.08.0115.1.01.3	Shifted to Ann-II		
4965	4.08.0116.1.01.4	LO	162554	CB DISC HANDLE; FLANGE
4966	4.08.0117.1.01.5	Shifted to Ann-II		
4967	4.08.0118.1.01.6	Repeated item		
4968	4.08.0118.1.01.6	PL	1022-01-32-1428 SUBSTITUTE 1022-01-00-142	ANGLEGEAR
4969	4.08.0119.1.01.7	PL	1904520016	FUSE/8A
4970	4.08.0120.1.01.8	PL	2155-STECKER	PLUG
4971	4.08.0121.1.01.9	Shifted to Ann-II		
4972	4.08.0122.1.01.1	PL	8JD005993-032 SUBSTITUTE 0986354003	FUSE BOX
4973	4.08.0123.1.01.2	PL	BU24OZ(DIL24MZ)	SOCKET
4974	4.08.0124.1.01.3	PL	BU28OZ SUBSTITUTE 641894-1	SOCKET
4975	4.08.0125.1.01.4	PL	EL-T7056S-6POL. SUBSTITUTE EL-T7056S	PLUG
4976	4.08.0126.1.01.5	PL	RM78705	SOCKET
4977	4.08.0127.1.01.6	Shifted to Ann-II		
4978	4.08.0128.1.01.7	Shifted to Ann-II		
4979	4.08.0129.1.01.8	PL	EL-T7126/20A	CIRCUIT BREAKER
4980	4.08.0130.1.01.9	Shifted to Ann-II		

4981	4.08.0131.1.01.1	Shifted to Ann-II		
4982	4.08.0132.1.01.2	PL	EL-T7126/40A	CIRCUIT BREAKER
4983	4.08.0133.1.01.3	Shifted to Ann-II		
4984	4.08.0134.1.01.4	Shifted to Ann-II		
4985	4.08.0135.1.01.5	LO	A87499	TERMINAL MALE MOTOR; PIGTAIL CONNECTOR
4986	4.08.0136.1.01.6	LO	A87500	TERMINAL FEMALE MOTOR PIGTAIL CONNECTOR
4987	4.08.0137.1.01.7	LO	B90411	CIRCUIT BREAKER 20 AMP 277VAC 3 POLE
4988	4.08.0138.1.01.8	KA	MCBI 461267.000 (India)	Logic Module Siemens Log O.12/24
4989	4.08.0139.1.01.9	GE	G2A-G11/2 NBR/P460NH	Connector-1
4990	4.08.0140.1.01.1	GE	1CN-22-08	Connector-2
4991	4.08.0141.1.01.2	GE	1CN-18-08	Connector-3
4992	4.08.0142.1.01.3	GE	1CN-18-06	Connector-4
4993	4.08.0143.1.01.4	GE	1CB-14-06	Connector-5
4994	4.08.0144.1.01.5	GE	2C9-14	Connector-6
4995	4.08.0145.1.01.6	GE	2C9-18	Connector-7
4996	4.08.0146.1.01.7	GE	1CB-30-12	Connector-8
4997	4.08.0147.1.01.8	GE	1CB-18-06	Connector-9
4998	4.08.0148.1.01.9	GE	1CB-14-04	Connector-10
4999	4.08.0149.1.01.1	GE	2C9-30	Connector-11
5000	4.08.0150.1.01.2	GE	1CN-36-16	Connector-12
5001	4.08.0151.1.01.3	GE	2C9-22	Connector-13
5002	4.08.0152.1.01.4	GE	1CN-18-04	Connector-14
5003	4.08.0153.1.01.5	GE	2C9-36	Connector-15
5004	4.08.0154.1.01.6	GE	1CB-22-08	Connector-16
5005	4.08.0155.1.01.7	GE	1CB-36-16	Connector-17
5006	4.08.0156.1.01.8	GE	YS02300002	Spare plug kit (Set)
5007	4.08.0157.1.01.9	CR	40100378-112	PLUG
5008	4.08.0158.1.01.1	CR	40107997	CONNECTOR
5009	4.08.0159.1.01.2	PL	EL-AM50.01	CAN BUS TERIMINAL PLUG
5010	4.08.0160.1.01.3	PL	192.168.0.54	MACHINE DATE CONNECTOR
5011	4.08.0161.1.01.4	PL	3600-P10-S1-5A-2350	CIRCUIT BREAKER
5012	4.08.0162.1.01.5	PL	3600-P10-S1-8A-2350	CIRCUIT BREAKER
5013	4.08.0163.1.01.6	PL	3600-P10-S1-15A-2350	CIRCUIT BREAKER
5014	4.08.0164.1.01.7	PL	3600-P10-S1-16A-2350	CIRCUIT BREAKER
5015	4.08.0165.1.01.8	CR	IC65H-DC 16/1P-C	CIRCUIT BREAKER-1
5016	4.08.0166.1.01.9	CR	IC65H-DC 10/1P-C	CIRCUIT BREAKER-2
5017	4.08.0167.1.01.1	CR	IC65H-DC 6/1P-C	CIRCUIT BREAKER-3
5018	4.08.0168.1.01.2	CR	IC65H-DC 20/1P-C	CIRCUIT BREAKER-4
5019	4.08.0169.1.01.3	CR	IC65H-DC 25/1P-C	CIRCUIT BREAKER-5
5020	4.08.0170.1.01.4	CR	IC65H-DC 40/1P-C	CIRCUIT BREAKER-6
5021	4.08.0171.1.01.5	CR	0.8MM	CHORD WIRE
5022	4.08.0172.1.01.6	CR	0.5MM	CHORD WIRE
5023	4.08.0173.1.01.7	PL	PVE32/157B4992	Amp plug(proportional valves)
5024	4.08.0174.1.01.8	PL	FFA.2E.304.CLAC60ZN	Plug 4pol(Inclinometer plug)
5025	4.08.0175.1.01.9	PL	FMK1	Connector housing/9 pins(communication cable plug)
5026	4.08.0176.1.01.1	PL	S-8.81.1	DOUBLE VALVE PLUG 107MM
5027	4.08.0177.1.01.2	PL	S-8.82.1	DOUBLE VALVE PLUG 134MM
5028	4.08.0178.1.01.3	PL	289-405	Transfer connection module
5029	4.08.0179.1.01.4	PL	ERB.2E.305.CLL	SOCKET 5 POLES
5030	4.08.0180.1.01.5	PL	TN-5305-T	ETHERNET SWITCH
5031	4.08.0181.1.01.6	PL	TN-5308-LV-T	ETHERNET SWITCH
5032	4.08.0182.1.01.7	PL	EL-T904-00005-2-84	PLUG ADAPTOR
5033	4.08.0183.1.01.8	PL	VS-08-RJ45-10G/Q	CONNECTOR RJ45
5034	4.08.0184.1.01.9	LO	143520	ETHERNET SWITCH; 4 PORT RJ45 MANAGED
5035	4.08.0185.1.01.1	LO	143523	CONN PLUG RJ45 IP 20
5036	4.08.0186.1.01.2	LO	100267	CONNECTOR MALE BNC COAX
5037	4.08.0187.1.01.3	LO	252351-216	CIRCUIT BREAKER REPLACEMENT KIT #1
5038	4.08.0188.1.01.4	LO	106307	TERMINAL BLOCK 10mm SINGLE LEVEL
5039	4.08.0189.1.01.5	LO	252351-21	CIRCUIT BREAKER REPLACEMENT KIT - SMALL
5040	4.08.0190.1.01.6	LO	116526	CONTROLNET Y-TAP STRAIGHT CONNECTOR
5041	4.08.0191.1.01.7	LO	117076	CONNECTOR BNC PLUG CONTROLNET CABLE
5042	4.08.0192.1.01.8	LO	129957	ISOLATOR
5043	4.08.0193.1.01.9	LO	251921	CIRCUIT BREAKER 15A 3P 600V; XT1 FIXED MOLDED CASE
5044	4.08.0194.1.01.1	LO	125996	TERMINAL BLOCK 5MM 3COND SINGLE SPRING CLAMP

5045	4.08.0195.1.01.2	LO	125998	TERMINAL BLOCK 5MM 3COND GND SINGLE SPRING CLAMP
5046	4.08.0196.1.01.3	LO	125999	TERMINAL BLOCK 5MM JUMPER 2POS SINGLE SPRING CLAMP
5047	4.08.0197.1.01.4	LO	126002	TERMINAL BLOCK END CLAMP SCREWLESS
5048	4.08.0198.1.01.5	LO	252351-57	CIRCUIT BREAKER REPLACEMENT KIT - MEDIUM
5049	4.08.0199.1.01.6	LO	252351-64	LARGE CIRCUIT BREAKER KIT
5050	4.08.0200.1.01.7	LO	160405	TERMINAL BLOCK 6mm 4COND FUSE SENSOR; SPRING CLAMP
5051	4.08.0201.1.01.8	LO	160406	TERMINAL BLOCK 5mm SENSOR SUPPLY SPRING CLAMP
5052	4.08.0202.1.01.9	LO	160407	TERMINAL BLOCK 6mm FUSE HOLDER PLUG
5053	4.08.0203.1.01.1	LO	160409	TERMINAL BLOCK 5mm SUPPLY END COVER; FOR SENSOR SUPPLY BLOCK
5054	4.08.0204.1.01.2	LO	164649	CONN MOTOR FEMALE #8; PIGTAIL
5055	4.08.0205.1.01.3	LO	252351-79	CIRCUIT BREAKER REPLACEMENT KIT - MEDIUM
5056	4.08.0206.1.01.4	LO	252351-86	ELECTRICAL CIRCUIT BREAKER KIT
5057	4.08.0207.1.01.5	LO	252351-99	LARGE CIRCUIT BREAKER KIT #2
5058	4.08.0208.1.01.6	LO	252351-101	ELECTRICAL CIRCUIT BREAKER KIT
5059	4.08.0209.1.01.7	LO	154531	PLUG DESICCANT (SMALL)
5060	4.08.0210.1.01.8	LO	A15515	GRIP CORD
5061	4.08.0211.1.01.9	LO	A17659	CONNECTOR CORD
5062	4.08.0212.1.01.1	LO	A19008	GRIP CORD
5063	4.08.0213.1.01.2	LO	A21987	CORD CONNECTOR
5064	4.08.0214.1.01.3	LO	A25487	CONNECTOR SEALTITE STR 1.00
5065	4.08.0215.1.01.4	LO	A25488	CONNECTOR 1 90 DEG
5066	4.08.0216.1.01.5	LO	A79519	CONNECTOR CORD
5067	4.08.0217.1.01.6	LO	107396	CORD CONNECTOR 1/2
5068	4.09.0001.1.01.7	PL	390507512	WIPER MOTOR
5069	4.09.0002.1.01.8	PL	EL-T9017.00	MOTOR
5070	4.09.0003.1.01.9	PH	4P26	D.C. MOTOR
5071	4.09.0004.1.01.1	PH	UTVI-10-01/00	WIPER MOTOR
5072	4.09.0005.1.01.2	LO	112275	FAN ASSY NO DWG
5073	4.09.0006.1.01.3	LO	112871	PILOT LIGHT CLEAR TRANSFORMER 120VAC
5074	4.09.0007.1.01.4	LO	112872	PILOT LIGHT RED; FULL VOLTAGE 24V AC/DC
5075	4.09.0008.1.01.5	LO	112887	PILOT LIGHT GREEN; FULL VOLTAGE 24V AC/DC
5076	4.09.0009.1.01.6	LO	112888	PILOT LIGHT AMBER FULL VOLTAGE 24V AC/DC
5077	4.09.0010.1.01.7	LO	117436	MOTOR GRINDING 30HP EXTENDED LIFE
5078	4.09.0011.1.01.8	LO	118351	PILOT LIGHT RED; TRANSFORMER 24 AC/DC
5079	4.09.0012.1.01.9	LO	118352	PILOT LIGHT GREEN; TRANSFORMER 24 AC/DC
5080	4.09.0013.1.01.1	LO	118408	MOTOR COLLECTOR BLOWER
5081	4.09.0014.1.01.2	LO	125951	PILOT LIGHT WHITE; FULL VOLTAGE 24V AC/DC
5082	4.09.0015.1.01.3	LO	125952	PILOT LIGHT AMBER; TRANSFORMER 120V AC
5083	4.09.0016.1.01.4	LO	126828	BLOWER 1970 CFM 120V DUAL TURBINE
5084	4.09.0017.1.01.5	LO	127805	MOTOR 30 HP
5085	4.09.0018.1.01.6	LO	156590	GENERATOR BLOWER RH MOD; 15 HP 3530 RPM
5086	4.09.0019.1.01.7	LO	158625	FAN MOTOR 1.5HP TEFC
5087	4.09.0020.1.01.8	LO	160730	HID HEADLIGHT RHS; COMBINED LED/TAIL MARKER
5088	4.09.0021.1.01.9	LO	160731	HID HEADLIGHT LHS; COMBINED LED/TAIL MARKER
5089	4.09.0022.1.01.1	LO	167054	LEESON MOTOR; 1-1/2 HP
5090	4.09.0023.1.01.2	LO	169276	TRACTION MOTOR COMBO; HYATT 6.5X12 BRG 1676 GA
5091	4.09.0024.1.01.3	LO	A79548	MOTOR 3/4 HP
5092	4.09.0025.1.01.4	LO	C83251	STROBE-BLUE 24VDC
5093	4.09.0026.1.01.5	LO	DRW90.44.13.000 (ME241)	ELECTRICAL MOTOR WITH REDUCTION GEAR.
5094	4.09.0027.1.01.6	LO	105-5081 (C9)	SELF STARTER
5095	4.09.0028.1.01.7	LO	105-5081 (C18)	SELF STARTER
5096	4.09.0029.1.01.8	LO	81769643	ALTERNATOR
5097	4.09.0030.1.01.9	LO	81852021	ALTERNATOR (POWER PACK)
5098	4.09.0031.1.01.1	LO	265.90B	DIESEL DOSE PUMP

5099	4.09.0032.1.01.2	PL	28V1,4WT5,5	INDICATION BULB
5100	4.09.0033.1.01.3	PL	31-963.2/28V	INDICATION BULB
5101	4.09.0034.1.01.4	PL	6-28V/P2-62	TEST LAMP
5102	4.09.0035.1.01.5	PL	879.94A SUBSTITUTE 805.22A	ELECTRIC MOTOR
5103	4.09.0036.1.01.6	PL	RMEL276A	Axial Fan
5104	4.09.0037.1.01.7	GE	GLLT008N-1AAWXX	LED floodlight
5105	4.09.0038.1.01.8		Shifted to Ann -II	
5106	4.09.0039.1.01.9		Shifted to Ann -II	
5107	4.09.0040.1.01.1	DE	0118 3716/0150A-44-001	SELF STARTER 24W.0KW
5108	4.09.0041.1.01.2	CU	4996709 (CUMMINS)	SELF STARTER
5109	4.09.0042.1.01.3		Shifted to Ann -II	
5110	4.09.0043.1.01.4	CA	4351240CW	SELF STARTER
5111	4.09.0044.1.01.5		Shifted to Ann -II	
5112	4.09.0045.1.01.6	LO	110766	WIPER MOTOR
5113	4.09.0046.1.01.7	LO	113044	WATER PUMP AND MOTOR 30HP 3600RPM 3PH TEFC
5114	4.09.0047.1.01.8	LO	132978	MOTOR SPRING CHARGING 110- 130VAC/DC
5115	4.09.0048.1.01.9	LO	134112	RING OUTER SEAL(PLASTIC); TRACTION MOTOR GEARCASE
5116	4.09.0049.1.01.1	LO	134113	RING INNER SEAL(PLASTIC); TRACTION MOTOR GEARCASE
5117	4.09.0050.1.01.2	LO	123660	SEAL PINOIN PLASTIC; TRACTION MOTOR GEARCASE
5118	4.09.0051.1.01.3	LO	108696	BATTERY BOX
5119	4.09.0052.1.01.4	LO	236442	ROTOR EXCITER;WITH RECTIFIER ASSY
5120	4.09.0053.1.01.5	LO	125690	STATOR EXCITER
5121	4.09.0054.1.01.6	LO	B65877	MOTOR ELECT 30 HP 1800 RPM/286TC W/FEET
5122	4.09.0055.1.01.7	LO	245778	LIGHT 24VDC UPGRADE KIT FOR OBSOLETE 116515 LIGHT ASSEMBLY
5123	4.09.0056.1.01.8	LO	207451	MOTOR VERTICAL SHAFT; 2.25OD 1.75ID 19.62LG
5124	4.09.0057.1.01.9	LO	252351-13	LIGHT KIT #2
5125	4.09.0058.1.01.1	LO	252351-14	LIGHT KIT #3
5126	4.09.0059.1.01.2	LO	252351-16	LIGHT KIT #5
5127	4.09.0060.1.01.3	LO	114116	LABEL-HIGH VOLTAGE 4.5 ISO3864 WARNING DECAL
5128	4.09.0061.1.01.4	LO	252351-23	LIGHT KIT #6
5129	4.09.0062.1.01.5	LO	252351-25	LIGHT KIT #7
5130	4.09.0063.1.01.6	LO	252351-36	LIGHT KIT #8
5131	4.09.0064.1.01.7	LO	252351-37	LIGHT KIT #9
5132	4.09.0065.1.01.8	LO	210126	LIGHT FIX LED; 24VDC 8W
5133	4.09.0066.1.01.9	LO	252351-45	LIGHT KIT #10
5134	4.09.0067.1.01.1	LO	237682	LIGHT FIX LED; 24VDC 19W
5135	4.09.0068.1.01.2	LO	A71538	LAMP 1000W NSP
5136	4.09.0069.1.01.3	LO	252351-105	LIGHT KIT #11
5137	4.10.0001.1.01.8	PL	EK-504CA-00C	R-ADAPTER FOR CMS SYSTEM
5138	4.10.0002.1.01.9	PL	EL-08-1.0138-B92B	CONTROL BOX
5139	4.10.0003.1.01.1	PL	EL-T7087/1.5A	EL.REMOTE CONTROL
5140	4.10.0004.1.01.2	PL	EL-T7163.00-A SUB. E L-T7163.00 (4SENS)	CONTROL UNIT
5141	4.10.0005.1.01.3	LO	105418	METER BOARD
5142	4.10.0006.1.01.4	LO	120128	COMPUTER ASSY ANALYSIS REMOVAL W/DATA COLLECTION - REQUIRES SETUP PRIOR TO DISPATCH
5143	4.10.0007.1.01.5	LO	148049	DB 1P 510A 600V 2LI 4LD
5144	4.10.0008.1.01.6		Shifted to Ann-II	
5145	4.10.0009.1.01.7	LO	160638	COMPUTER
5146	4.10.0010.1.01.8	LO	160639	ECU
5147	4.10.0011.1.01.9	LO	166697	COMPUTER RACK ASSY; RGI CAMP CAR
5148	4.10.0012.1.01.1	LO	171815	COMP DUOCORE 2.8 GHZ 160GB RAID 2GB RAM
5149	4.10.0013.1.01.2	PL	EL-T 631	Mike
5150	4.10.0014.1.01.3	PL	EL-T 631.11A	Microphone stuckbar
5151	4.10.0015.1.01.4	PL	DR4-29	Lowdspeaker
5152	4.10.0016.1.01.5	CR	6ES7516-3AN01-0AB0	CPU
5153	4.10.0017.1.01.6	PL	S-7.5.41	DECT-Multi interface DIG/NIMH
5154	4.10.0018.1.01.7	PL	S-7.5.42	DECT/AGS-headset digital NIMH
5155	4.10.0019.1.01.8	PL	CPU/3-0228-0150/1	CPU/PROGRAM
5156	4.10.0020.1.01.9	PL	CPU/3-0228-0270	CPU/PROGRAM
5157	4.10.0021.1.01.1	PL	CPU/3-0228-0271	CPU/PROGRAM
5158	4.10.0022.1.01.2	PL	MM1/2-CWS-1	MC TERMINAL /PROG
5159	4.10.0023.1.01.3	PL	171050	COLOUR CAMERA
5160	4.10.0024.1.01.4	PL	EL-T631.04B	MICROPHONE
5161	4.10.0025.1.01.5	PL	EL-T5201.03B/3.5M	CONNECTING CABLE ALC

5162	4.10.0026.1.01.6	PL	EL-T5558.03B/3.5M	CONNECTING CABLE ALC
5163	4.10.0027.1.01.7	PL	ELB-M00-02-003-MCL113	DATAMATIC MODULE
5164	4.10.0028.1.01.8	PL	ELB-M00-02-000-MCL113	DATAMATIC MODULE
5165	4.10.0029.1.01.9	PL	ELB-M00-02-000-MCL129	DATA MATIC
5166	4.10.0030.1.01.1	PL	ELB-M00-02-001-MCL129	DATAMATIC
5167	4.10.0031.1.01.2	PL	ELB-SM0-30-A-100-MCL123	ALC CARD
5168	4.10.0032.1.01.3	LO	163156	SEQUENCE MONITOR ASSY, 15 INCH MONITOR
5169	4.10.0033.1.01.4	LO	131137	COMP MONITOR 15.1 LCD COLOUR ACTIVE MATRIX
5170	4.10.0034.1.01.5	LO	154938	COMP KEY BOARD W/HULA POINT USB 116 KEY LAY OUT
5171	4.10.0035.1.01.6	LO	164835	RECEPTACLE COMPUTER SPEC ETHERNET/120V
5172	4.10.0036.1.01.7	LO	179889	MONITOR COLOR ASSY
5173	4.10.0037.1.01.8	LO	C83658	CAMERA DIGITAL PROCESSING 120VAC
5174	4.10.0038.1.01.9	LO	138883	POWVIEW MURPHY
5175	4.10.0039.1.01.1	LO	146606	METER MULTI-FUNCTION POWER MONITOR MODBUS
5176	4.10.0040.1.01.2	LO	250898	SH CAMERA WINDOW ASSY; RGMS
5177	4.10.0041.1.01.3	LO	249447	COMPUTER ASSY; RGMS IV
5178	4.10.0042.1.01.4	LO	247417	PLC 1756 CONTROLLER; CONTROLLOGIX 10M RAM
5179	4.10.0043.1.01.5	LO	248165	COMPUTER ASSY CONTROLS; WIN10 ENT
5180	4.10.0044.1.01.6	LO	249435	COMPUTER ASSY; RAILPRO RGMS IV RSLINX
5181	4.10.0045.1.01.7	LO	249183	ELECTRONIC CONTROL UNIT
5182	4.10.0046.1.01.8	LO	252351-139	COMPUTER SYSTEM MAINTENANCE KIT, SMALL
5183	4.10.0047.1.01.9	LO	252351-140	COMPUTER SYSTEM MAINTENANCE KIT, LARGE
5184	4.10.0048.1.01.1	LO	252351-141	COMPUTER SYSTEM REPAIR KIT, SMALL
5185	4.10.0049.1.01.2	LO	252351-142	COMPUTER SYSTEM REPAIR KIT, LARGE
5186	4.10.0050.1.01.3	LO	252351-186	PLC SYSTEM MAINTENANCE KIT, SMALL
5187	4.10.0051.1.01.4	LO	252351-187	PLC SYSTEM MAINTENANCE KIT, LARGE
5188	4.10.0052.1.01.5	LO	252351-188	PLC SYSTEM REPAIR KIT, SMALL
5189	4.10.0053.1.01.6	LO	252351-189	PLC SYSTEM REPAIR KIT, LARGE
5190	4.10.0054.1.01.7	LO	252351-190	PLC SYSTEM OVERHAUL KIT
5191	4.10.0055.1.01.8	LO	158994	METER RATE INDICATOR 9-28 VDC
5192	4.10.0056.1.01.9	PL	ELW-SM0-01	DISPLAY INSTRUMENT
5193	4.10.0057.1.01.1	PL	ELW-SM0-01-UL	DISPLAY INSTRUMENT
5194	4.10.0058.1.01.2	PL	ELW-SM0-01-1U	DISPLAY INSTRUMENT
5195	4.10.0059.1.01.3	PL	223100	COLOUR MONITOR
5196	4.10.0060.1.01.4	PL	MMI/ 1-0046-1	TOUCH SCREEN 8"
5197	4.10.0061.1.01.5	PL	MMI/ 1-0046-2	TOUCH SCREEN 12"
5198	4.10.0062.1.01.6	PL	MMI/ 1-0046-3	TOUCH SCREEN 8"
5199	5.01.0001.1.01.9	PL	0.06348395	SOCKET
5200	5.01.0002.1.01.1	ZF	0.461622103	PRESSURE LINE
5201	5.01.0003.1.01.2	ZF	0.461622104	PRESSURE LINE
5202	5.01.0004.1.01.3	ZF	0.461622105	PRESSURE LINE
5203	5.01.0005.1.01.2	ZF	0635-290-062	PLATE
5204	5.01.0006.1.01.5	ZF	36801165	SEALING RING
5205	5.01.0007.1.01.6	ZF	501315338	VALVE
5206	5.01.0008.1.01.7	ZF	501319251	SOLENOID VALVE
5207	5.01.0009.1.01.8	ZF	630302095	AXLE NEEDLE CAGE
5208	5.01.0010.1.01.9	ZF	630601006	TAB WASHER
5209	5.01.0011.1.01.1	ZF	630703032	TAB WASHER
5210	5.01.0012.1.01.2	ZF	634300185	SHAFT SEAL/SHAFT GEAR
5211	5.01.0013.1.01.3	ZF	634305009	PISTON RING
5212	5.01.0014.1.01.4	ZF	634305042	PISTON RING
5213	5.01.0015.1.01.5	ZF	634305093	PISTON RING
5214	5.01.0016.1.01.6	ZF	634306047	'O' RING
5215	5.01.0017.1.01.7	ZF	634306242	O RING
5216	5.01.0018.1.01.8	ZF	634306323	O RING
5217	5.01.0019.1.01.9	ZF	634402029	PISTON RING
5218	5.01.0020.1.01.1	ZF	634402140	PISTON RING
5219	5.01.0021.1.01.2	ZF	634801038	SEALING RING
5220	5.01.0022.1.01.3	ZF	634801045	SEALING RING
5221	5.01.0023.1.01.4	ZF	634801057	SEALING RING
5222	5.01.0024.1.01.5	ZF	634801074	SEALING RING
5223	5.01.0025.1.01.6	ZF	634801152	SEALING RING

5224	5.01.0026.1.01.7	ZF	634801165	SEALING RING
5225	5.01.0027.1.01.8	ZF	634801200	SEALING RING
5226	5.01.0028.1.01.9	ZF	634801205	SEALING RING
5227	5.01.0029.1.01.1	ZF	634801215	SEALING RING
5228	5.01.0030.1.01.2	ZF	634801227	SEALING RING
5229	5.01.0031.1.01.3	ZF	635290061	CASING DISC
5230	5.01.0032.1.01.4	ZF	635290062	SHAFT WASHER
5231	5.01.0033.1.01.5	ZF	635303056	NEEDLE SLEEVE
5232	5.01.0034.1.01.6	ZF	636015110	HEXAGON SCREW
5233	5.01.0035.1.01.7	ZF	636610109	STUD
5234	5.01.0036.1.01.8	ZF	636610127	STUD
5235	5.01.0037.1.01.9	ZF	636610177	STUD
5236	5.01.0038.1.01.1	ZF	637512004	SLOTTED NUT
5237	5.01.0039.1.01.2	ZF	637835003	UNION SCREW
5238	5.01.0040.1.01.3	ZF	637835005	UNION SCREW
5239	5.01.0041.1.01.4	ZF	637835006	UNION SCREW
5240	5.01.0042.1.01.5	ZF	732000072	CUP SPRING FOR ZF GEAR BOX
5241	5.01.0043.1.01.6	ZF	732040265	COMPRESSION SPRING
5242	5.01.0044.1.01.7	ZF	732040266	COMPRESSION SPRING
5243	5.01.0045.1.01.8	ZF	732040834	COMPRESSION SPRING
5244	5.01.0046.1.01.9	ZF	732040835	COMPRESSION SPRING
5245	5.01.0047.1.01.1	ZF	732040836	COMPRESSION SPRING
5246	5.01.0048.1.01.2	ZF	732040838	COMPRESSION SPRING
5247	5.01.0049.1.01.3	ZF	732041229	COMPRESSION SPRING
5248	5.01.0050.1.01.4	ZF	732041230	COMPRESSION SPRING
5249	5.01.0051.1.01.5	ZF	737835010	UNION SCREW
5250	5.01.0052.1.01.6	ZF	750131060	Z.F.FILTER ELEMENT
5251	5.01.0053.1.01.7	ZF	900021267	PLUG
5252	5.01.0054.1.01.8	PL	1010306005	SET OF SCREW
5253	5.01.0055.1.01.9	ZF	1019323053	COMPRESSION SPRING
5254	5.01.0056.1.01.1	ZF	1203306017	COMPRESSION SPRING
5255	5.01.0057.1.01.2	ZF	1203306019	COMPRESSION SPRING
5256	5.01.0058.1.01.3	ZF	1419306063	PISTON
5257	5.01.0059.1.01.4	ZF	4044306026	GASKET
5258	5.01.0060.1.01.5	ZF	4044306288	GASKET
5259	5.01.0061.1.01.6	ZF	4044306494	GASKET
5260	5.01.0062.1.01.7	ZF	4166041011	CONVERTER CPL
5261	5.01.0063.1.01.8	ZF	4166341177	GASKET
5262	5.01.0064.1.01.9	ZF	4609220002	Set of Converter Pressure valve (FIG 080-150)
5263	5.01.0065.1.01.1	ZF	634801098	Sealing Ring
5264	5.01.0066.1.01.2	ZF	636305023	Screw Plug
5265	5.01.0067.1.01.3	ZF	4609320002	Valve Sleeve
5266	5.01.0067.1.01.3	ZF	731201446	Cylindrical Pin Part No.
5267	5.01.0068.1.01.4	ZF	4068306029	Piston
5268	5.01.0069.1.01.5	ZF	730001828	Spring
5269	5.01.0070.1.01.6	ZF	630532004	Washer
5270	5.01.0071.1.01.7	ZF	4616105058	HYD AXLE CUT OFF / ZF AXLE DISENGAGER
5271	5.01.0072.1.01.8	ZF	4616120001	Set of Converter Relief valve for Z.F. Gear Box
5272	5.01.0073.1.01.9	ZF	635460095	Ball
5273	5.01.0074.1.01.1	ZF	732040021	Compression spring Ring
5274	5.01.0075.1.01.2	ZF	4616221012	LUBRICATION PIPE
5275	5.01.0076.1.01.3	ZF	4616221018	SUCTION TUBE
5276	5.01.0077.1.01.4	ZF	4616221026	LUBRICATION PIPE
5277	5.01.0078.1.01.5	ZF	4616221035	PRESSURE LINE
5278	5.01.0079.1.01.6	ZF	4616221038	PRESSURE LINE
5279	5.01.0080.1.01.7	ZF	4616221040	LUBRICATION PIPE
5280	5.01.0081.1.01.8	ZF	4616221049	PIPE
5281	5.01.0082.1.01.9	ZF	4616221899	UNION SCREW
5282	5.01.0083.1.01.1	ZF	4616301036	GASKET
5283	5.01.0084.1.01.2	ZF	4616301083	GASKET
5284	5.01.0085.1.01.3	ZF	4616301175	HOUSING
5285	5.01.0086.1.01.4	ZF	4616303171	OUTPUT SHAF
5286	5.01.0087.1.01.5	ZF	4616305001	OUTPUT SHAFT
5287	5.01.0088.1.01.6	ZF	4616306086	GASKET
5288	5.01.0089.1.01.7	ZF	4616306088	GASKET
5289	5.01.0090.1.01.8	ZF	4616306091	GASKET
5290	5.01.0091.1.01.9	ZF	4616307002	SPEEDO SHAFT
5291	5.01.0092.1.01.1	ZF	4616307005	SPEEDO CONN. PCB
5292	5.01.0093.1.01.2	ZF	4616321056	THREADED BUSH
5293	5.01.0094.1.01.3	ZF	4616321057	SPACER BUSH
5294	5.01.0095.1.01.4	ZF	4616329022	GASKET
5295	5.01.0096.1.01.5	ZF	4616336009	GASKET
5296	5.01.0097.1.01.6	ZF	4620306312	GASKET
5297	5.01.0098.1.01.7	ZF	4627306007	PROTECTING CAP

5298	5.01.0099.1.01.8	ZF	4644306001	GEAR SHIFT HOUSING
5299	5.01.0100.1.01.9	ZF	4644306010	PISTON
5300	5.01.0101.1.01.1	ZF	4644306050	ORIFICE
5301	5.01.0102.1.01.2	ZF	4644306488	GASKET
5302	5.01.0103.1.01.3	ZF	4644306490	GASKET
5303	5.01.0104.1.01.4	ZF	4646362013	FLANGE SHAFT
5304	5.01.0105.1.01.5	ZF	0501-319-202	SOL VALVE
5305	5.01.0106.1.01.6	ZF	0630 502 007	RETAINING RING
5306	5.01.0107.1.01.7	ZF	0630-001-012=72, 0630-001-037=54,0630-000-874=1,0630-001-828=4 ,0730-002-635=1, 0730-002-137=4,0730-002-626=5,0730-004-291=1, 0730-004-292=1, 0730-101-795=3	SET OF WASHER FOR ZF GEAR BOX
5307	5.01.0108.1.01.8	ZF	0630-302-095,0635-290-061,0635-290-620	AXLE NEEDLE CAGE 0630-302-095
5308	5.01.0109.1.01.9	ZF	0635-290-062-16080	PLATE
5309	5.01.0110.1.01.1	ZF	0630-361-033	SEALING CAP FOR ZF GEAR BOX
5310	5.01.0111.1.01.2	ZF	0630-361-052	SEALING CAP FOR ZF GEAR BOX
5311	5.01.0112.1.01.3	ZF	0630-501-025=2, 0630-501-031=1, 0630-501-035=1, 0630-501-039=1, 0630-501-046=4, 0630-501-048=1, 0630-501-050=3, 0630-501-052=1, 0630-501-054=2, 0630-501-060=2	SET OF RETAINING RING FOR ZF GEAR BOX CONSISTING OF:
5312	5.01.0113.1.01.4	ZF	0630503010,0630503015,0630513092,0630503023,0635513045,0630513078, 0630513125	SET OF SNAPING RING FOR ZF GEAR BOX
5313	5.01.0114.1.01.5	ZF	0631-306-179	CYLINDER PIN FOR ZF GEAR BOX
5314	5.01.0115.1.01.6	ZF	0631-359-001	SLOTTED PLUG FOR ZF GEAR BOX
5315	5.01.0116.1.01.7	ZF	0631-501-213	FITTING KEY FOR ZF GEAR BOX
5316	5.01.0117.1.01.8	ZF	0631-511-036	WOODRUFF KEY FOR ZF GEAR BOX
5317	5.01.0118.1.01.9	ZF	0634 -303- 796	'O' RING
5318	5.01.0119.1.01.1	ZF	0634 -303- 834	'O' RING
5319	5.01.0120.1.01.2	ZF	0634 -304- 358	'O' RING
5320	5.01.0121.1.01.3	ZF	0634 -306- 306	'O' RING
5321	5.01.0122.1.01.4	ZF	0634-300-053	SHAFT SEAL
5322	5.01.0123.1.01.5	ZF	0634-300-185	SHAFT SEAL
5323	5.01.0124.1.01.6	ZF	0634-300-721	SHAFT SEAL
5324	5.01.0125.1.01.7	ZF	0634-310-733	SHAFT SEAL
5325	5.01.0126.1.01.8	ZF	0634-319-247	SHAFT SEAL
5326	5.01.0127.1.01.9	ZF	0734-319-497	SHAFT SEAL
5327	5.01.0128.1.01.1	ZF	0634300231/0634302121	SHAFT SEAL (20X32X7)
5328	5.01.0129.1.01.2	ZF	0634300721/0634319247	SHAFT SEAL (85X110X12)
5329	5.01.0130.1.01.3	ZF	0634-303-199	'O' RING
5330	5.01.0131.1.01.4	ZF	0634-303-670	'O' RING
5331	5.01.0132.1.01.5	ZF	0634-303-718	'O' RING
5332	5.01.0133.1.01.6	ZF	0634-303-951	'O' RING
5333	5.01.0134.1.01.7	ZF	0634-305-020, LFN-155-VITON	PISTON RING
5334	5.01.0135.1.01.8	ZF	0634-306-292	'O' RING
5335	5.01.0136.1.01.9	ZF	0634310733/0734319497	SHAFT SEAL (90X110X13)
5336	5.01.0137.1.01.1	ZF	0634-313-118	'O' RING
5337	5.01.0138.1.01.2	ZF	0634-313-383	'O' RING
5338	5.01.0139.1.01.3	ZF	0635-300-117	NEEDLE CAGE BEARING
5339	5.01.0140.1.01.4	ZF	0635-300-151	NEEDLE CAGE BEARING
5340	5.01.0141.1.01.5	ZF	0635-410-143	ROLLER BEARING
5341	5.01.0142.1.01.6	ZF	0635-450-126	ROLLER BEARING
5342	5.01.0143.1.01.7	ZF	0635-460-029	BALL
5343	5.01.0144.1.01.8	ZF	0636-302-009=3, 0636-307-025=1, 0636-304-009=1,0636-305-046=1	SET OF SCREW PLUG FOR ZF GEAR BOX CONSISTING
5344	5.01.0145.1.01.9	ZF	0636-610-109,0636-610-020,0636-610-127,0636-610-177	SET OF STUD FOR ZF GEAR BOX
5345	5.01.0146.1.01.1	ZF	N/A	(i) 0636-610-609=3 Nos., (ii)0636-610/611-020=11 nos., (iii)0636-0610- 127=1 no., (iv)0636-610-177=1 no.
5346	5.01.0147.1.01.2	ZF	0637-835-005/515	HOLLOW SCREW FOR ZF GEAR BOX
5347	5.01.0148.1.01.3	ZF	0637-880-071	PIPE UNION
5348	5.01.0149.1.01.4	ZF	0659-160-054	CABLE CLIP FOR ZF GEAR BOX
5349	5.01.0150.1.01.5	ZF	0730 061 624	RING
5350	5.01.0151.1.01.6	ZF	0730-001-879, 0730-000-257, 0730-000-258, 0730-102-459, 2050-309-066, 4607-316-081, 5010-303-020	SHIM FOR ZF GEAR BOX OFF SIZES :
5351	5.01.0152.1.01.7	ZF	0730-001-927	INTERMEDIATE RING
5352	5.01.0153.1.01.8	ZF	0730-102-464.63, 62,61,60,67,68,69	SHIM
5353	5.01.0154.1.01.9	ZF	0734-303-035	O RING
5354	5.01.0155.1.01.1	ZF	0735-320-110	TAPER ROLLER & CAGE ASSY
5355	5.01.0156.1.01.2	ZF	0735-320-111	NEEDLE ROLLER & CAGE ASSY
5356	5.01.0157.1.01.3	ZF	0735-320-204	NEEDLE ROLLER & CAGE ASSY
5357	5.01.0158.1.01.4	ZF	0735-320-206	NEEDLE ROLLER & CAGE ASSY
5358	5.01.0159.1.01.5	ZF	0735-320-314	NEEDLE CAGE BEARING
5359	5.01.0160.1.01.6	ZF	0735-320-315	NEEDLE CAGE BEARING
5360	5.01.0161.1.01.7	ZF	0735-353-243	ROLLER CAGE

5361	5.01.0162.1.01.8	ZF	0735-358-032	ROLLER CAGE BEARING
5362	5.01.0163.1.01.9	ZF	0750-115-356	NEEDLE SLEEVE / VALVE
5363	5.01.0164.1.01.1	ZF	0750-118-019	NEEDLE ROLLER & CAGE ASSY
5364	5.01.0165.1.01.2	ZF	098635200 (IMPORTED)	PLUG
5365	5.01.0166.1.01.3	ZF	1240-310-013/1240-3100-13	OUT PUT SHAFT
5366	5.01.0167.1.01.4	ZF	1269302164 / 4616305007	SET OF TAB WASHER FOR ZF GEAR BOX
5367	5.01.0168.1.01.5	ZF	140X149X2 , 0634-305-089, 135-VITON	PISTON RING
5368	5.01.0169.1.01.6	ZF	1419-306-063= , 4620-306-255= , 4620-306-413= , 4620-306-414= , 4642-306-091= , 4644-306-010=	SET OF PISTON FOR ZF GEAR BOX CONSISTING OF:
5369	5.01.0170.1.01.7	ZF	2050-309-067/068/069	SHIM OPTIONAL
5370	5.01.0171.1.01.8	ZF	260X268X2.2, 0634-305-026	PISTON RING
5371	5.01.0172.1.01.9	ZF	320X332X2.5, 0634-305-093,155-VITON	PISTON RING
5372	5.01.0173.1.01.1	ZF	39.5X2 0634-402-029-DIN-34110	PISTON RING FOR ZF GEAR BOX
5373	5.01.0174.1.01.2	ZF	4116-301-175	HOUSING FOR ZF GEAR BOX
5374	5.01.0175.1.01.3	ZF	4139-334-002	O' CLUTCH DISC FOR CONVERTOR CLUTCH OF ZF GEAR
5375	5.01.0176.1.01.4	ZF	4166-039-077	CONVERTOR FOR ZF GEAR BOX
5376	5.01.0177.1.01.5	ZF	4166-236-111	'I' CLUTCH DISC FOR TORQUE
5377	5.01.0178.1.01.6	ZF	420X430X03, 155-VITON, 0634-305-042	PISTON RING (22123)
5378	5.01.0179.1.01.7	ZF	4616-307-007	SHIFT CONTROL ASSEMBLY
5379	5.01.0180.1.01.8	ZF	4616.208.003	CLUTCH DISC
5380	5.01.0181.1.01.9	ZF	4616.303.046	OUTPUT FLANGE
5381	5.01.0182.1.01.1	ZF	4616.303.156	OUTPUT FLANGE
5382	5.01.0183.1.01.2	ZF	4616.308.035	'I' CLUTCH DISC
5383	5.01.0184.1.01.3	ZF	4616-000-163/207/199	Z F GEAR BOX (IMPORTED)
5384	5.01.0185.1.01.4	ZF	4616-121	SET OF PIPE
5385	5.01.0186.1.01.5	ZF	4616-159-007	SHIFT CONTROL ASSY.FOR ZF GEAR BOX 4WG-65-11WK
5386	5.01.0187.1.01.6	ZF	4616-208/223-003	O' CLUTCH DISC FOR ZF GEAR BOX
5387	5.01.0188.1.01.7	ZF	4616-301-235	HOUSING
5388	5.01.0189.1.01.8	ZF	4616-301-244	QUILL SHAFT
5389	5.01.0190.1.01.9	ZF	4616-301-304	HOUSING FOR ZF GEAR BOX
5390	5.01.0191.1.01.1	ZF	4616-301-309	HOUSING FOR ZF GEAR BOX
5391	5.01.0192.1.01.2	ZF	4616-302-112	QUILL SHAFT
5392	5.01.0193.1.01.3	ZF	4616-303-006	OIL COIL PLATE
5393	5.01.0194.1.01.4	ZF	4616-303-008	OIL FEED RING
5394	5.01.0195.1.01.5	ZF	4616-303-011	OIL FEED BUSH
5395	5.01.0196.1.01.6	ZF	4616-303-026	SPUR GEAR
5396	5.01.0197.1.01.7	ZF	4616-303-028	BALL HOUSING FOR ZF GEAR BOX
5397	5.01.0198.1.01.8	ZF	4616-303-031	COVER FOR ZF GEAR BOX
5398	5.01.0199.1.01.9	ZF	4616-303-041	OUT PUT FLANGE FOR ZF GEAR BOX
5399	5.01.0200.1.01.1	ZF	4616-303-042	OUT PUT SHAFT FOR ZF GEAR BOX
5400	5.01.0201.1.01.2	ZF	4616-306-087	COVER PLATE FOR ZF GEAR BOX
5401	5.01.0202.1.01.3	ZF	4616-306-111	GEAR FOR ZF GEAR BOX
5402	5.01.0203.1.01.4	ZF	4616-307-003	SPUR GEAR FOR ZF GEAR BOX
5403	5.01.0204.1.01.5	ZF	4616-308-031	LAY SHAFT
5404	5.01.0205.1.01.6	ZF	4616-308-052	SPUR GEAR FOR ZF GEAR BOX
5405	5.01.0206.1.01.7	ZF	4616-308-111	GEAR FOR ZF GEAR BOX
5406	5.01.0207.1.01.8	ZF	4616-329-005	PUMP FLANGE
5407	5.01.0208.1.01.9	ZF	4616-336-010	HOUSING FOR ZF GEAR BOX
5408	5.01.0209.1.01.1	ZF	4616-336-009	CONVERTOR COVER
5409	5.01.0210.1.01.2	ZF	4616-441-011R/ 4616-159-022	ELECTRIC CIRCUIT
5410	5.01.0211.1.01.3	ZF	4644-164-003	GEAR SHIFT SYSTEM COMPLETE FOR ZF GEAR BOX
5411	5.01.0212.1.01.4	ZF	4644-303-268/4607.030.034	INPUT FLANGE
5412	5.01.0213.1.01.5	ZF	4644-306-599	REDUCTION VALVE FOR ZF GEAR BOX
5413	5.01.0214.1.01.6	ZF	4WE-65ii-4616000277	ZF GEAR BOX
5414	5.01.0215.1.01.7	ZF	4WG65II/4616000206	ZF GEAR BOX
5415	5.01.0216.1.01.8	ZF	4WG65II/4616000260	ZF GEARBOX
5416	5.01.0217.1.01.9	ZF	4WG65II/4616000262	ZF GEAR BOX
5417	5.01.0218.1.01.1	ZF	5010-304-015	SHIM PLATE FOR ZF GEAR BOX
5418	5.01.0219.1.01.2	ZF	55X2.5, SH-DIN-34110, 0634-402-052	PISTON RING
5419	5.01.0220.1.01.3	ZF	6006-016-109	GEAR SELECTOR FOR ZF GEAR BOX
5420	5.01.0221.1.01.4	ZF	6011-310-001	SPRING CAP
5421	5.01.0222.1.01.5	ZF	6029-199-002,0659-050-178/100	PLUG FOR ZF GEAR BOX
5422	5.01.0223.1.01.6	ZF	604/31002	VALVE
5423	5.01.0224.1.01.7	ZF	6041-232-210/184	MODULE
5424	5.01.0225.1.01.8	ZF	6041-315-007	INDUCTIVE TRANSMITTER ZF GEAR BOX (TRANSDUCER)
5425	5.01.0226.1.01.9	ZF	630-004-388/117/ 104/103/101/100	SHIM FOR ZF GEAR BOX
5426	5.01.0227.1.01.1	ZF	6W6200/4644026290	ZF GEAR BOX
5427	5.01.0228.1.01.2	ZF	7647.955.123	Z.F. OIL PUMP
5428	5.01.0229.1.01.3	ZF	90X97X2,0634-305-009	PISTON RING FOR ZF GEAR BOX

5429	5.01.0230.1.01.4	ZF	92X2.5, 0634-402-110	PISTON RING
5430	5.01.0231.1.01.5	ZF	4616000	Set of Lubrication Pressure Valve for Z.F. Gear Box Consisting of :-
5431	5.01.0232.1.01.6	ZF	44616320011	Valve Sleeve Part No
5432	5.01.0233.1.01.7	ZF	631329158	Slot Pin
5433	5.01.0234.1.01.8	ZF	4044306022	Piston
5434	5.01.0235.1.01.9	ZF	ZF 0735-320-204	NEEDLE ROLLER & CAGE ASSY
5435	5.01.0236.1.01.1	ZF	480290017	GEAR SHIFT FORK
5436	5.01.0237.1.01.2	ZF	0501310470	VALVE
5437	5.01.0238.1.01.3	ZF	0635-290-061	HOUSING DISC
5438	5.01.0239.1.01.4	GE	TDCN-22-1861	Hydro mechanical transmission gear box complete
5439	5.01.0240.1.01.5	PL	4616303156	FLANGE
5440	5.01.0241.1.01.6	GE	8-1750(Ms372)	Torque Converter
5441	5.01.0242.1.01.7	GE	YD432D-23-19-04	Flange-4
5442	5.02.0001.1.01.1	PL	63.09.2115	BEARING COVER
5443	5.02.0002.1.01.2	ZF	LK62.302	BEARING HOUSING
5444	5.03.0001.1.01.2	PL	64.04.3100	GEAR WHEEL
5445	5.03.0002.1.01.3	PL	64.04.3188	GEAR WHEEL
5446	5.03.0003.1.01.4	PL	64.04.3232	CARRIER
5447	5.03.0004.1.01.5	PL	64.04.3241	GEAR WHEEL
5448	5.03.0005.1.01.6	PL	64.04.3242	GEAR WHEEL
5449	5.03.0006.1.01.7	PL	64.04.3243	GEAR WHEEL
5450	5.03.0007.1.01.8	PL	64.04.3244	GEAR WHEEL
5451	5.03.0008.1.01.9	PL	64.04.3245	GEAR WHEEL
5452	5.03.0009.1.01.1	PL	64.04.3246	SHAFT WITH KEY
5453	5.03.0010.1.01.2	PL	64.04.3247	GEAR WHEEL
5454	5.03.0011.1.01.3	PL	64.04.3248	SHAFT WITH KEY
5455	5.03.0012.1.01.4	PL	64.04.3249	SHAFT WITH KEY
5456	5.03.0013.1.01.5	PL	64.04.3256	CARRIER
5457	5.03.0014.1.01.6	PL	64.04.3257	CARRIER
5458	5.03.0015.1.01.7	PL	64.04.3261	CARRIER
5459	5.03.0016.1.01.8	PL	64.04.3263	CARRIER
5460	5.03.0017.1.01.9	PL	64.08.3055	PINION
5461	5.03.0018.1.01.1	PL	SU 611.16.25.10	GEAR WHEEL FOR 3X
5462	5.03.0019.1.01.2	PL	U 75.607	GEAR WHEEL FOR 3X
5463	5.03.0020.1.01.3	PL	WN 70-3410 E	SLIDING GEAR Z=22
5464	5.03.0021.1.01.4	PL	WN 70-3411	GEAR WHEEL Z=93
5465	5.03.0022.1.01.5	PL	WN70.1107	SHAFT
5466	5.03.0023.1.01.6	PL	WN70.1107C	SHAFT
5467	5.03.0024.1.01.7	PL	WN70.3805	DOUBLE GEAR WHEEL
5468	5.03.0025.1.01.8	PL	WN70.3806	DOUBLE GEAR WHEEL
5469	5.03.0026.1.01.9	PL	WN80.1112	SHAFT
5470	5.03.0027.1.01.1	PL	WN80.2600-13	SHAFT
5471	5.03.0028.1.01.2	PL	WN80.2600-8	SHAFT
5472	5.03.0029.1.01.3	PL	WN81.503	CARRIER
5473	5.03.0030.1.01.4	PL	WN81.703	CARRIER
5474	5.03.0031.1.01.5	PL	WN81.903	CARRIER
5475	5.03.0032.1.01.6	KE	662339	CLUTCH ASSEMBLY
5476	5.03.0033.1.01.7	AM	17042	WHEEL CROWN FOR T -28
5477	5.03.0034.1.01.8	AM	17058	WHEEL PINION FOR T 28
5478	5.03.0035.1.01.9	PH	30233005	BEVEL PINION & GEAR
5479	5.03.0036.1.01.1	PH	UTV1.11/00/00	PTO ASSEMBLY
5480	5.03.0037.1.01.2	PL	1295151007/FLANSCH-120M SUBSTITUTE N70-1B(1295151007/FLANSCH)	POWER TAKE OFF ASSEMBLY
5481	5.03.0038.1.01.3	PL	62.13.409	SHAFT
5482	5.03.0039.1.01.4	PL	62.04.3100	GEAR WHEEL
5483	5.03.0040.1.01.5	PL	PB61.472	SHAFT (INTERMEDIATE)
5484	5.03.0041.1.01.6	PL	2249137EB	SWITCH GEAR
5485	5.03.0042.1.01.7	CR	40100378-057	GEAR-1
5486	5.03.0043.1.01.8	CR	40100378-058	GEAR-2
5487	5.03.0044.1.01.9	CR	40100378-064	GEAR
5488	5.03.0045.1.01.1	CR	40100378-068	CROWN GEAR
5489	5.03.0046.1.01.2	CR	40100378-076	PINION
5490	5.03.0047.1.01.3	CR	40100378-093	SHAFT-1
5491	5.03.0048.1.01.4	CR	40100378-107	SHAFT-2
5492	5.03.0049.1.01.5	CR	40100378-109	FLANGE-2
5493	5.03.0050.1.01.6	CR	40100378-116	SHAFT-1
5494	5.03.0051.1.01.7	CR	40100378-117	FLANGE
5495	5.03.0052.1.01.8	CR	BS550(IND)-03-01-02-03	DRIVING ROLLER SHAFT
5496	5.03.0053.1.01.9	CR	BS550(IND)-03-01-03-02	DIVERT ROLLER SHAFT
5497	5.03.0054.1.01.1	CR	QS1200-29-14	GEAR
5498	5.03.0055.1.01.2	CR	BS550(IND)-09-02-02	DRIVING ROLLER SHAFT
5499	5.03.0056.1.01.3	PL	WN75.1950-2	DRIVE SHAFT
5500	5.03.0057.1.01.4	PL	WN80.2600-15	SHAFT

5501	5.03.0058.1.01.5	PL	WN80.2605-1	GEAR WHEEL SHAFT (Z=44)
5502	5.03.0059.1.01.6	PL	64.11.1436	GEAR WHEEL
5503	5.03.0060.1.01.7	PL	WN71.154Z/ 155	Crown and Pinion
5504	5.04.0001.1.01.3	PL	2-330-854-6	CARRIER
5505	5.04.0002.1.01.4	PL	64.13.4032	COUPLING
5506	5.04.0003.1.01.5	PL	M63 254 DB	SHOE
5507	5.04.0004.1.01.6	PL	WN.220.27	FLEXIBLE COUPLING
5508	5.04.0005.1.01.7	PL	WN220.01A	COUPLING
5509	5.04.0006.1.01.8	PL	WN220.04A	COUPLING
5510	5.04.0007.1.01.9	PL	WN220.20	COUPLING
5511	5.04.0008.1.01.1	PL	WN220.30	COUPLING
5512	5.04.0009.1.01.2	PL	WN220.31	COUPLING
5513	5.04.0010.1.01.3	PL	WN220.32	COUPLING
5514	5.04.0011.1.01.4	PL	WN220.36	COUPLING
5515	5.04.0012.1.01.5	PL	WN70.1167	SLIDER
5516	5.04.0013.1.01.6	CR	40100378-051	FLANGE, SEAL SUPPORT
5517	5.04.0014.1.01.7	CR	40100378-067	FLANGE-1
5518	5.04.0015.1.01.8	CR	BS550-07-17-00	FLANGE
5519	5.04.0016.1.01.9	PL	UD61.10074	FLANGE
5520	5.04.0017.1.01.1	PL	UD220.2780.3	BEARING FLANGE
5521	5.04.0018.1.01.2	PL	WN220.04A/3X	COUPLING
5522	5.04.0019.1.01.3	PL	WN220.04B	COUPLING
5523	5.04.0020.1.01.4	PL	WN220.59	COUPLING
5524	5.04.0021.1.01.5	PL	WN220.76	COUPLING
5525	5.04.0022.1.01.6	PL	63.09.2103	FLANGE BUSH
5526	5.04.0023.1.01.7	PL	EL-T9124.50-3	COUPLING
5527	5.04.0024.1.01.8	LO	124253	FLANGE STR 3261 04FORB
5528	5.04.0025.1.01.9	LO	124888	FLANGE BLIND 1.50; 2461 O-RING GROOVE
5529	5.04.0026.1.01.1	LO	133644	FLANGE ADAPTER 2461 12FORB
5530	5.04.0027.1.01.2	LO	143866	FLANGE STR 3261 3261C; GA PORT 3X 04FORB
5531	5.04.0028.1.01.3	LO	143885	FLANGE EL90 3261C 3261C
5532	5.04.0029.1.01.4	LO	144064	FLANGE STR 2461 2461C; GA PORT 16FORB ALUM
5533	5.04.0030.1.01.5	PL	WN22076	Coupling
5534	5.05.0001.1.01.4	PL	KG120.0500.060.00	CARDON SHAFT
5535	5.05.0002.1.01.5	PL	KG180.1250.110.00/80	CARDON SHAFT
5536	5.05.0003.1.01.6	PL	KG150.0750.110.00	CARDON SHAFT
5537	5.05.0004.1.01.7	PL	KG150.0900.110.00	CARDON SHAFT
5538	5.05.0005.1.01.8	PL	KG180.0900.110.80	CARDON SHAFT
5539	5.05.0006.1.01.9	PL	KG180.0950.110.80	CARDON SHAFT
5540	5.05.0007.1.01.1	PL	KG180.1000.110.80	CARDON SHAFT
5541	5.05.0008.1.01.2	PL	KG180.1250.110.80	CARDON SHAFT
5542	5.05.0009.1.01.3	PL	KG180.1300.110.80	CARDON SHAFT
5543	5.05.0010.1.01.4	PL	KG180.1550.110.80	CARDON SHAFT
5544	5.05.0011.1.01.5	PL	KGW150.0700.110.00	CARDON SHAFT
5545	5.05.0012.1.01.6	PL	KGW150.0900.110.00	CARDON SHAFT
5546	5.05.0013.1.01.7	PL	KGW150.0950.110.00	CARDON SHAFT
5547	5.05.0014.1.01.8	PL	KGW150.1000.110.00	CARDON SHAFT
5548	5.05.0015.1.01.9	PL	KGW150.1200.110.00	CARDON SHAFT
5549	5.05.0016.1.01.1	PL	KGW180.0660.110.00	CARDON SHAFT
5550	5.05.0017.1.01.2	PL	KGW180.0700.110.50	CARDON SHAFT
5551	5.05.0018.1.01.3	PL	KGW180.0750.110.00	CARDON SHAFT
5552	5.05.0019.1.01.4	PL	KGW180.0900.110.00	CARDON SHAFT
5553	5.05.0020.1.01.5	PL	KGW180.0950.110.00	CARDON SHAFT
5554	5.05.0021.1.01.6	PL	KGW180.1000.110.00	CARDON SHAFT
5555	5.05.0022.1.01.7	PL	KGW180.1050.110.00	CARDON SHAFT
5556	5.05.0023.1.01.8	PL	KGW180.1100.110.00	CARDON SHAFT
5557	5.05.0024.1.01.9	PL	KGW180.1170.110.00	CARDON SHAFT
5558	5.05.0025.1.01.1	PL	KGW180.1200.110.00	CARDON SHAFT
5559	5.05.0026.1.01.2	PL	KGW180.1250.110.00	CARDON SHAFT
5560	5.05.0027.1.01.3	PL	KGW180.1300.110.00	CARDON SHAFT
5561	5.05.0028.1.01.4	PL	KGW180.1500.110.00	CARDON SHAFT
5562	5.05.0029.1.01.5	PL	LZ.500.L.450/187.20	CARDON SHAFT
5563	5.05.0030.1.01.6	PL	LZ.900.LA.80, UD.70.5231	CARDON SHAFT
5564	5.05.0031.1.01.7	PL	LZ1330LA110/CA72.1409	CARDON SHAFT
5565	5.05.0032.1.01.8	PL	LZ200/187,20	CARDON SHAFT
5566	5.05.0033.1.01.9	PL	LZ325LA35/0112130279 SUB. LZ325LA35/0112130800	CARDON SHAFT
5567	5.05.0034.1.01.1	PL	LZ400LA50/ 387,30	CARDON SHAFT
5568	5.05.0035.1.01.2	PL	LZ400LA50/UD72.4224	CARDON SHAFT
5569	5.05.0036.1.01.3	PL	LZ420LA40/UD72.2719G-A	CARDON SHAFT
5570	5.05.0037.1.01.4	PL	LZ470LA40/ 587,30FL.D.180	CARDON SHAFT
5571	5.05.0038.1.01.5	PL	LZ640LA110/0117111465 SUB. LZ640LA110/4369.1085.0640	CARDON SHAFT
5572	5.05.0039.1.01.6	PL	LZ740LA110/0120111001	CARDON SHAFT

5573	5.05.0040.1.01.7	PL	LZ742LA110/0158115001	CARDON SHAFT
5574	5.05.0041.1.01.8	PL	LZ760LA100/0110115001	CARDON SHAFT
5575	5.05.0042.1.01.9	PL	WN 151.120.12/24.1	CARDON SHAFT FLANGE
5576	5.05.0043.1.01.1	KE	663222	CARDON SHAFT YOKE FOR BRM
5577	5.05.0044.1.01.2	PH	UTV1 02/05/00	CARDON SHAFT
5578	5.05.0045.1.01.3	PH	UTV1 02/23/00	CARDON SHAFT
5579	5.05.0046.1.01.4	PL	4-68649	CARDAN SHAFT
5580	5.05.0047.1.01.5	PL	SOLA16-574	UNIVERSAL JOINT
5581	5.05.0048.1.01.6	KA	KPM1-220-5010-02	Cardan Shaft
5582	5.05.0049.1.01.7	KA	KPM3-2201010-12	Cardan Shaft (TGB to IGB)
5583	5.05.0050.1.01.8	KA	522A-2201010-12	Cardan Shaft
5584	5.05.0051.1.01.9	KA	KPMI-220-5010-02	Intermediate to 2nd Axle
5585	5.05.0052.1.01.1	GE	B1.1-2,Lz-225	Propeller shaft-1
5586	5.05.0053.1.01.2	GE	200.35-180/180-1000	Propeller shaft-2
5587	5.05.0054.1.01.3	GE	200.30-180/180-1050	Propeller shaft-3
5588	5.05.0055.1.01.4	GE	00.30-180/180-1000	Propeller shaft-4
5589	5.05.0056.1.01.5	GE	200.30-180/180-500	Propeller shaft-5
5590	5.05.0057.1.01.6	KA	257-2202010-17	CARDAN SHAFT
5591	5.05.0057.1.01.7	GE	200.30-180/180-1250	Propeller shaft-6
5592	5.05.0058.1.01.7	KA	2-224334	CARDAN SHAFT
5593	5.05.0059.1.01.8	PL	KG225.1550.110.00	CARDAN SHAFT
5594	5.05.0060.1.01.9	PL	KG150.1050.110.00	CARDAN SHAFT
5595	5.05.0061.1.01.1	PL	KG180.1600.110.080	CARDAN SHAFT
5596	5.05.0062.1.01.2	PL	KGW180.0665.110.00	CARDAN SHAFT
5597	5.05.0063.1.01.3	PL	KGW180.0720.110.00	CARDAN SHAFT
5598	5.05.0064.1.01.4	PL	LZ720LA110/0122140001	CARDAN SHAFT
5599	5.05.0065.1.01.5	PL	LZ550LA40/01221210001	CARDAN SHAFT
5600	5.05.0066.1.01.6	PL	LZ1000LA140/0122111001	CARDAN SHAFT(Eng to GB)
5601	5.05.0067.1.01.7	PL	KGW180.0665.110.00	CARDAN SHAFT(drive pump)
5602	5.05.0068.1.01.8	PL	KG225.1900.110.00 SUB LZ1900LA110/0120111001	CARDAN SHAFT
5603	5.05.0069.1.01.9	PL	KG180.1150.110.80	CARDAN SHAFT
5604	5.05.0070.1.01.1	PL	KG225.1300.140.00	CARDAN SHAFT
5605	5.05.0071.1.01.2	PL	LZ345LA35/387.20	CARDAN SHAFT
5606	5.05.0072.1.01.3	OEPL	222 02 00 03	CARDAN SHAFT
5607	5.05.0073.1.01.4	OEPL	223 02 00 04	CARDAN SHAFT
5608	5.05.0074.1.01.5	PL	LZ1900LA 1 10/ 0	Cardan shaft
5609	5.06.0001.1.01.5	AM	53879003	SEAL KIT CRAWLER REDUCTION GEAR BOX M709C3B23
5610	5.06.0002.1.01.6	PH	ADGB/GS/UTV/002	GASKET KIT FOR AXLE DRIVE GEAR BOX
5611	5.06.0003.1.01.7	PH	ADGB/GS/UTV/04	SEAL KIT FOR ADGB
5612	5.06.0004.1.01.8	PH	91500022	BREATHER CUM FILTER
5613	5.06.0005.1.01.9	PH	91500067	AXLE GEAR BOX BREATHER 3/4" BSP
5614	5.06.0006.1.01.1	PH	92000086	OIL SEAL ID.200XOD.230X15
5615	5.06.0007.1.01.2	PH	92000112	OIL SEAL
5616	5.06.0008.1.01.3	PH	92000121	DDGB OUTPUT SHAFT O RING
5617	5.06.0009.1.01.4	PL	100M12550023/G	SUPPORT
5618	5.06.0010.1.01.5	PL	61.02.200III	PISTON PUMP
5619	5.06.0011.1.01.6	PL	A2-22223	PISTON
5620	5.06.0012.1.01.7	GE	CDCK16A-56-11-00	Attachment
5621	5.06.0013.1.01.8	PL	UD222.702	VENTILATOR COVER
5622	5.06.0014.1.01.9	CR	40100378-045	RING
5623	5.06.0015.1.01.1	CR	40100378-047	RING-2
5624	5.06.0016.1.01.2	CR	40100378-060	RING, SPACER
5625	5.06.0017.1.01.3	CR	40100378-061	RING, ELASTIC-1
5626	5.06.0018.1.01.4	CR	40100378-062	RING, ELASTIC-2
5627	5.06.0019.1.01.5	CR	40100378-071	RING,SPACER
5628	5.06.0020.1.01.6	CR	40100378-072	RING, ELASTIC-3
5629	5.06.0021.1.01.7	CR	40100378-073	RING, ELASTIC-4
5630	5.06.0022.1.01.8	CR	40100378-077	RING, ELASTIC-5
5631	5.06.0023.1.01.9	CR	40100378-079	RING, ELASTIC-6
5632	5.06.0024.1.01.1	CR	40100378-080	RING, ELASTIC-7
5633	5.06.0025.1.01.2	CR	40100378-081	RING-1
5634	5.06.0026.1.01.3	CR	40100378-084	RING, ELASTIC-8
5635	5.06.0027.1.01.4	CR	40100378-085	RING-2
5636	5.06.0028.1.01.5	CR	40100378-089	RING-4
5637	5.06.0029.1.01.6	CR	40100378-106	RING, ELASTIC-9
5638	5.06.0030.1.01.7	CR	USH36.46.6	Y ring-7
5639	5.06.0031.1.01.8	CR	ISI70.80.6	Y ring-9
5640	5.06.0032.1.01.9	CR	SF-1 5525	COMPOSITE BUSHING-1
5641	5.06.0033.1.01.1	CR	SF-1 5590	COMPOSITE BUSHING-2
5642	5.06.0034.1.01.2	CR	BS550-07-14	BUSHING
5643	5.06.0035.1.01.3	CR	BS550(IND)-07-02-26	BUSHING I
5644	5.06.0036.1.01.4	CR	BS550(IND)-07-01-02-05	BUSHING I
5645	5.06.0037.1.01.5	CR	BS550(IND)-07-01-02-06	BUSHING II

5646	5.06.0038.1.01.6	CR	BS550(IND)-10-05-01-01	RING BUSHING
5647	5.06.0039.1.01.7	CR	BS550(IND)-10-05-01-02	SPACING BUSHING
5648	5.06.0040.1.01.8	CR	DPZ440-05-11	BUSHING 50X65X17.5
5649	5.06.0041.1.01.9	CR	DPZ440-05-18	BUSHING 50X65X31.5
5650	5.06.0042.1.01.1	CR	DPZ440-36-07	HINGE PIN
5651	5.06.0043.1.01.2	CR	DPZ440-05-19	BUSHING 40X55X22
5652	5.06.0044.1.01.3	CR	BS500W(IND)-13-01-12	BUSHING 40X55X65
5653	5.06.0045.1.01.4	CR	BS500W(IND)-13-20-06	BUSHING 17.5
5654	5.06.0046.1.01.5	CR	BS500W(IND)-13-20-15	PIN-1
5655	5.06.0047.1.01.6	CR	BS500W(IND)-13-20-16	PIN-2
5656	5.06.0048.1.01.7	CR	BS500W(IND)-13-20-17	PIN HANDLE
5657	5.06.0049.1.01.8	CR	BS550(IND)-15-02-07-00	MECHANIC PIN A
5658	5.06.0050.1.01.9	CR	BS550(IND)-15-02-08-00	MECHANIC PIN B
5659	5.06.0051.1.01.1	CR	23073450	Spacer
5660	5.06.0052.1.01.2	CR	23087623	pin
5661	5.06.0053.1.01.3	CR	20261420	Spacer
5662	5.06.0054.1.01.4	PL	HY-L507.1600.3ES OR 62.05.1000.426	FILTER ELEMENT
5663	5.06.0055.1.01.5	PL	DZ80/G=2000/HUB100	PULL CABLE
5664	5.06.0056.1.01.6	PL	DZ95/G=2000/HUB70	PULL CABLE
5665	5.06.0057.1.01.7	PL	DZ160/G=2000/HUB200	PULL CABLE
5666	5.06.0058.1.01.8	PL	DZ160/G=3000/HUB200	PULL CABLE
5667	5.06.0059.1.01.9	LO	237622	PIN .750D; MOD TILT LOCK
5668	5.07.0001.1.01.6	PL	61.4901	Driving Axle Front of UNIMAT
5669	5.07.0002.1.01.7	PL	61.8601	Driving Axle Front of UNIMAT
5670	5.07.0003.1.01.8	PL	CU.61.8502	Running Axle for CSM
5671	5.07.0004.1.01.9	PL	UD.62.01	Driving axle-duo
5672	5.07.0005.1.01.1	PL	UD62.2404	COVER (AXLE)
5673	5.07.0006.1.01.2	PL	UD62.3301	CSM Satellite of Driving Bogie Axle
5674	5.07.0007.1.01.3	PL	UD62.3301 SPUR 1668/1676	SATELLITE AXLE
5675	5.07.0008.1.01.4	PL	WN01.850.184.IND.RT.1	AXLE WHEEL FOR IMPORTED DUO
5676	5.07.0009.1.01.5	LO	134173	WHEEL AXLE SET W GEAR; DRIVE TRUCK MULTIPLE WEAR
5677	5.07.0010.1.01.6	GE	YD432D-20-03-00	Fixing axle
5678	5.07.0011.1.01.7	CR	TX100 II -14-03-01	AXLE BOX
5679	5.07.0012.1.01.8	CR	TX100 II -14-04-01	AXLE BOX RIGHT SIDE 1
5680	5.07.0013.1.01.9	PL	WN70.3404	AXLE
5681	5.07.0014.1.01.1	CR	CDC16W(IND)-08-03-00	DRIVEN WHEELSET
5682	5.07.0015.1.01.2	CR	BS550(IND)-09-05-01	AXLE
5683	5.07.0016.1.01.3	CR	BS550(IND)-10-04-06	AXLE
5684	5.07.0017.1.01.4	CR	BS550(IND)-10-05-05	AXLE
5685	5.07.0018.1.01.5	CR	BS500W(IND)-13-26	MOUNTING AXLE
5686	5.07.0019.1.01.6	CR	DPZ440-05-13	AXLE SLEEVE
5687	5.07.0020.1.01.7	CR	DPZ440-05-10	MOUNTING AXLE 50X170
5688	5.07.0021.1.01.8	CR	DPZ440-05-17	MOUNTING AXLE 50X200
5689	5.07.0022.1.01.9	CR	DPZ440-05-15	MOUNTING AXLE 55X450
5690	5.07.0023.1.01.1	CR	BS500W(IND)-13-01-11	UPPER MOUNTING AXLE OF VERTICAL CYLINDER 40X317
5691	5.07.0024.1.01.2	CR	BS500W(IND)-13-01-14	MOUNTING AXLE 40X162 -1
5692	5.07.0025.1.01.3	CR	BS500W(IND)-13-01-16	MOUNTING AXLE 40X162 -2
5693	5.07.0026.1.01.4	CR	BS500W(IND)-13-01-20	AXLE
5694	5.07.0027.1.01.5	CR	BS500W(IND)-13-20-05	MOUNTING AXLE-1
5695	5.07.0028.1.01.6	CR	BS500W(IND)-13-20-08	MOUNTING AXLE-2
5696	5.07.0029.1.01.7	CR	BS500W(IND)-13-20-09	MOUNTING AXLE 30X170
5697	5.07.0030.1.01.8	PL	UD64.1355Z/UD64.54Z	RING GEAR/DRIVE CROWN WHEEL
5698	5.07.0031.1.01.9	PL	WN02.120.184.1.1668/1676-2	DRIVE AXLE
5699	5.07.0032.1.01.1	PL	WN02.120.184.1.1668/1676-4	DRIVE AXLE
5700	5.07.0033.1.01.2	PL	WN04-1676.850.2040-1-V03	DRIVE AXLE SET VMS
5701	5.07.0034.1.01.3	PL	WN04-1676.850.2040-1-V05	DRIVE AXLE SET VMS
5702	5.07.0035.1.01.4	LO	100148	SEAL-ROD 4.00IDx4.50 ODX.25
5703	5.07.0036.1.01.5	PL	61. 02. 236	Piston
5704	5.07.0037.1.01.6	PL	UD70.251	Intermediate Bearing
5705	5.07.0038.1.01.7	PL	64.02.2110	Bush
5706	5.07.0039.1.01.8	PL	CU6 I .8601SPI66	Additional Drive axle
5707	5.08.0001.1.01.7	PL	WN 01-920-210-IND-7-1	WHEEL DISC
5708	5.08.0002.1.01.8	AM	16022	MOTORISED WHEEL - T 28
5709	5.08.0003.1.01.9	AM	16023	NON MOTORISED WHEEL - T 28
5710	5.08.0004.1.01.1	GE	CDCK16A-56-10-00	Lining wheel inst.
5711	5.08.0005.1.01.2	LO	113807	CARRIAGE WHEEL ASSEMBLY
5712	5.08.0006.1.01.3	LO	145472	AXLE WELDT WHEEL
5713	5.08.0007.1.01.4	LO	209926	WHEEL RIM 16.00 IN; 18.53 ODX 8.00IDX 5.50 W

5714	5.09.0001.1.01.8	PL	EMI 41.1067.1040 LG	DRIVE SHAFT
5715	5.09.0002.1.01.9	PL	EMI 6300.1008	PISTON
5716	5.09.0003.1.01.1	PL	EMI 6300.1009	PUMP CYLINDER (BEVEL GEAR LUB PUMP)
5717	5.09.0004.1.01.2	PL	G 10.39 PAS DU	CONE TUBE
5718	5.09.0005.1.01.3	PL	PB 61.301	AXLE BOGIE FRAME (CSM)
5719	5.09.0006.1.01.4	PL	PB 61.470	INTERMEDIATE BEARING
5720	5.09.0007.1.01.5	PL	PB 61-05	TORQUE SUPPORT (TORQUE ARM PLATE)
5721	5.09.0008.1.01.6	PL	PB 61-10	TORQUE SUPPORT (TORQUE ARM PLATE)
5722	5.09.0009.1.01.7	PL	RE 14.101	HYD. DRIVE GEAR BOX
5723	5.09.0010.1.01.8	PL	UD 61.12801.SP 1668/1676	DRIVE BOGIE FRAME FOR DUO
5724	5.09.0011.1.01.9	PL	UD 61.2831	CENTER PIN (BOGIE PIVOT)
5725	5.09.0012.1.01.1	PL	UD 61.31	PIVOT
5726	5.09.0013.1.01.2	PL	UD 61.5451	INTERMEDIATE BEARING
5727	5.09.0014.1.01.3	PL	UD 61.5460	INTERMEDIATE BEARING
5728	5.09.0015.1.01.4	PL	UD 61.605.55 SHORE	DISC SPRING
5729	5.09.0016.1.01.5	PL	UD 61.7880(A)	INTERMEDIATE BEARING (NEW DUO)
5730	5.09.0017.1.01.6	PL	UD 61.9201.SP 1668/1676 D	DRIVE AXLE BOGIE FRAME (UNI)
5731	5.09.0018.1.01.7	PL	UD 61-2635-02	ROD
5732	5.09.0019.1.01.8	PL	UD 61-9901-SP-1668-1676 R	RUNNING AXLE BOGIE FRAME (UNI)
5733	5.09.0020.1.01.9	PL	UD 62.5605	AXLE BEARING BODY
5734	5.09.0021.1.01.1	PL	UD 64.302	HELICAL GEAR OF 28 TEETH
5735	5.09.0022.1.01.2	PL	UD 64.903	HELICAL GEAR OF 28 TEETH
5736	5.09.0023.1.01.3	PL	UD61.2631	PIVOT
5737	5.09.0024.1.01.4	PL	UD64.1017G	OIL SUMP
5738	5.09.0025.1.01.5	PL	UD64.1304	SLIDING RING
5739	5.09.0026.1.01.6	CR	BS550(IND)-20-04-00	DRIVING DEVICE
				HOISTING PEDESTAL
5740	5.09.0027.1.01.7	CR	BS550(IND)-20-01-00	DRIVING SUSPENSION DEVICE
5741	5.09.0028.1.01.8	CR	BS550(IND)-21-00	Idle Bogie (Complete unit)
5742	5.09.0029.1.01.9	PL	WN63.14ZD6KN	SHOCK ABSORBER
5743	5.09.0030.1.01.1	LO	252351-109	BOGIE SYSTEM MAINTENANCE KIT, SMALL
5744	5.09.0031.1.01.2	LO	252351-110	BOGIE SYSTEM MAINTENANCE KIT, LARGE
5745	5.09.0032.1.01.3	LO	252351-111	BOGIE SYSTEM REPAIR KIT, SMALL
5746	5.09.0033.1.01.4	LO	252351-112	BOGIE SYSTEM REPAIR KIT, MED
5747	5.09.0034.1.01.5	LO	252351-113	BOGIE SYSTEM REPAIR KIT, LARGE
5748	5.09.0035.1.01.6	LO	252351-114	BOGIE SYSTEM OVERHAUL KIT
5749	5.09.0036.1.01.7	LO	252351-147	BOGIE SYSTEM MAINTENANCE KIT, SMALL
5750	5.09.0037.1.01.8	LO	252351-148	BOGIE SYSTEM MAINTENANCE KIT, LARGE
5751	5.09.0038.1.01.9	LO	252351-149	BOGIE SYSTEM REPAIR KIT
5752	5.09.0039.1.01.1	PL	UD61.7872	Shaft
5753	5.10.0001.1.01.9	PL	62-03-123	CROWN WHEEL HAND BRAKE
5754	5.10.0002.1.01.1	PL	62-03-124	CROWN WHEEL HAND BRAKE
5755	5.10.0003.1.01.2	PL	741401 MITTEL	MAGGIE FLEXIBLE WASHER
5756	5.10.0004.1.01.3	PL	741444 MITTEL	MAGGIE FLEXIBLE WASHER
5757	5.10.0005.1.01.4	PL	E63.118	SHOCK ABSORBER (EYE BORE 25.4)
5758	5.10.0006.1.01.5	PL	UD 61-4903	TORQUE SUPPORT PLATE
5759	5.10.0007.1.01.6	PL	UD 61-4912	TORQUE SUPPORT PLATE
5760	5.10.0008.1.01.7	PL	UD63.1051	TORQUE PLATE
5761	5.10.0009.1.01.8	PL	WN 131-23.5-147-335-1-DB	SPRING
5762	5.10.0010.1.01.9	PL	WN 131-35-223-335-1-DB	SPRING
5763	5.10.0011.1.01.1	PL	WN63.01ZD2.62KN	SHOCK ABSORBER
5764	5.10.0012.1.01.2	Shifted to Ann-II		
5765	5.10.0013.1.01.3	PL	WN63.03ZD0.5KN-A	SHOCK ABSORBER
5766	5.10.0014.1.01.4	PL	WN63.04ZD2.75KN	SHOCK ABSORBER
5767	5.10.0015.1.01.5	PL	2161976	SPRING
5768	5.10.0016.1.01.6	PL	2-05196	ADAPTER PLATE
5769	5.10.0017.1.01.7	PL	732073-MG-650-S4	Maggie Spring
5770	5.10.0018.1.01.8	KA	YK923.00.00.02	Maggie Flexible Washer
5771	5.10.0019.1.01.9	CR	HU20049	UNIT BRAKE-2
5772	5.10.0020.1.01.1	PL	UD214.4104-SP.1668/1676	BRAKE BAR
5773	5.10.0021.1.01.2	PL	UD214.4105-SP.1668/1676	BRAKE BAR
5774	5.10.0022.1.01.3	PL	UD215.1406	BRAKE LEVER
5775	5.10.0023.1.01.4	PL	UD230.352	FORK HEAD
5776	5.10.0024.1.01.5	KE	732106	BRAKE BLOCK
5777	5.10.0025.1.01.6	LO	250356	SHOE BRAKE, TYPE K; IR, 1000MM WHEEL
5778	5.10.0026.1.01.7	LO	252351-108	BRAKE STAND REPAIR KIT
5779	5.10.0027.1.01.8	LO	252351-115	BRAKE SYSTEM MAINTENANCE KIT, SMALL

5780	5.10.0028.1.01.9	LO	252351-116	BRAKE SYSTEM MAINTENANCE KIT, MED
5781	5.10.0029.1.01.1	LO	252351-117	BRAKE SYSTEM MAINTENANCE KIT, LARGE
5782	5.10.0030.1.01.2	LO	252351-150	BRAKE SYSTEM MAINTENANCE KIT, SMALL
5783	5.10.0031.1.01.3	LO	252351-151	BRAKE SYSTEM MAINTENANCE KIT, MED
5784	5.10.0032.1.01.4	LO	252351-152	BRAKE SYSTEM MAINTENANCE KIT, LARGE
5785	5.10.0033.1.01.5	PL	WN63.01Z13KN/	Shock Absorber (FRM)
5786	5.10.0034.1.01.6	PL	WN 160-40.440- 1	Rod
5787	5.12.0001.1.01.2	PL	2-05199	ADAPTER PLATE
5788	5.12.0002.1.01.3	PL	2-05776 SUB. 2-22155	SEAL RING Part No. 2-05776 SUBST 2-22155 = 03 Nos.
5789	5.12.0003.1.01.4	PL	2-05921 (A.302943) 2.4W	PISTON RING 52 DIA
5790	5.12.0004.1.01.5	PL	2-05921 (A-302943) 3.6W	PISTON RING 52 DIA
5791	5.12.0005.1.01.6	PL	2-05922	O RING
5792	5.12.0006.1.01.7	PL	2-05928	SEAL RING
5793	5.12.0007.1.01.8	PL	2-05929	SEAL RING
5794	5.12.0008.1.01.9	PL	2-05936 SUB. A.305784	SEAL RING
5795	5.12.0009.1.01.1	PL	2-05940	SEAL RING
5796	5.12.0010.1.01.2	PL	2-05949	PISTON GASKET
5797	5.12.0011.1.01.3	PL	2-05974	SNAP RING
5798	5.12.0012.1.01.4	PL	2-06734	SNAP RING
5799	5.12.0013.1.01.5	PL	2-06782	SNAP RING
5800	5.12.0014.1.01.6	PL	2-06794	SNAP RING
5801	5.12.0015.1.01.7	PL	2-06796	SNAP RING
5802	5.12.0016.1.01.8	PL	21.89X2.62 NBR90	O RING
5803	5.12.0017.1.01.9	PL	210-033/04/00	ANGLE GEAR
5804	5.12.0018.1.01.1	PL	2-12270	SNAP RING
5805	5.12.0019.1.01.2	PL	2-15054	PISTON HOUSING
5806	5.12.0020.1.01.3	PL	2-15055	PISTON HOUSING
5807	5.12.0021.1.01.4	PL	2-17202	SNAP RING
5808	5.12.0022.1.01.5	PL	2-17981	PRESSURE SPRING
5809	5.12.0023.1.01.6	PL	2-17982	DISC
5810	5.12.0024.1.01.7	PL	2-17984	PRESSURE SPRING
5811	5.12.0025.1.01.8	PL	2-18176	PRESSURE SPRING
5812	5.12.0026.1.01.9	PL	2-18177	PRESSURE SPRING
5813	5.12.0027.1.01.1	PL	2-18672	PRESSURE PLATE
5814	5.12.0028.1.01.2	PL	2-18677	SNAP RING
5815	5.12.0029.1.01.3	PL	2-18678	SNAP RING
5816	5.12.0030.1.01.4	PL	2-18693	SNAP RING
5817	5.12.0031.1.01.5	PL	2-18710	PRESSURE PLATE
5818	5.12.0032.1.01.6	PL	2-18785	WASHER
5819	5.12.0033.1.01.7	PL	2-20884	PISTON
5820	5.12.0034.1.01.8	PL	2-20900	SPLIT RING
5821	5.12.0035.1.01.9		Repeated item	
5822	5.12.0036.1.01.1	PL	2244571/KG2394.112.054	CLUTCH CYLINDER
5823	5.12.0037.1.01.2	PL	2-24570	SEAL RING
5824	5.12.0038.1.01.3	PL	24,99X3,53-N-DIN3771-NBR90	O-RING
5825	5.12.0039.1.01.4	PL	278,77X5,33-N-DIN3771-NBR90	O-RING
5826	5.12.0040.1.01.5	PL	32,97X3,53 NBR90	O RING
5827	5.12.0041.1.01.6	PL	3-20210	ADAPTER PLATE
5828	5.12.0042.1.01.7	PL	3-20212	ADAPTER PLATE
5829	5.12.0043.1.01.8	PL	3-20892	PISTON UNIT
5830	5.12.0044.1.01.9	PL	37,69X3,53-N-DIN3771-NBR90	O-RING
5831	5.12.0045.1.01.1	PL	5/8 Z-DIN-5401/III	STEEL BALL
5832	5.12.0046.1.01.2	PL	61.02.242	SPACER RING
5833	5.12.0047.1.01.3	PL	61.02.244	RING
5834	5.12.0048.1.01.4	PL	61.02.247	SPACER RING
5835	5.12.0049.1.01.5	PL	61-02-236	PISTON
5836	5.12.0050.1.01.6	PL	61-02-237	VALVE BUSH
5837	5.12.0051.1.01.7	PL	61-02-239	SPACER RING
5838	5.12.0052.1.01.8	PL	61-02-240	SPRING
5839	5.12.0053.1.01.9	PL	61-02-241	SPRING
5840	5.12.0054.1.01.1	PL	64.02+D4161:D4181.2000.51STKL	COUPLING
5841	5.12.0055.1.01.2	PL	0367	VALVE Part No. 2-03763 = 01 No.
5842	5.12.0056.1.01.3	PL	05199	ADAPTER PLATE Part No.2-05199 = 08 Nos.
5843	5.12.0057.1.01.4	PL	05928	SEAL RING Part No. 2-05928 = 01 No.
5844	5.12.0058.1.01.5	PL	05929	SEAL RING Part No.2-05929 = 01 No.
5845	5.12.0059.1.01.6	PL	05940	SEAL RING Part No. 2-05940 = 01 No.
5846	5.12.0060.1.01.7	PL	06734	SNAP RING Part No.2-06734 = 03 Nos.
5847	5.12.0061.1.01.8	PL	06794	SNAP RING Part No. 2-06794 = 01 No.
5848	5.12.0062.1.01.9	PL	06796	SNAP RING Part No.2-06796 = 01 No.
5849	5.12.0063.1.01.1	PL	2. 15054	PISTON HOUSING Part No. 2-15054 = 01 No.

5850	5.12.0064.1.01.2	PL	2.15055	PISTON HOUSING Part No. 2-15055 = 01 No.
5851	5.12.0065.1.01.3			Repeated item
5852	5.12.0066.1.01.4			Repeated item
5853	5.12.0067.1.01.5			Repeated item
5854	5.12.0068.1.01.6	PL	18677	SNAP RING Part No. 2-18677 = 01 No.
5855	5.12.0069.1.01.7	PL	18678	SNAP RING Part No. 2-18678 = 01 No.
5856	5.12.0070.1.01.8	PL	20210	ADAPTER PLATE Part No. 3-20210 = 09 Nos.
5857	5.12.0071.1.01.9	PL	20884	PISTON Part No. 2-20884 = 01 No.
5858	5.12.0072.1.01.1	PL	20892	PISTON UNIT Part No. 3-20892 = 01 No.
5859	5.12.0073.1.01.2	PL	3.20896	DRUM-UNIT Part No. 3-20896 = 01 No.
5860	5.12.0074.1.01.3	PL	24570	SEAL RING Part No. 2-24570 = 03 Nos.
5861	5.12.0075.1.01.4	PL	64.02.2000.52STKL	COUPLING Consisting of
5862	5.12.0076.1.01.5	PL	2.03761	VALVE
5863	5.12.0077.1.01.6			Repeated item
5864	5.12.0078.1.01.7			Repeated item
5865	5.12.0079.1.01.8	PL	2=05922	O-RING Part No. 2-05922 = 01 No.
5866	5.12.0080.1.01.9	PL	2-25949	PISTON GASKET Part No. 2-05949 = 01 No.
5867	5.12.0081.1.01.1			Repeated item
5868	5.12.0082.1.01.2			Repeated item
5869	5.12.0083.1.01.3			Repeated item
5870	5.12.0084.1.01.4			Repeated item
5871	5.12.0085.1.01.5			Repeated item
5872	5.12.0086.1.01.6	PL	2.18513	PISTON HOUSING Part No. A2-18513 = 01 No.
5873	5.12.0087.1.01.7			Repeated item
5874	5.12.0088.1.01.8			Repeated item
5875	5.12.0089.1.01.9			Repeated item
5876	5.12.0090.1.01.1	PL	2.19692	PISTON UNIT Part No. A3-19692 = 01 No.
5877	5.12.0091.1.01.2	PL	2.20212	ADAPTER PLATE Part No. 3-20212 = 09 Nos.
5878	5.12.0092.1.01.3	PL	2.20994	PISTON HOUSING Part No. A2-20994 = 01 No.
5879	5.12.0093.1.01.4			Repeated item
5880	5.12.0094.1.01.5	PL	2.22223	PISTON Part No. A2-22223 = 01 No.
5881	5.12.0095.1.01.6	PL	64.02.2101	CLUTCH GEAR WHEEL
5882	5.12.0096.1.01.7	PL	64.02.2103	CLUTCH GEAR WHEEL
5883	5.12.0097.1.01.8	PL	64.08.8319	PLATE
5884	5.12.0098.1.01.9	PL	64-02-2000-129STKL	COUPLING FOR BCM & FRM
5885	5.12.0099.1.01.1	PL	64-02-2000-130STKL	COUPLING FOR BCM & FRM
5886	5.12.0100.1.01.2	PL	64-09-1348	PRESSURE SPRING
5887	5.12.0101.1.01.3	PL	A2-18513	PISTON HOUSING
5888	5.12.0102.1.01.4	PL	A2-20994	PISTON HOUSING
5889	5.12.0103.1.01.5	PL	A2-22223	PISTON
5890	5.12.0104.1.01.6	PL	A3-19692	PISTON UNIT
5891	5.12.0105.1.01.7	PL	A3-20898	NAVE UNIT
5892	5.12.0106.1.01.8	PL	A3-29200	NAVE-UNIT
5893	5.12.0107.1.01.9	PL	A3-29204	DRUM-UNIT
5894	5.12.0108.1.01.1	PL	A38X44X1,5DIN7603-CU	SEAL RING
5895	5.12.0109.1.01.2	PL	ATD70-90-6DIN3760-NB	SEAL RING
5896	5.12.0110.1.01.3	PL	SU 1702-21-1-6	NAVE UNIT
5897	5.12.0111.1.01.4	PL	U61.103	PRESSURE DISC
5898	5.12.0112.1.01.5	PL	UD 70-1301	CLUTCH BELL HOUSING
5899	5.12.0113.1.01.6	PL	UD 70-4532	DRIVE SHAFT
5900	5.12.0114.1.01.7	PL	UD 76-03	SPUR WHEEL
5901	5.12.0115.1.01.8	PL	UD 76-16	CLUTCH ACTUATING ASSY.
5902	5.12.0116.1.01.9	PL	UD 76-205	SPLINED SHAFT
5903	5.12.0117.1.01.1	PL	UD 76-216	FLANGE
5904	5.12.0118.1.01.2	PL	UD 76-803	SPUR WHEEL
5905	5.12.0119.1.01.3	PL	WN 152-5480-12/24-1	CARRIER
5906	5.12.0120.1.01.4	PL	WN 152-5480-16/32-1	CARRIER
5907	5.12.0121.1.01.5	PL	WN 152-5480-5480-2	CARRIER
5908	5.12.0122.1.01.6	PL	WN 152-5480-5480-5	CARRIER
5909	5.12.0123.1.01.7	PL	WN 152-5480-5480-6	CARRIER FOR FRM SPLITTER BOX
5910	5.12.0124.1.01.8	PL	WN 21-61-95-6-1	WASHER
5911	5.12.0125.1.01.9	PL	WN 67-00C	CARRIER
5912	5.12.0126.1.01.1	PL	2-05921(A-302943)2.4W	PISTON RING 55 DIA
5913	5.12.0127.1.01.2	PL	3-20896	DRUM UNIT
5914	5.12.0128.1.01.3			Repeated item

5915	5.12.0129.1.01.4			Repeated item
5916	5.12.0130.1.01.5			Repeated item
5917	5.12.0131.1.01.6	PL	62.09.1008	PRESSURE SPRING
5918	5.12.0132.1.01.7			Shifted to Ann-II
5919	5.12.0133.1.01.8	PL	64.02.2109	SPACER RING
5920	5.12.0134.1.01.9	PL	E4245.1.01.8 PL	SLEEVE RING
5921	5.12.0135.1.01.1	PL	A2-20994	PISTON HOUSING
5922	5.12.0136.1.01.2			Repeated item
5923	5.12.0137.1.01.3			Repeated item
5924	5.12.0138.1.01.4			Repeated item
5925	5.12.0139.1.01.5	PL	2-03763	VALVE
5926	5.12.0140.1.01.6	PL	WN74.303	SPUR WHEEL
5927	5.12.0141.1.01.7	PL	WN74.304	SPUR WHEEL
5928	5.12.0142.1.01.8	PL	WN70.3400-111	DRIVE SHAFT
5929	5.12.0143.1.01.9	PL	UD73.504	DRIVE SHAFT
5930	5.12.0144.1.01.1	PL	WN152-5480.5480-10	CARRIER
5931	5.12.0145.1.01.2	PL	M63.254-DB	PRESSURE SPRING
5932	5.12.0146.1.01.3	CR	40100378-090	PISTON, CLUTCH
5933	5.12.0147.1.01.4	PL	64.04.2118	Clutch Bearing
5934	5.13.0001.1.01.3	PL	64.04.3000.114	MAIN GEAR BOX FRONT FOR BCM
5935	5.13.0002.1.01.4	PL	64.04.3000.115	MAIN GEAR BOX REAR FOR BCM
5936	5.13.0003.1.01.5	PL	EM-1045-MR-1/3-55	REDUCTION GEAR BOX ASSEMBLY COMPLETE
5937	5.13.0004.1.01.6			Shifted to Ann-II
5938	5.13.0005.1.01.7	PL	-	TURRET GEAR BOX
5939	5.13.0006.1.01.8	PL	--	PUMP DRIVE GEAR BOX FOR 09-3X
5940	5.13.0007.1.01.9	PL	---	PUMP DRIVE GEAR BOX FOR MPT
5941	5.13.0008.1.01.1	KE	799108	TRANSMISSION GEAR BOX FOR BRM
5942	5.13.0009.1.01.2	HA	H-3191 W01	GEAR BOX & AXLE ASSY. OF TRT,SL. NO.144,146,147
5943	5.13.0010.1.01.3	PH	UTV1.02/04/00	DROP DOWN GEAR BOX COMPLETE
5944	5.13.0011.1.01.4	KA	51.00.00.000.14	HYD.TRANSMISSION GEAR BOX
5945	5.13.0012.1.01.5	PL	WN43.00/EM1045F/701/00-OMT	REDUCTION GEAR BOX
5946	5.13.0013.1.01.6	GE	FAP-200	Auxiliary driving axle gear box
5947	5.13.0014.1.01.7	GE	GEO-15K	Transmission Gear Box
5948	5.13.0015.1.01.8	GE	RR510MS/- 4(154B5751M5+154-2259+154-5986)	Reduction box
5949	5.13.0016.1.01.9	CR	BS550(IND)-20-06-00	GEAR BOX WHEELSET -
5950	5.13.0017.1.01.1	CR	KDM 215	AXEL GEAR BOX (Complete)
5951	5.13.0018.1.01.2	PL	UD62.3900.1	SATELLITE AXEL GEAR BOX ASSY
5952	5.13.0019.1.01.3	PL	WN70.1200	GEAR BOX ASSY
5953	6.01.0001.1.01.1	GE	TE03-02.01.00A-XF	Tamping uplift cylinder
5954	6.01.0002.1.01.2	GE	50.18	Squeeze cylinder
5955	6.01.0003.1.01.3	CR	40108603	Tool tilting cylinder
5956	6.03.0001.1.01.3	CR	23081889	Left outside tamping arm
5957	6.03.0002.1.01.4	CR	23081890	Right outside tamping arm
5958	6.03.0003.1.01.5	CR	23081891	Left inside tamping arm
5959	6.03.0004.1.01.6	CR	23081892	Right inside tamping arm
5960	6.03.0005.1.01.7	CR	23081888	Right tamping arm
5961	6.03.0006.1.01.8	CR	23081887	Left tamping arm
5962	6.03.0007.1.01.9	CR	23079887	LEFT TAMPING ARM
5963	6.03.0008.1.01.1	CR	23079888	RIGHT TAMPING ARM
5964	6.04.0001.1.01.4	CR	23086759	Vibration shaft assembly
5965	6.05.0001.1.01.5	GE	TE03-01.02.33	Screw, against the tamping tine
5966	6.05.0002.1.01.6	GE	CDCK16A-56-06-00	Center post
5967	6.05.0003.1.01.7	GE	GB/T2509 20-26-30	Copper alloy integrated axle bushing-1
5968	6.05.0004.1.01.8	GE	GB/T2509 25-32-30	Copper alloy integrated axle bushing-2
5969	6.05.0005.1.01.9	GE	CDC16A-56(1)-02-09	Position-limited plate
5970	6.05.0006.1.01.1	GE	PM5050DX	Sleeve-1
5971	6.05.0007.1.01.2	GE	PM5030DX	Sleeve-2
5972	6.05.0008.1.01.3	GE	4N-04	Plug
5973	6.05.0009.1.01.4	CR	BS550(IND)-20-05-01	PIN-1
5974	6.05.0010.1.01.5	CR	BS550(IND)-20-05-03	PIN-2
5975	6.05.0011.1.01.6	CR	GB/Y882-B16X90X84	PIN-3
5976	6.05.0012.1.01.7	CR	BS550(IND)-20-07-06	CENTER PIN OF CENTER PLATE
5977	6.05.0013.1.01.8	CR	40100378-094	PIN, SOLID
5978	6.05.0014.1.01.9	CR	BS550-07-04	PIN-1
5979	6.05.0015.1.01.1	CR	BS550-07-02-17-04	PIN-2
5980	6.05.0016.1.01.2	CR	BS550-07-02-18	PIN-3
5981	6.05.0017.1.01.3	CR	BS550(IND)-09-30	PIN-1
5982	6.05.0018.1.01.4	CR	BS550(IND)-09-41	PIN-2

5983	6.05.0019.1.01.5	CR	BS550-10-16-08	PIN
5984	6.05.0020.1.01.6	CR	BS500W(IND)-13-01-09	SLEEVE
5985	6.05.0021.1.01.7	CR	BS500W(IND)-13-01-10	SLEEVE 2
5986	6.05.0022.1.01.8	CR	23067096	PIN(35mm)Near vibration shaft
5987	6.05.0023.1.01.9	CR	23067097	PIN(35mm)away from vibration shaft
5988	6.05.0024.1.01.1	CR	23067098	PIN(35mm)Vertical
5989	6.05.0025.1.01.2	CR	20261423	Tamping arm Pin(55mm)
5990	6.05.0026.1.01.3	CR	20261429	Shaft(65mm Pin)
5991	6.05.0027.1.01.4	CR	23069831	PIN
5992	6.05.0028.1.01.5	PL	V 40. CPD 510	V.Ring
5993	6.05.0029.1.01.6	PL	DL 10.56	Cover
5994	6.06.0001.1.01.6	CR	23067100	Pin bushing
5995	6.06.0002.1.01.7	CR	23067101	Pin bushing
5996	6.08.0001.1.01.8	GE	CU30.6820	Alloy tamping tine-9
5997	6.08.0002.1.01.9	GE	CU30.2723	Alloy tamping tine-8
5998	6.08.0003.1.01.1	CR	80264411938	TAMPING TOOLS
5999	6.08.0004.1.01.2	CR	80264411108	TAMPING TOOLS
6000	6.08.0005.1.01.3	CR	80264412930	TAMPING TOOLS
6001	6.11.0001.1.01.2	GE	CDCK16A-56-01-00	Lifting and lining bracket
6002	6.11.0002.1.01.3	GE	CDCK16A-56-02-00	Lifting hook kit
6003	6.11.0003.1.01.4	GE	CDCK16A-56-03	Guide post
6004	6.11.0004.1.01.5	GE	CDCK16A-56-05-00	Longitudinal displacement mechanism
6005	6.11.0005.1.01.6	GE	CDC16A-56(I)-02-00	Rail clamp ass.
6006	6.11.0006.1.01.7	GE	CDC16A-56(I)-19	Pin shaft-1
6007	6.11.0007.1.01.8	GE	CDCK16A-56-08-00	Locking device
6008	6.11.0008.1.01.9	GE	CDCK16A-56-02-01	Left guide sleeve
6009	6.11.0009.1.01.1	GE	CDCK16A-56-02-02	Lifting hook
6010	6.11.0010.1.01.2	GE	CDCK16A-56-02-04	Right guide sleeve
6011	6.11.0011.1.01.3	GE	GB/T 1096 12-32	Flat key
6012	6.11.0012.1.01.4	GE	FI24(12-10-430)	Felt
6013	6.11.0013.1.01.5	GE	GB/T893.1 110	Retainer ring for hole-1
6014	6.11.0014.1.01.6	GE	CDCK16A-56-02-05	Cover
6015	6.11.0015.1.01.7	GE	CDCK16A-56-02-06	Bushing
6016	6.11.0016.1.01.8	GE	GB/T 1152 M10-1	Oil cup
6017	6.11.0017.1.01.9	GE	CDCK16A-56-02-09	Pin shaft
6018	6.11.0018.1.01.1	GE	GB/T839.1 55	Retainer ring for hole-2
6019	6.11.0019.1.01.2	GE	CDC16A-56(I)-02-01	Clamp cylinder
6020	6.11.0020.1.01.3	GE	CDC16A-56(I)-02-02	Dual-arm clamp
6021	6.11.0021.1.01.4	GE	CDC16A-56(I)-02-03	Single-arm clamp
6022	6.11.0022.1.01.5	CR	23083964	CLAMP ROLLER ASSEMBLY
6023	6.11.0023.1.01.6	CR	23083963	TRACK LIFTING HOOK
6024	6.11.0024.1.01.7	CR	23083965	CLAMP ROLLER
6025	6.11.0025.1.01.8	CR	23085587	FRONT CLAMP ROLLER
6026	6.11.0026.1.01.9	PL	UD313.1002LI	Guide Piece.
6027	6.11.0027.1.01.1	PL	UD313. 1002RE	Guide Piece.
6028	7.01.0001.1.01.2	CR	40100378-063	BEARING, RADIAL BALL-1
6029	7.01.0002.1.01.3	CR	40100378-074	BEARING, RADIAL BALL
6030	7.01.0003.1.01.4	CR	40100378-099	BEARING, RADIAL BALL-3
6031	7.01.0004.1.01.5	CR	1308	SINGLE-ROW RADIAL BALL BEARING
6032	7.01.0005.1.01.6	CR	GB/T276-94-6020	SINGLE ROW DEEP GROOVE BALL BEARING
6033	7.01.0006.1.01.7	CR	GB-T276-104	DEEP GROOVE BALL BEARING
6034	7.01.0007.1.01.8	Shifted to Ann-II		
6035	7.01.0008.1.01.9	PL	S626ZSJA5C8/13EQL21 OR S626ZSJA5C8/13EQL 10-6	BEARING
6036	7.01.0009.1.01.1	PL	S6000ZSJA5C8/13EQL10-6 OR S6000GPRJL001	BEARING
6037	7.02.0001.1.01.3	PH	90010010	CYLINDER ROLLER BEARING
6038	7.02.0002.1.01.4	CR	40100378-075	BEARING, CYLINDRICAL ROLLER-1
6039	7.02.0003.1.01.5	CR	40100378-078	BEARING, CYLINDRICAL ROLLER-2
6040	7.02.0004.1.01.6	PL	WN71.115/H67C and Sub : WN71.115	BEARING
6041	7.02.0005.1.01.7	PL	UD64.1306	ROLLER BEARING
6042	7.03.0001.1.01.4	GE	GE30ES-2RS	Spherical bearing
6043	7.03.0002.1.01.5	CR	41061562	SPHERICAL BEARING
6044	7.04.0001.1.01.5	PH	90020012	TAPER ROLLER BEARING
6045	7.04.0002.1.01.6	PH	90020045	BEARING TAPER ROLLER
6046	7.04.0003.1.01.7	PH	UTV1.01/07/00	BEARING ROLLER
6047	7.08.0001.1.01.9	CR	41072226	Bush(pg bush)
6048	7.08.0002.1.01.1	PL	WN121-90.95.90-1	Plain bearing bush (Glacier bush)
6049	7.08.0003.1.01.2	PL	MB3520DU	BUSH
6050	7.08.0004.1.01.3	PL	PM3530DX	BUSH

6051	7.08.0005.1.01.4	LO	100115	BUSHING SLIDE 2.952 OD 2.265 BORE 3.12-12 THREAD
6052	7.08.0006.1.01.5	LO	242910	BUSHING HARDENED STEEL; 1.75IDX2.25 OD NO CANT
6053	7.08.0007.1.01.6	LO	100126	BUSHING SLIDE 4.875 OD 4.010 BORE 5.25-12 THREAD
6054	7.08.0008.1.01.7	LO	100140	BUSHING-HARDENED STEEL; P-64-10
6055	7.08.0009.1.01.8	LO	100178	BUSHING HARDENED STEEL 1.00 ID x 1.25 OD x .75LG
6056	7.08.0010.1.01.9	LO	208567	BUSHING-HARDENED STEEL; .75 ID X 1.00 OD X 1.00 LG
6057	7.09.0001.1.01.1	PL	UCT-311	BEARING
6058	7.09.0002.1.01.2			Shifted to Ann-II
6059	7.09.0003.1.01.3	PL	WN70.1217/H67 C, SUB. LM236749/LM236710	TAPERED ROLLER BEARING
6060	7.09.0004.1.01.4	KE	161099	BROOM BEARING
6061	7.09.0005.1.01.5	KE	238975	UJ CROSS FOR BRM
6062	7.09.0006.1.01.6			Shifted to Ann-II
6063	7.09.0007.1.01.7	KE	44353	KIT CROSS BEARING
6064	7.09.0008.1.01.8	KE	81859	BEARING
6065	7.09.0009.1.01.9	LO	109289	BEARING T.M. SUPPORT .03; UNDERSIZE 8.00 TWIN SEAL
6066	7.09.0010.1.01.1	GE	GB/T9163 GE35	Joint bearing
6067	7.09.0011.1.01.2	CR	BS550(IND)-10-04-02	BEARING PEDESTAL
6068	7.09.0012.1.01.3	PL	UD15.5252	BEARING BUSH
6069	7.09.0013.1.01.4	PL	UD61.10070KGV and Sub UD61.10070	INTERMEDIATE BEARING
6070	7.09.0014.1.01.5	PL	WN73.210-225	CARDAN SHAFT I.BEAING
6071	7.09.0015.1.01.6	LO	177643	BEARING SPHERICAL PLAIN; .75 ID X 1.50 OD W/PTFE (REPAIR PART FOR 206370)
6072	7.09.0016.1.01.7	LO	242904	BUSHING SLIDE 2.953 OD; 2.269 BORE
6073	7.09.0017.1.01.8	LO	H30290	BUSHING SPLIT 16-10
6074	8.01.0001.1.01.3	CR	40100378-066	SCREW, ALLEN, M10X55 (12.9)
6075	8.01.0002.1.01.4	CR	40100378-069	SCREW, ALLEN, M10X45 (12.9)
6076	8.01.0003.1.01.5	CR	40100378-096	SCREW, ALLEN, M10X30 (12.9)
6077	8.01.0004.1.01.6	CR	40100378-101	SCREW, ALLEN, M8X130 (8.8)
6078	8.01.0005.1.01.7	CR	40100378-108	SCREW, ALLEN, M14X45 (8.8)
6079	8.01.0006.1.01.8	CR	40100378-110	SCREW, ALLEN, M10X45 (8.8)
6080	8.01.0007.1.01.9	CR	GB/T78-M12X30	HEXAGON SOCKET SET SCREWS WITH CONE POINT
6081	8.01.0008.1.01.1	CR	GB/T78-M12X16	HEXAGON SOCKET SET SCREWS WITH CONE POINT
6082	8.02.0001.1.01.4	CR	40100378-105	SCREW, HEX, M10X60 (8.8)
6083	8.02.0002.1.01.5	CR	GB-T5783-M12X40-12.9	BOLT M12X40-12.9
6084	8.02.0003.1.01.6	CR	GB/T5783-M8X40	BOLT M8X40
6085	8.02.0004.1.01.7	CR	GB-T5782-M12x40	BOLT M12X40
6086	8.03.0001.1.01.5	GE	GB/T93 8	Spring washer
6087	8.03.0002.1.01.6	GE	GB/T93 12	Spring washer
6088	8.03.0003.1.01.7	CR	40100378-019	WASHER, CONICAL-1
6089	8.03.0004.1.01.8	CR	40100378-111	WASHER, COPPER
6090	8.03.0005.1.01.9	CR	GB-T97.1-12	FLAT WASHER A-CLASS
6091	8.03.0006.1.01.1	CR	GB/T95-12	FLAT WASHER
6092	8.03.0007.1.01.2	GE	GB/T93 10	Spring washer-1
6093	8.03.0008.1.01.3	GE	GB/T93 16	Spring washer-3
6094	8.03.0009.1.01.4	GE	GB/T93 14	spring washer-1
6095	8.03.0010.1.01.5	GE	CDCK16A-56-07	Retainer plate
6096	8.03.0011.1.01.6	CR	CQS300-04-15-05	TAB WASHER
6097	8.03.0012.1.01.7	CR	BS550(IND)-09-12-03	WASHER-1
6098	8.03.0013.1.01.8	CR	BS550(IND)-09-55	WASHER-2
6099	8.03.0014.1.01.9	CR	DWY-S-02-03-07	CHECK WASHER
6100	8.03.0015.1.01.1	CR	23067102	TAFLON WASHER
6101	8.03.0016.1.01.2	LO	101813	WASHER SNUBBING
6102	8.03.0017.1.01.3	LO	125608	WASHER SNUBBING
6103	8.04.0001.1.01.6	CR	GB/T91-4X28	SPLIT PIN-1
6104	8.04.0002.1.01.7	CR	GB/T91-8X60	SPLIT PIN-2
6105	8.04.0003.1.01.8	CR	GB/T91-3.2X22	SPLIT PIN-3
6106	8.04.0004.1.01.9	CR	GB/T91-4X32	SPLIT PIN-4
6107	8.04.0005.1.01.1	CR	GB/T91-5x45	SPLIT PIN-5
6108	8.05.0001.1.01.7	GE	GB/T5782 M8-40	Bolt-2

6109	8.05.0002.1.01.8	CR	CDC16W(IND)-07-08	BOLT FOR HEXAGON SCREW ROD WITH HOLE
6110	8.05.0003.1.01.9	CR	GB-T32.1-M10X35	EYE BOLT M10X35
6111	8.05.0004.1.01.1	LO	157447	CLAMP T-BOLT 25.50-25.81 DIA
6112	8.06.0001.1.01.8	GE	GB/T70.1 M12-40	Screw-1
6113	8.06.0002.1.01.9	GE	M48-1.5	Slotted nut
6114	8.06.0003.1.01.1	CR	40100378-097	SCREW, SET M8X8
6115	8.06.0004.1.01.2	CR	GB-T6182-M12	PREVAILING TORQUE TYPE HEXAGON NUTS (WITH NON-METALLIC INSERT), STYLE 2
6116	8.06.0005.1.01.3	CR	GB-T6170-M8-8	TYPE 1 HEXAGONAL NUT
6117	8.06.0006.1.01.4	GE	15 GB/T70.1 M10-25	Screw-1
6118	8.06.0007.1.01.5	GE	GB/T70.1 M12-35	Screw-2
6119	8.06.0008.1.01.6	GE	GB/T6171 M14-1.5-10	nut
6120	8.06.0009.1.01.7	GE	GB/T70.1 M14-38-10.9	screw-1
6121	8.06.0010.1.01.8	GE	GB/T70.1 M16-45-10.9	screw-2
6122	8.06.0011.1.01.9	GE	GB/T70.1 M12-20	Screw-2
6123	8.06.0012.1.01.1	GE	GB/T5783 M16-60-10.9	screw-3
6124	8.06.0013.1.01.2	GE	TE02-01.02.16	Hexagon posi. screw
6125	8.07.0001.1.01.9	PL	ESNH100-3/4Z-16UNF-R60	NUT
6126	8.07.0002.1.01.1	PL	UD311.2112.4	JOINT HEAD COMPLETE
6127	8.07.0003.1.01.2	PL	UD313.1805	LEVER
6128	8.07.0004.1.01.3	PL	UD313.1806	LEVER
6129	8.07.0005.1.01.4	PL	UD72.2807	CARRIER
6130	8.07.0006.1.01.5	PL	WN 81-303	BOLT
6131	8.07.0007.1.01.6	PL	19MM	LOCK FOR S.S STRIP
6132	8.07.0008.1.01.7	PL	19X1000	S.S. STRIP
6133	8.07.0009.1.01.8	PL	WN 81-328	CARRIER
6134	8.07.0010.1.01.9	PL	SBA-75	FOUNDATION PAD
6135	8.07.0011.1.01.1	PL	UD311.307	SPRING
6136	8.07.0012.1.01.2	CR	23086606	Transverse cylinder assembly of outer frame
6137	8.07.0013.1.01.3	CR	230866076	Transverse cylinder assembly of inner frame
6138	8.07.0014.1.01.4	CR	23071657	Lifting oil cylinder
6139	8.07.0015.1.01.5	CR	23086608	support cylinder assembly
6140	8.07.0016.1.01.6	CR	23086609	Transverse cylinder assembly of guide beam
6141	8.07.0017.1.01.7	CR	23086610	Rotating cylinder assembly
6142	8.07.0018.1.01.8	CR	23067929	LINING FORK
6143	8.07.0019.1.01.9	PL	G10.39PAS. DU	Cone Tube
6144	8.07.0020.1.01.1	PL	UD72.3724	Bracket
6145	8.07.0021.1.01.2	PL	UD50.2605	Damping Disc
6146	8.08.0001.1.01.1	PL	10MMDIN5401/III	STEEL BALL
6147	8.08.0002.1.01.2	PL	21 x 40DIN 1481	TENTION SLEEVE
6148	8.08.0003.1.01.3	PL	305-64-04-3246	DRIVE SHAFT FOR BCM
6149	8.08.0004.1.01.4	PL	62.11.1100.03	DRIVE STATION
6150	8.08.0005.1.01.5	PL	62.11.1100.04	DREDGER STATION FOR BCM
6151	8.08.0006.1.01.6	PL	62.11.7000.09/39	ROLLER FOR BCM & FRM
6152	8.08.0007.1.01.7	PL	62.11.7000.11/49	ROLLER
6153	8.08.0008.1.01.8	PL	62.11.7000.13/41	ROLLER
6154	8.08.0009.1.01.9	PL	62.11.7000.14/53	ROLLER
6155	8.08.0010.1.01.1	PL	62.11.7000.15/54	ROLLER
6156	8.08.0011.1.01.2	PL	62.11.7000.18/42	ROLLER
6157	8.08.0012.1.01.3	PL	62.11.7000.20/50	ROLLER
6158	8.08.0013.1.01.4	PL	62.11.7000.21/43	SUPORT RING FOR BCM & FRM
6159	8.08.0014.1.01.5	PL	62.11.7000.23/44	ROLLER FOR BCM & FRM
6160	8.08.0015.1.01.6	PL	62.11.7000.24/45	ROLLER FOR BCM & FRM
6161	8.08.0016.1.01.7	PL	62.11.7000.25/51	ROLLER
6162	8.08.0017.1.01.8	PL	62.11.7000.27/46	ROLLER
6163	8.08.0018.1.01.9	PL	62.11.7000.28/52	ROLLER
6164	8.08.0019.1.01.1	PL	62.11.7000.29/47	ROLLER
6165	8.08.0020.1.01.2	PL	62.11.7000.49	ROLLER FOR BCM & FRM
6166	8.08.0021.1.01.3	PL	62-09-1010	LEVER
6167	8.08.0022.1.01.4	PL	62-11-7000-10/40	ROLLER
6168	8.08.0023.1.01.5	PL	62-11-7000-42	ROLLER
6169	8.08.0024.1.01.6	PL	62-11-7000-44	ROLLER
6170	8.08.0025.1.01.7	PL	62-11-7000-45	ROLLER
6171	8.08.0026.1.01.8	PL	62-11-7000-46	ROLLER
6172	8.08.0027.1.01.9	PL	64.04.3313	SHAFT OF BCM TURRET GEAR
6173	8.08.0028.1.01.1	PL	64.08.1000.201	CHAIN GUIDE EMPTY FOR BCM
6174	8.08.0029.1.01.2	PL	64.08.8000.39	COVERING HOOD
6175	8.08.0030.1.01.3	PL	64.08.8075	GUARD PLATE
6176	8.08.0031.1.01.4	PL	64.08.8146	FRAME JOINT
6177	8.08.0032.1.01.5	PL	64.08.8163	SIDE WALL
6178	8.08.0033.1.01.6	PL	64.08.8170	TRAVERSE BEAM

6179	8.08.0034.1.01.7	PL	64.08.8317	SIDE WALL
6180	8.08.0035.1.01.8	PL	64.08.8323	GUARD PLATE
6181	8.08.0036.1.01.9		Shifted to Annexure-IIIB	
6182	8.08.0037.1.01.1		Shifted to Annexure-IIIB	
6183	8.08.0038.1.01.2	PL	64.11.10088	ROLL HOLDER
6184	8.08.0039.1.01.3	PL	64.11.3198	ROLL HOLDER
6185	8.08.0040.1.01.4	PL	64.14.1005	FLANGE
6186	8.08.0041.1.01.5	PL	64.14.1006	FLANGE
6187	8.08.0042.1.01.6		Shifted to Ann-II	
6188	8.08.0043.1.01.7	PL	64-08-3000-22	DREDGER DRUM GEAR BOX
6189	8.08.0044.1.01.8	PL	64-09-842	RUBBER PAD
6190	8.08.0045.1.01.9	PL	64-11-1000-02	DREDGER STATION
6191	8.08.0046.1.01.1	PL	64-11-1000-04	DREDGER STATION
6192	8.08.0047.1.01.2	PL	64-93-5000-103	DRIVE STATION
6193	8.08.0048.1.01.3	PL	90X60X56 MM	ROLLER TYDCR
6194	8.08.0049.1.01.4	PL	As per list	CUTTER BAR MODIFICATION SET Consisting of
6195	8.08.0050.1.01.5	PL	2.32	Mounting Block Part No. HY150.32 (1 no.)
6196	8.08.0051.1.01.6	PL	2.559	Bracket Part No. IN43-559 (2 Nos.)
6197	8.08.0052.1.01.7	PL	2.534	Bracket Part No. IN43-534 (2 Nos.)
6198	8.08.0053.1.01.8	PL	2.5.2X16	Plastic Clamp Assembly Part No. WN4-5.2X16(6 Nos.)
6199	8.08.0054.1.01.9	PL	2.0130	Cylinder Part No. RM08A-27-0130 (2 Nos.)
6200	8.08.0055.1.01.1	PL	2.0110	Fork Part No. RM08A-27-0110 (2 Nos.)
6201	8.08.0056.1.01.2	PL	2.1995	Block Part No. 64.08.1995 (2 Nos.)
6202	8.08.0057.1.01.3	PL	2.1927	Bush Part No. 64.08.1927 (2 Nos.)
6203	8.08.0058.1.01.4	PL	2.N90	Wiper Part No. DA17-0450-N90 (2 Nos.)
6204	8.08.0059.1.01.5	PL	2.1481	Tension Sleeve Part No. 21X40DIN1481 (8 Nos.)
6205	8.08.0060.1.01.6	PL	2.02	Wear Plate Part No. RM08-25,2150-02(1 No.)
6206	8.08.0061.1.01.7	PL	2.1007	Switch Box Part No. 64-07-3000-1007(1 No.)
6207	8.08.0062.1.01.8	PL	2.1006	Switch Box Part No. 64-07-3000-1006(1 No.)
6208	8.08.0063.1.01.9	PL	2.273	Plug Part No. IN43-273 (5 Nos.)
6209	8.08.0064.1.01.1	PL	2.472	Circlip Part No. 160DIN472 (2 Nos.)
6210	8.08.0065.1.01.2	PL	2.1947	Bolt Part No. 64-08-1947 (2 Nos.)
6211	8.08.0066.1.01.3	PL	62.04.0114	SEAL SET FOR EXTRA LIFTING
6212	8.08.0067.1.01.4		Repeated item	
6213	8.08.0068.1.01.5	PL	97,79X3.53-N-DIN3771-NBR90	O-Ring Part No. 97,79X3.53-N-DIN3771-NBR90(1 No.)
6214	8.08.0069.1.01.6	PL	2.023	Grooved Sealing Ring Part No. G10.63(0040.070.023) (2 Nos.)
6215	8.08.0670.1.01.7	PL	2.63(2512005.209	Wiper Part No. P7-63(2512005.209) (2 Nos.)
6216	8.08.0071.1.01.8	PL	EC-2045/FE/1600	MAIN CONVEYOR BELT DRIVE REDUCTION GEAR BOX
6217	8.08.0072.1.01.9	PL	IN43.399	DISTRIBUTOR
6218	8.08.0073.1.01.1	PL	IN43.540 SUB. IN43.54	DISTRIBUTOR
6219	8.08.0074.1.01.2	PL	RE 15-200-24	PLATE
6220	8.08.0075.1.01.3	PL	RE 15-200-25	PLATE
6221	8.08.0076.1.01.4	PL	RE 20.204-LI	BRACKET
6222	8.08.0077.1.01.5	PL	RE 20.204-RE	BRACKET
6223	8.08.0078.1.01.6	PL	RE 20.420	COVER
6224	8.08.0079.1.01.7	PL	RE 20.610	BRACKET
6225	8.08.0080.1.01.8		Repeated item	
6226	8.08.0081.1.01.9	PL	TYPGR-Dia-90X60X56	ROLLER FOR BCM & FRM
6227	8.08.0082.1.01.1	PL	U 75-913	SHAFT
6228	8.08.0083.1.01.2	PL	U75.14	CONNECTING PIECE
6229	8.08.0084.1.01.3	PL	UD 50-1803	ROLLER FOR SAT. SUPPORT
6230	8.08.0085.1.01.4	PL	UD 61-453	PRESSURE PLATE
6231	8.08.0086.1.01.5	PL	UD72.302	DOUBLE U-BEARING
6232	8.08.0087.1.01.6	PL	WN70.3803	DRIVE SHAFT
6233	8.08.0088.1.01.7	PL	21X40DIN1481	TENSION SLEEVE
6234	8.08.0089.1.01.8	PL	22g8M16X75X100DIN1438	BOLT
6235	8.08.0090.1.01.9	PL	59,7X52X79M.FAC.	BUSH
6236	8.08.0091.1.01.1	PL	61.04.211	INTERMEDIATE LINK
6237	8.08.0092.1.01.2	PL	62.08.8192	ANGLE
6238	8.08.0093.1.01.3	PL	63.09.2076	FLANGE
6239	8.08.0094.1.01.4	PL	63.09.2077	RING
6240	8.08.0095.1.01.5	PL	63.09.2078	DISC
6241	8.08.0096.1.01.6	PL	63.11.1022	BUSH
6242	8.08.0097.1.01.7	PL	64.02.1111	BOLT
6243	8.08.0098.1.01.8	PL	64.02.2000.153	EXCHANGE SET WORK IN GDRIVE
6244	8.08.0099.1.01.9	PL	64.02.2000.154	EXCHANGE SET DRIVE GEAR

6245	8.08.0100.1.01.1	PL	64.02.2107.00	BUSH
6246	8.08.0101.1.01.2	PL	64.04.1120	FLANGE
6247	8.08.0102.1.01.3	PL	656.080.1050	BOLT
6248	8.08.0103.1.01.4	PL	MSB-T-AC-27642	ROUND CONNECTOR M12
6249	8.08.0104.1.01.5	PL	MSDLO-AC-T-27646	ROUND CONNECTOR M12
6250	8.08.0105.1.01.6	PL	NATR17PP	ROLLER
6251	8.08.0106.1.01.7		Shifted to Ann-II	
6252	8.08.0107.1.01.8	PL	S-5.14.1.1A	FLANGE
6253	8.08.0108.1.01.9	PL	SB115	SNAP RING
6254	8.08.0109.1.01.1	PL	SB26	RING
6255	8.08.0110.1.01.2	PL	SB52	SNAP RING
6256	8.08.0111.1.01.3		Repeated item	
6257	8.08.0112.1.01.4	PL	HIIA1845C360	SPRING
6258	8.08.0113.1.01.5	PL	HN2	RIVETING MACHINE
6259	8.08.0114.1.01.6	PL	U75.812	SHAFT
6260	8.08.0115.1.01.7	PL	64.08.10083 FOR RM08B.27.0200	CONNECTING ELBOW
6261	8.08.0116.1.01.8	PL	62.11.4000. 15	DRIVE STATION
6262	8.08.0117.1.01.9	PL	62. 08.3068	Drive shaft
6263	8.09.0001.1.01.2	PL	62.03.115	BUSH
6264	8.09.0002.1.01.3	PL	6,4X18STAHL/KOPFDURCHM.19 SUB. TSP/D/BS8190	RIVET WITH WASHER
6265	8.09.0003.1.01.4	PL	62088032/62088033	COVER BOW FOR CONVEYOR DRUM
6266	8.09.0004.1.01.5	PL	64.11.1000.37	GEAR BOX FOR MAIN CONVEYOR DRIVE OF BCM
6267	8.09.0005.1.01.6	PL	8MM/6MM	RIVETS FOR FRM
6268	8.09.0006.1.01.7	PL	RE 30-150-2	CONVEYOR SHAFT
6269	8.09.0007.1.01.8	PL	RE 30-273-3	DRIVE SHAFT FOR EXCAVATING CONVEYOR SHAFT
6270	8.09.0008.1.01.9	PL	RE 350.101	SIDE WALL
6271	8.09.0009.1.01.1	PL	RE 350.102	SIDE WALL
6272	8.09.0010.1.01.2	PL	RE 350.103	SIDE WALL
6273	8.09.0011.1.01.3	PL	RE 350.104	SIDE WALL
6274	8.09.0012.1.01.4	PL	RE 350.105	SIDE WALL
6275	8.09.0013.1.01.5	PL	RE 350.106	SIDE WALL
6276	8.09.0014.1.01.6	PL	RE 350.107	SIDE WALL
6277	8.09.0015.1.01.7	PL	RE 350.108	SIDE WALL
6278	8.09.0016.1.01.8	PL	RE20.275-2	DRIVE SHAFT
6279	8.09.0017.1.01.9	PL	RE-21-205	SLIDER FOR EXCAVATING UNIT OF FRM -80
6280	8.09.0018.1.01.1	PL	RE22.209	GUIDE BLOCK FRM MACHINE
6281	8.09.0019.1.01.2	PL	RE-30-151	COVER BOW OF MAIN CONVEYOR UNIT OF FRM-80
6282	8.09.0020.1.01.3	PL	RE-30-152	COVER BOW OF MAIN CONVEYOR UNIT OF FRM-80
6283	8.09.0021.1.01.4		Repeated item	
6284	8.09.0022.1.01.5	PL	SSP-70-01-610	CARRIER
6285	8.09.0023.1.01.6	PL	SU1201.708.1.2.1 SUB. RE20.250-2	SPROCKET DRIVE STATION FRM (SHAFT)
6286	8.09.0024.1.01.7	PL	WN 70-9102	SLIDING GEAR
6287	8.09.0025.1.01.8	PL	WN70.402E	TOOTHED GEAR
6288	8.09.0026.1.01.9	PL	WN80.2604-2	SHAFT
6289	8.09.0027.1.01.1	GE	50MV-630/151B3108	Motor
6290	8.09.0028.1.01.2	CR	BS500W(IND)-11-02-01-05- 01	upper feeding end screen
6291	8.09.0029.1.01.3	CR	BS500W(IND)-11-02-01-05- 02	upper screen
6292	8.09.0030.1.01.4	CR	BS500W(IND)-11-02-01-06- 01	Lower screen-1
6293	8.09.0031.1.01.5	CR	BS500W(IND)-11-02-01-06- 02	Lower screen-2
6294	8.09.0032.1.01.6	CR	BS550(IND)-07-00 / BS550(IND)-36-00	Left Excavating Device/ Right Excavating Device (Complete)
6295	8.09.0033.1.01.7	CR	BS550(IND)-07-01-00	LEFT EXCAVATOR
6296	8.09.0034.1.01.8	CR	BS550(IND)-36-01-00	RIGHT EXCAVATOR
6297	8.09.0035.1.01.9	CR	BS550(IND)-07-02-00	LEFT EXCAVATING EQUIPMENT CHAIN GUIDE
6298	8.09.0036.1.01.1	CR	BS550(IND)-36-02-00	RIGHT EXCAVATING EQUIPMENT CHAIN GUIDE
6299	8.09.0037.1.01.2	CR	BS550(IND)-07-03-00	EXCAVATING EQUIPMENT MOUNTING FRAME
6300	8.09.0038.1.01.3	CR	BS550(IND)-07-05-00	EXCAVATING EQUIPMENT SAFETY CHAIN
6301	8.09.0039.1.01.4	CR	GB561-65 A3.5	OPEN TURNBUCKLE
6302	8.09.0040.1.01.5	CR	BS550-07-02-17-03	PLATE
6303	8.09.0041.1.01.6	CR	BS550(IND)-07-01-01-00	LEFT EXCAVATOR BRACKET

6304	8.09.0042.1.01.7	CR	BS550(IND)-36-01-01-00	RIGHT EXCAVATOR BRACKET
6305	8.09.0043.1.01.8	CR	BS550(IND)-07-01-03-00	DRIVING DEVICE
6306	8.09.0044.1.01.9	CR	BS550-07-01-04-00	CHAIN WHEEL COMPONENT
6307	8.09.0045.1.01.1	CR	BS550(IND)-07-01-04-00	EXCAVATING CHAIN
6308	8.09.0046.1.01.2	CR	BS550(IND)-07-01-05	OPERATION SIDE WEAR PLATE I
6309	8.09.0047.1.01.3	CR	BS550(IND)-07-01-06	OPERATION SIDE WEAR PLATE II
6310	8.09.0048.1.01.4	CR	BS550(IND)-07-01-07	OPERATION SIDE WEAR PLATE III
6311	8.09.0049.1.01.5	CR	BS550(IND)-07-01-08	OPERATION SIDE WEAR PLATE IV
6312	8.09.0050.1.01.6	CR	BS550(IND)-07-01-51	OPERATION SIDE WEAR PLATE VIII
6313	8.09.0051.1.01.7	CR	BS550(IND)-07-01-09	OPERATION SIDE WEAR PLATE V
6314	8.09.0052.1.01.8	CR	BS550(IND)-07-01-10	OPERATION SIDE WEAR PLATE VI
6315	8.09.0053.1.01.9	CR	BS550(IND)-07-01-11	OPERATION SIDE WEAR PLATE VII
6316	8.09.0054.1.01.1	CR	BS550(IND)-07-01-12-00	EXCAVATING CHAIN SLOT COMPONENT I
6317	8.09.0055.1.01.2	CR	BS550(IND)-07-01-13-00	EXCAVATING CHAIN SLOT COMPONENT II
6318	8.09.0056.1.01.3	CR	BS550(IND)-07-01-14-00	EXCAVATING CHAIN SLOT COMPONENT III
6319	8.09.0057.1.01.4	CR	BS550(IND)-07-01-15-00	EXCAVATING CHAIN SLOT COMPONENT IV
6320	8.09.0058.1.01.5	CR	BS550(IND)-07-01-16-00	EXCAVATING CHAIN SLOT COMPONENT V
6321	8.09.0059.1.01.6	CR	BS550(IND)-07-01-17-00	EXCAVATING CHAIN SLOT COMPONENT VI
6322	8.09.0060.1.01.7	CR	BS550(IND)-07-01-18-00	EXCAVATING CHAIN SLOT COMPONENT VII
6323	8.09.0061.1.01.8	CR	BS550(IND)-07-01-19-00	EXCAVATING CHAIN SLOT COMPONENT VIII
6324	8.09.0062.1.01.9	CR	BS550(IND)-07-01-20-00	EXCAVATING CHAIN SLOT COMPONENT IX
6325	8.09.0063.1.01.1	CR	BS550(IND)-07-01-21-00	EXCAVATING CHAIN SLOT COMPONENT X
6326	8.09.0064.1.01.2	CR	BS550(IND)-07-01-22-00	EXCAVATING CHAIN SLOT COMPONENT XI
6327	8.09.0065.1.01.3	CR	BS550(IND)-07-01-23-00	EXCAVATING CHAIN SLOT COMPONENT XII
6328	8.09.0066.1.01.4	CR	BS550(IND)-07-01-61-00	INNER BRACKET I OF ISOLATION HOOD I
6329	8.09.0067.1.01.5	CR	BS550(IND)-07-01-62-00	INNER BRACKET II OF ISOLATION HOOD II
6330	8.09.0068.1.01.6	CR	BS550(IND)-07-01-28-00	INNER BRACKET II OF ISOLATION HOOD III
6331	8.09.0069.1.01.7	CR	BS550(IND)-07-01-29-00	INNER BRACKET III OF ISOLATION HOOD IV
6332	8.09.0070.1.01.8	CR	BS550(IND)-36-01-29-00	INNER BRACKET III OF ISOLATION HOOD V
6333	8.09.0071.1.01.9	CR	BS550(IND)-07-01-26-00	HALFTONE COVER
6334	8.09.0072.1.01.1	CR	BS550(IND)-07-01-69	HALFTONE I
6335	8.09.0073.1.01.2	CR	BS550(IND)-07-01-70	HALFTONE II
6336	8.09.0074.1.01.3	CR	BS550(IND)-07-01-71	HALFTONE III
6337	8.09.0075.1.01.4	CR	BS550(IND)-07-01-32	PLATEN OF ISOLATION HOOD BRACKET III
6338	8.09.0076.1.01.5	CR	BS550(IND)-07-01-33	PLATEN OF ISOLATION HOOD BRACKET IV
6339	8.09.0077.1.01.6	CR	BS550(IND)-07-01-34	PLATEN OF ISOLATION HOOD BRACKET V
6340	8.09.0078.1.01.7	CR	BS550(IND)-07-01-35	PLATEN OF ISOLATION HOOD BRACKET VI
6341	8.09.0079.1.01.8	CR	BS500W(IND)-07-01-65	INNER JUNCTION PLATE
6342	8.09.0080.1.01.9	CR	BS500W(IND)-07-01-66	OUTER JUNCTION PLATE
6343	8.09.0081.1.01.1	CR	BS500W(IND)-07-01-67-00	LEFT SHIELD OF TENSION CYLINDER
6344	8.09.0082.1.01.2	CR	BS500W(IND)-07-01-68-00	RIGHT SHIELD OF TENSION CYLINDER
6345	8.09.0083.1.01.3	CR	BS550(IND)-07-01-02-01-00	Digging Plate Assemble (Complete)
6346	8.09.0084.1.01.4	CR	BS550(IND)-07-01-02-01-02	DIGGING PLATE MAIN PART

6347	8.09.0085.1.01.5	CR	BS550(IND)-07-01-02-01-01- 00	DIGGING PLATE WELDING COMPONENT
6348	8.09.0086.1.01.6	CR	BS500W(IND)-07-01-02-01-03	SLEEVE
6349	8.09.0087.1.01.7	CR	BS500W(IND)-07-01-02-01-00	DIGGING PLATE ASSEMBLE
6350	8.09.0088.1.01.8	CR	BS550(IND)-07-01-02-02-00	CHAIN ASSEMBLE
6351	8.09.0089.1.01.9	CR	BS550(IND)-07-01-02-03	EXCAVATING CHAIN CONNECTION SHAFT I
6352	8.09.0090.1.01.1	CR	BS550(IND)-07-01-02-07	ROLLER
6353	8.09.0091.1.01.2	CR	BS550(IND)-07-02-01-00	LEFT EXCAVATING EQUIPMENT CHAIN GUIDE BODY
6354	8.09.0092.1.01.3	CR	BS550(IND)-36-02-01-00	RIGHT EXCAVATING EQUIPMENT CHAIN GUIDE BODY
6355	8.09.0093.1.01.4	CR	BS550(IND)-07-02-02-00	OUTER LEFT BALLAST- GATHERING-PLATE
6356	8.09.0094.1.01.5	CR	BS550(IND)-36-02-02-00	OUTER RIGHT BALLAST-GATHERING- PLATE
6357	8.09.0095.1.01.6	CR	BS550(IND)-07-02-03-00	INNER LEFT BALLAST- GATHERING-PLATE
6358	8.09.0096.1.01.7	CR	BS550(IND)-36-02-03-00	INNER RIGHT BALLAST- GATHERING-PLATE
6359	8.09.0097.1.01.8	CR	BS550(IND)-07-02-27-00	BALLAST-GATHERING- PLATE JACK STAY
6360	8.09.0098.1.01.9	CR	BS550(IND)-07-02-28-00	INNER BALLAST- GATHERING-PLATE JACK STAY
6361	8.09.0099.1.01.1	CR	BS550(IND)-07-02-16	ARTICULATED SHAFT
6362	8.09.0100.1.01.2	CR	BS550(IND)-07-02-07	BOTTOM WEAR PLATE I
6363	8.09.0101.1.01.3	CR	BS550(IND)-07-02-08	BOTTOM WEAR PLATE II
6364	8.09.0102.1.01.4	CR	BS550(IND)-07-02-09	END WEAR PLATE
6365	8.09.0103.1.01.5	CR	BS550(IND)-07-02-10	SIDE WEAR PLATE I
6366	8.09.0104.1.01.6	CR	BS550(IND)-07-02-11	SIDE WEAR PLATE II
6367	8.09.0105.1.01.7	CR	BS550(IND)-07-02-12	SIDE WEAR PLATE III
6368	8.09.0106.1.01.8	CR	BS550(IND)-07-02-13	SIDE WEAR PLATE IV
6369	8.09.0107.1.01.9	CR	BS550(IND)-07-02-14	SIDE WEAR PLATE V
6370	8.09.0108.1.01.1	CR	BS550(IND)-07-02-15	SIDE WEAR PLATE VI
6371	8.09.0109.1.01.2	CR	BS550(IND)-07-02-06-00	LEFT CHAIN GUIDE DIGGING PLATE COMPONENT-1
6372	8.09.0110.1.01.3	CR	BS550(IND)-36-02-06-00	LEFT CHAIN GUIDE DIGGING PLATE COMPONENT-2
6373	8.09.0111.1.01.4	CR	BS550(IND)-06-01-00	HEAD OF MACHINE
6374	8.09.0112.1.01.5	CR	BS550(IND)-06-02-00	MIDDLE PART 1
6375	8.09.0113.1.01.6	CR	BS550(IND)-06-03-00	MIDDLE PART
6376	8.09.0114.1.01.7	CR	BS550(IND)-06-04-00	MACHINE TAIL PART
6377	8.09.0115.1.01.8	CR	BS550(IND)-06-05-00	BALLAST FUNNEL
6378	8.09.0116.1.01.9	CR	BS550(IND)-06-06-00	PEDESTAL
6379	8.09.0117.1.01.1	CR	BS550(IND)-06-07-00	SUPPORT-1
6380	8.09.0118.1.01.2	CR	BS550(IND)-06-08-00	SUPPORT-2
6381	8.09.0119.1.01.3	CR	BS550(IND)-06-16-00	DRIVE PULLEY GROUP
6382	8.09.0120.1.01.4	CR	BS550(IND)-06-01-01-00	HEAD FRAME
6383	8.09.0121.1.01.5	CR	BS550-06-01-05-00	THROUGHING IDLER GROUP
6384	8.09.0122.1.01.6	CR	BS550-06-01-06-00	RETURN IDLER
6385	8.09.0123.1.01.7	CR	BS550(IND)-06-01-02-00	TOUNGE SCRAPER
6386	8.09.0124.1.01.8	CR	BS550(IND)-06-01-03-00	SUPPORT OF CONVEYOR BELT
6387	8.09.0125.1.01.9	CR	BS550(IND)-06-01-04-00	BAFFLE SUPPORT
6388	8.09.0126.1.01.1	CR	BS550(IND)-06-01-05-00	SPRING SCRAPER
6389	8.09.0127.1.01.2	CR	BS550(IND)-06-01-06	SUPPORTING PLATE OF BEARING PEDESTAL
6390	8.09.0128.1.01.3	CR	BS550(IND)-06-01-07	STIFFENED PANEL
6391	8.09.0129.1.01.4	CR	CQS300-17-01-06	DECKPLATE
6392	8.09.0130.1.01.5	CR	BS550(IND)-06-01-08	DECKPLATE 1
6393	8.09.0131.1.01.6	CR	BS550(IND)-06-02-02	STEEL PLATE
6394	8.09.0132.1.01.7	CR	BS550(IND)-06-01-11	STEEL PLATE Δ6 -2
6395	8.09.0133.1.01.8	CR	BS550(IND)-06-01-12	BATTEN 1
6396	8.09.0134.1.01.9	CR	BS550(IND)-06-01-13	STEEL PLATE Δ6 -3
6397	8.09.0135.1.01.1	CR	BS550(IND)-06-02-08	BATTEN
6398	8.09.0136.1.01.2	CR	BS550-06-01-05-02-00	BRACKET OF IDLER ROLLER
6399	8.09.0137.1.01.3	CR	BS550-06-01-05-01-00	ROLLER Φ102X245
6400	8.09.0138.1.01.4	CR	BS550-06-01-06-01-00	HANGING BRACKET
6401	8.09.0139.1.01.5	CR	BS550-06-01-06-02-00	ROLLER Φ102X730
6402	8.09.0140.1.01.6	CR	BS550(IND)-06-02-01-00	MIDDLE PART FRAME 2
6403	8.09.0141.1.01.7	CR	BS550(IND)-06-02-03	STEEL PLATE Δ6 -5
6404	8.09.0142.1.01.8	CR	BS550(IND)-06-02-04	BATTEN 2
6405	8.09.0143.1.01.9	CR	BS550(IND)-06-02-05	STEEL PLATE Δ6 -6
6406	8.09.0144.1.01.1	CR	BS550(IND)-06-02-09	BATTEN 4

6407	8.09.0145.1.01.2	CR	BS550(IND)-06-02-10	BATTEN 5
6408	8.09.0146.1.01.3	CR	BS550(IND)-06-02-11	STEEL PLATE Δ6 -7
6409	8.09.0147.1.01.4	CR	BS550(IND)-06-02-12	STEEL PLATE Δ6 -8
6410	8.09.0148.1.01.5	CR	BS550(IND)-06-03-01-00	MIDDLE PART FRAME
6411	8.09.0149.1.01.6	CR	BS550-06-02-04-00	BELOW CENTRING FLAT IDLER
6412	8.09.0150.1.01.7	CR	BS550(IND)-06-03-02-00	UPPER CENTRING FLAT IDLER
6413	8.09.0151.1.01.8	CR	BS550(IND)-06-03-02	STEEL PLATE Δ6 -9
6414	8.09.0152.1.01.9	CR	BS550(IND)-06-03-03	STEEL PLATE Δ6 -11
6415	8.09.0153.1.01.1	CR	BS550(IND)-06-03-04	BATTEN-4
6416	8.09.0154.1.01.2	CR	BS550(IND)-06-03-02-01-00	LARGE ROLLER
6417	8.09.0155.1.01.3	CR	BS550(IND)-03-02-00	ROTATING PEDESTAL
6418	8.09.0156.1.01.4	CR	CQS300-04-16-00	LOCKING DEVICE
6419	8.09.0157.1.01.5	CR	BS550(IND)-03-01-01-00	FRAME
6420	8.09.0158.1.01.6	CR	BS550(IND)-03-01-02-00	DRIVE PULLEY GROUP
6421	8.09.0159.1.01.7	CR	BS550(IND)-03-01-03-00	DIVERT ROLLER GROUP
6422	8.09.0160.1.01.8	CR	BS550(IND)-03-01-04-00	TENSIONER
6423	8.09.0161.1.01.9	CR	BS550(IND)-03-01-05-00	CARRIER FLAT IDLER
6424	8.09.0162.1.01.1	CR	BS550(IND)-03-01-06-00	IMPACT IDLER SET
6425	8.09.0163.1.01.2	CR	BS550(IND)-03-01-07-00	PARALLEL RETURN IDLER SET
6426	8.09.0164.1.01.3	CR	BS550(IND)-03-01-08-00	SPRING SCRAPER
6427	8.09.0165.1.01.4	CR	BS550(IND)-03-01-09-00	RETURN SCRAPER
6428	8.09.0166.1.01.5	CR	BS550(IND)-03-01-10-00	BAFFLE
6429	8.09.0167.1.01.6	CR	CQS300-17-02-02-01	PEDESTAL BODY
6430	8.09.0168.1.01.7	CR	BS550(IND)-03-01-02-01-00	PULLEY BODY
6431	8.09.0169.1.01.8	CR	DWY-S-02-03-06	SHAFT END BAFFLE
6432	8.09.0170.1.01.9	CR	BS550(IND)-03-01-02-02-01	END COVER
6433	8.09.0171.1.01.1	CR	BS550(IND)-03-01-03-01-00	ROLLER BODY
6434	8.09.0172.1.01.2	CR	BS550(IND)-03-02-01-00	PEDESTAL-1
6435	8.09.0173.1.01.3	CR	BS550(IND)-03-02-02-00	SUPPORT-1
6436	8.09.0174.1.01.4	CR	BS550(IND)-03-02-03-00	SUPPORT-2
6437	8.09.0175.1.01.5	CR	BS550(IND)-03-02-04-00	CHASSIS
6438	8.09.0176.1.01.6	CR	BS550(IND)-03-02-05	COVER PLATE
6439	8.09.0177.1.01.7	CR	CQS300-04-11	PEDESTAL-2
6440	8.09.0178.1.01.8	CR	CQS300-04-15-03-00	ASSEMBLY OF GUARD COVER
6441	8.09.0179.1.01.9	CR	CQS300-04-15-04	SHAFT END BAFFLE-2
6442	8.09.0180.1.01.1	CR	BS550(IND)-22-13-07-00	SWIVEL JOINT ASSEMBLY
6443	8.09.0181.1.01.2	CR	BS550(IND)-09-02-00	DRIVE PULLEY GROUP
6444	8.09.0182.1.01.3	CR	BS550(IND)-09-03-00	ROLLER GROUP OF CONVEYOR BELT
6445	8.09.0183.1.01.4	CR	BS550(IND)-09-04-00	SCRAPER FRAME
6446	8.09.0184.1.01.5	CR	BS550(IND)-09-05-00	IDLER PULLEY-1
6447	8.09.0185.1.01.6	CR	BS550(IND)-09-06-00	IDLER PULLEY-2
6448	8.09.0186.1.01.7	CR	BS550(IND)-09-07-00	ANGLE SCRAPER
6449	8.09.0187.1.01.8	CR	BS550(IND)-09-08-00	ROLLING FRAME-1
6450	8.09.0188.1.01.9	CR	BS550(IND)-09-09-00	ROLLING FRAME-2
6451	8.09.0189.1.01.1	CR	BS550(IND)-09-10-00	WHEEL BRACKET
6452	8.09.0190.1.01.2	CR	BS550(IND)-09-11-00	TAIL DIVERT ROLLER GROUP
6453	8.09.0191.1.01.3	CR	BS550(IND)-09-12-00	REAR BAFFLE
6454	8.09.0192.1.01.4	CR	BS550(IND)-09-13-00	ROLLER GROUP 2 OF CONVEYOR BELT
6455	8.09.0193.1.01.5	CR	BS550(IND)-09-14-00	BAFFLE-1
6456	8.09.0194.1.01.6	CR	BS550(IND)-09-15-00	BAFFLE-2
6457	8.09.0195.1.01.7	CR	BS550(IND)-09-16-00(R)	BAFFLE 2
6458	8.09.0196.1.01.8	CR	BS550(IND)-09-17-00	SUPPORT-1
6459	8.09.0197.1.01.9	CR	BS550(IND)-09-18-00	BAFFLE-3
6460	8.09.0198.1.01.1	CR	BS550(IND)-09-19-00	FUNNEL
6461	8.09.0199.1.01.2	CR	BS550(IND)-09-20-00	INTERFACE WITH EXCAVATING EQUIPMENT
6462	8.09.0200.1.01.3	CR	BS550(IND)-09-21-00	SPIRAL TENSIONER
6463	8.09.0201.1.01.4	CR	BS550(IND)-09-22-00	SAFETY CHAIN
6464	8.09.0202.1.01.5	CR	BS550(IND)-09-23-00	MOUNTING PEDESTAL
6465	8.09.0203.1.01.6	CR	BS550(IND)-09-25	IDLER RING
6466	8.09.0204.1.01.7	CR	BS550(IND)-09-26	SPRING PEDESTAL-1
6467	8.09.0205.1.01.8	CR	BS550(IND)-09-27	SPRING PEDESTAL-2
6468	8.09.0206.1.01.9	CR	BS550(IND)-09-29	COMPRESSING SPRING
6469	8.09.0207.1.01.1	CR	BS550(IND)-09-33	GUARD PLATE STRIP
6470	8.09.0208.1.01.2	CR	BS550(IND)-09-39	IDLER BRACKET
6471	8.09.0209.1.01.2	CR	BS550(IND)-09-43	BATTEN 3
6472	8.09.0210.1.01.4	CR	BS550(IND)-09-44	BATTEN 2
6473	8.09.0211.1.01.5	CR	BS550(IND)-09-45	BATTEN 1
6474	8.09.0212.1.01.6	CR	BS550(IND)-09-47	BAFFLE-4

6475	8.09.0213.1.01.7	CR	BS550(IND)-09-48	BATTEN
6476	8.09.0214.1.01.8	CR	BS550(IND)-09-50	PLATEN
6477	8.09.0215.1.01.9	CR	BS550(IND)-09-52	BATTEN 4
6478	8.09.0216.1.01.1	CR	BS550(IND)-09-53	COVER PLATE
6479	8.09.0217.1.01.2	CR	BS550(IND)-09-54-00	SUPPORT-2
6480	8.09.0218.1.01.3	CR	BS550(IND)-09-02-01-00	PULLEY BODY-1
6481	8.09.0219.1.01.4	CR	BS550(IND)-06-16-02-00	BEARING PEDESTAL-1
6482	8.09.0220.1.01.5	CR	BS550(IND)-06-16-03-00	BEARING PEDESTAL-2
6483	8.09.0221.1.01.6	CR	BS550(IND)-09-03-01-00	SLOTTED IDLER-1
6484	8.09.0222.1.01.7	CR	BS550(IND)-09-03-02-00	SLOTTED IDLER-2
6485	8.09.0223.1.01.8	CR	BS550(IND)-09-03-04	STIFFENED PANEL
6486	8.09.0224.1.01.9	CR	BS550(IND)-09-03-05	BRACKET
6487	8.09.0225.1.01.1	CR	BS550(IND)-09-05-01-00	PULLEY BODY-2
6488	8.09.0226.1.01.2	CR	BS550(IND)-09-03-01-05	COVER
6489	8.09.0227.1.01.3	CR	BS550(IND)-09-20-01-00	ASSEMBLY OF UPPER SUPPORT
6490	8.09.0228.1.01.4	CR	BS550-09-64-02-00	ASSEMBLY OF LOWER SUPPORT
6491	8.09.0229.1.01.5	CR	BS550(IND)-09-20-02-00	SUPPORTING BEAM
6492	8.09.0230.1.01.6	CR	BS550(IND)-09-16-00(L)	BAFFLE5(L)
6493	8.09.0231.1.01.7	CR	BS550(IND)-09-17-00(L)	SUPPORT
6494	8.09.0232.1.01.8	CR	BS550(IND)-09-01-01-00	RECTANGULAR TUBE-1
6495	8.09.0233.1.01.9	CR	BS550(IND)-09-01-02	WING PLATE
6496	8.09.0234.1.01.1	CR	BS550(IND)-09-01-03	CONNECTING BEAM-1
6497	8.09.0235.1.01.2	CR	BS550(IND)-09-01-04	ANGLE STEEL-1
6498	8.09.0236.1.01.3	CR	BS550(IND)-09-01-05	INNER SIDE PLATE
6499	8.09.0237.1.01.4	CR	BS550(IND)-09-01-06	ANGLE STEEL-2
6500	8.09.0238.1.01.5	CR	BS550(IND)-09-01-07(L)	INNER SIDE PLATE(R)
6501	8.09.0239.1.01.6	CR	BS550(IND)-09-01-08(L)	INNER SIDE PLATE(L)
6502	8.09.0240.1.01.7	CR	BS550(IND)-09-01-09	INNER SIDE PLATE 2
6503	8.09.0241.1.01.8	CR	BS550(IND)-09-01-10	SUPPORTING PLATE
6504	8.09.0242.1.01.9	CR	BS550(IND)-09-01-11	RECTANGULAR TUBE-2
6505	8.09.0243.1.01.1	CR	BS550(IND)-09-01-12	BLOCKING PLATE
6506	8.09.0244.1.01.2	CR	BS550(IND)-09-01-13	CONNECTING PLATE
6507	8.09.0245.1.01.3	CR	BS550(IND)-09-01-14	ANGLE STEEL-3
6508	8.09.0246.1.01.4	CR	BS550(IND)-09-01-15	ANGLE STEEL-4
6509	8.09.0247.1.01.5	CR	BS550(IND)-09-01-16	BENDING PLATE-1
6510	8.09.0248.1.01.6	CR	BS550(IND)-09-01-17	BENDING PLATE-2
6511	8.09.0249.1.01.7	CR	BS550(IND)-09-01-18	ENFORCING PLATE
6512	8.09.0250.1.01.8	CR	BS550(IND)-09-01-19	CONNECTING BEAM-2
6513	8.09.0251.1.01.9	CR	BS550-10-03-02-00	ROLLER-1
6514	8.09.0252.1.01.1	CR	BS550-10-03-03-00	ROLLER-2
6515	8.09.0253.1.01.2	CR	BS550(IND)-10-05-00	DRIVE PULLEY GROUP
6516	8.09.0254.1.01.3	CR	BS550-10-06-02-00	ROLLER-3
6517	8.09.0255.1.01.4	CR	BS550(IND)-10-07-00	SPRING SCRAPER
6518	8.09.0256.1.01.5	CR	BS550-10-07-02-00	ROLLER-4
6519	8.09.0257.1.01.6	CR	BS550-10-08-02-00	COMBING ROLLER
6520	8.09.0258.1.01.7	CR	BS550(IND)-10-06-00	RETURN SCRAPER
6521	8.09.0259.1.01.8	CR	BS550(IND)-10-04-00	TAIL IDLER
6522	8.09.0260.1.01.9	CR	BS550-10-04-01-00	IMPACT ROLLER-1
6523	8.09.0261.1.01.1	CR	BS550-10-04-02-00	IMPACT ROLLER-2
6524	8.09.0262.1.01.2	CR	BS550(IND)-10-04-01-00	TAIL ROLLER
6525	8.09.0263.1.01.3	CR	BS550-06-01-02-01-01	PEDESTAL BODY
6526	8.09.0264.1.01.4	CR	BS500W(IND)-13-00	Assembly of Side Plough (Complete)
6527	8.09.0265.1.01.5	CR	BS500W(IND)-13-01-00	LEFT SIDE PLOUGH
6528	8.09.0266.1.01.6	CR	BS500W(IND)-13-02-00	RIGHT SIDE PLOUGH
6529	8.09.0267.1.01.7	CR	BS500W(IND)-13-08	WING PLATE PROXIMITY SWITCH MOUNTING PLATE
6530	8.09.0268.1.01.8	CR	BS500W(IND)-13-09	STIFFENED PANEL 1 OF VEHICLE FRAME
6531	8.09.0269.1.01.9	CR	BS500W(IND)-13-10	STIFFENED PANEL 2 OF VEHICLE FRAME
6532	8.09.0270.1.01.1	CR	BS500W(IND)-13-11	STIFFENED PANEL 3 OF VEHICLE FRAME
6533	8.09.0271.1.01.2	CR	BS500W(IND)-13-12	STIFFENED PANEL 4 OF VEHICLE FRAME
6534	8.09.0272.1.01.3	CR	BS500W(IND)-13-22-00	TURNBUCKLE ASSEMBLE
6535	8.09.0273.1.01.4	CR	BS500W(IND)-13-14-00	SAFETY CHAIN
6536	8.09.0274.1.01.5	CR	DPZ440-05-39	SHAFT PEDESTAL
6537	8.09.0275.1.01.6	CR	DPZ440-05-41	SHAFT SLEEVE
6538	8.09.0276.1.01.7	CR	160A-05-06-00F	COMPOSITION OF TURN-OVER CYLINDER HINGE SHAFT
6539	8.09.0277.1.01.8	CR	DPZ440-05-24	SHAFT END PLATEN
6540	8.09.0278.1.01.9	CR	BS500W(IND)-13-20-00	LEFT REAR PLOUGH PLATE

6541	8.09.0279.1.01.1	CR	BS500W(IND)-13-21-00	REAR RIGHT PLOUGH PLATE
6542	8.09.0280.1.01.2	CR	BS500W(IND)-13-01-01-00	LEFT WING PLOUGH
6543	8.09.0281.1.01.3	CR	BS500W(IND)-13-01-02-00	LEFT PLOUGH PLATE
6544	8.09.0282.1.01.4	CR	BS500W(IND)-13-01-03-00	INNER HORIZONTAL TELESCOPIC CYLINDER
6545	8.09.0283.1.01.5	CR	BS500W(IND)-13-01-04-00	OUTER HORIZONTAL TELESCOPIC CYLINDER
6546	8.09.0284.1.01.6	CR	BS500W(IND)-13-01-05-00	VERTICAL TELESCOPIC CYLINDER
6547	8.09.0285.1.01.7	CR	BS500W(IND)-13-01-06	COVER PLATE OF VERTICAL TELESCOPIC CYLINDER
6548	8.09.0286.1.01.8	CR	BS500W(IND)-13-01-07	MOUNTING SHAFT OF PLOUGH PLATE AND WING PLATE
6549	8.09.0287.1.01.9	CR	BS500W(IND)-13-01-08	SHAFT END PLATEN-1
6550	8.09.0288.1.01.1	CR	DPZ440-05-25	BRASS SLEEVE
6551	8.09.0289.1.01.2	CR	BS500W(IND)-13-01-15	SHAFT END COVER PLATE
6552	8.09.0290.1.01.3	CR	BS500W(IND)-13-01-18	SPACING PLATE
6553	8.09.0291.1.01.4	CR	BS500W(IND)-13-01-21	PLATEN
6554	8.09.0292.1.01.5	CR	BS550(IND)-13-01-01-00	Left Wing Plough (Complete)
6555	8.09.0293.1.01.6	CR	BS500W(IND)-13-01-01-18	INNER BLADE OF WING PLOUGH
6556	8.09.0294.1.01.7	CR	BS550(IND)-13-01-02-00	Left Plough Plate (Complete)
6557	8.09.0295.1.01.8	CR	BS500W(IND)-13-01-02-08	MAIN SIDE PLOUGH INNER BLADE(H)
6558	8.09.0296.1.01.9	CR	BS500W(IND)-13-20-01-00	BASEPLATE
6559	8.09.0297.1.01.1	CR	BS500W(IND)-13-20-02-00	LEFT ROTATING PLATE
6560	8.09.0298.1.01.2	CR	BS500W(IND)-13-20-03-00	INNER VERTICAL TELESCOPIC CYLINDER
6561	8.09.0299.1.01.3	CR	BS500W(IND)-13-20-04-00	OUTER VERTICAL TELESCOPIC CYLINDER
6562	8.09.0300.1.01.4	CR	BS500W(IND)-13-20-10	SHAFT END COVER PLATE
6563	8.09.0301.1.01.5	CR	BS500W(IND)-13-20-11	MOUNTING PEDESTAL- 1
6564	8.09.0302.1.01.6	CR	BS500W(IND)-13-20-12	MOUNTING PEDESTAL- 2
6565	8.09.0303.1.01.7	CR	BS500W(IND)-13-20-13	LOCKING OTIC PLACODE (IND)
6566	8.09.0304.1.01.8	CR	160A-05-00-15-02	SEALING CUP (Φ26)
6567	8.09.0305.1.01.9	CR	BS500W(IND)-13-20-04-08	SUPPORT
6568	8.09.0306.1.01.1	CR	BS500W(IND)-13-20-18	LIMITED BLOCK
6569	8.09.0307.1.01.2	CR	BS500W(IND)-13-20-19-00	GUARD RAIL COVER
6570	8.09.0308.1.01.3	CR	BS500W(IND)-13-21-01-00	RIGHT BASEPLATE
6571	8.09.0309.1.01.4	CR	BS500W(IND)-13-21-02-00	RIGHT ROTARY PLATE
6572	8.09.0310.1.01.5	CR	BS550(IND)-15-01-00	LINE BRUSH CLEANING (Complete)
6573	8.09.0311.1.01.6	CR	BS550(IND)-15-01-01-00	LINE BRUSH MOUNTING FRAME
6574	8.09.0312.1.01.7	CR	BS550(IND)-15-01-02-00	LIFTING SLIDING ROD
6575	8.09.0313.1.01.8	CR	BS550(IND)-15-01-03-00	SLIDING SLEEVE
6576	8.09.0314.1.01.9	CR	BS550(IND)-15-01-05-00	ROLLER SET
6577	8.09.0315.1.01.1	CR	BS550(IND)-15-01-07-00	AIR CYLINER ASSEMBLE
6578	8.09.0316.1.01.2	CR	GB/T63-M20	LIFTING NUT
6579	8.09.0317.1.01.3	CR	BS550(IND)-15-01-08-00	AIR LOCK
6580	8.09.0318.1.01.4	CR	BS550(IND)-15-01-06-00	GUIDING SLEEVE FIXING PEDESTAL
6581	8.09.0319.1.01.5	CR	BS550(IND)-15-01-15	8MM BRUSH(EDGE)
6582	8.09.0320.1.01.6	CR	BS550(IND)-15-01-12	4MM BRUSH (MIDDLE)
6583	8.09.0321.1.01.7	CR	BS550(IND)-15-01-16	BRUSH LOCK PLATE
6584	8.09.0322.1.01.8	CR	BS550(IND)-15-01-14	4MM BRUSH(EDGE)
6585	8.09.0323.1.01.9	CR	BS550(IND)-15-01-02-04	LIFTING ROD WEAR PLATE
6586	8.09.0324.1.01.1	CR	BS550(IND)-15-02-01-00	MOBILE PEDESTAL (LEFT)
6587	8.09.0325.1.01.2	CR	BS550(IND)-15-02-03-00	SLIDING RAIL ASSEMBLE
6588	8.09.0326.1.01.3	CR	BS550(IND)-15-02-02-00	LIFTING AIR CYLINDER ASSEMBLE
6589	8.09.0327.1.01.4	CR	BS550(IND)-15-02-12	CONNECTING BLOCK (UPPER)
6590	8.09.0328.1.01.5	CR	BS550(IND)-15-02-11	PLATEN
6591	8.09.0329.1.01.6	CR	BS550(IND)-15-02-09	SLIDING RAIL COVER PLATE
6592	8.09.0330.1.01.7	CR	BS550(IND)-15-02-10	STIFFENED PANEL

6593	8.09.0331.1.01.8	CR	BS550(IND)-15-02-05	STIFFENED PANEL OF LEFT BROOM
6594	8.09.0332.1.01.9	CR	BS550(IND)-15-02-06-00	MECHANIC PIN PEDESTAL
6595	8.09.0333.1.01.1	CR	30mm	KEY RING
6596	8.09.0334.1.01.2	CR	BS550(IND)-15-02-13	LIMITATION STOP
6597	8.09.0335.1.01.3	CR	23067083	Gripping oil cylinder
6598	8.09.0336.1.01.4	PL	3000.08.141-US	BALLAST DEFLECTOR SHIELD
6599	8.09.0337.1.01.5	PL	PP.BOP.0678	SWEEPER WIRE BRUSH METAL
6600	8.09.0338.1.01.6	PL	RE25.975-1	BEARING BODY
6601	8.09.0339.1.01.7	PL	RE25.975-3	DRIVE SHAFT
6602	8.09.0340.1.01.8	PL	RE30.475	DRIVE STATION
6603	8.09.0341.1.01.9	PL	RE30.475-1	DRIVE SHAFT
6604	8.09.0342.1.01.1	PL	RE401.04	PINION
6605	8.09.0343.1.01.2	PL	SU1702.21.10.9	ROD END
6606	8.09.0344.1.01.3	PL	SU 1702.521.5.19	Fork head
6607	8.10.0001.1.01.3	KE	30294	BUSHING
6608	8.10.0002.1.01.4	KE	82153	CLUTCH RELEASE YOKE
6609	8.10.0003.1.01.5	PL	UD 214-5430-DB	BRAKE BLOCK SHOE
6610	8.10.0004.1.01.6	PL	UD 61-402 PAS	SLIDE PLATE
6611	8.10.0005.1.01.7	PL	UD 67-2108 PAS	SLIDE PLATE (UNIMAT T. UNIT FRAME,TEFLAN PLATE)
6612	8.10.0006.1.01.8	Shifted to Ann II		
6613	8.10.0007.1.01.9	PL	62.08.8057	STRIP
6614	8.10.0008.1.01.1	KE	83705	BREATHER
6615	8.10.0009.1.01.2	KE	90583	YOKE SLIP WITH DUST CAP A
6616	8.10.0010.1.01.3	KE	115941	BOLT,PLOW 1/2"X2"
6617	8.10.0011.1.01.4	PL	SU 1702-21-1-5	TOOTHED DISK
6618	8.10.0012.1.01.5	PL	TSP/D/BS 8190	POP REVITS
6619	8.10.0013.1.01.6	KE	132179	PUSH PULL CABLE THROTTLE
6620	8.10.0014.1.01.7	KE	132277	PUSH PULL CABLE HIGH/LOW
6621	8.10.0015.1.01.8	PL	SU 1702-21-1-16	GUIDANCE
6622	8.10.0016.1.01.9	PL	SU 1702-21-1-17	GUIDANCE
6623	8.10.0017.1.01.1	KE	142123	CONTROL PROPELLING
6624	8.10.0018.1.01.2	PL	MSW 100 1101-31	SPRING BRAKE LINER REVERSER
6625	8.10.0019.1.01.3	PL	RE 20-275-2A	DRIVE SHAFT FOR EXCAVATING CONVEYOR BELT
6626	8.10.0020.1.01.4	PL	RE 20-415	COVER
6627	8.10.0021.1.01.5	PL	RE 20-416	COVER
6628	8.10.0022.1.01.6	PL	RE 30-275-3	DRIVE SHAFT FOR MAIN CONVEYOR BELT
6629	8.10.0023.1.01.7	KE	150064	BOLT, 1/2"X1 1/2"
6630	8.10.0024.1.01.8	KE	150101	CAP SCREW, HX HD 3/4"-10X2"
6631	8.10.0025.1.01.9	KE	150740	NUT (PLOW)
6632	8.10.0026.1.01.1	KE	150742	NUT 5/8"
6633	8.10.0027.1.01.2	KE	150744	LOCKNUT, 3/4"-10
6634	8.10.0028.1.01.3	KE	150746	LOCKNUT 1"-8
6635	8.10.0029.1.01.4	KE	150840	WASHER 5/8" LOCK
6636	8.10.0030.1.01.5	KE	151882	NUT 5/8"
6637	8.10.0031.1.01.6	PL	CRW-400-8790A	WEAR PLATE FOR R11
6638	8.10.0032.1.01.7	PL	CRW-400-8791A	WEAR PLATE FOR R11
6639	8.10.0033.1.01.8	PL	CRW-400-8792A-8P1667	WEAR PLATE FOR R11
6640	8.10.0034.1.01.9	PL	CRW-400-8793A-8P1667	WEAR PLATE FOR R11
6641	8.10.0035.1.01.1	PL	CRW-400-8794A-8P1667	WEAR PLATE FOR R11
6642	8.10.0036.1.01.2	PL	CRW-400-8795A-8P1667	WEAR PLATE FOR R11
6643	8.10.0037.1.01.3	PL	CRW-400-8796A-8P1667	WEAR PLATE FOR R11
6644	8.10.0038.1.01.4	PL	CRW-400-8799A-8P1667	WEAR PLATE FOR R11
6645	8.10.0039.1.01.5	PL	CRW-600-10-9A	WEAR STRIP FOR R11
6646	8.10.0040.1.01.6	PL	CRW-600-224	WEAR STRIP FOR R11
6647	8.10.0041.1.01.7	PL	CRW-800-909 LI-8P 1676	BALLST DEFLECTOR SHIELD -R11
6648	8.10.0042.1.01.8	PL	CRW-800-909 RE-8P 1676	BALLST DEFLECTOR SHIELD -R11
6649	8.10.0043.1.01.9	PL	CU 65-1062	BRACKET
6650	8.10.0044.1.01.1	PL	E 34-143 AS	DAMPING DISC
6651	8.10.0045.1.01.2	KE	186197	SPRING INNER FOR BRM
6652	8.10.0046.1.01.3	KE	186198	SPRING OUTER
6653	8.10.0047.1.01.4	PL	CRW-400-8789A	WEAR PLATE FOR R11
6654	8.10.0048.1.01.5	PL	CRW-400-8789A-8P1667	WEAR PLATE FOR R11
6655	8.10.0049.1.01.6	KE	194037	BROOM ELEMENT CLAMPS
6656	8.10.0050.1.01.7	KE	195258	STABILIZER FOR BRM
6657	8.10.0051.1.01.8	KE	196438	BOLT, PLOW
6658	8.10.0052.1.01.9	PL	CRW-400-8787B	WEAR PLATE FOR R11
6659	8.10.0053.1.01.1	PL	CRW-400-8788A	WEAR PLATE FOR R11
6660	8.10.0054.1.01.2	KE	201681	SOCHK ABSORBER
6661	8.10.0055.1.01.3	KE	203842	SPRING INNER
6662	8.10.0056.1.01.4	KE	207660	CLEVIS
6663	8.10.0057.1.01.5	KE	210011	CHAIN 60 DOUBLE
6664	8.10.0058.1.01.6	KE	211153	LINK MASTER

6665	8.10.0059.1.01.7	KE	211222	BUSHING
6666	8.10.0060.1.01.8	KE	211620	BUSHING
6667	8.10.0061.1.01.9	PL	CRW-400-8785A-8P1667	WEAR PLATE FOR R11
6668	8.10.0062.1.01.1	PL	CRW-400-8786B	WEAR PLATE FOR R11
6669	8.10.0063.1.01.2	KE	219265	ROLLER WITHOUT BEARING
6670	8.10.0064.1.01.3	KE	221427	BOLT, GRADER BLADE
6671	8.10.0065.1.01.4	KE	228553	TUBE PROPELLING BRM
6672	8.10.0066.1.01.5	PL	CRW-400-8784A8P1667	WEAR PLATE FOR R11
6673	8.10.0067.1.01.6	KE	229072	SPROKET
6674	8.10.0068.1.01.7	PL	CRW-400-8728-8P1667	WEAR PLATE FOR R11
6675	8.10.0069.1.01.8	PL	CRW-400-8729-8P1667	WEAR PLATE FOR R11
6676	8.10.0070.1.01.9	PL	CRW-400-8730-8P1667	WEAR PLATE FOR R11
6677	8.10.0071.1.01.1	PL	CRW-400-8731-8P1667	WEAR PLATE FOR R11
6678	8.10.0072.1.01.2	PL	CRW-400-8732-8P1667	WEAR PLATE FOR R11
6679	8.10.0073.1.01.3	PL	CRW-400-8781A-8P1667	WEAR PLATE FOR R11
6680	8.10.0074.1.01.4	PL	CRW-400-8782A-8P1667	WEAR PLATE FOR R11
6681	8.10.0075.1.01.5	PL	CRW-400-8783A-8P1667	WEAR PLATE FOR R11
6682	8.10.0076.1.01.6	KE	662089	SWIVEL
6683	8.10.0077.1.01.7	KE	662264	ADAPTOR SHAFT
6684	8.10.0078.1.01.8	PL	CRW 600-408 LI	GLIDER
6685	8.10.0079.1.01.9	PL	CRW 600-408 RE	GLIDER
6686	8.10.0080.1.01.1	PL	CRW-400-8717-8P1667	WEAR PLATE FOR R11
6687	8.10.0081.1.01.2	PL	CRW-400-8727-8P1667	WEAR PLATE FOR R11
6688	8.10.0082.1.01.3	KE	663182	SHAFT, INP UT TRANSMISSION
6689	8.10.0083.1.01.4	PL	CRW 600-406 RE	BRACKET
6690	8.10.0084.1.01.5	KE	700077	WING PINS
6691	8.10.0085.1.01.6	PL	CRW 600-10A-LI	WING
6692	8.10.0086.1.01.7	PL	CRW 600-10A-RE	WING
6693	8.10.0087.1.01.8	KE	718362	SPROKET
6694	8.10.0088.1.01.9	KE	704923 & 704334	SLIDER BOX & MOUNTING WING WITH BUSHES
6695	8.10.0089.1.01.1	KE	AR /120/132/12	WIPER
6696	8.10.0090.1.01.2	PL	CA216 100-1-STKL	BRAKE BLOCKS -R11
6697	8.10.0091.1.01.3	PL	CRW 600-109 N SA LI	PLOUGH PLATE
6698	8.10.0092.1.01.4	PL	CRW 600-109 N SA RE	PLOUGH PLATE
6699	8.10.0093.1.01.5	KE	731429	TUBE PROPELLING
6700	8.10.0094.1.01.6	KE	731430	TUBE PROPELLING
6701	8.10.0095.1.01.7	KE	799151	BRM WING ASSEMBLY
6702	8.10.0096.1.01.8	PL	62-11-1101	BEARING BODY
6703	8.10.0097.1.01.9	PL	62-11-1112	SHAFT
6704	8.10.0098.1.01.1	PL	UD61.402-PAS-LX	SLIDE PLATE
6705	8.10.0099.1.01.2	PL	CRW600.406LI	BRACKET
6706	8.10.0100.1.01.3	PL	CRW800.563	DOOR NAIL
6707	8.10.0101.1.01.4	PL	CRW800.906LI	COVER
6708	8.10.0102.1.01.5	PL	CRW800.906RE	COVER
6709	8.10.0103.1.01.6	KE	112533	PIN
6710	8.10.0104.1.01.7	KE	47520	CLEVIS
6711	8.10.0105.1.01.8	KE	176892	BOLT CARRIAGE
6712	8.10.0106.1.01.9	KE	510531	REEL FOR BROOM ASSY
6713	8.10.0107.1.01.1	KE	662242	FORK
6714	8.10.0108.1.01.2	KE	708158	ROD ADJUSTING
6715	8.10.0109.1.01.3	KE	708163	TUBE
6716	8.10.0110.1.01.4	KE	708164	BAR
6717	8.11.0001.1.01.4	PL	15-IN-20-10-I	SYNCRONISING SHAFT BIG FLANGE TYPE
6718	8.11.0002.1.01.5	PL	15-IN-20-10-II	SYNCRONISING SHAFT SMALL FLANGE TYPE
6719	8.11.0003.1.01.6	PL	15-IN-32-07	ADOPTER PLATE FOR PQRS
6720	8.11.0004.1.01.7	PL	62-10-4076	SWEEPER ELEMENT
6721	8.11.0005.1.01.8	SI	242001150001	MMS100 CUPLING
6722	8.12.0001.1.01.5	PL	02011507-0-006	O. T. CONVEYOR ASSEMBLY
6723	8.12.0002.1.01.6	HA	B8534 WAA	ROLLER SLED ASSEMBLY FOR TRT
6724	8.12.0003.1.01.7	HA	C 2511 WAA / C 2511 WAB	CARRIER WELDMENT FOR TRT
6725	8.12.0004.1.01.8	HA	C2510WAA	WATCH BEND SLED ASSEMBLY
6726	8.12.0005.1.01.9	HA	D 1911 VAD	OLD SLEEPER PICKUP UNIT
6727	8.12.0006.1.01.1	HA	D1913 WAC	ARM WELDMENT FOR TRT
6728	8.13.0001.1.01.6	AM	17083	SPRING HELICAL BALANCING - T 28
6729	8.13.0002.1.01.7		Shifted to Ann II	
6730	8.13.0003.1.01.8	AM	79632900	MANUAL CONTRL LEVER W/O CABLE T-28-VDO 8A
6731	8.13.0004.1.01.9	AM	222090009	BRAKE SHAFT FOR UTV
6732	8.13.0005.1.01.1	AM	2031001	T-28 Complete Frame
6733	8.13.0006.1.01.2	AM	2031006	T-28 Horizontal Structure with Rollers and Pins
6734	8.13.0007.1.01.3	AM	0017022	T-28 Vertical Structure with Rollers and Pins
6735	8.13.0008.1.01.4	AM	RRULPC377D	Guide Roller PC366C

6736	8.13.0009.1.01.5	AM	61800009	Flow Divider PLD20/20
6737	8.13.0010.1.01.6	AM	60501015	Pipe Winder A2S-420
6738	8.13.0011.1.01.7	AM	2038001	Horizontal Sliding cylinder for T-28
6739	8.14.0001.1.01.7	PL	GLF311.841 Sub. GLF311.856	ROLLER
6740	8.14.0002.1.01.8	PL	GLF311.847	AXLE
6741	8.14.0003.1.01.9	PL	U 73-253-D	VENTILATOR FOR DGS
6742	8.14.0004.1.01.1	PL	UD 220-9602	BRACKET
6743	8.14.0005.1.01.2	PL	UD 220-9603	BRACKET
6744	8.14.0006.1.01.3	PL	UD 220-9607	RING
6745	8.14.0007.1.01.4	PL	UD 236-3425	SCREWING PIECE
6746	8.14.0008.1.01.5	PL	UD 311-307	SPRING FOR DGS
6747	8.14.0009.1.01.6	PL	UD 313-3850-8	SPRING
6748	8.14.0010.1.01.7	PL	UNDRIVE M6000-07401000A10	COMMANDER UNIT
6749	8.14.0011.1.01.8	PL	UD64.16	Spacer ring
6750	8.14.0012.1.01.9	PL	UD64.344	Shaft
6751	8.15.0001.1.01.8	PH	30210018	BEARING RETAINER
6752	8.15.0002.1.01.9	PH	30214006	BEARING CARRIER
6753	8.15.0003.1.01.1	PH	30214014	BEARING CARRIER
6754	8.15.0004.1.01.2	PH	30266001	SPRING DISC
6755	8.15.0005.1.01.3	PH	93010041	EXTERNAL CIRCLIP TYPE A
6756	8.15.0006.1.01.4	PH	1P2	CIRCLIP
6757	8.15.0007.1.01.5	PH	1P5	GM BUSH
6758	8.15.0008.1.01.6	PH	2P1	BOTTOM COVER
6759	8.15.0009.1.01.7	PH	2P11	PIN
6760	8.15.0010.1.01.8	PH	2P17	PIN
6761	8.15.0011.1.01.9	PH	2P18	G.M.BUSH
6762	8.15.0012.1.01.1	PH	2P2	CIRCLIP
6763	8.15.0013.1.01.2	PH	2P21	PIN LOCK PLATE
6764	8.15.0014.1.01.3	PH	2P22	PIN
6765	8.15.0015.1.01.4	PH	2P27	PIN
6766	8.15.0016.1.01.5	PH	2P31	PIN LOCK PLATE
6767	8.15.0017.1.01.6	PH	2P32	PIN
6768	8.15.0018.1.01.7	PH	2P36	PIN
6769	8.15.0019.1.01.8	PH	3ADGB06	SPACER SEAL INPUT
6770	8.15.0020.1.01.9	PH	3P1	MAIN BOOM
6771	8.15.0021.1.01.1	PH	3P18	RETAINER PLATE
6772	8.15.0022.1.01.2	PH	3P26	RETAINER PLATE
6773	8.15.0023.1.01.3	PH	3P3	2ND EXTENSION BOOM
6774	8.15.0024.1.01.4	PH	3P4	3RD EXTENSION BOOM
6775	8.15.0025.1.01.5	PH	3P5	HOOK
6776	8.15.0026.1.01.6	PH	3P7	RETAIN LOCK PLATE
6777	8.15.0027.1.01.7	PH	3P8	SLOTTED NUT
6778	8.15.0028.1.01.8	PH	6P8	10MM STEEL TUBING WITH SWIVEL ENDS
6779	8.15.0029.1.01.9	PH	7P6	10MM STEEL TUBING WITH SWIVEL ENDS
6780	8.15.0030.1.01.1	PH	UTV 1-04-09/00	BRAKE BLOCK FOR UTV
6781	8.15.0031.1.01.2	PH	UTV-0451/00	BUSH
6782	8.15.0032.1.01.3	PH	UTV1.04/41/00	BUSH
6783	8.15.0033.1.01.4	PH	UTV1.04/44/00	BUSH
6784	8.15.0034.1.01.5	PH	UTV1.04/45/00	BUSH
6785	8.15.0035.1.01.6	PH	UTV1.04/46/00	BUSH
6786	8.15.0036.1.01.7	PH	UTV1.04/47/00	BUSH
6787	8.15.0037.1.01.8	PH	UTV1.04/48/00	BUSH
6788	8.15.0038.1.01.9	PH	UTV1.04/49/00	BUSH
6789	8.15.0039.1.01.1	PH	UTV1.04/50/00	BUSH
6790	8.15.0040.1.01.2	PH	UTVI.01.09/00	HELICAL COIL SPRING
6791	8.15.0041.1.01.3	PH	UTVI.04 43/00	BUSH
6792	8.15.0042.1.01.4	PH	UTVI.04.42/00	BUSH
6793	8.15.0043.1.01.5	PH	UTVI-03 03/00	DUST SHIELD SPRING
6794	8.15.0044.1.01.6	PH	UTVI-03 04/00	DUST SHIELD
6795	8.15.0045.1.01.7	PH	UTVI-03 08/00	GUIDE BUSH
6796	8.15.0046.1.01.8	PH	UTVI-03 18/00	PIN
6797	8.16.0001.1.01.9	PH	V 40C PD 510	V RING
6798	8.16.0002.1.01.1	LO	104698	VALVE PRESS SECOND STAGE FITS UNDER DPCV
6799	8.16.0003.1.01.2	LO	109788	INSERT SHAFT COUPLING 500 SERIES HYTREL 50D
6800	8.16.0004.1.01.3	LO	109789	COUPLING HUB SPLINE 14T 12/24 SPLINE SPLIT
6801	8.16.0005.1.01.4	LO	112952	REGULATOR .75 NPT
6802	8.16.0006.1.01.5	LO	112991	THROTTLE SINGLE DIRECTION
6803	8.16.0007.1.01.6	LO	115045	DESICCANT PLUGS
6804	8.16.0008.1.01.7	LO	115307	BRUSH HOLDER ASSY; CONSTANT PRESSURE STYLE
6805	8.16.0009.1.01.8	LO	118407	FAN WHEEL COLLECTOR BLOWER
6806	8.16.0010.1.01.9	LO	120889	DOOR HOLDER

6807	8.16.0011.1.01.1	LO	124433	COUPLING SPLINED 13T 16/32DP X 17T 16/32DP
6808	8.16.0012.1.01.2	LO	126293	BLOWER COOLING LH 5 HP
6809	8.16.0013.1.01.3	LO	126294	BLOWER COOLING RH 5 HP
6810	8.16.0014.1.01.4	LO	127470	VALVE BTFL 90PSI 50GPM 4861 4861C SWITCH
6811	8.16.0015.1.01.5	LO	148468	VALVE REGULATOR CONTROL
6812	8.16.0016.1.01.6	LO	157789	BLANKET SPARK .13X17.25X131.00
6813	8.16.0017.1.01.7	LO	158496	BLANKET SPARK 17.46X19.69
6814	8.16.0018.1.01.8	LO	158634	ELEMENT
6815	8.16.0019.1.01.9	LO	159491	REGULATOR
6816	8.16.0020.1.01.1	LO	159498	ELEMENT OIL SEPERATOR
6817	8.16.0021.1.01.2	LO	159499	VALVE PRESSURE RELIEF
6818	8.16.0022.1.01.3	LO	159501	COOLER
6819	8.16.0023.1.01.4	LO	159502	FAN
6820	8.16.0024.1.01.5	LO	160494	BLANKET SPARK .065X33.00X147.00
6821	8.16.0025.1.01.6	LO	136247	STONE STOP MOUNTED ON MOTOR SHAFT
6822	8.16.0026.1.01.7	LO	144591	STONE 10V STD ; 10.23X6.00X3.25
6823	8.16.0027.1.01.8	LO	161253	COMP ASSY CONTROLS RGI
6824	8.16.0028.1.01.9	LO	161286	480V LOCKER ASSY; RGI CONTROL CAR
6825	8.16.0029.1.01.1	LO	177695	AIR CONDITIONER UNIT; TOP MOUNT
6826	8.16.0030.1.01.2	LO	177834	AIR CONDITIONER UNIT; BOTTOM MOUNT
6827	8.16.0031.1.01.3	LO	117440-ROLL	SPARK BLANKET 40 WIDE - 900" ROLL
6828	8.16.0032.1.01.4	LO	A61103	JOURNAL BOX 6.50 X 12.00; PLAIN/JEM TYPE
6829	8.16.0033.1.01.5	LO	A76178	END BRASS
6830	8.16.0034.1.01.6	LO	A78094	COUPLING HUB 1.88B .50 KW 500 SERIES SET SCREW
6831	8.16.0035.1.01.7	LO	A85052	VALVE SOL .50 NPT N CLSD 24 VDC
6832	8.16.0036.1.01.8	LO	B75056	NOZZLE FIRE HOSE 1 INCH SWIVEL INLET
6833	8.16.0037.1.01.9	LO	H22363	COUPLING 02FNPT 02FNPT; 3000# FS
6834	8.16.0038.1.01.1	LO	158672	ELEC INTERCONNECT ASSY; RGI5
6835	8.16.0039.1.01.2	LO	A86534	COVER DISTRIBUTION BLOCK
6836	8.16.0040.1.01.3	LO	111542	E STOP KIT
6837	8.16.0041.1.01.4	LO	111543	HEATER BLOCK ENGINE 120V 3000WATT
6838	8.16.0042.1.01.5	LO	162572	Bar gauge(Gauge Rail 66.00)
6839	8.16.0043.1.01.6	LO	148898	Star Gauge(Star Gauge 221195-1)
6840	8.16.0044.1.01.7	LO	117489	Isolator Universal Mount
6841	8.16.0045.1.01.8	LO	117573	Safty gate
6842	8.16.0046.1.01.9	LO	168477	SPRING ELLIPTIC BOLS SPCL; HEAVY DUTY .527 LEAVES
6843	8.16.0047.1.01.1	LO	160164	DRIVE TRUCK ASSY HD W TM
6844	8.16.0048.1.01.2	LO	110768	WIPER BLADE
6845	8.16.0049.1.01.3	LO	113853	ELBOW EXHAUST LEFT BANK; RG302 FRONT CONTROL CAR
6846	8.16.0050.1.01.4	LO	129421	HANDLE DS RED/YEL NEMA 4X
6847	8.16.0051.1.01.5	LO	129423	SHAFT DS FOR HANDLE
6848	8.16.0052.1.01.6	LO	162926	DITCH SPRAY GP ASSEMBLY
6849	8.16.0053.1.01.7	LO	163001	OIL COOLER ELEC ASSY; RGI GC
6850	8.16.0054.1.01.8	LO	B75603	NOZZLE ASSEMBLY 90X30-5
6851	8.16.0055.1.01.9	LO	C84386	NOZZLE FIRE HOSE 1 INCH SWIVEL INLET
6852	8.16.0056.1.01.1	LO	A48676	BEARING T.M.SUPPORT STANDARD 8.00 TWIN SEAL
6853	8.16.0057.1.01.2	LO	109290	BEARING T.M.SUPPORT .06 UNDERSIZE 8.00 TWIN SEAL
6854	8.16.0058.1.01.3	LO	109291	BEARING T.M.SUPPORT .09 UNDERSIZE 8.00 TWIN SEAL
6855	8.16.0059.1.01.4	LO	109292	BEARING T.M.SUPPORT .13 UNDERSIZE 8.00 TWIN SEAL
6856	8.16.0060.1.01.5	LO	123480	BEARING T.M.SUPPORT STANDARD 8.25 TWIN SEAL
6857	8.16.0061.1.01.6	LO	123461	BEARING T.M.SUPPORT .03 UNDERSIZE 8.25 TWIN SEAL
6858	8.16.0062.1.01.7	LO	123462	BEARING T.M.SUPPORT .06 UNDERSIZE 8.25 TWIN SEAL
6859	8.16.0063.1.01.8	LO	123463	BEARING T.M.SUPPORT .09 UNDERSIZE 8.25 TWIN SEAL
6860	8.16.0064.1.01.9	LO	123464	BEARING T.M.SUPPORT .13 UNDERSIZE 8.25 TWIN SEAL
6861	8.16.0065.1.01.1	LO	A72380	SEAL RING 8.00 DIA FOR T.M.SUPPORT BEARING

6862	8.16.0066.1.01.2	LO	123469	SEAL RING 8.25 DIA FOR T.M.SUPPORT BEARING
6863	8.16.0067.1.01.3	LO	123470	SEAL RING 8.25 DIA FOR T.M.SUPPORT BEARING
6864	8.16.0068.1.01.4	LO	A71693	GUARD RUBBER DUST SUPPORT BRG TO WHEEL HUB
6865	8.16.0069.1.01.5	LO	A71692	CLAMP DUST GUARD
6866	8.16.0070.1.01.6	LO	133765	GEARCASE ASSY RG TRACTION MOTOR
6867	8.16.0071.1.01.7	LO	142359	COVER BOTTOM BRUSH LARGE FOR CAST FRAME
6868	8.16.0072.1.01.8	LO	142360	COVER BOTTOM BRUSH LARGE FOR FAB FRAME
6869	8.16.0073.1.01.9	LO	142361	COVER BOTTOM BRUSH SMALL FOR CAST/FAB FRAME
6870	8.16.0074.1.01.1	LO	142362	GASKET BOTTOM BRUSH COVER LARGE FOR CAST FRAME
6871	8.16.0075.1.01.2	LO	142363	GASKET BOTTOM BRUSH COVER LARGE FOR FAB FRAME
6872	8.16.0076.1.01.3	LO	142364	GASKET BOTTOM BRUSH COVER SMALL FOR CAST/FAB FRAME
6873	8.16.0077.1.01.4	LO	140194	TM SUSPENSION ASSY RUBBER NOSE PACK
6874	8.16.0078.1.01.5	LO	117146	TUBE ASSY.BENT 0.50X.065 ss orfs; carriage cyl.lift top
6875	8.16.0079.1.01.6	LO	252351-170	FUEL SYSTEM MAINTENANCE KIT, SMALL
6876	8.16.0080.1.01.7	LO	252351-171	FUEL SYSTEM MAINTENANCE KIT, LARGE
6877	8.16.0081.1.01.8	LO	252351-172	FUEL SYSTEM REPAIR KIT, SMALL
6878	8.16.0082.1.01.9	LO	252351-173	FUEL SYSTEM REPAIR KIT, LARGE
6879	8.16.0083.1.01.1	LO	252351-174	ENGINE/POWER SYSTEM MAINTENANCE KIT, SMALL
6880	8.16.0084.1.01.2	LO	252351-175	ENGINE/POWER SYSTEM MAINTENANCE KIT, LARGE
6881	8.16.0085.1.01.3	LO	252351-176	ENGINE/POWER SYSTEM REPAIR KIT, SMALL
6882	8.16.0086.1.01.4	LO	252351-177	ENGINE/POWER SYSTEM REPAIR KIT, MED
6883	8.16.0087.1.01.5	LO	252351-178	ENGINE/POWER SYSTEM REPAIR KIT, LARGE
6884	8.16.0088.1.01.6	LO	252351-179	ENGINE/POWER SYSTEM OVERHAUL KIT
6885	8.16.0089.1.01.7	LO	252351-59	ENGINE INJECTOR KIT #2
6886	8.16.0090.1.01.8	LO	252351-60	ENGINE INJECTOR KIT #1
6887	8.16.0091.1.01.9	LO	125627	MAIN RESERVOIR (LEFTHAND)
6888	8.16.0092.1.01.1	LO	125628	MAIN RESERVOIR (RIGHTHAND)
6889	8.16.0093.1.01.2	LO	252351-2	ENGINE EXHAUST KIT #1
6890	8.16.0094.1.01.3	LO	252351-11	ENGINE SYSTEM KIT #1
6891	8.16.0095.1.01.4	LO	252351-12	ENGINE SYSTEM KIT #2
6892	8.16.0096.1.01.5	LO	249744	AIR FILTER; SECONDARY
6893	8.16.0097.1.01.6	LO	249743	AIR FILTER; PRIMARY
6894	8.16.0098.1.01.7	LO	251111	PRECLEANER; AIR CLEANER
6895	8.16.0099.1.01.8	LO	249344	ELBOW 90 DEG; MACHINE LEFT
6896	8.16.0100.1.01.9	LO	249345	ELBOW 90 DEG; MACHINE RIGHT
6897	8.16.0101.1.01.1	LO	249378	ELBOW 90 DEG WITH BELLOWES; MACHINE LEFT
6898	8.16.0102.1.01.2	LO	252351-69	EXHAUST INSULATION REPAIR KIT #1
6899	8.16.0103.1.01.3	LO	249641	INSULATION SILENCER RH
6900	8.16.0104.1.01.4	LO	249640	INSULATION SILENCER LH
6901	8.16.0105.1.01.5	LO	249636	INSULATION ELBOW; LEFT BANK EXHAUST
6902	8.16.0106.1.01.6	LO	249637	INSULATION ELBOW; RIGHT BANK EXHAUST
6903	8.16.0107.1.01.7	LO	252351-70	AIR CLEANER REPAIR KIT
6904	8.16.0108.1.01.8	LO	252351-72	ENGINE REPAIR KIT #3
6905	8.16.0109.1.01.9	LO	252351-75	ENGINE BELTS KIT
6906	8.16.0110.1.01.1	LO	240415	CIRCUIT BREAKER DS HANDLE FLANGE; W/ 48" CIRCUIT BREAKER & MECH
6907	8.16.0111.1.01.2	LO	167046	V-BELT
6908	8.16.0112.1.01.3	LO	166938	FILTER GENERATOR STEEL 20X25X2
6909	8.16.0113.1.01.4	LO	252351-87	ENGINE REPAIR KIT #3
6910	8.16.0114.1.01.5	LO	237620	BRACKET MOD CATCH
6911	8.16.0115.1.01.6	LO	252351-91	ENGINE REPAIR KIT #3
6912	8.16.0116.1.01.7	LO	251160	FILTER AIR;SECONDARY TOP/REAR
6913	8.16.0117.1.01.8	LO	207052	FILTER 4IN 16X20; PLEATED PAPER
6914	8.16.0118.1.01.9	LO	252351-103	ENGINE REPAIR KIT
6915	8.16.0119.1.01.1	LO	B83501	THERMOSTAT

6916	8.16.0120.1.01.2	LO	115079	CUT OFF ENCLOSURE 1
6917	8.16.0121.1.01.3	LO	115080	ENCLOSURE 2 CUT OFF
6918	8.16.0122.1.01.4	LO	144046	AC/HEATER UNIT 115VAC 60HZ 1PHASE
6919	8.16.0123.1.01.5	LO	252351-77	RAIL PROFILE REPAIR KIT - LARGE
6920	8.16.0124.1.01.6	LO	252351-180	ELECTRICAL SYSTEM MAINTENANCE KIT, SMALL
6921	8.16.0125.1.01.7	LO	252351-181	ELECTRICAL SYSTEM MAINTENANCE KIT, LARGE
6922	8.16.0126.1.01.8	LO	252351-182	ELECTRICAL SYSTEM REPAIR KIT, SMALL
6923	8.16.0127.1.01.9	LO	252351-183	ELECTRICAL SYSTEM REPAIR KIT, MED
6924	8.16.0128.1.01.1	LO	252351-184	ELECTRICAL SYSTEM REPAIR KIT, LARGE
6925	8.16.0129.1.01.2	LO	252351-185	ELECTRICAL SYSTEM OVERHAUL KIT
6926	8.16.0130.1.01.3	LO	252351-1	ELECTRICAL KIT #1
6927	8.16.0131.1.01.4	LO	252351-215	ELECTRICAL KIT #2
6928	8.16.0132.1.01.5	LO	252351-3	ELECTRICAL KIT #3
6929	8.16.0133.1.01.6	LO	252351-5	ELECTRICAL KIT #4
6930	8.16.0134.1.01.7	LO	131706	BUZZER 24V AC/DC ROUND BLACK
6931	8.16.0135.1.01.8	LO	252351-18	ELECTRICAL KIT #5
6932	8.16.0136.1.01.9	LO	115416	FAN COOLING 100CFM 120VAC 60HZ
6933	8.16.0137.1.01.1	LO	252351-22	ELECTRICAL KIT #6
6934	8.16.0138.1.01.2	LO	116405	RECEPTACLE DPLEX 120V 15A DIN RAIL MOUNT COMPLETE
6935	8.16.0139.1.01.3	LO	252351-24	ELECTRICAL KIT #7
6936	8.16.0140.1.01.4	LO	252351-28	ELECTRICAL KIT #8
6937	8.16.0141.1.01.5	LO	252351-29	ELECTRICAL KIT #9
6938	8.16.0142.1.01.6	LO	118098	CONTROLNET TERMINATOR 75 OHM
6939	8.16.0143.1.01.7	LO	252351-35	ELECTRICAL KIT #10
6940	8.16.0144.1.01.8	LO	260016	CABLE OPERATED FLANGE KIT; XT3 CB
6941	8.16.0145.1.01.9	LO	242911	CLEVIS BRACKET MACHINED; MOD LIFT ROD END
6942	8.16.0146.1.01.1	LO	126257	CONDUIT ST 2.00 CONN MYERS
6943	8.16.0147.1.01.2	LO	252351-48	METER REPLACEMENT KIT #1
6944	8.16.0148.1.01.3	LO	252351-51	ELECTRICAL KIT #11
6945	8.16.0149.1.01.4	LO	252351-52	ELECTRICAL KIT #12
6946	8.16.0150.1.01.5	LO	252351-53	ENGINE REPAIR KIT #2
6947	8.16.0151.1.01.6	LO	252351-55	ELECTRICAL KIT #13
6948	8.16.0152.1.01.7	LO	139276	CONDUIT RIG RDG BUSHING; 2 IN TO 1 IN
6949	8.16.0153.1.01.8	LO	252351-67	ELECTRICAL KIT #14
6950	8.16.0154.1.01.9	LO	252351-68	ELECTRICAL KIT #15
6951	8.16.0155.1.01.1	LO	A39313	CONDUIT SEALTITE 1-1/4 (MINIMUM QTY 10)
6952	8.16.0156.1.01.2	LO	252351-89	ELECTRICAL KIT #16
6953	8.16.0157.1.01.3	LO	252351-96	ELECTRICAL KIT #17
6954	8.16.0158.1.01.4	LO	252351-98	ELECTRICAL KIT #18
6955	8.16.0159.1.01.5	LO	252351-102	ELECTRICAL KIT #19
6956	8.16.0160.1.01.6	LO	A87501	BOOT RUBBER MOTOR LEADS FOR PIGTAIL CONNECTOR
6957	8.16.0161.1.01.7	LO	A88802	CONDUIT GASKET 1.25 SEAL
6958	8.16.0162.1.01.8	LO	252351-104	ELECTRICAL KIT #20
6959	8.16.0163.1.01.9	LO	252351-106	ELECTRICAL KIT #21
6960	8.16.0164.1.01.1	LO	B83657	LENS 2.8-12MM ASPHERICAL DC IRIS
6961	8.16.0165.1.01.2	LO	255115	CAMERA VIDEO 2.1MP HD; 30FPS HD-ANALOG HD-TVI or HD-CVI OUTPUTS
6962	8.16.0166.1.01.3	LO	252351-207	ELECTRICAL REPAIR KIT - SMALL
6963	8.16.0167.1.01.4	LO	252351-219	TRACTION SYSTEM KIT
6964	8.16.0168.1.01.5	LO	252351-221	TRACTION SYSTEM KIT #2
6965	8.16.0169.1.01.6	LO	244116	CARRIAGE SUPPORT WELDT; RH
6966	8.16.0170.1.01.7	LO	252351-46	TRACTION SYSTEM HOSE AND FITTING KIT
6967	8.16.0171.1.01.8	LO	169947	SKID PLATE ASSEMBLY FLEX BUGGY
6968	8.16.0172.1.01.9	LO	242906	MODULE TILT ASSY
6969	8.16.0173.1.01.1	LO	252351-222	TRACTION SYSTEM KIT #3
6970	8.16.0174.1.01.2	LO	242925	MODULE ASSY 25HP
6971	8.16.0175.1.01.3	LO	252351-82	FILTER KIT #2
6972	8.16.0176.1.01.4	LO	242929	CARRIAGE SUPPORT ASSY LH
6973	8.16.0177.1.01.5	LO	252351-121	TRACTION SYSTEM MAINTENANCE KIT, SMALL
6974	8.16.0178.1.01.6	LO	252351-122	TRACTION SYSTEM MAINTENANCE KIT, LARGE
6975	8.16.0179.1.01.7	LO	252351-123	TRACTION SYSTEM REPAIR KIT, SMALL

6976	8.16.0180.1.01.8	LO	252351-124	TRACTION SYSTEM REPAIR KIT, LARGE
6977	8.16.0181.1.01.9	LO	252351-125	TRACTION SYSTEM OVERHAUL KIT
6978	8.16.0182.1.01.1	LO	172844	MANIFOLD ASSEMBLY BUGGY LIFT
6979	8.16.0183.1.01.2	LO	244208	BOTTOM PLATE MACHINED; MODULE ASSY
6980	8.16.0184.1.01.3	LO	244205	TOP PLATE MACHINED; MODULE ASSY
6981	8.16.0185.1.01.4	LO	157035	TUBE SLIDE ASSEMBLY BUGGY TOW
6982	8.16.0186.1.01.5	LO	244952	BRACKET ASSY; SLIDE TUBE TOW BALL
6983	8.16.0187.1.01.6	LO	245342	SPARK GUARD UPPER; 17.50X22.50X11GA
6984	8.16.0188.1.01.7	LO	114771	STRAINER SUCTION 3 NPT INTANK 30 MESH W/BYPASS
6985	8.16.0189.1.01.8	LO	252351-42	CYLINDER SEAL KIT #1
6986	8.16.0190.1.01.9	LO	252351-43	CYLINDER SEAL KIT #2
6987	8.16.0191.1.01.1	LO	252351-44	CYLINDER SEAL KIT #3
6988	8.16.0192.1.01.2	LO	142885	O-RING FUEL LIFT PUMP ELECTRIC
6989	8.16.0193.1.01.3	LO	252351-71	CYLINDER SEAL KIT #4
6990	8.16.0194.1.01.4	LO	252351-73	CYLINDER SEAL KIT #5
6991	8.16.0195.1.01.5	LO	252351-74	GRINDING SYSTEM KIT #2
6992	8.16.0196.1.01.6	LO	161650	PLATE SEAL 3261C 3261C; .50 THICK THROUGH HOLES
6993	8.16.0197.1.01.7	LO	237639	TILT STOP WELDT; GAUGE LH
6994	8.16.0198.1.01.8	LO	252351-217	DERAIL DETECTION KIT
6995	8.16.0199.1.01.9	LO	251112	HUMP HOSE REDUCER; 7.00X5.50
6996	8.16.0200.1.01.1	LO	A37405	SEAL ROD STANDARD POLYPAK 2.25 IDX2.75 ODX.25 W
6997	8.16.0201.1.01.2	LO	252351-90	CYLINDER END KIT #2
6998	8.16.0202.1.01.3	LO	A66395	SEAL CLAMP FLAT SS 6.00 DIA
6999	8.16.0203.1.01.4	LO	252351-95	GAUGE REPAIR KIT #1
7000	8.16.0204.1.01.5	LO	252351-97	GAUGE REPAIR KIT #2
7001	8.16.0205.1.01.6	LO	237691	TILT STOP WELDT; FIELD/STONE CHANGE
7002	8.16.0206.1.01.7	LO	242945	SNAP RING 1.78 OD; INVERTED LUGS .062 WIDTH
7003	8.16.0207.1.01.8	LO	252351-191	MECHANICAL SYSTEM MAINTENANCE KIT, SMALL
7004	8.16.0208.1.01.9	LO	252351-192	MECHANICAL SYSTEM MAINTENANCE KIT, LARGE
7005	8.16.0209.1.01.1	LO	252351-193	MECHANICAL SYSTEM REPAIR KIT, SMALL
7006	8.16.0210.1.01.2	LO	252351-194	MECHANICAL SYSTEM REPAIR KIT, LARGE
7007	8.16.0211.1.01.3	LO	252351-199	10 STONE BUGGY SYSTEM REPAIR KIT, SMALL
7008	8.16.0212.1.01.4	LO	252351-200	10 STONE BUGGY SYSTEM REPAIR KIT, LARGE
7009	8.16.0213.1.01.5	LO	252351-201	10 STONE BUGGY SYSTEM MAINTENANCE KIT, SMALL
7010	8.16.0214.1.01.6	LO	252351-202	10 STONE BUGGY SYSTEM MAINTENANCE KIT, MED
7011	8.16.0215.1.01.7	LO	252351-203	10 STONE BUGGY SYSTEM MAINTENANCE KIT, LARGE
7012	8.16.0216.1.01.8	LO	252351-204	10 STONE BUGGY SYSTEM OVERHAUL KIT
7013	8.16.0217.1.01.9	LO	252351-30	MECHANICAL KIT #4
7014	8.16.0218.1.01.1	LO	252351-31	MECHANICAL KIT #5
7015	8.16.0219.1.01.2	LO	252351-32	MECHANICAL KIT #6
7016	8.16.0220.1.01.3	LO	252351-34	MECHANICAL KIT #8
7017	8.16.0221.1.01.4	LO	242926	TILT STOP ASSY; RGM BUGGY FIELD/GAUGE
7018	8.16.0222.1.01.5	LO	242930	CARRIAGE SUPPORT WELDT; LH
7019	8.16.0223.1.01.6	LO	207214	MOTOR GRINDING STR SHAFT; 256TC ALUMINUM FRAME TEO
7020	8.16.0224.1.01.7	LO	247870	DITCH AND TIE SPRAY ASSY; DITCH 8-30GPM/TIE 1.5GPM
7021	8.16.0225.1.01.8	LO	252351-134	RAIL MEASUREMENT SYSTEM MAINTENANCE KIT, SMALL
7022	8.16.0226.1.01.9	LO	252351-135	RAIL MEASUREMENT SYSTEM MAINTENANCE KIT, LARGE
7023	8.16.0227.1.01.1	LO	252351-136	RAIL MEASUREMENT SYSTEM REPAIR KIT, SMALL
7024	8.16.0228.1.01.2	LO	252351-137	RAIL MEASUREMENT SYSTEM REPAIR KIT, LARGE
7025	8.16.0229.1.01.3	LO	252351-138	RAIL MEASUREMENT SYSTEM OVERHAUL KIT

7026	8.16.0230.1.01.4	LO	252351-143	MECHANICAL SYSTEM MAINTENANCE KIT, SMALL
7027	8.16.0231.1.01.5	LO	252351-144	MECHANICAL SYSTEM MAINTENANCE KIT, LARGE
7028	8.16.0232.1.01.6	LO	252351-145	MECHANICAL SYSTEM REPAIR KIT, SMALL
7029	8.16.0233.1.01.7	LO	252351-146	MECHANICAL SYSTEM REPAIR KIT, LARGE
7030	8.16.0234.1.01.8	LO	245610-02	DOOR ASSY 5ST; BUGGY DUST CONTAINMENT
7031	8.16.0235.1.01.9	LO	252351-S01	STONE 10V STD 10.230DX6.00IDX3.25
7032	8.16.0236.1.01.1	LO	252351-S02	STONE GRINDING WHEEL 11V; 6.00OD X 2.50ID X 3.00
7033	8.16.0237.1.01.2	LO	165739	BRACKET WELDT; SPARK BLANKET
7034	8.16.0238.1.01.3	LO	102154	CONDUIT GASKET 1.50 SEAL (MIN QTY 10)
7035	8.16.0239.1.01.4	LO	207476	LATCH FLEX DRAW
7036	8.16.0240.1.01.5	LO	106759	CLAMP-EASY DUCT 12.00 DIA
7037	8.16.0241.1.01.6	LO	207567	PIVOT WELDT; DUST CONTAINMENT
7038	8.16.0242.1.01.7	LO	112175	STRIKER-PADDLE LATCH
7039	8.16.0243.1.01.8	LO	208669	PIN MODULE LIFT STOP; .75 OD M12 THREAD
7040	8.16.0244.1.01.9	LO	252351-17	MECHANICAL KIT #1
7041	8.16.0245.1.01.1	LO	252351-20	MECHANICAL KIT #2
7042	8.16.0246.1.01.2	LO	115298	ENCLOSURE 10X4X3 NEMA 4
7043	8.16.0247.1.01.3	LO	117095	SLEEVE 25.13 I.D.
7044	8.16.0248.1.01.4	LO	208800	BRACKET MOTOR TOP LH; SPARK GUARD DEFLECTOR
7045	8.16.0249.1.01.5	LO	117428	STANDOFF THRD MALE/FEMALE; .25 X.50 8-32 THREAD
7046	8.16.0250.1.01.6	LO	252351-27	MECHANICAL KIT #3
7047	8.16.0251.1.01.7	LO	245329	BULKHEAD WELDT; DUST CONTAINMENT 5ST
7048	8.16.0252.1.01.8	LO	242902	CLAMP BLOCK; TILT BUSHING
7049	8.16.0253.1.01.9	LO	118703	DOOR LATCH GROUP METRIC VERSION
7050	8.16.0254.1.01.1	LO	209346	BRACKET GAS SPRING; LEFT HAND
7051	8.16.0255.1.01.2	LO	244169	STONE HOLDER ASSY; 10" STRAIGHT SHAFT
7052	8.16.0256.1.01.3	LO	209347	BRACKET GAS SPRING; RIGHT HAND
7053	8.16.0257.1.01.4	LO	207720	SPARK BLANKET CENTER; DUST CONTAINMENT
7054	8.16.0258.1.01.5	LO	178368	STONE HOLDER ASSY 6 INCH; FOR STRAIGHT SHAFT MOTOR
7055	8.16.0259.1.01.6	LO	154040	MOUNT WELDT; PUMP DRIVE
7056	8.16.0260.1.01.7	LO	241590-00	ENCL ASSY LADDER BOM ONLY; BASE COMPONENTS
7057	8.16.0261.1.01.8	LO	178203	STONE STOP 6 INCH STONE; FOR STRAIGHT SHAFT MOTOR
7058	8.16.0262.1.01.9	LO	129008	FILTER ELEMENT REPLACEMENT FOR 125419 BLOWER1/12HP 460VAC
7059	8.16.0263.1.01.1	LO	252351-58	MECHANICAL KIT #9
7060	8.16.0264.1.01.2	LO	131538	TENSSONER ASSY AUTO FAN IDLER
7061	8.16.0265.1.01.3	LO	252351-63	MECHANICAL KIT #10
7062	8.16.0266.1.01.4	LO	178223	STONE STOP 10 INCH STONE FOR STRAIGHT SHAFT MOTOR
7063	8.16.0267.1.01.5	LO	252351-65	MECHANICAL KIT #11
7064	8.16.0268.1.01.6	LO	252351-66	MECHANICAL KIT #12
7065	8.16.0269.1.01.7	LO	146636	SPRING TORSION
7066	8.16.0270.1.01.8	LO	245343	SPARK GUARD LOWER; 9.50X22.50X11GA
7067	8.16.0271.1.01.9	LO	249332	CAP RAIN COVER
7068	8.16.0272.1.01.1	LO	165090	BLANKET SPARK LONG
7069	8.16.0273.1.01.2	LO	165711	BLANKET SPARK SHORT
7070	8.16.0274.1.01.3	LO	207719	SPARK BLANKET SHORT; DUST CONTAINMENT
7071	8.16.0275.1.01.4	LO	245236	SHAFT 3.00; 2.00 ID X 48.25 LG
7072	8.16.0276.1.01.5	LO	252351-76	SPARK CONTAINMENT REPAIR KIT SMALL
7073	8.16.0277.1.01.6	LO	207696	SPARK BLANKET LONG; DUST CONTAINMENT
7074	8.16.0278.1.01.7	LO	207568	END WALL WELDT; DUST CONTAINMENT
7075	8.16.0279.1.01.8	LO	252351-83	MECHANICAL KIT #13
7076	8.16.0280.1.01.9	LO	252351-84	MECHANICAL KIT #14
7077	8.16.0281.1.01.1	LO	252351-85	MECHANICAL KIT #15
7078	8.16.0282.1.01.2	LO	248744	BRACKET WELDT; SPARK BLANKET 1600MM

7079	8.16.0283.1.01.3	LO	A26562	EYE SWIVEL
7080	8.16.0284.1.01.4	LO	249479	CLAMP V-BAND
7081	8.16.0285.1.01.5	LO	A61025	GROMMET TOP (REPLACES A61027)
7082	8.16.0286.1.01.6	LO	A61026	GROMMET BOTTOM (REPLACES A92141)
7083	8.16.0287.1.01.7	LO	252351-92	MECHANICAL KIT #16
7084	8.16.0288.1.01.8	LO	252351-93	MECHANICAL KIT #17
7085	8.16.0289.1.01.9	LO	A70871	CONDUIT GASKET 1.00 SEAL
7086	8.16.0290.1.01.1	LO	245357	CLAMP T-BOLT 6.28 IN - 6.59 IN
7087	8.16.0291.1.01.2	LO	A83286	KIT-SOUND UNIT REPAIR FOR USE W/A15560-HORN
7088	8.16.0292.1.01.3	LO	252351-100	VALVE REPAIR KIT #1
7089	8.16.0293.1.01.4	LO	252351-S03	STONE C715 STD; 10.23X6.00X3.25
7090	8.16.0294.1.01.5	LO	B82744	FITTING-LUBE MODIFIED
7091	8.16.0295.1.01.6	LO	178224	STONE HOLDER ASSY 10 INCH; FOR STRAIGHT SHAFT MOTOR
7092	8.16.0296.1.01.7	LO	H17570	FITTING LUBE .12NPT STR EXTRA SHORT
7093	8.16.0297.1.01.8	LO	252351-206	MECHANICAL REPAIR KIT - SMALL
7094	8.16.0298.1.01.9	LO	H26774	GASKET
7095	8.16.0299.1.01.1	LO	252351-209	MECHANICAL REPAIR KIT #1
7096	8.16.0300.1.01.2	LO	252351-210	MECHANICAL REPAIR KIT #2
7097	8.16.0301.1.01.3	LO	252351-211	MECHANICAL REPAIR KIT #3
7098	8.16.0302.1.01.4	LO	209896	BRACKET BULKHEAD SUPPORT; RIGHT HAND
7099	8.16.0303.1.01.5	LO	252351-212	MECHANICAL REPAIR KIT #4
7100	8.16.0304.1.01.6	LO	252351-213	MECHANICAL REPAIR KIT #5
7101	8.16.0305.1.01.7	LO	165391	SKID WELDT DERAIL DETECTION
7102	8.16.0306.1.01.8	LO	171788	BUMPER 1.01 FREE HEIGHT
7103	8.16.0307.1.01.9	LO	252351-38	AIR SYSTEM KIT #2
7104	8.16.0308.1.01.1	LO	157441	DUST HOPPER ASSY
7105	8.16.0309.1.01.2	LO	160969	DUST BLOWER ASSEMBLY
7106	8.16.0310.1.01.3	LO	252351-166	DUST SYSTEM MAINTENANCE KIT, SMALL
7107	8.16.0311.1.01.4	LO	252351-167	DUST SYSTEM MAINTENANCE KIT, LARGE
7108	8.16.0312.1.01.5	LO	252351-168	DUST SYSTEM REPAIR KIT, SMALL
7109	8.16.0313.1.01.6	LO	252351-169	DUST SYSTEM REPAIR KIT, LARGE
7110	8.16.0314.1.01.7	LO	157439	DUCT; 12.00 DIA X 6.00 LG
7111	8.16.0315.1.01.8	LO	157440	DUCT; 12.00 DIA X 19.13 LG
7112	8.17.0001.1.01.1	PL	41656	HANDLE
7113	8.17.0002.1.01.2	PL	506896	SERVO ADJUSTMENT DEVICE
7114	8.17.0003.1.01.3	PL	986352000	SOLDERING IRON PLUG
7115	8.17.0004.1.01.4	PL	C-001	BAND-IT-TOOL
7116	8.17.0005.1.01.5	PL	DL131.06-KPL	MULTIPURPOSE EXTRACTING DEVICE
7117	8.17.0006.1.01.6	PL	IN43.623	HANDLE
7118	8.17.0007.1.01.7	PL	RCH-603T	CYLINDER-60T
7119	8.17.0008.1.01.8	PL	SU 1502.208.1.2.3	JACK
7120	8.17.0009.1.01.9	PL	SU 1502.208.1.2.4	JACK
7121	8.17.0010.1.01.1	PL	WN180.01A-VERSTAERKT	LOCK
7122	8.17.0011.1.01.2	PL	WN180.02	DOOR HANDLE
7123	8.17.0012.1.01.3	PL	WN180.13-SPERRE 7221-1045	DOOR HANDLE
7124	8.17.0013.1.01.4	PL	WN81.204	LOCKING PIECE
7125	8.17.0014.1.01.5	LO	107164	WATER CANNON GROUP 125 GPM
7126	8.17.0015.1.01.6	PL	AK5000	SILICONE OIL
7127	8.17.0016.1.01.7	PL	ELB-KGO-OO	RPM CONTROL
7128	8.17.0017.1.01.8	PL	SE27	ROSTA ELEMENT
7129	8.17.0018.1.01.9	PL	HY717D.08/6.8KW/EL	Diesel Emergency Unit
7130	8.17.0019.1.01.1	PL	64.09.7000.30	Ballast Guide Assembly
7131	8.17.0020.1.01.2	GE	YD432D-20-02	Anti-loosen lock
7132	8.17.0021.1.01.3	GE	H25	Dust-proof cover
7133	8.17.0022.1.01.4	GE	08-03-2901	Micro muffler
7134	8.17.0023.1.01.5	Volvo Penta	82269261	Filter
7135	8.17.0024.1.01.6	Volvo Penta	22856665	Filter
7136	8.17.0025.1.01.7	Volvo Penta	21315240	SENSOR
7137	8.17.0026.1.01.8	Volvo Penta	23763152	Viscous Clutch
7138	8.17.0027.1.01.9	Volvo Penta	VOLVO Mix 40/60 (Green colour) Part no. 22567233	Engine cooling agent
7139	8.17.0028.1.01.1	AM	51206014	Threaded Stem Joint
7140	8.17.0029.1.01.1	GE	3/8-16UNC-35	Bolt-1
7141	8.17.0030.1.01.3	GE	GB/T5782 M16-40	Bolt-2
7142	8.17.0031.1.01.4	GE	7/16-14UNC-35	Bolt-3
7143	8.17.0032.1.01.5	GE	GB/T5786 M14-1.5-50-10.9	Bolt-1
7144	8.17.0033.1.01.6	GE	GB/T5786 M14-1.5-45-10.9	Bolt-2
7145	8.17.0034.1.01.7	GE	DCL32-23-01-02-01-05	Steel pipe-1
7146	8.17.0035.1.01.8	GE	DCL32-23-01-02-01-03	Steel pipe-2
7147	8.17.0036.1.01.9	GE	DCL32-23-01-02-01-01	Steel pipe-3

7148	8.17.0037.1.01.1	GE	DCL32-23-01-02-01-07	Steel pipe-4
7149	8.17.0038.1.01.2	GE	DCL32-23-01-02-05-01	Steel pipe-5
7150	8.17.0039.1.01.3	GE	CDCM16A-23-01-02	Steel pipe-6
7151	8.17.0040.1.01.4	GE	DCL32-23-01-02-19	Steel pipe-7
7152	8.17.0041.1.01.5	GE	DGMPC-5-ABN-BAN- 30	Double-way hydraulic lock
7153	8.17.0042.1.01.6	GE	DGMPC-3-ABN-BAN- 30	Hydraulic lock (Set)
7154	8.17.0043.1.01.7	CR	BS550(IND)-20-10-00	RAIL SCRAPER (RIGHT)
7155	8.17.0044.1.01.8	CR	BS550(IND)-20-09-00	RAIL SCRAPER (LEFT)
7156	8.17.0045.1.01.9	CR	BS550(IND)-20-07-00	CENTER PLATE ASSEMBLE
7157	8.17.0046.1.01.1	CR	BS550(IND)-20-03-00	SIDE BEARING ASSEMBLY
7158	8.17.0047.1.01.2	CR	BS550(IND)-20-05-05	UNDERBOARDING
7159	8.17.0048.1.01.3	CR	T50-J47C13U	OIL DAMPER
7160	8.17.0049.1.01.4	CR	BS550(IND)-20-03-03	SHIM
7161	8.17.0050.1.01.5	CR	BS550(IND)-20-03-01-00	SIDE BEARING BOX
7162	8.17.0051.1.01.6	CR	BS550(IND)-20-07-05	U CARD
7163	8.17.0052.1.01.7	CR	BS550(IND)-20-07-04	SPHERICAL SUSPENDER
7164	8.17.0053.1.01.8	CR	BS550(IND)-20-07-01	UPPER CENTER PLATE
7165	8.17.0054.1.01.9	CR	40100378-053	SHIM, 0.19 MM
7166	8.17.0055.1.01.1	CR	40100378-054	SHIM, 0.25 MM
7167	8.17.0056.1.01.2	CR	40100378-055	SHIM, 0.35 MM
7168	8.17.0057.1.01.3	CR	40100378-070	REDUCER
7169	8.17.0058.1.01.4	CR	40100378-082	EXTERNAL DISC
7170	8.17.0059.1.01.5	CR	40100378-083	INTERNAL DISC
7171	8.17.0060.1.01.6	CR	40100378-086	SPRING
7172	8.17.0061.1.01.7	CR	40100378-088	BELL
7173	8.17.0062.1.01.8	CR	40100378-100	HOUSING-1
7174	8.17.0063.1.01.9	CR	40100378-103	HOUSING-2
7175	8.17.0064.1.01.1	CR	40100378-104	MANIFOLD
7176	8.17.0065.1.01.2	CR	BS550(IND)-20-02-00(3)	FRAME (3)
7177	8.17.0066.1.01.3	CR	T50-J47C13M	OIL DAMPER RIGHT
7178	8.17.0067.1.01.4	CR	BS550(IND)-20-05-02	SUPPORTING BLOCK
7179	8.17.0068.1.01.5	CR	36.41.20	Guide collar
7180	8.17.0069.1.01.6	CR	BS550(IND)-30-16-03	COOLING PIPE
7181	8.17.0070.1.01.7	CR	CQS300-19-03-01	ALLOCATION BLOCK
7182	8.17.0071.1.01.8	CR	BS500W(IND)-30-31	MOUNTING PLATE
7183	8.17.0072.1.01.9	CR	N 008 734 08	QUICK CONNECTOR SOCKET
7184	8.17.0073.1.01.1	CR	BS550(IND)-07-01-52	TAB SHIM
7185	8.17.0074.1.01.2	CR	GB/T 1096-8X7X28	NORMAL TYPE FLAT KEY
7186	8.17.0075.1.01.3	CR	GB/T 13871-FB80X110X10	SEALING RING
7187	8.17.0076.1.01.4	CR	CQS300-17-02-05	KEY
7188	8.17.0077.1.01.5	CR	BS550(IND)-09-37	PLYWOOD-5
7189	8.17.0078.1.01.6	CR	BS550(IND)-09-40	PLYWOOD-6
7190	8.17.0079.1.01.7	CR	BS550(IND)-09-42	STIFFENER
7191	8.17.0080.1.01.8	CR	BS550(IND)-06-16-05	KEY
7192	8.17.0081.1.01.9	CR	GB/T 894.2-70	CIRCLIP FOR SHAFT
7193	8.17.0082.1.01.1	CR	1308JV	DUSTPROOF RING
7194	8.17.0083.1.01.2	CR	BS550(IND)-10-04-03	COLLAR
7195	8.17.0084.1.01.3	CR	GB/T 893.1-190	CIRCLIP FOR HOLES
7196	8.17.0085.1.01.4	CR	BS550(IND)-10-05-02	KEY
7197	8.17.0086.1.01.5	CR	DIN3404-A R1/4 St	GREASE NUZZLE
7198	8.17.0087.1.01.6	CR	BS550(IND)-10-05-01-04	BEARING CAP
7199	8.17.0088.1.01.7	CR	BS550-10-02-01-00	PULLEY BODY
7200	8.17.0089.1.01.8	CR	BS550(IND)-10-05-03	RING
7201	8.17.0090.1.01.9	CR	BS500W(IND)-13-03-00	PEDESTAL WELDING
7202	8.17.0091.1.01.1	CR	BS500W(IND)-13-05-00	AIR LOCK DEVICE-1
7203	8.17.0092.1.01.2	CR	BS500W(IND)-13-06-00	MAIN LOCK PEDESTAL
7204	8.17.0093.1.01.3	CR	BS500W(IND)-13-07-00	AIR LOCK DEVICE-2
7205	8.17.0094.1.01.4	CR	BS500W(IND)-13-25	UNIVERSAL SOCKET
7206	8.17.0095.1.01.5	CR	41064504	Seal ring
7207	8.17.0096.1.01.6	CR	20261427	Lubrication sleeve
7208	8.17.0097.1.01.7	CR	20261430	Lubrication sleeve
7209	8.17.0098.1.01.8	CR	20261426	Lubrication plate
7210	8.17.0099.1.01.9	CR	23008098	Piston
7211	8.17.0100.1.01.1	CR	23067085	Piston Rod
7212	8.17.0101.1.01.2	CR	82008021480	piston rod
7213	8.17.0102.1.01.3	CR	82008021482	cylinder head
7214	8.17.0103.1.01.4	CR	82008021481	cylinder body
7215	8.17.0104.1.01.5	CR	82008021490	piston rod
7216	8.17.0105.1.01.6	CR	82008021492	cylinder head
7217	8.17.0106.1.01.7	CR	82008021491	cylinder body
7218	8.17.0107.1.01.8	CR	82008021506	piston rod
7219	8.17.0108.1.01.9	CR	82008021508	cylinder head

7220	8.17.0109.1.01.1	CR	82008021507	cylinder body
7221	8.17.0110.1.01.2	CR	82010040054	piston rod
7222	8.17.0111.1.01.3	CR	82010040055	cylinder head
7223	8.17.0112.1.01.4	CR	82008021437	cylinder body
7224	8.17.0113.1.01.5	CR	23068419	OIL CYLINDER PIN
7225	8.17.0114.1.01.6	CR	23069242	INSTALLATION OF OIL CYL. HEAD
7226	8.17.0115.1.01.7	CR	30030540	SPHERIC JOINT
7227	8.17.0116.1.01.8	CR	23083971	ROLLER
7228	8.17.0117.1.01.9	CR	23083972	LUBRICATION SLEEVE
7229	8.17.0118.1.01.1	CR	40101896	JOINT HEAD
7230	8.17.0119.1.01.2	CR	40103143	SPLINE SHAFT
7231	8.17.0120.1.01.3	CR	40089258	4 WAY OPERATIONAL ROD
7232	8.17.0121.1.01.4	CR	23067084	SQUEEZING CYL. BODY
7233	8.17.0122.1.01.5	CR	23070028	DEPTH SENSOR BASE
7234	8.17.0123.1.01.6	CR	40083643	BRAKE SHOE HOLDER
7235	8.17.0124.1.01.7	CR	40098537	BRAKE SHOE
7236	8.17.0125.1.01.8	CR	23066373	MAGNETIC SCREW PLUG
7237	8.17.0126.1.01.9	CR	40105701	AIR CYL. WITH MAGNETIC RING
7238	8.17.0127.1.01.1	PL	BX-38.3.11.08.95	ADJUSTING BRUSH
7239	8.17.0128.1.01.2	PL	CA250.2402	BEARING SUPPORT
7240	8.17.0129.1.01.3	PL	TYPER90/60DX56 or F64.11.1000	GUIDE ROLLER
7241	8.17.0130.1.01.4	PL	U221.721	DRIVE SHAFT
7242	8.17.0131.1.01.5	PL	63.09.2104	RING
7243	8.17.0132.1.01.6	PL	63.09.2105	RING
7244	8.17.0133.1.01.7	PL	63.09.2106	RING
7245	8.17.0134.1.01.8	VOLVO PENTA	21538975	FILTER
7246	8.17.0135.1.01.9	VOLVO PENTA	21746575	FILTER
7247	8.17.0136.1.01.1	VOLVO PENTA	23381562	FILTER (ADBLUE)
7248	8.17.0137.1.01.2	VOLVO PENTA	21164790	TEMPERATURE SENSOR
7249	8.17.0138.1.01.3	VOLVO PENTA	21426987	SPEED SENSOR
7250	8.17.0139.1.01.4	VOLVO PENTA	21537231	GASKET
7251	8.17.0140.1.01.5	VOLVO PENTA	21746511	FUEL PIPE
7252	8.17.0141.1.01.6	VOLVO PENTA	21880678	PRESSURE SENSR
7253	8.17.0142.1.01.7	VOLVO PENTA	22128302	FUEL HOSE
7254	8.17.0143.1.01.8	VOLVO PENTA	22254065	GASKET
7255	8.17.0144.1.01.9	VOLVO PENTA	22707523	V RIBBED BELT
7256	8.17.0145.1.01.1	VOLVO PENTA	22795892	FUEL HOSE
7257	8.17.0146.1.01.2	VOLVO PENTA	22796425	FUEL HOSE
7258	8.17.0147.1.01.3	VOLVO PENTA	22827991	SENSOR
7259	8.17.0148.1.01.4	VOLVO PENTA	22827993	SENSOR
7260	8.17.0149.1.01.5	VOLVO PENTA	22899626	PRESSURE SENSOR
7261	8.17.0150.1.01.6	VOLVO PENTA	23307414	VACCUM SWITCH
7262	8.17.0151.1.01.7	VOLVO PENTA	23958454	OIL FILTER KIT
7263	8.17.0152.1.01.8	VOLVO PENTA	24037387	Level Sensor
7264	8.17.0153.1.01.9	VOLVO PENTA	22224040	Control Valve kit
7265	8.17.0154.1.01.1	VOLVO PENTA	23552770	Coolant Pump
7266	8.17.0155.1.01.2	VOLVO PENTA	21795852	Gasket
7267	8.17.0156.1.01.3	VOLVO PENTA	990821	O-Ring
7268	8.17.0157.1.01.4	VOLVO PENTA	21746213	Thermostat
7269	8.17.0158.1.01.5	VOLVO PENTA	24170981	Sensor
7270	8.17.0159.1.01.6	VOLVO PENTA	969163	Fuse
7271	8.17.0160.1.01.7	VOLVO PENTA	969162	Fuse
7272	8.17.0161.1.01.8	VOLVO PENTA	22422785	Sensor
7273	8.17.0162.1.01.9	VOLVO PENTA	21976026	Pressure sensor
7274	8.17.0163.1.01.1	PL	USIG	SAFETY CLIP
7275	8.17.0164.1.01.2	PL	2.7902.2.31.08 00	RADIATOR
7276	8.18.0001.1.01.2	LO	106938	OIL-SYNTHETIC GEAR T/M BULL GEAR LUBE ; ORDER MULTIPLE OF 48 EACH = 1 BOX
7277	8.18.0002.1.01.3	LO	A81853	PALLUBE 32 LUBRICOLANT; 5 GALLON CONTAINER
7278	8.18.0003.1.01.4	SHELL	SHELL SPIRAX S4TXM - 10W30	LUB OIL for ZF
7279	8.18.0004.1.01.5	SHELL	SHELL RIMULA R6 LM 10W40	LUBE OIL for Engine
7280	8.18.0005.1.01.6	SHELL	SHELL RIMULA R4 15W40	LUBE OIL
7281	8.18.0006.1.01.7	SHELL	Shell Omala S2 G 68	Hydraulic Oil
7282	8.18.0007.1.01.8	SHELL	Shell Tellus S2 MX 100	Hydraulic Oil
7283	8.18.0008.1.01.9	SHELL	Shell Tellus S2 MX 68	Hydraulic Oil
7284	8.18.0009.1.01.1	SHELL	Shell Tellus S2 VX 68	Hydraulic Oil
7285	8.18.0010.1.01.2	SHELL	Shell Gadus S2 V 100 2	GREASE
7286	8.18.0011.1.01.3	SHELL	SHELL GADUS S3 V220 C2	GREASE
7287	8.18.0012.1.01.4	SHELL	Shell Omala S2 G 100	GEAR OIL

7288	8.18.0013.1.01.5	SHELL	Shell OMALA S4 GX V150	GEAR OIL
7289	8.18.0014.1.01.6	SHELL	SPIRAX S2 G 80W90	GEAR OIL
7290	8.18.0015.1.01.7	MOBIL	Mobil DELVAC 1 ATF	GEAR OIL for ZF
7291	8.18.0016.1.01.8		Repeated item	
7292	8.18.0017.1.01.9	CR	0165.20.075	Engine diesel coarse filter(on tank)
7293	8.18.0018.1.01.1	CR	S6 AXME 75W90	GEAR OIL
7294	8.18.0019.2.01.2	CR	0165.22.248	Engine Air filter(OUTER)
7295	8.18.0020.1.01.3	CR	0165.22.249	Engine Air filter(INNER)
7296	8.18.0021.1.01.4	CR	80262200765	Diesel metal filter
7297	8.18.0022.1.01.5	CR	0165-22-248	AIR FILTER OUTER
7298	8.18.0023.1.01.6	CR	0165-22-249	AIR FILTER INNER
7299	8.18.0024.1.01.7	CR	2443833/41064314	Engine Rough Diesel Filter
7300	8.18.0025.1.01.8	CR	40095692/2676398	Air Drying Agent Filter
7301	8.18.0026.1.01.9	CR	40095697/74671181	CAT. Genset Diesel Filter
7302	8.18.0027.1.01.1	CR	4692718	COOLANT -20 LTR
7303	8.18.0028.1.01.2	CR	7W2327	OIL FILTER
7304	8.18.0029.1.01.3	CR	40102787	DRYING AGENT
7305	8.18.0030.1.01.4	CR	40097602	DRYING AGENT
7306	8.18.0031.1.01.5	CR	40102522	FILTER CARTRIDGE
7307	8.18.0032.1.01.6		Shifted to Ann II	
7308	8.18.0033.1.01.7	AM	9990187 and Donaldson part no.P553315	LUBE OIL FILTER
7309	8.18.0034.1.01.8		Shifted to Ann II	
7310	8.18.0035.1.01.9		Shifted to Ann II	
7311	8.18.0036.1.01.1		Shifted to Ann II	
7312	8.18.0037.1.01.2	CR	SHELL TELLUS S100	TAMPING UNIT OIL
7313	8.18.0038.1.01.3	PL	UD80.1115	MUSHROOM-SHAPPED PRESSURE PIECE
7314	8.19.0001.1.01.3		Shifted to Ann II	
7315	8.19.0002.1.01.4	CU	41064318	ENGINE BELT
7316	8.19.0003.1.01.5	LO	127019	BELT FAN POLY V 23 RIB K SECTION
7317	8.20.0001.1.01.4	KA	MSVP.461264-547	SETTING DEVICE
7318	8.20.0002.1.01.5	KA	PD 1.1.5 M PQ27SH	PRESSURE RECEIVER
7319	8.20.0003.1.01.6	KA	PK 16.11S 5008.T3	SWITCH
7320	8.21.0001.1.01.5		Repeated item	
7321	8.21.0002.1.01.6	PL	UD150.1554	STOPPING DISC
7322	8.21.0003.1.01.7	PL	UD257.406	ROLLER COMPLETE
7323	8.21.0004.1.01.8	PL	UD80.4230	BUSH
7324	8.21.0005.1.01.9	PL	WN119-M16.80-1	HEX SCREW WITH CONED HALF DOG
7325	8.21.0006.1.01.1	PL	WN121-30H7.35/6.20-1	INTERMEDIATE BUSHING
7326	8.21.0007.1.01.2	PL	WN141-19H7.40.15-2	FISH PLATE
7327	8.21.0008.1.01.3	PL	WN141-28H7.180.20-1	FISH PLATE
7328	8.21.0009.1.01.4	PL	WN141-35J7.180.50.20-1	FISH PLATE
7329	8.21.0010.1.01.5	PL	WN141-35J7.65.20-1	FISH PLATE
7330	8.21.0011.1.01.6	PL	WN141-62H7.100.150.35-1	FISH PLATE
7331	8.22.0001.1.01.6	PL	SU-3"-JV	CHAIN
7332	8.22.0002.1.01.7	PL	0950/L5320/R200/B150	ENERGY CHAIN
7333	8.22.0003.1.01.8	PL	RE13.11.501	Ballast guide blade
7334	8.22.0004.1.01.9	PL	RE152.37.111	Guide
7335	8.22.0005.1.01.1	PL	RE152.5812	Slider
7336	8.22.0006.1.01.2	PL	RM10.40.0151	Tunnel
7337	8.22.0007.1.01.3	PL	UD190.1309	Roller
7338	8.22.0008.1.01.4	PL	RE11.09.1105	SUPPORT WITH OUT BEARING
7339	8.22.0009.1.01.5	PL	RE11.09.1106	SUPPORT COMPLETE WITH BEARING
7340	8.22.0010.1.01.6	PL	SU1600.509.1.5	SUPPORTS WITH OUT BEARING
7341	8.22.0011.1.01.7	PL	SU1600.509.1.6	SUPPORT WITH BEARING
7342	8.22.0012.1.01.8	PL	RE11.11.2112-1HA	CONVEYOR TRACK B+E 1745
7343	8.22.0013.1.01.9	PL	RE11.14.1112-42	WEAR STRIP B+E 1020
7344	8.22.0014.1.01.1	PL	RE11.14.1112-43	WEAR STRIP B+E 1020
7345	8.22.0015.1.01.2	PL	RE11.08.2112-33	WEAR STRIP B+E 770
7346	8.22.0016.1.01.3	PL	RE11.08.2112-34	WEAR STRIP B+E 770
7347	8.22.0017.1.01.4	PL	RE08.31.409-3Z/4Z	SPLIT CHAIN WHEEL (SPROCKET)
7348	8.22.0018.1.01.5	PL	63.08.2006-GEHAERTET	SECURING BOLT
7349	8.22.0019.1.01.6	PL	RE08.11.202	ASC.ELBOW JOINT
7350	8.22.0020.1.01.7	PL	RE08.11.302	DES.ELBOW JOINT
7351	8.22.0021.1.01.8	PL	RE08.02.716	Rod head(connecting elbow)
7352	8.22.0022.1.01.9	PL	RE11.24.2113-30	B3 slewing gear box
7353	8.22.0023.1.01.1	PL	RE151.102.N-TS	ROLLER CLAMP ASSEMBLY
7354	8.22.0024.1.01.2	PL	RE153.804	ROLLER CLAMP ASSEMBLY
7355	8.22.0025.1.01.3	PL	WN83.50W	PLANETARY GEAR
7356	8.22.0026.1.01.4	PL	RE11.09.1101-4	DRIVE SHAFT
7357	8.22.0027.1.01.5	PL	RE11.09.1102-1	CROSS SHAFT of turn station
7358	8.22.0028.1.01.6	PL	RE11.08.2101-4	DRIVE SHAFT
7359	8.22.0029.1.01.7	PL	SU1512.1108.6.2.1	CROSS SHAFT B600, D199
7360	8.22.0030.1.01.8	PL	RE08.02.1003	Locking chock

7361	9.01.0001.1.01.4	PL	786030	CONE BEARING
7362	9.01.0002.1.01.5	PL	13100602 SUB. 786030MITTEL	CONE BEARING
7363	9.01.0003.1.01.6	PL	571801313-50SH	CONE BEARING
7364	9.01.0004.1.01.7	PL	571801917-70SH	CONE BEARING
7365	9.01.0005.1.01.8	PL	UD72.304 SUB. 586280025	DAMPING BLOCK
7366	9.01.0006.1.01.9	PL	UD72.305 SUB. GE1576(02301/1)	DAMPING BLOCK
7367	9.01.0007.1.01.1	PL	5018053-11MN55	CONE BEARING
7368	9.02.0001.1.01.5	PL	5118002.11MN70	BEARING
7369	9.02.0002.1.01.6	PL	5418069B	BEARING
7370	9.02.0003.1.01.7	PH	UTV1-02-10/00	ANTI VIBRATION MOUNTING
7371	9.02.0004.1.01.8	PH	UTV1-02-11/01	ANTI VIBRATION MOUNTING
7372	9.02.0005.1.01.9	PH	UTV1-02-14/00	ANTI VIBRATION MOUNTING
7373	9.02.0006.1.01.1	PH	UTVI-02-11/00	ANTI VIBRATION MOUNTING
7374	9.02.0007.1.01.2	PL	571801313-11MN50	CONE BEARING
7375	9.03.0001.1.01.6	CR	BS550(IND)-06-00	Dirt Conveyor Belt (Main Conveyor) complete
7376	9.03.0002.1.01.7	CR	EP300X650X3(4+2)-39250	RUBBER BELT
7377	9.03.0003.1.01.8	CR	BS550(IND)-03-00	Assembly of Rotating Conveyor Belt Assembly (Complete)
7378	9.03.0004.1.01.9	CR	BS550(IND)-03-01-00	ROTATING CONVEYER BELT
7379	9.03.0005.1.01.1	CR	EP300 600X3(4.5+2)X19530	CONVEYOR BELT
7380	9.03.0006.1.01.2	CR	BS550(IND)-09-01-00(L)	MAIN FRAME OF LEFT MIXED BALLAST BELT
7381	9.03.0007.1.01.3	CR	BS550(IND)-10-00	Back Filling Conveyor Belt (Complete)
7382	9.03.0008.1.01.4	CR	BS550(IND)-10-00(L)	LEFT BACK FILLING CONVEYOR BELT
7383	9.03.0009.1.01.5	CR	BS550(IND)-10-00(R)	RIGHT BACK FILLING CONVEYOR BELT
7384	9.03.0010.1.01.6	CR	BS550(IND)-10-00 (R)	Right Back Filling Conveyor Belt (Complete)
7385	9.03.0011.1.01.7	PL	BR25.6720	CONVEYOR BELT
7386	9.04.0001.1.01.7	PL	9830382	SEAL RING
7387	9.04.0002.1.01.8	PL	9830978	SEAL RING
7388	9.04.0003.1.01.9	PL	9830979	SEAL RING
7389	9.04.0004.1.01.1	PL	1630820 SUB. 050302	SHAFT SEAL RING
7390	9.04.0005.1.01.2	PL	C400.116SP1668	RUBBER SCRAPER BLADE
7391	9.04.0006.1.01.3	PL	62.02.114	RUBBER ELEMENT
7392	9.05.0001.1.01.8	PL	33X55X280MM	SWEEP BRUSH
7393	9.05.0002.1.01.9	PL	33X55X305MM	SWEEP BRUSH
7394	9.05.0003.1.01.1	PL	33X55X310MM	SWEEP BRUSH
7395	9.05.0004.1.01.2	PL	33X55X315MM	SWEEP BRUSH
7396	9.05.0005.1.01.3	PL	33X55X320MM	SWEEP BRUSH
7397	9.05.0006.1.01.4	PL	33X55X330MM	SWEEP BRUSH
7398	9.05.0007.1.01.5	PL	33X55X335MM	SWEEP BRUSH
7399	9.05.0008.1.01.6	PL	33X55X340MM	SWEEP BRUSH
7400	9.05.0009.1.01.7	PL	33X55X345MM	SWEEP BRUSH
7401	9.05.0010.1.01.8	PL	33X55X350MM	SWEEP BRUSH
7402	9.05.0011.1.01.9	PL	230016	BROOM ELEMENT FOR BRM
7403	9.05.0012.1.01.1	PL	EL-T874.00	MARKING
7404	9.05.0013.1.01.2	PL	MMI/2-CMS-1	MC TERMINAL/PROG.
7405	9.05.0014.1.01.3	KA	43.01.00.049	Brake shoe
7406	9.05.0015.1.01.4	PL	732073/MG670 S6	MEGGIE SPRING
7407	9.05.0016.1.01.5	HA	HO403Y02	OT RUBBER PAD
7408	9.05.0017.1.01.6	PL	UD61.14168	RUBBER SPRING ELEMENT
7409	9.05.0018.1.01.7	PL	732073-MG660-S5	MAGGIE SPRING
7410	9.05.0019.1.01.8	CR	40100378-065	O-RING-1
7411	9.05.0020.1.01.9	CR	40100378-095	O-RING-2
7412	9.05.0021.1.01.1	CR	40100378-102	O-RING-3
7413	9.05.0022.1.01.2	CR	40100378-113	O-RING-1
7414	9.05.0023.1.01.3	CR	40100378-114	RING-1
7415	9.05.0024.1.01.4	CR	40100378-115	O-RING-2
7416	9.05.0025.1.01.5	CR	101.19.3.53	O ring-15
7417	9.05.0026.1.01.6	CR	56.3.5	O ring-16
7418	9.05.0027.1.01.7	CR	26.3.1	O ring-11
7419	9.05.0028.1.01.8	CR	73.3.5	O ring-12
7420	9.05.0029.1.01.9	CR	70.75.15	Guide ring-13
7421	9.05.0030.1.01.1	CR	93.3.5	O ring-17
7422	9.05.0031.1.01.2	CR	41.8.3.1	O ring-18
7423	9.05.0032.1.01.3	CR	59.3.5	O RING-1
7424	9.05.0033.1.01.4	CR	FA45.55.6.5.3/7	SCRAPPER RING
7425	9.05.0034.1.01.5	CR	ISI45.55.6	Y RING-1
7426	9.05.0035.1.01.6	CR	45.50.15	GUIDE RING-1
7427	9.05.0036.1.01.7	CR	SPD63.52.4.2	GUIDE RING-2
7428	9.05.0037.1.01.8	CR	58.63.10	GUIDE RING-3

7429	9.05.0038.1.01.9	CR	ISI40.50.6	Y RING-2
7430	9.05.0039.1.01.1	CR	75.80.10	GUIDE RING-4
7431	9.05.0040.1.01.2	CR	SPD80.64.5.6.3	GUIDE RING-5
7432	9.05.0041.1.01.3	CR	40.45.10	GUIDE RING-6
7433	9.05.0042.1.01.4	CR	33.8.3.1	O RING-5
7434	9.05.0043.1.01.5	CR	36.46.6	Y ring-4
7435	9.05.0044.1.01.6	CR	36.41.10	Guide ring-8
7436	9.05.0045.1.01.7	CR	48.3	O ring-7
7437	9.05.0046.1.01.8	CR	20.2.2.4	O ring-8
7438	9.05.0047.1.01.9	CR	83.3.5	O ring-31
7439	9.05.0048.1.01.1	CR	50.55.10	Guide ring-21
7440	9.05.0049.1.01.2	CR	ISI50.60.6	Y ring-16
7441	9.05.0050.1.01.3	CR	GS50.65.1.6.3	Stern ring-2
7442	9.05.0051.1.01.4	CR	45.55.6	Y ring-13
7443	9.05.0052.1.01.5	CR	45.50.6	Guide ring-18
7444	9.05.0053.1.01.6	CR	USH45.55.6	Y ring-12
7445	9.05.0054.1.01.7	CR	45.50.10	Guide ring-16
7446	9.05.0055.1.01.8	CR	73.8.3.1	O ring-23
7447	9.05.0056.1.01.9	CR	ISI80.90.6	Y ring-15
7448	9.05.0057.1.01.1	CR	80.85.15	Guide ring-20
7449	9.05.0058.1.01.2	CR	ISI32.42.6	Y ring-10
7450	9.05.0059.1.01.3	CR	32.37.15	Guide ring-14
7451	9.05.0060.1.01.4	CR	57.3.1	O ring
7452	9.05.0061.1.01.5	CR	22.2.65	O ring-20
7453	9.05.0062.1.01.6	CR	26.7.2.65	O ring-22
7454	9.05.0063.1.01.7	CR	BS550(IND)-15-02-00	VERTICLE ROTARY WIPER (Complete)
7455	9.05.0064.1.01.8	CR	BS550(IND)-15-02-04-03	8MM ROTARY BRUSH
7456	9.05.0065.1.01.9	GE	CDCK16A-56-13	Gasket
7457	9.05.0066.1.01.1	CR	I516033-1	CONE RUBBER SPRING
7458	9.05.0067.1.01.2	CR	BS550(IND)-20-07-02	CENTER PLATE GASKET
7459	9.05.0068.1.01.3	CR	40100378-091	GASKET-1
7460	9.05.0069.1.01.4	CR	40100378-092	GASKET-2
7461	9.05.0070.1.01.5	CR	40100378-098	GASKET-3
7462	9.05.0071.1.01.6	CR	I516008-5	CONE RUBBER SPRING
7463	9.05.0072.1.01.7	CR	BS550(IND)-07-01-72	RUBBER PLATE OF ISOLATION HOOD I
7464	9.05.0073.1.01.8	CR	BS550(IND)-07-01-73	RUBBER PLATE OF ISOLATION HOOD II
7465	9.05.0074.1.01.9	CR	BS550(IND)-07-01-74	RUBBER PLATE OF ISOLATION HOOD III
7466	9.05.0075.1.01.1	CR	BS550(IND)-07-01-42	RUBBER PLATE OF ISOLATION HOOD VII
7467	9.05.0076.1.01.2	CR	BS550(IND)-07-01-43	RUBBER PLATE OF ISOLATION HOOD VIII
7468	9.05.0077.1.01.3	CR	BS550(IND)-07-01-44	RUBBER PLATE OF ISOLATION HOOD IX
7469	9.05.0078.1.01.4	CR	BS550(IND)-07-01-45	RUBBER PLATE OF ISOLATION HOOD X
7470	9.05.0079.1.01.5	CR	BS550(IND)-07-02-20	RUBBER PLATE I
7471	9.05.0080.1.01.6	CR	BS550(IND)-07-02-21	RUBBER PLATE II
7472	9.05.0081.1.01.7	CR	BS550(IND)-06-01-09	RUBBER PLATE-1
7473	9.05.0082.1.01.8	CR	BS550(IND)-06-01-10	RUBBER PLATE-2
7474	9.05.0083.1.01.9	CR	BS550(IND)-06-01-14	RUBBER PLATE Δ5 -1
7475	9.05.0084.1.01.1	CR	BS550(IND)-06-02-06	RUBBER PLATE Δ5 -2
7476	9.05.0085.1.01.2	CR	BS550(IND)-06-02-07	RUBBER PLATE Δ5 -3
7477	9.05.0086.1.01.3	CR	BS550(IND)-06-02-13	RUBBER PLATE Δ5 -4
7478	9.05.0087.1.01.4	CR	BS550(IND)-06-03-05	RUBBER PLATE Δ5 -5
7479	9.05.0088.1.01.5	CR	EP200X800X3(4+2)-9256	RUBBER BELT
7480	9.05.0089.1.01.6	CR	BS550(IND)-09-00(R)	Right Mixed Ballast Belt complete
7481	9.05.0090.1.01.7	CR	BS550(IND)-09-01-00(R)	RIGHT MIXED BALLAST BELT MAIN PART
7482	9.05.0091.1.01.8	CR	BS550(IND)-09-34	RUBBER SCRAPER-1
7483	9.05.0092.1.01.9	CR	BS550(IND)-09-36	RUBBER PARTS
7484	9.05.0093.1.01.1	CR	BS550(IND)-09-38	RUBBER SCRAPER-2
7485	9.05.0094.1.01.2	CR	BS550(IND)-09-46	RUBBER PLATE-1
7486	9.05.0095.1.01.3	CR	BS550(IND)-09-49	RUBBER PLATE-2
7487	9.05.0096.1.01.4	CR	BS550(IND)-09-51	RUBBER PLATE-3
7488	9.05.0097.1.01.5	CR	BS550(IND)-09-00(L)	Left Mixed Ballast Belt complete
7489	9.05.0098.1.01.6	CR	EP300X650X3(4+2)-16230	RUBBER BELT
7490	9.05.0099.1.01.7	CR	BS550-10-01-16	RUBBER PLATE
7491	9.05.0100.1.01.8	CR	BS550(IND)-10-02-05-02	RUBBER ELEMENT
7492	9.05.0101.1.01.9	CR	BS550(IND)-15-01-04-00	RUBBER STICK SET
7493	9.05.0102.1.01.1	CR	20261419	Rubber ring

7494	9.05.0103.1.01.2	CR	40103560/40095760	Hydraulic cylinder sealing ring(full set)
7495	9.06.0001.1.01.9	PL	101,32X1,78-N-DIN3771-NBR90	O-RING
7496	9.06.0002.1.01.1	PL	18.72X2.62 NBR90	O RING
7497	9.06.0003.1.01.2	PL	196,2X5,33-N-DIN3771-NBR90	O-RING
7498	9.06.0004.1.01.3	PL	40,2X3-N-DIN-3771-NBR-90	O RING
7499	9.06.0005.1.01.4	PL	46,2X3 N DIN 3771 NBR 90	O RING
7500	9.06.0006.1.01.5	PL	47.22X3.53 NBR90	O RING
7501	9.06.0007.1.01.6	PL	50X3-N-DIN3771-NBR90	O-RING
7502	9.06.0008.1.01.7	PL	56,74X3,53-N-DIN3771-NBR90	O-RING
7503	9.06.0009.1.01.8	PL	69,44X3,53-N-DIN3771-NBR90	O-RING
7504	9.06.0010.1.01.9	PL	85X6-N-DIN3771-NBR90	O-RING
7505	9.06.0011.1.01.1	PL	97,79X5,33-N-DIN3771-NBR90	O-RING
7506	9.06.0012.1.01.2	PL	A13X20X1,5DIN7603-CU	SEAL RING
7507	9.06.0013.1.01.3	PL	BA230-255-15DIN3760-NB	SEAL RING
7508	9.06.0014.1.01.4	PH	3P28	MELAMINE SHEET
7509	9.06.0015.1.01.5	PH	30516001	GASKET 0.8 TH
7510	9.06.0016.1.01.6	PH	UTVI-01 13/00	FELT RING
7511	9.06.0017.1.01.7	PH	UTVI-03 07/00	RUBBER PACKING RING
7512	9.06.0018.1.01.8	PH	UTVI-03 12/00	RUBBER SNUBBER
7513	9.06.0019.1.01.9	PH	UTV1-03 17/00	SHOCK ABSORBER
7514	9.06.0020.1.01.1	LO	106566	BOOT RUBBER #4 LEADS FOR PIGTAIL CONNECTOR
7515	9.06.0021.1.01.2	LO	A32670	DUCT FLEX
7516	9.06.0022.1.01.3		Repeated item	
7517	9.06.0023.1.01.4	PL	129,2X5,7-N-DIN3771-NBR90	O-RING
7518	9.06.0024.1.01.5	PL	1630820 SUBSTITUTE 050302	SHAFT SEAL RING
7519	9.06.0025.1.01.6	PL	164,2X5,7-N-DIN3771-NBR90	O-RING
7520	9.06.0026.1.01.7	PL	170,82X5,33-N-DIN3771-NBR90	O-RING
7521	9.06.0027.1.01.8	PL	171,12X2,62-DIN3771-NBR90	O-RING
7522	9.06.0028.1.01.9	PL	190X3-N-DIN-3771-NBR90	O-RING
7523	9.06.0029.1.01.1	PL	45,69X2,62-N-DIN3771-NBR90	O-RING
7524	9.06.0030.1.01.2	PL	63,09X3,53-N-DIN3771-NBR90	O-RING
7525	9.06.0031.1.01.3	PL	72,62X3,53-N-DIN3771-NBR90	O-RING
7526	9.06.0032.1.01.4	PL	85,32X3,53-N-DIN3771-NBR90	O-RING
7527	9.06.0033.1.01.5	PL	86X6-N-DIN3771-NBR90	O-RING
7528	9.06.0034.1.01.6	PL	BGS-12"-DS	PISTON RUBBER PACKING 12"
7529	9.06.0035.1.01.7	PL	OMV500/630DS	SEAL KIT
7530	9.06.0036.1.01.8	PL	62.02.2064	RING
7531	9.06.0037.1.01.9	PL	2-05922 = 01 No.	O-RING
7532	9.07.0001.1.01.1	PL	DL 12.22A	RADIAL SEAL
7533	9.07.0002.1.01.2	PL	2E34.228-6.95	TAFLON WASHER
7534	9.07.0003.1.01.3	PL	2E34.228-7.00	TAFLON WASHER
7535	9.07.0004.1.01.4	PL	2E34.228-7.05	TAFLON WASHER
7536	9.07.0005.1.01.5	PL	2E34.228-7.10	TAFLON WASHER
7537	9.07.0006.1.01.6	PL	2E34.228-7.15	TAFLON WASHER
7538	9.07.0007.1.01.7	PL	2E34.228-7.20	TAFLON WASHER
7539	9.07.0008.1.01.8	PL	2E34.228-7.25	TAFLON WASHER

KAILASH NARAYAN

Digitally signed by
KAILASH NARAYAN
Date: 2025.01.22
10:42:22 +05'30'

Kailash Narayan
Director Track Machine-I