

| Annexure IIIA |                  |                         |                    |                                                                            |                                                                               |             |
|---------------|------------------|-------------------------|--------------------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------|-------------|
| SN            | SPN              | PART NO.                | MACHINE            | DESCRIPTION                                                                | DRG. NO.                                                                      | SPEC NO.    |
| 1             | 2.04.0001.3.01.2 | 64.08.4007              | BCM                | Tube of tensioning cylinder of BCM                                         | RDSO/TM/11/14                                                                 | TM/HM/6/353 |
| 2             | 2.04.0002.3.01.3 | 62.08.4009              | BCM                | Piston Rod for tensioning cylinder of BCM                                  | RDSO/TM/12/14                                                                 | TM/HM/6/354 |
| 3             | 2.04.0003.3.01.4 | 62.08.4005              | BCM                | Piston for tensioning cylinder of BCM                                      | RDSO/TM/13/14                                                                 | TM/HM/6/355 |
| 4             | 2.04.0004.3.01.5 | 62.08.4008              | BCM                | Bush for tensioning cylinder of BCM                                        | RDSO/TM/14/14                                                                 | TM/HM/6/356 |
| 5             | 2.04.0005.3.01.6 | W33.205A                | Common<br>Tammer   | Piston for Brake cylinder of UNO, DUO, WST, UNI, & T-Exp. tamping machine. | RDSO/TM/05/12                                                                 | TM/HM/6/329 |
| 6             | 2.04.0006.3.01.7 | W33.139.3               | Common<br>Tammer   | Cover for Brake Cylinder of UNO, DUO, WST, UNI, & T-EXP.                   | RDSO/TM/07/12                                                                 | TM/HM/6/331 |
| 7             | 2.04.0007.3.01.8 | HZ09.GB.100.0300        | CSM                | Sleeve of Lining Cylinder for CSM                                          | RDSO/TM/09/19                                                                 | TM/HM/6/430 |
| 8             | 2.04.0008.3.01.9 | HZ10.100.045.0420.1     | CSM                | Piston Rod Complete of Lining Cylinder for CSM                             | RDSO/TM/10/19                                                                 | TM/HM/6/431 |
| 9             | 2.04.0009.3.01.1 | HZ06.100.045            | CSM                | Gland of Lining Cylinder for CSM                                           | RDSO/TM/12/19                                                                 | TM/HM/6/436 |
| 10            | 2.04.0010.3.01.2 | HZGB.100.045.0300.1.003 | CSM                | Yoke of Lining Cylinder for CSM sub assembly                               | RDSO/TM/13/19                                                                 | TM/HM/6/437 |
| 11            | 2.04.0011.3.01.3 | HZMB.63.036.0180.1      | DTS                | Yoke of Roller Clamp Cylinder for DTS Machine sub assembly.                | RDSO/TM/14/19                                                                 | TM/HM/6/438 |
| 12            | 2.04.0012.3.01.4 | HZGB.063.036.0305.1     | UNIMAT             | Angular movement cylinder of tamping unit for Unimat                       | RDSO/TM/05/20<br>(1OF2)<br>RDSO/TM/05/20<br>(2OF2)                            | TM/HM/6/445 |
| 13            | 2.04.0013.3.01.5 | HZGB.050.025.0580.1.001 | UNIMAT             | Hook displacement cylinder of lifting unit for Unimat                      | RDSO/TM/06/20<br>(1OF3)<br>RDSO/TM/06/20<br>(2OF3)<br>RDSO/TM/06/20<br>(3OF3) | TM/HM/6/446 |
| 14            | 2.04.0014.3.01.6 | HZGB.100.045.400.1.015  | WST                | Hydraulic lining cylinder for WST                                          | RDSO/TM/10/20<br>(1OF2)<br>RDSO/TM/10/20<br>(2OF2)                            | TM/HM/6/470 |
| 15            | 2.04.0015.3.01.7 | 2E36.452                | CSM,DUO<br>& T-Exp | Piston rod for Tamping cylinder of CSM,DUO & Tamping Express               | RDSO/TM/17/20                                                                 | TM/HM/6/480 |
| 16            | 2.04.0016.3.01.8 | HZGB.125.050.0500.1     | DUO                | Track lifting cylinder of Duomatic                                         | RDSO/TM/14/20<br>(1OF2)<br>RDSO/TM/14/20<br>(2OF2)                            | TM/HM/4/477 |
| 17            | 2.04.0017.3.01.9 | HZGB.100.050.0400.1     | CSM                | Tamping unit sliding cylinder of CSM                                       | RDSO/TM/15/20<br>(1OF2)<br>RDSO/TM/15/20<br>(2OF2)                            | TM/HM/6/478 |
| 18            | 2.04.0018.3.01.1 | HZMB.100.045.0540.2.001 | UNIMAT             | Hydraulic cylinder for lining of Unimat                                    | RDSO/TM/11/20<br>(1OF2)<br>RDSO/TM/11/20<br>(2OF2)                            | TM/HM/6/471 |
| 19            | 2.04.0019.3.01.2 | HZGB.125.050.0330.1     | CSM                | Track Lifting Cylinder for CSM                                             | RDSO/TM/16/20<br>(1OF2)<br>RDSO/TM/16/20<br>(2OF2)                            | TM/HM/6/479 |
| 20            | 2.04.0020.3.01.3 | HZQB.050.036.0600.1.002 | CSM                | Acceleration Cylinder for CSM                                              | RDSO/TM/12/20<br>(1OF2)<br>RDSO/TM/12/20<br>(2OF2)                            | TM/HM/6/472 |

|    |                  |                         |                  |                                                                 |                                              |                   |
|----|------------------|-------------------------|------------------|-----------------------------------------------------------------|----------------------------------------------|-------------------|
| 21 | 2.04.0021.3.01.4 | HZGB.125.050.0435.1.001 | UNIMAT           | Track Lifting Cylinder for Unimat-3S &4S                        | RDSO/TM/13/20 (1OF2)<br>RDSO/TM/13/20 (2OF2) | TM/HM/6/473       |
| 22 | 2.04.0022.3.01.5 | HZMB.063.040.0410.1.001 | UNIMAT           | Lifting unit axial movement cylinder of Unimat-3S               | RDSO/TM/01/21                                | TM/HM/6/486       |
| 23 | 2.04.0023.3.01.6 | HZGB.063.036.0580.1     | UNIMAT           | Tamping unit sliding cylinder of Unimat                         | RDSO/TM/02/21 (1OF2)<br>RDSO/TM/02/21 (2OF2) | TM/HM/6/487       |
| 24 | 2.04.0024.3.01.7 | UD19.286                | T-EXP            | Cover plate for Squeezing Cylinder male of Tamping Express      | RDSO/TM/04/21                                | TM/HM/6/489       |
| 25 | 2.04.0025.3.01.8 | W37.2054B               | Unimat           | Piston Rod for Tamping Cylinder of Unimat                       | RDSO/TM/16/21                                | TM/HM/6/501       |
| 26 | 2.04.0026.3.01.9 | 2E35.306                | CSM, DUO & T-    | Piston rod for squeezing cylinder (small) of CSM, DUO & T-Exp   | TM/0536 Rev-1                                | TM/HM/6/227 Rev-1 |
| 27 | 2.04.0027.3.01.1 | WN102.30h8.99.8.1       | UNIMAT           | Pin for Hydraulic cylinder of Unimat                            | RDSO/TM/02/22                                | TM/HM/6/513       |
| 28 | 2.04.0028.3.01.2 | WN107-20e8.70.5.5.2     | UNIMAT           | Pin for hydraulic cylinder of Unimat                            | RDSO/TM/03/22                                | TM/HM/6/514       |
| 29 | 2.04.0029.3.01.3 | UD50.207                | Unimat & T-      | Head rest for wheel support cylinder of Unimat & T-Exp          | RDSO/TM/05/22                                | TM/HM/6/515       |
| 30 | 2.04.0030.3.01.4 | HZ10.080.045.0350.2     | UNIMAT           | Piston rod complete of hook UP/DN cylinder                      | RDSO/TM/04/24                                | TM/HM/6/554       |
| 31 | 2.04.0031.3.01.5 | HZ10.100.045.0500.2     | UNIMAT           | Piston rod complete lining cylinder                             | RDSO/TM/05/24                                | TM/HM/6/555       |
| 32 | 2.04.0032.3.01.6 | HZ10.080.036.0210.2     | UNIMAT           | Piston rod complete of Bogie tension cylinder                   | RDSO/TM/06/24                                | TM/HM/6/556       |
| 33 | 2.04.0033.3.01.7 | WN 107.45h7.139.8.5.1   | UNIMAT           | Pin for Hydraulic Cylinder of UNIMAT                            | RDSO/TM/09/24                                | TM/HM/6/559       |
| 34 | 2.04.0034.3.01.8 | WN 107.25e8.70.5.5.1    | UNIMAT           | Pin for Hydraulic Cylinder of UNIMAT                            | RDSO/TM/10/24                                | TM/HM/6/560       |
| 35 | 2.04.0035.3.01.9 | HY-40-73A               | DUO, CSM & T.Exp | Throtal for tamping unit up down Cylinder DUO, CSM & T.Exp      | RDSO/TM/17/24                                | TM/HM/6/567       |
| 36 | 3.03.0001.3.01.2 | PN2-ZG-100X25X400       | CSM              | Yoke for Pneumatic Cylinder of CSM                              | RDSO/TM/05/19                                | TM/HM/6/428       |
| 37 | 5.02.0001.3.01.3 | NA                      | Common Tamper    | Foundation block for Main Gear Box.                             | TM/0301                                      | TM/HM/6/112       |
| 38 | 5.02.0002.3.01.4 | Part No. UD72.06        | T-Exp, CSM &     | Cover for reducing gear box of T-Exp, CSM & Duomatic            | RDSO/TM/16/19                                | TM/HM/6/440       |
| 39 | 5.02.0003.3.01.5 | HY-40.25                | DUO              | M.S. Foundation for Hyd. Pump of Duomatic                       | RDSO/TM/14/24                                | TM/HM/6/564       |
| 40 | 5.03.0001.3.01.4 | UD63.1014               | Common Tamper    | Slider for Axle Gear of CSM                                     | TM/0304                                      | TM/HM/6/115       |
| 41 | 5.03.0002.3.01.5 | UD.64.1311              | Common Tamper    | Gear with Fork                                                  | TM/010/06                                    | TM/HM/6/296       |
| 42 | 5.03.0003.3.01.6 | UD63.1204               | CSM              | Shaft for satellite gear box of CSM.                            | RDSO/TM/31/17                                | TM/HM/6/410       |
| 43 | 5.03.0004.3.01.7 | U64.1302E               | CSM              | Gear Wheel (Satellite Gear Box) for Track Tamping (09-32-CSM) . | TM/9614                                      | TM/HM/6/97        |
| 44 | 5.03.0005.3.01.8 | U64.1303                | CSM              | Gear Wheel Pinion for (09-32-CSM)                               | TM/9615                                      |                   |
| 45 | 5.03.0006.3.01.9 | PB61.472                | Duomatic         | Intermediate shaft for drive axle of Duomatic                   | RDSO/TM/20/22                                | TM/HM/6/529       |
| 46 | 5.03.0007.3.01.1 | UD-214.1508             | UNIMAT & T.EXP   | Fork for Brake Cylinder of UNIMAT & T.EXP                       | RDSO/TM/11/24                                | TM/HM/6/561       |
| 47 | 5.04.0001.3.01.5 | 2E.71.07                | Common Tamper    | Flange for main Gear Box                                        | TM/0305                                      | TM/HM/6/116       |
| 48 | 5.04.0002.3.01.6 | 1238.309.067            | Common Tamper    | Selector Housing Cover                                          | TM/0306                                      | TM/HM/6/117       |
| 49 | 5.04.0003.3.01.7 | UD71.713ST              | WST              | Cover for Intermediate Shaft-DUO/UNO                            | TM/0309                                      | TM/HM/6/120       |
| 50 | 5.04.0004.3.01.8 | UD64.908                | Common Tamper    | Cover Plate for Housing of differential Gear Box                | TM/0310                                      | TM/HM/6/121       |

|    |                  |                  |                     |                                                       |               |             |
|----|------------------|------------------|---------------------|-------------------------------------------------------|---------------|-------------|
| 51 | 5.04.0005.3.01.9 | PB61.473         | CSM                 | Closing Cover for Intermediate shaft for CSM          | TM/0311       | TM/HM/6/122 |
| 52 | 5.04.0006.3.01.1 | PB61.474         | Common<br>Tamper    | Cardan Shaft Flange of Drive Axle Gear Box            | TM/0317       | TM/HM/6/123 |
| 53 | 5.04.0007.3.01.2 | 2E71.09          | Common<br>Tamper    | Bracket                                               | TM/0318       | TM/HM/6/124 |
| 54 | 5.04.0008.3.01.3 | G70.71A          | WST                 | Cover Plate for Main Gear Box –DUO                    | TM/0441       | TM/HM/6/177 |
| 55 | 5.04.0009.3.01.4 | UD.236.3001-5    | Common<br>Tamper    | Cover for Measuring Bogie Wheel                       | TM/0449       | TM/HM/6/185 |
| 56 | 5.04.0010.3.01.5 | DL63.316         | Common<br>Tamper    | Flange for axle gear box                              | TM/0590       | TM/HM/6/280 |
| 57 | 5.04.0011.3.01.6 | UD75.355         | Common<br>Tamper    | Cardan Shaft Flange of Main Gear Box                  | TM/0595       | TM/HM/6/285 |
| 58 | 5.04.0012.3.01.7 | UD64.1019        | WST                 | Cover plate for tail pinion of Duomatic               | RDSO/TM/04/17 | TM/HM/6/386 |
| 59 | 5.04.0013.3.01.8 | UD71.1002        | UNI                 | Cover plate for axle of Unimat                        | RDSO/TM/09/17 | TM/HM/6/391 |
| 60 | 5.04.0014.3.01.9 | DL63.308         | CSM/DTS             | Cover for Axle Gear Box of CSM                        | RDSO/TM/26/17 | TM/HM/6/405 |
| 61 | 5.04.0015.3.01.1 | UD64.907         | CSM                 | Cover plate for distributor gear box of CSM.          | RDSO/TM/29/17 | TM/HM/6/408 |
| 62 | 5.04.0016.3.01.2 | UD62.2404        | CSM                 | Housing cover for satellite axle of CSM               | RDSO/TM/25/17 | TM/HM/6/412 |
| 63 | 5.04.0017.3.01.3 | UD64.34          | CSM                 | Coupler for funk gear box of CSM                      | RDSO/TM/21/20 | TM/HM/6/482 |
| 64 | 5.04.0018.3.01.4 | 64.04.519        | BCM                 | Disc for Tumbler/Turret gear box of BCM               | RDSO/TM/13/21 | TM/HM/6/498 |
| 65 | 5.04.0019.3.01.5 | UD76.216         | CSM                 | Flange for driving motor of CSM                       | RDSO/TM/18/22 | TM/HM/6/527 |
| 66 | 5.06.0001.3.01.7 | 79000.32.49      | Common<br>Tamper    | Seal Ring Tail Pinion                                 | TM/0303       | TM/HM/6/114 |
| 67 | 5.06.0002.3.01.8 | UD.62.205        | WST                 | Disc for Axle                                         | TM/0439       | TM/HM/6/175 |
| 68 | 5.06.0003.3.01.9 | DL61.215         | CSM/DTS             | Support ring for axle                                 | TM/0528       | TM/HM/6/214 |
| 69 | 5.06.0004.3.01.1 | DL61.214         | CSM/DTS             | Support ring for axle                                 | TM/0529       | TM/HM/6/215 |
| 70 | 5.06.0005.3.01.2 | U61.104          | WST                 | Pin with castle nut for torque support                | TM/0531       | TM/HM/6/217 |
| 71 | 5.06.0006.3.01.3 | UD214.1020       | Common<br>Tamper    | Pin of Brake assembly                                 | TM/0593       | TM/HM/6/283 |
| 72 | 5.06.0007.3.01.4 | D216.451         | Common<br>Tamper    | Sleeve for brake cylinder                             | RDSO/TM/10/12 | TM/HM/6/333 |
| 73 | 5.06.0008.3.01.5 | UD21.04          | WST                 | Pin for brake assembly of Duomatic                    | RDSO/TM/05/17 | TM/HM/6/387 |
| 74 | 5.06.0009.3.01.6 | UD64.1303        | UNI                 | Spacer for axle gear of Unimat                        | RDSO/TM/10/17 | TM/HM/6/392 |
| 75 | 5.06.0010.3.01.7 | UD63.1008        | CSM/UNI/D           | Spacer for satellite gear box of CSM                  | RDSO/TM/11/17 | TM/HM/6/393 |
| 76 | 5.06.0011.3.01.8 | 2E71.20          | Common<br>Tamper    | Pin for differential gear box of CSM                  | RDSO/TM/12/17 | TM/HM/6/394 |
| 77 | 5.06.0012.3.01.9 | E63.119          | Common<br>Tamper    | Pin for shock absorber                                | TM/0539       | TM/HM/6/230 |
| 78 | 5.06.0013.3.01.1 | UD62.216         | Common<br>Tamper    | Pin for brake assembly                                | TM/0540       | TM/HM/6/231 |
| 79 | 5.06.0014.3.01.2 | UD.210.45        | Common<br>Tamper    | Pin for brake assembly                                | TM/0541       | TM/HM/6/232 |
| 80 | 5.06.0015.3.01.3 | E.69.119         | CSM/UNI             | Pin for big Shocker for axle bogie 09CSM              | TM/0583       | TM/HM/6/276 |
| 81 | 5.06.0016.3.01.4 | M63.512          | CSM                 | Pin for Satellite Axle Guard of CSM                   | TM/0579       | TM/HM/6/272 |
| 82 | 5.06.0017.3.01.5 | UD70.8854        | CSM/UNI/            | Bolt                                                  | TM/002/06     | TM/HM/6/288 |
| 83 | 5.06.0018.3.01.6 | CU61.5413        | Common<br>Tamper    | Distance Washer                                       | TM/007/06     | TM/HM/6/293 |
| 84 | 5.06.0019.3.01.7 | UD63.1013.D-9-46 | CSM                 | Bolt for satellite gear box of CSM                    | RDSO/TM/26/21 | TM/HM/6/510 |
| 85 | 5.06.0020.3.01.8 | UD64.906         | CSM, UNI<br>& T-Exp | Bearing bush for distributor gear of CSM, UNI & T-Exp | RDSO/TM/27/21 | TM/HM/6/511 |
| 86 | 5.06.0021.3.01.9 | SU126.2011.2.2   | FRM-80              | Bearing ring of drive station of FRM-80               | RDSO/TM/11/22 | TM/HM/6/521 |
| 87 | 5.07.0001.3.01.8 | UD.63.1011       | CSM/UNI/            | Axle of Satellite Gear Box of CSM                     | TM/009/06     | TM/HM/6/295 |
| 88 | 5.07.0002.3.01.9 | 236.3001.8       | Common<br>Tamper    | Axle for wheel of lining trolley                      | TM/0588       | TM/HM/6/278 |

|     |                  |                                                                                  |                          |                                                                   |                       |                   |
|-----|------------------|----------------------------------------------------------------------------------|--------------------------|-------------------------------------------------------------------|-----------------------|-------------------|
| 89  | 5.07.0003.3.01.1 | UD150.1555                                                                       | CSM                      | Axle of lining roller assembly for CSM                            | RDSO/TM/10/16         | TM/HM/6/375       |
| 90  | 5.07.0004.3.01.2 | 62.13.412                                                                        | BCM/FRM                  | Disc for axle bearing of BCM/FRM                                  | RDSO/TM/03/18         | TM/HM/6/415       |
| 91  | 5.07.0005.3.01.3 | 6.04.02.101                                                                      | VPR Tamping Machine      | Power Axle ( First) of VPR Tamping Machine (Part no. 6.04.02.101) | RDSO/TM/01/23 Rev-1   | TM/HM/6/532 Rev-1 |
| 92  | 5.07.0006.3.01.4 | 6.04.02.101-04                                                                   | VPR Tamping Machine      | Power Axle ( Second) of VPR Tamping Machine                       | RDSO/TM/02/23 Rev-1   | TM/HM/6/533 Rev-1 |
| 93  | 5.07.0007.3.01.5 | UD-62-3301                                                                       | CSM                      | CSM Satellite or driving bogie axle                               | TM/0322 Rev-1         | TM/HM/6/128 Rev-1 |
| 94  | 5.07.0008.3.01.6 | UD62.01                                                                          | Duomatic tamping machine | Driving axle for Duomatic tamping machine                         | TM/0324 Rev-1         | TM/HM/6/130 Rev-1 |
| 95  | 5.07.0009.3.01.7 | CU61.8801                                                                        | Unimat                   | Driving axle (front) of Unimat                                    | TM/0325 Rev-1         | TM/HM/6/131 Rev-1 |
| 96  | 5.07.0010.3.01.8 | CU62.4901                                                                        | Unimat                   | Driving axle (back) of Unimat                                     | TM/0326 Rev-1         | TM/HM/6/132 Rev-1 |
| 97  | 5.08.0001.3.01.9 | UD.236.3001-7                                                                    | Common Tamper            | Wheel for Bogie (sensing wheel)                                   | TM/0448               | TM/HM/6/184       |
| 98  | 5.09.0001.3.01.1 | 2E71.19RT                                                                        | Common Tamper            | Suspension Bracket for Clutch Actuator of DUO                     | TM/0320               | TM/HM/6/126       |
| 99  | 5.09.0002.3.01.2 | 380.932.117                                                                      | Common Tamper            | Tail pinion housing                                               | TM/0530               | TM/HM/6/216       |
| 100 | 5.09.0003.3.01.3 | EM160.1005                                                                       | CSM                      | Guide for Satellite Gear Box                                      | TM/006/06             | TM/HM/6/292       |
| 101 | 5.09.0004.3.01.4 | LK62.302                                                                         | CSM                      | Body bearing for axle of CSM.                                     | RDSO/TM/30/17         | TM/HM/6/409       |
| 102 | 5.09.0005.3.01.5 | UD64.1018                                                                        | Common Tamper            | Bearing housing for tail pinion of Duo                            | RDSO/TM/03/17         | TM/HM/6/385       |
| 103 | 5.09.0006.3.01.6 | SU1502.208.1.1.6                                                                 | SBCM                     | Bearing housing of excavating conveyor of SBCM                    | RDSO/TM/25/21         | TM/HM/6/509       |
| 104 | 5.10.0001.3.01.2 | UD.214.1023                                                                      | Common Tamper            | Locking Block for Break Assembly                                  | TM/0429               | TM/HM/6/165       |
| 105 | 5.10.0002.3.01.3 | D160.52                                                                          | Common Tamper            | Piston rod for brake cylinder                                     | RDSO/TM/09/12         | TM/HM/6/332       |
| 106 | 5.10.0003.3.01.4 | UD214.1024                                                                       | Common Tamper            | Bolt For Brake assembly                                           | TM/0596               | TM/HM/6/286       |
| 107 | 6.01.0001.3.01.3 | 2E33.21                                                                          | CSM/WST                  | Squeezing Cylinder (Small Female) of DUO& CSM 09-32.              | RDSO/TM/011/07 Rev-1  | TM/HM/6/309 Rev-1 |
| 108 | 6.01.0002.3.01.4 | 2E34.201B                                                                        | CSM/WST                  | Squeezing Cylinder (Big Male) of DUO, CSM.                        | RDSO/TM /012/07 Rev-1 | TM/HM/6/310       |
| 109 | 6.01.0003.3.01.5 | 2E.34.202B                                                                       | CSM/WST                  | Squeezing Cylinder (Small Male) of DUO, CSM                       | RDSO/TM /013/07 Rev-1 | TM/HM/6/311       |
| 110 | 6.01.0004.3.01.6 | 2E34.41A                                                                         | CSM/WST                  | Squeezing Cylinder (Big Female) of DUO, CSM                       | RDSO/TM/014/07 Rev-1  | TM/HM/6/312       |
| 111 | 6.01.0005.3.01.7 | CU12.501                                                                         | UNI3S                    | Squeezing Cylinder (Male) Unimat.                                 | RDSO/TM 015/07 Rev-1  | TM/HM/6/313       |
| 112 | 6.01.0006.3.01.8 | CU12.501                                                                         | UNI3S                    | Squeezing Cylinder (Female) Unimat.                               | RDSO/TM/016/07 Rev-1  | TM/HM/6/314       |
| 113 | 6.01.0007.3.01.9 | 2E35.303                                                                         | UNI3S                    | Piston for Squeezing Cylinder                                     | TM/0130               | TM/HM/6/109       |
| 114 | 6.01.0008.3.01.1 | W.37.1295                                                                        | UNI3S                    | Piston for Squeezing Cylinder                                     | TM/0417 Rev-1         | TM/HM/6/383       |
| 115 | 6.01.0009.3.01.2 | 2E.36.443                                                                        | UNI3S                    | Piston Squeezing Cylinder                                         | TM/0414 Rev-1         | TM/HM/6/383       |
| 116 | 6.01.0010.3.01.3 | Specification and Drawing of spare parts has been revised and place at Sr No. 26 |                          |                                                                   |                       |                   |
| 117 | 6.01.0011.3.01.4 | HZ10.063.036.0315.1                                                              | DTS                      | Piston Rod Complete of vibrator slide Cylinder Of DGS.            | RDSO/TM/09/14         | TM/HM/6/351       |
| 118 | 6.01.0012.3.01.5 | W33.201                                                                          | All UNI/MPT              | Barrel for Tool Tilting Cylinder                                  | RDSO/TM/01/12 Rev-1   | TM/HM/6/319       |
| 119 | 6.01.0013.3.01.6 | W33.202A                                                                         | All                      | Piston Rod For Tool Tilting Cylinder                              | TM/0551               | TM/HM/6/242       |
| 120 | 6.01.0014.3.01.7 | W33.205                                                                          | All UNI/MPT              | Piston For Tool Tilting Cyl Of Unimat                             | TM/0552 Rev-1         | TM/HM/6/383       |

|     |                   |                                                                                  |                 |                                                    |               |             |
|-----|-------------------|----------------------------------------------------------------------------------|-----------------|----------------------------------------------------|---------------|-------------|
| 121 | 6.01.0015.3.01.8  | JT30.06A                                                                         | CSM             | Piston Rod For Squeezing Cyl-Unimat                | TM/0562       | TM/HM/6/253 |
| 122 | 6.01.0016.3.01.9  | Specification and Drawing of spare parts has been revised and place at Sr No. 99 |                 |                                                    |               |             |
| 123 | 6.01.0017.3.01.1  | W37.2052                                                                         | Unimat -4S      | Squeezing Cylinder body (Male) of Unimat-4S        | RDSO/TM/08/23 | TM/HM/6/538 |
| 124 | 6.01.0018.3.01.2  | W37.2053                                                                         | Unimat -4S      | Squeezing Cylinder body (Female) of Unimat-4S      | RDSO/TM/09/23 | TM/HM/6/539 |
| 125 | 6.03.0001.3.01.5  | CU.30.413                                                                        | CSM/WST         | Tamping Arm Small                                  | TM/0127       | TM/HM/6/106 |
| 126 | 6.03.0002.3.01.6  | W37.1702                                                                         | UNIMAT          | Tamping arm left of unimat                         | RDSO/TM/03/20 | TM/HM/6/443 |
| 127 | 6.03.0003.3.01.7  | W37.1461                                                                         | UNIMAT          | Tamping arm right of unimat                        | RDSO/TM/04/20 | TM/HM/6/444 |
| 128 | 6.03.0004.3.01.8  | UD17.673A                                                                        | CSM             | Tamping arm modified big for CSM                   | RDSO/TM/07/20 | TM/HM/6/461 |
| 129 | 6.03.0005.3.01.9  | CU37.603                                                                         | UNIMAT          | Tool holder for tamping unit of Unimat             | RDSO/TM/08/20 | TM/HM/6/462 |
| 130 | 6.03.0006.3.01.1  | UD15.1212                                                                        | Unimat-4S       | Swivel Bearing Right for Tamping Unit of Unimat-4S | RDSO/TM/09/20 | TM/HM/6/463 |
| 131 | 6.03.0007.3.01.2  | CA21.2404                                                                        | T-EXP           | Tamping Arm left of Tamping Express                | RDSO/TM/22/20 | TM/HM/6/483 |
| 132 | 6.03.0008.3.01.3  | CA21.2405                                                                        | T-EXP           | Tamping Arm right of Tamping Express               | RDSO/TM/23/20 | TM/HM/6/484 |
| 133 | 6.03.0009.3.01.4  | UD15.4202                                                                        | CSM             | Tamping arm modified small for CSM                 | RDSO/TM/03/21 | TM/HM/6/488 |
| 134 | 6.03.0010.3.01.5  | CA21.2401                                                                        | Tamping Express | Tamping arm right of Tamping Express               | RDSO/TM/07/21 | TM/HM/6/492 |
| 135 | 6.03.0011.03.01.6 | CA21.2402                                                                        | Tamping Express | Tamping arm right of Tamping Express               | RDSO/TM/08/21 | TM/HM/6/493 |
| 136 | 6.03.0012.3.01.7  | UD19.1202                                                                        | Tamping Express | Tamping arm left of Tamping Express                | RDSO/TM/09/21 | TM/HM/6/494 |
| 137 | 6.03.0013.3.01.8  | UD19.1203                                                                        | Tamping Express | Tamping arm left of Tamping Express                | RDSO/TM/10/21 | TM/HM/6/495 |
| 138 | 6.03.0014.3.01.9  | W37.1703                                                                         | Unimat          | Tamping Arm of Unimat                              | RDSO/TM/15/21 | TM/HM/6/500 |
| 139 | 6.03.0015.3.01.1  | W37.1301                                                                         | UNI-3S          | Swivel bearing for tamping unit of UNI-3S          | RDSO/TM/18/21 | TM/HM/6/502 |
| 140 | 6.03.0016.3.01.2  | W37.1302                                                                         | UNI-3S          | Swivel bearing right for tamping unit of UNI-3S    | RDSO/TM/19/21 | TM/HM/6/503 |
| 141 | 6.03.0017.3.01.3  | CU37.604                                                                         | Unimat          | Tool holder right for tamping unit of Unimat       | RDSO/TM/20/21 | TM/HM/6/504 |
| 142 | 6.03.0018.3.01.9  | CU37.503                                                                         | Unimat -2S/     | Tool Holder for tamping unit of UNIMAT-2S/3S       | RDSO/TM/03/23 | TM/HM/6/534 |
| 143 | 6.03.0019.3.01.1  | CU37.504                                                                         | Unimat -2S/     | Tool Holder for tamping unit of UNIMAT-2S/3S       | RDSO/TM/04/23 | TM/HM/6/535 |
| 144 | 6.03.0020.3.01.2  | W37.1462                                                                         | Unimat -4S      | Tamping Arm for Unimat-4S                          | RDSO/TM/05/23 | TM/HM/6/536 |
| 145 | 6.04.0001.3.01.6  | DL23.401                                                                         | CSM/WST         | Eccentric Vibration Shaft with Disc and Nut        | TM/0321 Rev-1 | TM/HM/6/127 |
| 146 | 6.04.0002.3.01.7  | UD25-1101                                                                        | 09-3X           | Eccentric Vibration Shaft of 3X Machine            | RDSO/TM/02/12 | TM/HM/6/327 |
| 147 | 6.04.0003.3.01.8  | UD25-1102                                                                        | 09-3X           | Eccentric Vibration Shaft of 3X Machine            | RDSO/TM/03/12 | TM/HM/6/328 |
| 148 | 6.04.0004.3.01.9  | 2E.22.36                                                                         | 09-3X           | Castle nut for vibration shaft                     | TM/0509       | TM/HM/6/196 |
| 149 | 6.04.0005.3.01.9  | CU20.301                                                                         | UNIMAT          | Vibration shaft for vibration drive of Unimat      | RDSO/TM/18/20 | TM/HM/6/481 |
| 150 | 6.04.0006.3.01.1  | CU20.103                                                                         | Unimat -4S      | Connecting Piece for Vibration drive of Unimat-4S  | RDSO/TM/10/23 | TM/HM/6/540 |
| 151 | 6.04.0007.3.01.2  | UD-63-1004                                                                       | UNI             | Shaft for UNIMAT drive                             | RDSO/TM/15/23 | TM/HM/6/544 |
| 152 | 6.04.0008.3.01.3  | DL 23 102 2                                                                      | UNI             | Eccentric vibration shaft of Unimat                | RDSO/TM/01/24 | TM/HM/6/551 |
| 153 | 6.04.0009.3.01.4  | UD 25-501                                                                        | DUO             | Eccentric vibration shaft of Duomatic              | RDSO/TM/08/24 | TM/HM/6/558 |

|     |                  |                                |                 |                                                                        |                     |                   |
|-----|------------------|--------------------------------|-----------------|------------------------------------------------------------------------|---------------------|-------------------|
| 154 | 6.05.0001.3.01.7 | 2E31.02A                       | All TU          | Steel Bush for Tamping Arm Centre pin                                  | TM/0129 Rev-1       | TM/HM/6/108 Rev-1 |
| 155 | 6.05.0002.3.01.8 | DL10.53                        | Common Tamper   | Support Plate and Bolt                                                 | TM/0409             | TM/HM/6/141       |
| 156 | 6.05.0003.3.01.9 | UD67.752                       | CSM             | Guide Rod for CSM                                                      | TM/0424             | TM/HM/6/160       |
| 157 | 6.05.0004.3.01.1 | E.6203                         | CSM             | Guide rod for tamping unit                                             | TM/0505             | TM/HM/6/192       |
| 158 | 6.05.0005.3.01.2 | G20.13                         | All TU          | Connecting rod for tamping unit                                        | TM/0510             | TM/HM/6/197       |
| 159 | 6.05.0006.3.01.3 | UD313.1035                     | Common Tamper   | Guide Rod For Lifting Hook Sliding Unit -UNI                           | TM/0561             | TM/HM/6/252       |
| 160 | 6.05.0007.3.01.4 | UD19.221                       | 09-3X           | Connecting rod bolt of Tamping Express                                 | RDSO/TM/06/16 Rev-1 | TM/HM/6/366       |
| 161 | 6.05.0008.3.01.5 | G20.26B                        | All TU          | Sleeve for tamping unit                                                | TM/0508 Rev-2       | TM/HM/6/195       |
| 162 | 6.05.0009.3.01.6 | DL150.02                       | Common Tamper   | Sleeve for roll clamp                                                  | TM/0511             | TM/HM/6/198       |
| 163 | 6.05.0010.3.01.7 | W37.1410                       | UNI             | Axle Bolt                                                              | TM/0554 Rev-1       | TM/HM/6/245       |
| 164 | 6.05.0011.3.01.8 | W37.1293                       | UNI             | Gland Bush For Squeezing Cyl.                                          | TM/0556 Rev-1       | TM/HM/6/383       |
| 165 | 6.05.0012.3.01.9 | CU37.308                       | UNI             | Bearing Bush                                                           | TM/0557             | TM/HM/6/248       |
| 166 | 6.05.0013.3.01.1 | 2W31.205                       | UNI             | Bearing Bush                                                           | TM/0558             | TM/HM/6/249       |
| 167 | 6.05.0014.3.01.2 | W33.159                        | UNI             | Bush                                                                   | TM/0563             | TM/HM/6/254       |
| 168 | 6.05.0015.3.01.3 | UD19.285                       | 09-3X           | Bearing Bush                                                           | TM/0580 Rev-1       | TM/HM/6/383       |
| 169 | 6.05.0016.3.01.4 | WN153.82f7.1365-1              | 09-3X           | Guide column for Tamping Express                                       | RDSO/TM/03/16 Rev-1 | TM/HM/6/363       |
| 170 | 6.05.0017.3.01.5 | CU.37.632                      | UNI             | Tamping Unit Pin                                                       | TM/0553             | TM/HM/6/244       |
| 171 | 6.05.0018.3.01.6 | 2E.33.62                       | All TU          | Pin for clapper Bracket                                                | TM/0501             | TM/HM/6/188       |
| 172 | 6.05.0019.3.01.7 | E36.65A                        | All TU          | Pin for clapper cylinder Dia.12x92                                     | TM/0515             | TM/HM/6/201       |
| 173 | 6.05.0020.3.01.8 | E36.63A                        | All TU          | Pin for clapper cylinder                                               | TM/0516             | TM/HM/6/202       |
| 174 | 6.05.0021.3.01.9 | 2E.33.65a                      | All TU          | Pin for clapper Bracket                                                | TM/0532             | TM/HM/6/223       |
| 175 | 6.05.0022.3.01.1 | 2E.33.63a                      | All TU          | Pin for clapper Bracket                                                | TM/0533             | TM/HM/6/224       |
| 176 | 6.05.0024.3.01.3 | 2E.34.210                      | All TU          | Bush for Tamping Arm                                                   | TM/0411 Rev-2       | TM/HM/6/383       |
| 177 | 6.05.0025.3.01.4 | Item is repeated at Sr No .191 |                 |                                                                        |                     |                   |
| 178 | 6.05.0026.3.01.5 | 2E.34.231                      | UNI             | Piston Rod Bush                                                        | TM/0413 Rev-1       | TM/HM/6/383       |
| 179 | 6.05.0027.3.01.6 | 2E36.46C                       | UNI             | Gland Bush for Squeezing Cylinder                                      | TM/0415 Rev-1       | TM/HM/6/383       |
| 180 | 6.05.0028.3.01.7 | DL12.06                        | All TU          | Guide Rod Bush                                                         | TM/0416 Rev-2       | TM/HM/6/383       |
| 181 | 6.05.0029.3.01.8 | W.33.220                       | UNI             | Gland Bush for Arm Tilting Cylinder                                    | TM/0418 Rev-1       | TM/HM/6/383       |
| 182 | 6.05.0030.3.01.9 | W.61.02.25                     | Common Tamper   | Sliding Guide Rod Bush                                                 | TM/0419 Rev-1       | TM/HM/6/383       |
| 183 | 6.05.0031.3.01.1 | 2E.22.09                       | All TU          | Bush for NJ219 bearing                                                 | TM/0502 Rev-2       | TM/HM/6/189       |
| 184 | 6.05.0032.3.01.2 | UD22.350                       | CSM/WST         | Vibration Shaft Key                                                    | TM/0571             | TM/HM/6/262       |
| 185 | 6.05.0033.3.01.3 | UD22.307                       | 09-3X           | Vibration Shaft Key                                                    | TM/0572             | TM/HM/6/263       |
| 186 | 6.05.0034.3.01.4 | UD15.1231                      | UNI 4S          | Pin, Nut and Washer of Tamping Unit                                    | RDSO/TM/01/17       | TM/HM/6/378       |
| 187 | 6.05.0035.3.01.5 | E60.08 ASS                     | Common Tamper   | Hex Bolt Special (Guide Column Bolt)                                   | TM/013/06           | TM/HM/6/299       |
| 188 | 6.05.0036.3.01.6 | W37.1440                       | UNI             | Thrust Washer                                                          | TM/0559 Rev-1       | TM/HM/6/383       |
| 189 | 6.05.0037.3.01.7 | M30X2X340DIN 960-8.8           | 09-3X           | Hex screw for tamping unit of Tamping Express.                         | RDSO/TM/28/17       | TM/HM/6/407       |
| 190 | 6.05.0038.3.01.8 | 2E32.05                        | Common Tamper   | Cap washer of CSM/DUO/WST                                              | RDSO/TM/16/17       | TM/HM/6/398       |
| 191 | 6.05.0039.3.01.9 | 2E36.48                        | All TU          | Bolt for Tamping Arm Center Bore & Nut                                 | TM/0425 Rev-2       | TM/HM/6/161       |
| 192 | 6.05.0040.3.01.1 | W37.2382                       | UNI 4S          | Bolt for tamping unit of Unimat 08-457 4S                              | RDSO/TM/06/15       | TM/HM/6/361       |
| 193 | 6.05.0041.3.01.2 | G30.42                         | UNI             | Set Screw                                                              | TM/0560             | TM/HM/6/251       |
| 194 | 6.05.0042.3.01.3 | 2E31.04                        | All TU          | Piston Screw                                                           | TM/0426             | TM/HM/6/162       |
| 195 | 6.05.0043.3.01.4 | UD19.1230                      | Tamping Express | Counter weight for squeezing cylinder small female for Tamping Express | RDSO/TM/02/18       | TM/HM/6/414       |
| 196 | 6.05.0044.3.01.5 | UD15.1211                      | UNIMAT          | Swivel bearing for tamping unit of Unimat-4S                           | RDSO/TM/05/21       | TM/HM/6/490       |
| 197 | 6.05.0045.3.01.6 | UD19.287                       | Tamping Express | Bearing bush for tamping cylinder of Tamping Express                   | RDSO/TM/17/21       | TM/HM/6/383       |

|     |                   |                                |                  |                                                                 |               |                   |
|-----|-------------------|--------------------------------|------------------|-----------------------------------------------------------------|---------------|-------------------|
| 198 | 6.05.0046.3.01.7  | UD25.1130                      | Tamping Express  | Sleeve for vibration shaft of Tamping Express                   | RDSO/TM/21/21 | TM/HM/6/505       |
| 199 | 6.05.0047.3.01.8  | UD25.1131                      | Tamping Express  | Sleeve for vibration shaft of Tamping Express                   | RDSO/TM/22/21 | TM/HM/6/506       |
| 200 | 6.05.0048.3.01.9  | UD25.1132                      | Tamping Express  | Sliding Sleeve for vibration shaft of Tamping Express           | RDSO/TM/23/21 | TM/HM/6/507       |
| 201 | 6.05.0049.3.01.1  | 2E33.25                        | DUO/CSM          | Bearing Bush                                                    | TM/0412 Rev-2 | TM/HM/6/383       |
| 202 | 6.05.0050.3.01.2  | G20.14                         | UNIMAT           | Modified steel bush for squeezing cylinder of Unimat            | RDSO/TM/01/22 | TM/HM/6/512       |
| 203 | 6.05.0051.3.01.3  | Item is repeated at Sr No .166 |                  |                                                                 |               |                   |
| 204 | 6.05.0052.3.01.4  | Item is repeated at Sr No.170  |                  |                                                                 |               |                   |
| 205 | 6.05.0053.03.01.5 | WN153.82f.1340.01              | Tamping Unit     | Guide Rod for Tamping Unit                                      | RDSO/TM/06/23 | TM/HM/6/537       |
| 206 | 6.05.0054.3.01.6  | E120.13B                       | Unimat -2S/3S    | Coupling Cover for tamping unit of Unimat -2S/3S                | RDSO/TM/11/23 | TM/HM/6/541       |
| 207 | 6.05.0055.3.01.7  | C-1005                         | CSM/DUO          | Cover for fly wheel of CSM/DUO                                  | RDSO/TM/12/23 | TM/HM/6/542       |
| 208 | 6.05.0056.3.01.8  | CU20.302                       | Unimat -4S       | Fly wheel for tamping unit of Unimat -4S                        | RDSO/TM/13/23 | TM/HM/6/543       |
| 209 | 6.05.0057.3.01.9  | CU 20-732                      | 09-3x            | Sliding sleeve for vibration shaft of Tamping Express           | RDSO/TM/02/24 | TM/HM/6/552       |
| 210 | 6.06.0001.3.01.8  | MB6560DX                       | CSM/WST          | P.B Bush of lining roller assembly for CSM                      | RDSO/TM/13/16 | TM/HM/6/383       |
| 211 | 6.06.0002.3.01.9  | E150.35a & E150.35b            | CSM              | Semi finished Bush of Lifting Unit of CSM                       | RDSO/TM/07/19 | TM/HM/6/383       |
| 212 | 6.06.0003.3.01.1  | 1023.46.00.018                 | VPR              | Bushing of Tamping Unit for VPR                                 | RDSO/TM/08/19 | TM/HM/6/383       |
| 213 | 6.07.0001.3.01.9  | 2E22.10A                       | UNI              | Fly Wheel Outer                                                 | TM/0405 Rev-1 | TM/HM/6/137 Rev-1 |
| 214 | 6.07.0002.3.01.1  | U21.01                         | CSM/WST          | Fly Wheel Inner                                                 | TM/0406       | TM/HM/6/138       |
| 215 | 6.07.0003.3.01.2  | UD22.325                       | CSM/WST          | Fly wheel(Inner) for Tamping Express                            | RDSO/TM/04/16 | TM/HM/6/364       |
| 216 | 6.07.0004.3.01.3  | E23.70a                        | UNI              | Fly Wheel Of Unimat                                             | TM/0547 Rev-1 | TM/HM/6/238 Rev-1 |
| 217 | 6.07.0005.3.01.4  | E23.60a                        | UNI              | Fly Wheel Of Unimat                                             | TM/0548 Rev-1 | TM/HM/6/239 Rev-1 |
| 218 | 6.07.0006.3.01.5  | U21.01                         | CSM              | Fly Wheel with Auxiliary Plate                                  | TM/003/06     | TM/HM/6/289       |
| 219 | 6.07.0007.3.01.6  | UD25.909                       | 09-3X            | Flange                                                          | TM/0567       | TM/HM/6/258       |
| 220 | 6.07.0008.3.01.7  | DL.12.51                       | All TU           | Cover                                                           | TM/0504       | TM/HM/6/191       |
| 221 | 6.07.0009.3.01.8  | CU20.434                       | 09-3X            | Cover                                                           | TM/0564       | TM/HM/6/255       |
| 222 | 6.07.0010.3.01.9  | 2E34.50                        | 09-3X            | Cover Plate                                                     | TM/0403       | TM/HM/6/135       |
| 223 | 6.07.0011.3.01.1  | DL.10.56                       | All T/U          | Cover for Pivot Bearing                                         | TM/0443       | TM/HM/6/179       |
| 224 | 6.07.0012.3.01.2  | DL.12.05                       | All T/U          | Cover plate for tamping unit guide rod bush                     | TM/0503       | TM/HM/6/190       |
| 225 | 6.07.0013.3.01.3  | 2E35.314                       | CSM/WST          | Cover Plate for Small Squeezing Cylinder                        | TM/0404       | TM/HM/6/136       |
| 226 | 6.07.0014.3.01.4  | W.33.143                       | UNI              | Cover Plate for Tool Tilting Cylinder                           | TM/0422       | TM/HM/6/156       |
| 227 | 6.07.0015.3.01.5  | 2E.31.19ART                    | All T/U          | Cover Plate for Tamping Tool                                    | TM/0437       | TM/HM/6/173       |
| 228 | 6.07.0016.3.01.6  | W37.1294                       | UNI              | Cover plate for squeezing cylinder of Unimat                    | TM/0549       | TM/HM/6/240       |
| 229 | 6.07.0017.3.01.7  | UD25.1133                      | 09-3X            | Cover plate for vibration shaft of T-Exp                        | RDSO/TM/02/16 | TM/HM/6/362       |
| 230 | 6.07.0018.3.01.8  | TDL.20.01                      | All T/U          | Top Plate for Guide Rod                                         | TM/0438       | TM/HM/6/174       |
| 231 | 6.07.0019.3.01.9  | 2E22.15                        | All T/U          | Bearing Cover                                                   | TM/0128       | TM/HM/6/107       |
| 232 | 6.07.0020.3.01.1  | 2E22.16                        | All T/U          | Bearing Cover                                                   | TM/0407       | TM/HM/6/139       |
| 233 | 6.07.0021.3.01.2  | 2E34.211                       | All T/U          | Pressure Disc Cover                                             | TM/0131 Rev-1 | TM/HM/6/110       |
| 234 | 6.07.0022.3.01.3  | E.61.04                        | All T/U          | Bottom bearing plate for guide rod                              | TM/0507       | TM/HM/6/194       |
| 235 | 6.07.0023.3.01.4  | 2E22.11                        | All T/U          | Body Bearing                                                    | TM/0408       | TM/HM/6/140       |
| 236 | 6.07.0024.3.01.5  | DI.23.103                      | CSM/WST          | Box bearing                                                     | TM/0513       | TM/HM/6/199       |
| 237 | 6.07.0025.3.01.6  | DL10.52                        | Common Tamper    | Support Ring (Tamping unit lifting cylinder suspension bracket) | TM/0410       | TM/HM/6/143       |
| 238 | 6.07.0026.3.01.7  | W.37.14407                     | CSM/UNI/ WST T/U | Spacer Ring                                                     | TM/0421 Rev-1 | TM/HM/6/383       |
| 239 | 6.07.0027.3.01.8  | 2E223.01A                      | CSM/UNI/ WST T/U | Spacer ring for vibration shaft                                 | TM/0517 Rev-2 | TM/HM/6/203 Rev-2 |

|     |                  |                                   |                     |                                                               |               |                      |
|-----|------------------|-----------------------------------|---------------------|---------------------------------------------------------------|---------------|----------------------|
| 240 | 6.07.0028.3.01.9 | DL.23.107                         | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0518 Rev-2 | TM/HM/6/204          |
| 241 | 6.07.0029.3.01.1 | 2E22.04A                          | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0519 Rev-2 | TM/HM/6/205<br>Rev-2 |
| 242 | 6.07.0030.3.01.2 | DL23.108                          | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0520 Rev-2 | TM/HM/6/206<br>Rev-2 |
| 243 | 6.07.0031.3.01.3 | 2E22.06                           | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0521 Rev-2 | TM/HM/6/207<br>Rev-2 |
| 244 | 6.07.0032.3.01.4 | 2E.22.07                          | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0522 Rev-2 | TM/HM/6/208          |
| 245 | 6.07.0033.3.01.5 | Item deleted                      |                     |                                                               |               |                      |
| 246 | 6.07.0034.3.01.6 | 2E.22.12                          | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0523 Rev-1 | TM/HM/6/209<br>Rev-1 |
| 247 | 6.07.0035.3.01.7 | 2E.22.26                          | CSM/UNI/<br>WST T/U | Spacer ring for vibration shaft                               | TM/0525 Rev-2 | TM/HM/6/211          |
| 248 | 6.07.0036.3.01.8 | UD25.306                          | CSM/UNI/<br>WST T/U | Spacer Ring                                                   | TM/0565       | TM/HM/6/256          |
| 249 | 6.07.0037.3.01.9 | U21.720                           | 09-3X               | Support ring                                                  | TM/0566       | TM/HM/6/257          |
| 250 | 6.07.0038.3.01.1 | WN121.65.1.85.16.1                | 09-3X               | Spacer Ring                                                   | TM/0568       | TM/HM/6/259          |
| 251 | 6.07.0039.3.01.2 | WN121.65.1.85.24.6.1              | 09-3X               | Spacer Ring                                                   | TM/0569       | TM/HM/6/260          |
| 252 | 6.07.0040.3.01.3 | UD19.222                          | 09-3X               | Spacer Bush Ring                                              | TM/0570 Rev-1 | TM/HM/6/261<br>Rev-1 |
| 253 | 6.07.0041.3.01.4 | UD 25.908                         | 09-3X               | Spacer Ring                                                   | TM/0573       | TM/HM/6/264          |
| 254 | 6.07.0042.3.01.5 | UD 25.307                         | 09-3X               | Spacer Ring                                                   | TM/0574       | TM/HM/6/265          |
| 255 | 6.07.0043.3.01.6 | 2E.36.457                         | 09-3X               | Piston                                                        | TM/0581 Rev-1 | TM/HM/6/383          |
| 256 | 6.07.0044.3.01.7 | 2E.34.55                          | 09-3X               | Spacer Ring                                                   | TM/0582       | TM/HM/6/275          |
| 257 | 6.07.0045.3.01.8 | W37.2040                          | UNI 4S              | Spacer ring for tamping unit of Unimat 08-457 4S              | RDSO/TM/02/15 | TM/HM/6/357          |
| 258 | 6.07.0046.3.01.9 | W37.2356                          | UNI 4S              | Spacer ring for tamping unit of Unimat 08-457 4S              | RDSO/TM/03/15 | TM/HM/6/358          |
| 259 | 6.07.0047.3.01.1 | W37.2055                          | UNI 4S              | Spacer ring for tamping unit of Unimat 08-457 4S              | RDSO/TM/04/15 | TM/HM/6/359          |
| 260 | 6.07.0048.3.01.2 | W33.159                           | UNI 4S              | Spacer ring for tamping unit of Unimat 08-457 4S              | RDSO/TM/05/15 | TM/HM/6/360          |
| 261 | 6.07.0050.3.01.4 | 2E.36.47a                         | 09-3X               | Piston screw for squeezing cylinder piston rod small          | TM/0534       | TM/HM/6/225          |
| 262 | 6.07.0051.3.01.5 | E.36.42C                          | Common<br>Tammer    | Piston Rod with Piston Screw                                  | TM/0423       | TM/HM/6/159          |
| 263 | 6.07.0052.3.01.6 | U.21.02                           | CSM/WST             | Part Clutch                                                   | TM/0451       | TM/HM/6/187          |
| 264 | 6.07.0053.3.01.7 | NA                                | UNI                 | Distributor Block of tamping unit of UNI                      | TM/0587       | TM/HM/6/277          |
| 265 | 6.07.0054.3.01.8 | 2E.134.42a                        | UNI                 | Piston rod                                                    | TM/0538       | TM/HM/6/229          |
| 266 | 6.07.0055.3.01.9 | E20.13c                           | UNI                 | Toothed Coupling for Unimat                                   | TM/0545       | TM/HM/6/236          |
| 267 | 6.07.0056.3.01.1 | NA                                | WST                 | Locking Device for Tamping Unit of-<br>DUO                    | TM/0401       | TM/HM/6/133          |
| 268 | 6.07.0057.3.01.2 | NA                                | CSM/WST             | Locking Device for Tamping Unit of<br>CSM                     | TM/0402       | TM/HM/6/134          |
| 269 | 6.07.0058.3.01.3 | UD19.936                          | 09-3X               | Mounting plate for guide rod of<br>Tamping Express.           | RDSO/TM/27/17 | TM/HM/6/406          |
| 270 | 6.07.0059.3.01.4 | UD25.742                          | 09-3X               | Bearing arm with plate guard of<br>Tamping Express            | RDSO/TM/05/16 | TM/HM/6/365          |
| 271 | 6.07.0060.3.01.5 | E19.916                           | 09-3X               | Plate guard motor-side for Tamping<br>Express                 | RDSO/TM/07/16 | TM/HM/6/372          |
| 272 | 6.07.0061.3.01.6 | CU20.1141                         | 09-3X               | Cover plate of vibration shaft for T-Exp                      | RDSO/TM/08/16 | TM/HM/6/373          |
| 273 | 6.07.0062.3.01.7 | E62.01-15/16G &<br>E62.01-30/31AG | T-Exp,<br>CSM &     | Holding Bracket for Lifting Unit of T-<br>Exp, CSM & Duomatic | RDSO/TM/06/19 | TM/HM/6/429          |
| 274 | 6.07.0063.3.01.8 | UD19.901ALI                       | Tamping<br>Express  | Cover plate for mounting bracket of<br>Tamping Express        | RDSO/TM/06/21 | TM/HM/6/491          |
| 275 | 6.07.0064.3.01.9 | 2E45.60LE                         | Tamping<br>Express  | Distributor left for tamping unit of T-Exp.                   | RDSO/TM/11/21 | TM/HM/6/496          |

|     |                  |                   |                  |                                                                         |                |                          |
|-----|------------------|-------------------|------------------|-------------------------------------------------------------------------|----------------|--------------------------|
| 276 | 6.07.0065.3.01.1 | 2E45.60RE         | Tamping Express  | Distributor right for tamping unit of Tamping Express.                  | RDSO/TM/12/21  | TM/HM/6/497              |
| 277 | 6.07.0066.3.01.2 | UD10.2980         | CSM & Duomatic   | Outer cover guard of CSM & Duomatic                                     | RDSO/TM/14/21  | TM/HM/6/499              |
| 278 | 6.07.0067.3.01.3 | UD25.908A         | Tamping Express  | Spacer ring for vibration shaft of Tamping Express                      | RDSO/TM/24/21  | TM/HM/6/508              |
| 279 | 6.07.0068.3.01.4 | E34.143AS         | T-Exp            | Damping Discs for wheel support of T-Exp                                | RDSO/TM/05/22  | TM/HM/6/515              |
| 280 | 6.07.0069.3.01.5 | DL90.53A          | Unimat-2S/3      | Distributorblock of Unimat-2S/3S                                        | RDSO/TM/09/22  | TM/HM/6/519              |
| 281 | 6.07.0070.3.01.6 | DL90.53           | Unimat-4S        | Hydraulic distributor block of Unimat-4S                                | RDSO/TM/10/22  | TM/HM/6/520              |
| 282 | 6.07.0071.3.01.7 | UD19.624          | tamping ex       | Mounting plate for guide column of tamping express                      | RDSO/TM/12/22  | TM/HM/6/522              |
| 283 | 6.07.0072.3.01.8 | UD25.619          | Tamping ex       | Clutch flange for vibration shaft of tamping express                    | RDSO/TM/13/22  | TM/HM/6/523              |
| 284 | 6.07.0073.3.01.9 | UD66.3273-I       | CSM,DUO, 09-3X & | Round unit for tamping cyl of CSM,DUO,09-3X & Unimat                    | RDSO/TM/14/22  | TM/HM/6/524              |
| 285 | 6.07.0074.3.01.1 | DL23.104          | DUO,CSM and UNI- | Bearing flange for vibration driveof DUO,CSM and UNI-2S/3S              | RDSO/TM/15/22  | TM/HM/6/525              |
| 286 | 6.07.0075.3.01.2 | Repeated item     |                  |                                                                         |                |                          |
| 287 | 6.07.0076.3.01.3 | 2E.22.05A         | CSM/UNI/ WST T/U | Spacer ring for vibration shaft                                         | TM/0524 Rev-2  | TM/HM/6/210 Rev-2        |
| 288 | 6.08.0001.3.01.1 | NA                | CSM              | Tamping Tool for CSM                                                    | TM/9303        | TM/HM/6/26               |
| 289 | 6.08.0002.3.01.2 | NA                | UNI              | Tamping Tool for P & C Tamper (Unimat)                                  | TM/9327/1      | TM/HM/6/26               |
| 290 | 6.08.0003.3.01.3 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM/15A/16 | TM/HM/6/320 Rev-2 (2016) |
| 291 | 6.08.0004.3.01.4 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 15B/16 | TM/HM/6/320 Rev-2 (2016) |
| 292 | 6.08.0005.3.01.5 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 15C/16 | TM/HM/6/320 Rev-2 (2016) |
| 293 | 6.08.0006.3.01.6 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 15D/16 | TM/HM/6/320 Rev-2 (2016) |
| 294 | 6.08.0007.3.01.7 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 15E/16 | TM/HM/6/320 Rev-2 (2016) |
| 295 | 6.08.0008.3.01.8 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM/14A/16 | TM/HM/6/320 Rev-2 (2016) |
| 296 | 6.08.0009.3.01.9 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 14B/16 | TM/HM/6/320 Rev-2 (2016) |
| 297 | 6.08.0010.3.01.1 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 14C/16 | TM/HM/6/320 Rev-2 (2016) |
| 298 | 6.08.0011.3.01.2 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 14D/16 | TM/HM/6/320 Rev-2 (2016) |
| 299 | 6.08.0012.3.01.3 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 01A/16 | TM/HM/6/320 Rev-2 (2016) |
| 300 | 6.08.0013.3.01.4 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 01B/16 | TM/HM/6/320 Rev-2 (2016) |
| 301 | 6.08.0014.3.01.5 | NA                | All T/U          | Tungsten Carbide Tip Tamping Tool (TCTT) for On-Track Tamping Machines. | RDSO/TM 01C/16 | TM/HM/6/320 Rev-2 (2016) |
| 302 | 6.08.0015.3.01.6 | NA                | CSM/WST          | Tamping Tool Square Armed for CSM                                       | TM/9702        | TM/HM/6/26               |
| 303 | 6.10.0001.3.01.3 | WN153.90.f6.945.1 | UNI              | Hook Sliding Guide Rod -3S                                              | RDSO/TM/075/05 | TM/HM/6/266              |

|     |                  |                              |             |                                                                           |                                                                                            |                                                                           |
|-----|------------------|------------------------------|-------------|---------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| 304 | 6.10.0002.3.01.4 | WN109.20.e85.55.2            | UNI         | Pin for Unit Sliding Cylinder -3S                                         | RDSO/TM/077/05                                                                             | TM/HM/6/268                                                               |
| 305 | 6.11.0001.3.01.4 | E150.100                     | CSM/WST     | Lifting unit guide rod                                                    | TM/0526                                                                                    | TM/HM/6/212                                                               |
| 306 | 6.11.0002.3.01.5 | E150.27                      | All         | Pin for track lifting unit                                                | TM/0527                                                                                    | TM/HM/6/213                                                               |
| 307 | 6.11.0003.3.01.6 | WN109.60f.8.147              | UNI         | Pin for Roller UNI-3S                                                     | RDSO/TM/078/05                                                                             | TM/HM/6/269                                                               |
| 308 | 6.11.0004.3.01.7 | UD150.1306                   | CSM/WST     | Roller of lining roller assembly for CSM                                  | RDSO/TM/09/16                                                                              | TM/HM/6/374                                                               |
| 309 | 6.11.0005.3.01.8 | UD150.1556                   | 09-3X       | Eccentric Bush of lining roller assembly for CSM-3X                       | RDSO/TM/11/16                                                                              | TM/HM/6/376                                                               |
| 310 | 6.11.0006.3.01.9 | UD150.1557                   | 09-3X       | Key of lining roller assembly for CSM-3X                                  | RDSO/TM/12/16                                                                              | TM/HM/6/377                                                               |
| 311 | 6.11.0007.3.01.1 | CU311.3020                   | UNI         | Semi finished bush for lifting hook of Unimat                             | RDSO/TM/14/17                                                                              | TM/HM/6/383                                                               |
| 312 | 6.11.0008.3.01.2 | CU311.3019                   | UNI         | Semi finished bush for lifting hook guide rod of Unimat                   | RDSO/TM/15/17                                                                              | TM/HM/6/383                                                               |
| 313 | 6.11.0009.3.01.3 | UD311.1205                   | UNI         | Knuckle joint with bolt of Unimat                                         | RDSO/TM/19/17                                                                              | TM/HM/6/404                                                               |
| 314 | 6.11.0010.3.01.4 | E150.01                      | All Tampers | Roller Disk Clamp and Pressure Bush for Lifting/Lining on Tamping Machine | TM/9322 Rev-2                                                                              | TM/HM/6/21 Rev-2                                                          |
| 315 | 6.11.0011.3.01.5 | HZ09GB.050.0580.001          | UNI         | Tube / Sleeve for Hook Sliding Cylinder of Unimat                         | RDSO/TM/003/07                                                                             | TM/HM/6/301                                                               |
| 316 | 6.11.0012.3.01.6 | HZ10.050.025.0580.1          | UNI         | Piston Rod for Hook Sliding Cylinder of Unimat                            | RDSO/TM/04/07                                                                              | TM/HM/6/302                                                               |
| 317 | 6.11.0013.3.01.7 | HZ10.050.025.0580.1          | UNI         | Piston for Hook Sliding Cylinder of Unimat                                | RDSO/TM 05/07 Rev-1                                                                        | TM/HM/6/383                                                               |
| 318 | 6.11.0014.3.01.8 | WN141.35H7.73.40.1           | UNI         | Pin with washer for Hook Sliding Cylinder of Unimat                       | RDSO/TM/006/07                                                                             | TM/HM/6/304                                                               |
| 319 | 6.11.0015.3.01.9 | UD313.1963                   | UNI         | Support / Yoke for Hook Sliding Cylinder of Unimat                        | RDSO/M/007/07                                                                              | TM/HM/6/305                                                               |
| 320 | 6.11.0016.3.01.1 | HZ06.050.025                 | UNI         | Gland for Hook Sliding Cylinder of Unimat                                 | RDSO/TM/008/07                                                                             | TM/HM/6/306                                                               |
| 321 | 6.11.0017.3.01.2 | E150.180                     | CSM/WST     | Hydraulic Rail Clamp Cylinder                                             | RDSO/TM/009/07,R<br>DSO/TM/010/07,<br>RDSO/TM /01/08,<br>RDSO/TM /02/08,<br>RDSO/TM /03/08 | TM/HM/6/307,<br>TM/HM/6/308,<br>TM/HM/6/315,<br>TM/HM/383,<br>TM/HM/6/317 |
| 322 | 6.11.0018.3.01.3 | E150.182                     | CSM         | Piston Rod for Hydraulic Rail Clamp Cylinder of CSM                       | RDSO/TM/009/07                                                                             | TM/HM/6/307                                                               |
| 323 | 6.11.0019.3.01.4 | E150.183                     | CSM         | Piston for Hydraulic Rail Clamp Cyl of CSM                                | RDSO/TM/010/07                                                                             | TM/HM/6/308                                                               |
| 324 | 6.11.0020.3.01.5 | E.150-185                    | CSM         | Cover Plate of Hy. Rail clamp cyl.of CSM                                  | RDSO/TM /01/08                                                                             | TM/HM/6/315                                                               |
| 325 | 6.11.0021.3.01.6 | E.150-184                    | CSM         | Gland of Hy. Rail clamp Cyl.of CSM                                        | RDSO/TM /02/08                                                                             | TM/HM/383                                                                 |
| 326 | 6.11.0022.3.01.7 | E.150-181                    | CSM         | Sleeve of Hy. Rail clamp Cyl of CSM                                       | RDSO/TM /03/08                                                                             | TM/HM/6/317                                                               |
| 327 | 6.11.0023.3.01.8 | HZ09.MB.063.0180             | DTS         | Cylinder Tube of roller clamp lifting Cylinder of DGS                     | RDSO/TM/02/14                                                                              | TM/HM/6/344                                                               |
| 328 | 6.11.0024.3.01.9 | HZ10.063.036.0180.1          | DTS         | Piston Rod Complete of roller clamp lifting Cylinder of DGS               | RDSO/TM/03/14                                                                              | TM/HM/6/345                                                               |
| 329 | 6.11.0025.3.01.1 | HZ06.063.036                 | DTS         | Guide Bush of roller clamp lifting Cylinder of DGS                        | RDSO/TM/04/14                                                                              | TM/HM/6/346                                                               |
| 330 | 6.11.0026.3.01.2 | HZ09.GB.063.036.007<br>5.001 | DTS         | Cylinder Tube of vibrator slide Cylinder Of DGS.                          | RDSO/TM/08/14                                                                              | TM/HM/6/350                                                               |
| 331 | 6.11.0027.3.01.3 | WN107.20h7.71.5.1            | UNI         | Pin for rail clamp cylinder of Unimat                                     | RDSO/TM/07/17                                                                              | TM/HM/6/389                                                               |
| 332 | 6.11.0028.3.01.4 | WN107.20h7.84.6.3.2          | UNI         | Pin for rail clamp cylinder of Unimat                                     | RDSO/TM/08/17                                                                              | TM/HM/6/390                                                               |
| 333 | 6.11.0029.3.01.5 | DL.150.11.a                  | UNI         | Hex Nut for Clamp Roller                                                  | TM/0537                                                                                    | TM/HM/6/228                                                               |
| 334 | 6.11.0030.3.01.6 | DL150.06                     | T-Exp       | Pressure nut for roller clamps of T-Exp                                   | RDSO/TM/21/22                                                                              | TM/HM/6/530                                                               |

|     |                  |                        |                                                                                      |                                                       |                  |                        |
|-----|------------------|------------------------|--------------------------------------------------------------------------------------|-------------------------------------------------------|------------------|------------------------|
| 335 | 6.11.0031.3.01.7 | E 150.15               | CSM                                                                                  | Pin for roller clamp of CSM                           | RDSO/TM/16/24    | TM/HM/6/566            |
| 336 | 6.11.0032.3.01.8 | E 150.24               | CSM                                                                                  | Pin for lifting unit of CSM                           | RDSO/TM/18/24    | TM/HM/6/568            |
| 337 | 7.07.0001.3.01.1 | UD61.833               | CSM                                                                                  | Bush for pivot of CSM                                 | RDSO/TM/28/21    | TM/HM/6/383            |
| 338 | 8.06.0001.3.01.1 | E150-06                | Duo, CSM & T. Exp                                                                    | Chuck Nut for disc clamp of Duo, CSM & T. Exp         | RDSO/TM/15/24    | TM/HM/6/565            |
| 339 | 8.07.0001.3.01.2 | 2W20.3                 | UNI                                                                                  | Part clutch                                           | TM/0514          | TM/HM/6/200            |
| 340 | 8.07.0002.3.01.3 | UD890.4452             | Tamping Exp (Roller with pin, spacer bush, nilos ring & castle nut for Tamping Exp.) | Roller                                                | RDSO/TM/01/20    | TM/HM/6/441            |
|     |                  | WN109-45g6.298.M30X2-2 |                                                                                      | Pin                                                   |                  |                        |
|     |                  | WN121-45H11.54.128.1   |                                                                                      | Spacer Bush                                           |                  |                        |
|     |                  | 6209AV                 |                                                                                      | Nilos Ring                                            |                  |                        |
|     |                  | M28XDIN980-8           |                                                                                      | Castle Nut                                            |                  |                        |
| 341 | 8.07.0003.3.01.4 | UD80.4200C             | T-Exp                                                                                | Satellite roller for T-Exp                            | RDSO/TM/19/22    | TM/HM/6/528            |
| 342 | 8.07.0004.3.01.5 | UD 61.852              | UNIMAT, CSM &                                                                        | Pin for Cabin Support Cylinder of UNIMAT, CSM & T.EXP | RDSO/TM/12/24    | TM/HM/6/562            |
| 343 | 8.08.0001.3.01.3 | 62.08.1215             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/1 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 344 | 8.08.0002.3.01.4 | 64.08.1636             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/1 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 345 | 8.08.0003.3.01.5 | 64.08.1369             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/1 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 346 | 8.08.0004.3.01.6 | 64.08.1449             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/1 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 347 | 8.08.0005.3.01.7 | 64.08.1623             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/2 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 348 | 8.08.0006.3.01.8 | 62.08.1217             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/2 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 349 | 8.08.0007.3.01.9 | 64.08.1461             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/2 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 350 | 8.08.0008.3.01.1 | 62.08.1300             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/2 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 351 | 8.08.0009.3.01.2 | 64.08.1209             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/3 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 352 | 8.08.0010.3.01.3 | 64.08.1451             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/3 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 353 | 8.08.0011.3.01.4 | 62.08.1299             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/3 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 354 | 8.08.0012.3.01.5 | 62.08.1301             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/3 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 355 | 8.08.0013.3.01.6 | 64.08.1637             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/4 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 356 | 8.08.0014.3.01.7 | 62.08.1214             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/4 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 357 | 8.08.0015.3.01.8 | 62.08.1624             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/4 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 358 | 8.08.0016.3.01.9 | 62.08.1213             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9315/4 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 359 | 8.08.0017.3.01.1 | 64.08.1469             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/5 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 360 | 8.08.0018.3.01.2 | 64.08.1617             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/5 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 361 | 8.08.0019.3.01.3 | 62.08.1211             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/5 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 362 | 8.08.0020.3.01.4 | 64.08.1619             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/5 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 363 | 8.08.0021.3.01.5 | 64.08.1450             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/6 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 364 | 8.08.0022.3.01.6 | 64.08.1620             | BCM                                                                                  | Wear Plates / Strips of BCM (RM-80)                   | TM/9415/6 Rev -1 | TM/HM/6/15Rev-2 (2015) |

|     |                  |            |     |                                      |                   |                        |
|-----|------------------|------------|-----|--------------------------------------|-------------------|------------------------|
| 365 | 8.08.0023.3.01.7 | 64.08.1329 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/6 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 366 | 8.08.0024.3.01.8 | 64.08.1642 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/6 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 367 | 8.08.0025.3.01.9 | 62.08.1230 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/7 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 368 | 8.08.0026.3.01.1 | 64.08.1635 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/7 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 369 | 8.08.0027.3.01.2 | 64.08.1226 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/7 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 370 | 8.08.0028.3.01.3 | 64.08.1618 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/7 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 371 | 8.08.0029.3.01.4 | 64.08.1455 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/8 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 372 | 8.08.0030.3.01.5 | 64.08.1212 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/8 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 373 | 8.08.0031.3.01.6 | 62.08.1222 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/8 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 374 | 8.08.0032.3.01.7 | 64.08.1333 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/8 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 375 | 8.08.0033.3.01.8 | 64.08.1335 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/8 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 376 | 8.08.0034.3.01.9 | 62.08.1032 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/9 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 377 | 8.08.0035.3.01.1 | 64.08.1609 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/9 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 378 | 8.08.0036.3.01.2 | 64.08.1181 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/9 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 379 | 8.08.0037.3.01.3 | 62.08.1277 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/9 Rev -1  | TM/HM/6/15Rev-2 (2015) |
| 380 | 8.08.0038.3.01.4 | 64.08.1622 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/10 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 381 | 8.08.0039.3.01.5 | 64.08.1458 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/10 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 382 | 8.08.0040.3.01.6 | 64.08.1745 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/10 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 383 | 8.08.0041.3.01.7 | 64.08.1456 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/10 Rev -1 | TM/HM/6/15Rev-2 (2015) |
| 384 | 8.08.0042.3.01.8 | 64.08.1330 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/11 Rev-1  | TM/HM/6/15Rev-2 (2015) |
| 385 | 8.08.0043.3.01.9 | 64.08.1328 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/11 Rev-1  | TM/HM/6/15Rev-2 (2015) |
| 386 | 8.08.0044.3.01.1 | 62.08.1223 | BCM | Wear Plates / Strips of BCM (RM-80)  | TM/9415/11 Rev-1  | TM/HM/6/15Rev-2 (2015) |
| 387 | 8.08.0045.3.01.2 | 64.08.5047 | BCM | Corner Roller Housing of BCM         | RDSO/TM/06/14     | TM/HM/6/348            |
| 388 | 8.08.0046.3.01.3 | 64.08.5049 | BCM | Cover Plate for Corner Roller of BCM | RDSO/TM/07/14     | TM/HM/6/349            |

|     |                  |                                              |                       |                                                                                          |               |                  |
|-----|------------------|----------------------------------------------|-----------------------|------------------------------------------------------------------------------------------|---------------|------------------|
| 389 | 8.08.0047.3.01.4 | 64.08.5050                                   | BCM                   | Scrapper Shovel, Intermediate Link, Round Shaft chisel, Chain Bolt etc for BCM           | TM/9302 Rev-1 | TM/HM/6/111      |
| 390 | 8.08.0048.3.01.5 | NA                                           | BCM                   | Scrapper Shovel, Intermediate Link, Round Shaft chisel, Chain Bolt etc for P & C Cleaner | TM/9403       | TM/HM/6/39       |
| 391 | 8.08.0049.3.01.6 | NA                                           | SBCM                  | Scrapper Shovel, Intermediate Link, Bolt Roller, sleeve & Bush                           | TM/9422/1     | TM/HM/6/62       |
| 392 | 8.08.0050.3.01.7 | 64.08.5053                                   | BCM                   | Base Plate, Bracket, Cap & Cotter Pin                                                    | TM/9422/2     | TM/HM/6/62       |
| 393 | 8.08.0051.3.01.8 | 62.08.1174                                   | BCM                   | Cutter Bar for Ballast Cleaning Machine                                                  | TM/9616       | TM/HM/6/142      |
| 394 | 8.08.0052.3.01.9 | 64.08.2034HM                                 | BCM                   | Tungsten Carbide Round Shaft Chisel for BCM                                              | RDSO/TM/03/19 | TM/HM/6/435      |
| 395 | 8.08.0053.3.01.1 | 64.08.5048                                   | BCM                   | Bush                                                                                     | RDSO/TM/02/20 | TM/HM/6/442      |
|     |                  | NA                                           | (Bush,                | Lock Bush                                                                                |               |                  |
|     |                  | 36DIN125                                     | lock bush,            | Machined Washer                                                                          |               |                  |
|     |                  | M36XDIN937                                   | machined              | Castle Nut                                                                               |               |                  |
|     |                  | 64.08.5062                                   | washer,               | Pin                                                                                      |               |                  |
|     |                  | NA                                           | castle nut, pin & key | Key                                                                                      |               |                  |
| 396 | 8.08.0054.3.01.2 | 64.08.1623-H5, RM08.25.2150.02 & 64.08.10188 | BCM                   | Wear plates of BCM                                                                       | RDSO/TM/16/22 | TM/HM/6/15 Rev-2 |
| 397 | 8.08.0055.3.01.3 | RM.08.25.2150.01                             | BCM                   | Cutter bar                                                                               | RDSO/TM/03/24 | TM/HM/6/553      |
| 398 | 8.08.0056.3.01.4 | 64.09.7185                                   | BCM &                 | Shaft for ballast distribution device                                                    | RDSO/TM/07/24 | TM/HM/6/557      |
| 399 | 8.08.0057.3.01.5 | 64.08.5062 & 5052                            | BCM                   | Pin & Key for corner roller of BCM                                                       | RDSO/TM/16/23 | TM/HM/6/545      |
| 400 | 8.08.0058.3.01.6 | 64.08.5048                                   | BCM                   | Bush for corner roller of BCM                                                            | RDSO/TM/19/23 | TM/HM/6/546      |
| 401 | 8.08.0059.3.01.7 | 64.08.5051                                   | BCM                   | Bush for corner roller pin no. 1 & 5 of BCM                                              | RDSO/TM/20/23 | TM/HM/6/547      |
| 402 | 8.08.0060.3.01.8 | 64.08.1458                                   | BCM                   | Side Plate ascending for BCM RM-80                                                       | RDSO/TM/22/23 | TM/HM/6/15 Rev-2 |
| 403 | 8.08.0061.3.01.9 | 64.04.3256                                   | BCM                   | Carrier for BCM                                                                          | RDSO/TM/17/23 | TM/HM/6/550      |
| 404 | 8.08.0062.3.01.1 | 64.04.3261                                   | BCM                   | Carrier for BCM                                                                          | RDSO/TM/18/23 | TM/HM/6/550      |
| 405 | 8.09.0001.3.01.4 | SU1702.21.1.27                               | FRM-80                | Wear plate for cutting trough                                                            | RDSO/TM/20/17 | TM/HM/6/399      |
| 406 | 8.09.0002.3.01.5 | SU1702.21.1.28                               | FRM-80                | Wear plate for cutting trough                                                            | RDSO/TM/21/17 | TM/HM/6/399      |
| 407 | 8.09.0003.3.01.6 | SU1702.21.3.19                               | FRM-80                | Wear plate for cutting trough                                                            | RDSO/TM/22/17 | TM/HM/6/399      |
| 408 | 8.09.0004.3.01.7 | RE20.338 left                                | FRM-80                | Terminal strip of cutting belt of FRM-80                                                 | RDSO/TM/23/17 | TM/HM/6/400      |
| 409 | 8.09.0005.3.01.8 | RE20.338 right                               | FRM-80                | Terminal strip of cutting belt of FRM-81                                                 | RDSO/TM/24/17 | TM/HM/6/400      |
| 410 | 8.09.0006.3.01.9 | RE21.205                                     | FRM                   | Slider for excavating chain for FRM                                                      | RDSO/TM/17/22 | TM/HM/6/526      |
| 411 | 8.09.0007.3.01.1 | RE20.1050.1                                  | FRM                   | Bearing support for FRM                                                                  | RDSO/TM/22/22 | TM/HM/6/531      |
| 412 | 8.09.0008.3.01.2 | 64.09.5299                                   | FRM                   | Wear Plate for Screen FRM-80                                                             | RDSO/TM/21/23 | TM/HM/6/15 Rev-2 |
| 413 | 8.10.0001.3.01.5 | 218508                                       | BRM                   | Blade Girder of (BRM)                                                                    | TM/0116       | TM/HM/6/270      |
| 414 | 8.10.0002.3.01.6 | 223418                                       | BRM                   | Blade Girder of (BRM)                                                                    | TM/0117       | TM/HM/6/271      |
| 415 | 8.10.0003.3.01.7 | 400091                                       | BRM                   | Blade Girder of (BRM)                                                                    | TM/0118       | TM/HM/6/272      |
| 416 | 8.10.0004.3.01.8 | 708222                                       | BRM                   | Blade Girder of (BRM)                                                                    | TM/0119       | TM/HM/6/273      |
| 417 | 8.10.0005.3.01.9 | 708223                                       | BRM                   | Blade Girder of (BRM)                                                                    | TM/0120       | TM/HM/6/274      |
| 418 | 8.14.0001.3.01.9 | HZ60.01-3                                    | DTS                   | Fork head of DGS                                                                         | RDSO/TM/05/14 | TM/HM/6/347      |

|     |                  |                         |                          |                                                                  |                 |             |
|-----|------------------|-------------------------|--------------------------|------------------------------------------------------------------|-----------------|-------------|
| 419 | 8.14.0002.3.01.1 | GLF311.1009             | DTS                      | Fork head of DGS.                                                | RDSO/TM/10/14   | TM/HM6/352  |
| 420 | 8.17.0001.3.01.3 | UD 19/17                | All tampers              | Suspension Bracket                                               | TM/0121         | TM/HM/6/271 |
| 421 | 8.17.0002.3.01.4 | 253.20A                 | CSM/WST                  | Bush for Shadow Board Rod                                        | TM/0420 Rev-1   | TM/HM/6/383 |
| 422 | 8.17.0003.3.01.5 | HY30.70                 | All tampers              | Centering Ring for Hyd Pump-DUO                                  | TM/0446         | TM/HM/6/182 |
| 423 | 8.17.0004.3.01.6 | UD214.1515              | WST                      | Push fork for brake cylinder of Duomatic                         | RDSO/TM/06/17   | TM/HM/6/388 |
| 424 | 8.17.0005.3.01.7 | WN105.50.h7.232.6.1     | UNI                      | Pin for Lever Clamp UNI-3S                                       | TM/0576         | TM/HM/6/267 |
| 425 | 8.17.0006.3.01.8 | UD61.2631               | UNI                      | Pivot for driving bogie of Unimat                                | RDSO/TM/17/17   | TM/HM/6/397 |
| 426 | 8.17.0007.3.01.9 | E150.57                 | WST                      | Stud Bolt                                                        | TM/014/06 Rev-1 | TM/HM/6/383 |
| 427 | 8.17.0008.3.01.1 | W31.133A                | UNI                      | Pin, Nut & Washer                                                | TM/0555 Rev-2   | TM/HM/6/246 |
| 428 | 8.17.0009.3.01.2 | DI.20.28                | All tampers              | Locking Ring                                                     | TM/011/06       | TM/HM/6/297 |
| 429 | 8.17.0010.3.01.3 | 2E.1202a                | All tampers              | Dowel Pin                                                        | TM/012/06       | TM/HM/6/298 |
| 430 | 8.17.0011.3.01.4 | UD62.216                | All tampers              | Pin for Shock Absorber                                           | TM/001/06       | TM/HM/6/287 |
| 431 | 8.17.0012.3.01.5 | UD80.305                | CSM                      | Roller                                                           | TM/004/06       | TM/HM/6/290 |
| 432 | 8.17.0013.3.01.6 | UD80.308                | CSM                      | Pin                                                              | TM/005/06       | TM/HM/6/291 |
| 433 | 8.17.0014.3.01.7 | WN102-50h9.190.10-1     | CSM/UNIMAT/09-           | Pin for Support Clamp of CSM/UNIMAT/09-3X/DUO                    | RDSO/TM/07/18   | TM/HM/6/418 |
| 434 | 8.17.0015.3.01.8 | CU20.216                | Unimat-4S                | Cover disc for vibration drive of Unimat-4S                      | RDSO/TM/15/19   | TM/HM/6/439 |
| 435 | 8.17.0016.3.01.9 | E253.20a                | CSM & T-Exp              | P.B Bush for shadow board rod of CSM & T-Exp                     | RDSO/TM/04/22   | TM/HM/6/383 |
| 436 | 8.17.0017.3.01.1 | 90.23.00.100            | VPR machine              | Conical shock absorber for VPR machine                           | RDSO/TM/08/22   | TM/HM/6/518 |
| 437 | 8.17.0018.3.01.2 | M18                     | DUO                      | M.S.Clamps for 18 dia hose pipe of Duomatic                      | RDSO/TM/13/24   | TM/HM/6/563 |
| 438 | 8.17.0019.3.01.3 | WN102.32.5h11.159.6.5.1 | CSM                      | Pin for shock absorber of CSM                                    | RDSO/TM/19/24   | TM/HM/6/569 |
| 439 | 8.17.0020.3.01.4 | WN102.32.5h11.189.6.5.1 | CSM                      | Pin for shock absorber of CSM                                    | RDSO/TM/20/24   | TM/HM/6/570 |
| 440 | 8.17.0021.3.01.5 | UD210.17                | UNI                      | Pin for Measuring Bogie of Unimat-3S                             | RDSO/TM/23/23   | TM/HM/6/548 |
| 441 | 8.17.0022.3.01.6 | DL310.09                | UNI, CSM & DUO           | Pin for Track Lining cylinder of Unimat, CSM & Duomatic Machines | RDSO/TM/24/23   | TM/HM/6/549 |
| 442 | 9.04.0001.3.01.9 | NA                      | TRT                      | N T Rubber Pad of Track Relaying train Model P-811S              | TM/9606         | TM/HM/6/146 |
| 443 | 9.04.0002.3.01.1 | 40x30 M10               | T-Exp, Duomatic & Unimat | Round rubber pad for T-Exp, Duomatic & Unimat                    | RDSO/TM/06/22   | TM/HM/6/516 |
| 444 | 9.04.0003.3.01.2 | 60x40 M12               | T-Exp, CSM &             | Round rubber pad for T-Exp, CSM & Unimat                         | RDSO/TM/07/22   | TM/HM/6/517 |

KAILASH  Digitally signed by  
 NARAYAN Date: 2025.01.22  
 10:46:42 +05'30'  
 Kailash Narayan  
 Director Track Machine-I